


29274



NOTE:

Hang one end of chain link (O1) to one arm (N) of the fixture, chain link (O2) to top scroll and the other end of chain link (O3) to another arm as shown in diagram.

WARNING:

No additional wiring is required when assembling each arm (N) to center housing (I). Be sure to insert each arm (N) in an upright position for proper installation.

ASSEMBLY STEPS:

1. B ————— A
2. C ————— A
3. D.E.F.G.H.I.J — C
4. K ————— J
5. L.M ————— K
6. N ————— I
7. O ————— I.N.A
8. P.Q ————— I.N

Free Manuals Download Website

<http://myh66.com>

<http://usermanuals.us>

<http://www.somanuals.com>

<http://www.4manuals.cc>

<http://www.manual-lib.com>

<http://www.404manual.com>

<http://www.luxmanual.com>

<http://aubethermostatmanual.com>

Golf course search by state

<http://golfingnear.com>

Email search by domain

<http://emailbydomain.com>

Auto manuals search

<http://auto.somanuals.com>

TV manuals search

<http://tv.somanuals.com>