

MAXIMIZE YOUR HOME ENTERTAINMENT EXPERIENCE



VIZIO HIGH DEFINITION TVs
with VIZIO INTERNET APPS

WIRELESS:

1. Press the MENU button on the VIA remote and select NETWORK.
2. Select VIZIO HD from the Wireless Access Point list.
3. When prompted, enter the wireless security password.

WIRED:

1. Power off the TV.
2. Connect an Ethernet cable from a numbered port (1-4) on the router to the Ethernet port on the back of the TV.
3. Power on the TV.



VIZIO BLU-RAY™ PLAYERS
with VIZIO INTERNET APPS

WIRELESS:

1. Press the green button on the remote control or select MENU then NETWORK on screen.
2. Select WIRELESS
3. Select NETWORK LIST and choose your wireless network.
4. If your network is password protected, input password and select CONNECT. Your Blu-Ray™ player is now connected to the internet.

WIRED:

1. Connect an Ethernet cable from a numbered port (1-4) on the router to the Ethernet port on the back of the Blu-Ray™ Player.
2. Press the green button on the remote control or select MENU then NETWORK on screen.
3. Select WIRED
4. Select APPLY. Your Blu-Ray™ player is now connected to the internet.

VIZIO

DUAL-BAND HD WIRELESS INTERNET ROUTER QUICK START GUIDE



The built-in VIZIO prioritization technology intelligently prioritizes time-sensitive traffic such as streaming video over data, optimizing your network for HD streaming.

VIZIO XWR100 DUAL-BAND HD WIRELESS INTERNET ROUTER

Quick Start Guide

(Save this sheet for future reference or support help.)



What You Need:

- Your VIZIO Router, power adapter and Ethernet cable (included)
- High-speed Internet connection and access to your Internet modem (contact your local provider if you need help with this)
- Additional Ethernet cable (usually provided with your Internet modem)
- A computer to run the Quick Setup App

To set-up your new router, follow these simple steps:

1. Unplug the power cable from your high-speed internet modem.
2. Connect one end of the Ethernet cable (included) to the **number 1 port** on the router (Fig. 1).
3. Connect the other end to the Ethernet port on your computer (Fig. 2).
4. Connect an Ethernet cable from your high-speed Internet modem into the **Internet port** on the router (Fig. 3).
5. Plug the power back into your high-speed internet modem. Plug the power adapter (included) into the router and wait 30 seconds before plugging it into a power outlet.
6. Wait 30 seconds for the router to fully connect and open an Internet browser window (such as Internet Explorer, Firefox, Safari). Type **http://vizio.home** or **http://192.168.1.1** in the browser window and press Enter (Fig 4). The Quick Start App will automatically start.

For more information, click on the Help button in the Quick Start App to view the User Manual (Fig. 5).



VIZIO XWR100 DUAL-BAND HD WIRELESS INTERNET ROUTER

Default Wireless Network Settings

(Save this sheet for future reference or support help.)

	BEST For use with Dual-Band devices, 802.11a/n	BETTER For use with Single-Band devices, 802.11g/n	GOOD For use with legacy devices, 802.11b
Network Name (SSID)	VIZIO HD	VIZIO	Classic
Ideal Usage	Optimized for HD video streaming, this network typically has good coverage for most homes and operates at 5GHz.	Supports all types of data, this network can give you greater coverage while operating at 2.4GHz.	Supports older wireless device with a slower speed at 2.4GHz.
Security Type	WPA2 Personal	WPA Personal	WEP 64bits
Security Key	<input type="text"/>	<input type="text"/>	<input type="text"/>
Network Status	ACTIVE	ACTIVE	DISABLED

* Use these default wireless SSIDs and Security Keys to add any wireless Internet device to your network.

* If you personalized the SSIDs or Security Keys during Quick Start App, use those settings instead of the defaults.

* WPS: For devices without a WPS button, please input the following pin:

Refer to the manufacturer's instructions for help on accessing the wireless settings for your devices (like Internet HDTVs, Blu-ray players, laptops, game consoles or smart phones).

For additional support ! Web: www.VIZIO.com | Email: techsupport@VIZIO.com | Phone: 877 MY VIZIO (877.698.4946)

Free Manuals Download Website

<http://myh66.com>

<http://usermanuals.us>

<http://www.somanuals.com>

<http://www.4manuals.cc>

<http://www.manual-lib.com>

<http://www.404manual.com>

<http://www.luxmanual.com>

<http://aubethermostatmanual.com>

Golf course search by state

<http://golfingnear.com>

Email search by domain

<http://emailbydomain.com>

Auto manuals search

<http://auto.somanuals.com>

TV manuals search

<http://tv.somanuals.com>