


Before You Begin

- Verify all of the contents of your accessory package
- Review safety guidelines in Owner's Manual
- Place Liquid Crystal TV so the rear connectors are accessible
- Install AA batteries into the VIZIO Universal Remote Control
- Write down your VX37L Serial Number (located on the back)

Contents:



The Best Connection

For the best quality picture, we recommend using HDMI, DTV, RGB or Component inputs when possible. These are the only inputs capable of high definition (HD). Using these inputs does not guarantee high definition unless a high definition source is connected. However, not all equipment is capable of these connections. TV, AV and S-Video are not capable of HD signals.

+ Both DTV and TV share the same port. The television will automatically register which input type is connected.



Four Easy Steps

Simply follow our color-coded Step Charts and you're done.

1) Choose items to connect to your VX37L

- Determine which type of Signal Source and any Additional Equipment you wish to connect to your VX37L.
- The colored dots under each Signal Source and Additional Equipment indicate which type of connections you may use to connect to your VX37L.

2) Choose equipment connection methods

- Using the colored dots from Step One, follow the row across to Step Two to match up the colored dots to the same colored connection method.
- Chose ONLY one method for each piece of equipment.

3) Select cables and make connections

- Once you have determined the connection methods from Step Two, follow the row to Step Three to determine what kind of cables you need and what the connections look like on your equipment.
- Following the color-coded system, use the appropriate cables and connect your Signal Source and Additional Equipment to the color-coded inputs on your VX37L. (Refer to **Connection Map** at bottom of page.)
- Once connected, turn on your VX37L and all your equipment.

4) Use your VX37L

- Fill in the Connection Reference Chart below, noting how you will connect your equipment/signal source to your VX37L.
- If you are using the DTV/TV input, turn over this guide and follow the programming instructions and then return to this last step.
- If you are not using the DTV/TV input continue to next step.
- Press the INPUT button on your remote. The INPUT menu will appear. (See image below.)
- Continue pressing the INPUT button until you reach the corresponding connection.
- (To program TV Channels, see back.)

Signal Sources						Additional Equipment								Connection Methods						My Equipment Has			My VX37L Has			Cable Needed			Connection Reference						
Cable	Antenna	Cable Box	Digital Cable Box	Satellite Box		Computer	Digital Camera	DVD	DVR	Game System	Sound System	VCR	Video Camera																						
[dot]	[dot]	[dot]	[dot]	[dot]				[dot]	[dot]												[dot]	[dot]	[dot]	[dot]			[dot]	[dot]							
[dot]	[dot]	[dot]	[dot]	[dot]				[dot]	[dot]												[dot]	[dot]	[dot]	[dot]			[dot]	[dot]							
[dot]	[dot]	[dot]	[dot]	[dot]				[dot]	[dot]												[dot]	[dot]	[dot]	[dot]			[dot]	[dot]							
[dot]	[dot]	[dot]	[dot]	[dot]				[dot]	[dot]												[dot]	[dot]	[dot]	[dot]			[dot]	[dot]							
[dot]	[dot]	[dot]	[dot]	[dot]				[dot]	[dot]												[dot]	[dot]	[dot]	[dot]			[dot]	[dot]							
[dot]	[dot]	[dot]	[dot]	[dot]				[dot]	[dot]												[dot]	[dot]	[dot]	[dot]			[dot]	[dot]							
[dot]	[dot]	[dot]	[dot]	[dot]				[dot]	[dot]												[dot]	[dot]	[dot]	[dot]			[dot]	[dot]							
[dot]	[dot]	[dot]	[dot]	[dot]				[dot]	[dot]												[dot]	[dot]	[dot]	[dot]			[dot]	[dot]							
[dot]	[dot]	[dot]	[dot]	[dot]				[dot]	[dot]												[dot]	[dot]	[dot]	[dot]			[dot]	[dot]							
[dot]	[dot]	[dot]	[dot]	[dot]				[dot]	[dot]												[dot]	[dot]	[dot]	[dot]			[dot]	[dot]							
[dot]	[dot]	[dot]	[dot]	[dot]				[dot]	[dot]												[dot]	[dot]	[dot]	[dot]			[dot]	[dot]							
[dot]	[dot]	[dot]	[dot]	[dot]				[dot]	[dot]												[dot]	[dot]	[dot]	[dot]			[dot]	[dot]							



Connection Reference	Connected Equipment
HDMI 1	Connected Equipment
HDMI 2	Connected Equipment
DTV / TV	Connected Equipment
RGB PC	Connected Equipment
COMPONENT 1	Connected Equipment
COMPONENT 2	Connected Equipment
AV 1	Connected Equipment
AV 2	Connected Equipment
OPTICAL	Connected Equipment**
AUDIO OUT	Connected Equipment**

To Use This Chart: Write your equipment or signal source into the squares corresponding to your connection method.

*RF Cable, HDMI Cable, DVI-HDMI cable, VGA cable, Audio mini-jack, Component Cable, Optical Audio Cable and Coaxial Splitter are not included. These cables are available at www.viziotv.com. View back for more details. **Turn VX37L speakers off. (See AUDIO ADJUSTMENT MENU.)

3 WAYS TO GET HDTV

- 1) Off-Air antenna (using the DTV antenna input). To see if you are able to receive HD signals off-air and for help choosing the right antenna, visit www.antennaweb.org.
- 2) Cable - Subscribe to HD programming through your local cable company (HD cable box required).
- 3) Satellite - Subscribe to HD programming through Direct TV or Dish Network (HD satellite receiver required).



VIZIO provides wall mounts & Installation Services. (See Install with a Pro details on back) Visit www.viziotv.com or call 1-888-849-4623 to order today.



VIZIO
www.viziotv.com

Where Vision Meets Value

Program your TV

Programming your VX37L is a simple TWO STEP process.
All you need is your Remote Control.

STEP 1

Connect your Signal Source to the **DTV/TV** connection, go to **STEP 2**.



Please Note:

- Be sure the batteries in your remote are inserted correctly.
- Be sure you have pressed the "TV" button on the top left hand corner of your remote.

For advanced setups, refer to chapter 3 of your VX37L User Manual.

STEP 2

On your Remote Control...

- 1 Turn on the TV, the INITIAL SETUP screen should appear. If this screen does not appear see User Manual Chapter 3 for TV Tuner Setup.
- 2 Select Language; English, Français, Español.
- 3 Press **TV** once to select Cable or Air. Select Cable if you are using cable from the wall or Air if you are using an antenna.
- 4 Press **TV** once to select Auto Search.
- 5 Press **OK** on remote to scan for channels. Scanning for available channels could take several minutes.
- 6 Once scanning is finished, programming is complete.
- 7 For more detailed information see Chapter 3 of your User Manual.



Programming Your Cable or Satellite Box Remote

Consult your Cable or Satellite Owner's Manual to determine if you need a 3, 4 or 5-digit code. If your Cable or Satellite Box requires:

- 3-digits, please use "627" (This code usually works with DISHNetwork.)
- 4-digits, please use "1758", "0178" or "0128"
- 5-digits, please use "11758", "10178" or "10128" (These codes usually work for DIRECTV.)

➤ **Install with a Pro**
Know your VIZIO is at its Best.
Choose from four different levels of installation



➤ Basic

- Setting up and connecting your VIZIO TV to your existing home theater or audio system located in the same room
- Programming of your VIZIO remote and 1 other remote to operate your display and cable or satellite box
- Up to 20 minutes of educational demonstration and orientation
- 1 year warranty on the installation

➤ Deluxe

- Includes the Basic service plus wall mounting with surface-routing cabling
- Removing the stand from your VIZIO TV
- Mounting and securing the TV to the wall
- Neatly surface-routing cables from your video and audio equipment

➤ Premium

- Includes the Basic service plus wall mounting with in wall cabling
- Removing the stand from your VIZIO TV
- Mounting and securing the TV to the wall
- Concealing your video and audio cables in a standard frame wall
- Concealing your power cable with track molding if necessary

➤ All-Inclusive HDTV off-air Installation

- Includes equipment and installation for local off-air HDTV broadcast
- HDTV antenna optimized for your location
- Up to 125 feet of antenna cabling
- If needed up to 2 diplexers, antenna mount, mast, pre-amplifier, splitters
- Connecting antenna to your VIZIO TV

➤ Extended Service Plans

We recommend you register your VIZIO product either at our website www.vizioce.com or fill in your registration card and mail it in. For peace of mind and to protect your investment beyond the standard warranty, VIZIO offers on-site extended warranty service plans. Extended service plans are offered at 2, 3, 4 and 5 years. These plans give you additional coverage during the standard warranty period. Visit our website or call us to purchase a plan.

CALL 800-988-4196
FOR EXTENDED WARRANTY SERVICES

➤ Optional Components




Enhance your VIZIO Experience.

When it comes to components and accessories, don't settle for less than VIZIO. We offer a full line of products specifically designed to accentuate your VX37L. To learn more about how you can enhance your VIZIO experience, call 888-849-4623 or visit www.viziotv.com.



VIZIO High-Definition Certified Cables

Our VIZIO Certified HD cables carry the same standards of excellence as all our VIZIO products. Available in: DVI, HDMI and Component in lengths of 2, 5, and 10 meters.



VIZIO Certified Mounts

FLUSH MOUNT- turn your HDTV into a work of art
TILT MOUNT- adjust your HDTV for the most comfortable viewing position
ARTICULATING ARM- position your HDTV exactly where you want it

Free Manuals Download Website

<http://myh66.com>

<http://usermanuals.us>

<http://www.somanuals.com>

<http://www.4manuals.cc>

<http://www.manual-lib.com>

<http://www.404manual.com>

<http://www.luxmanual.com>

<http://aubethermostatmanual.com>

Golf course search by state

<http://golfingnear.com>

Email search by domain

<http://emailbydomain.com>

Auto manuals search

<http://auto.somanuals.com>

TV manuals search

<http://tv.somanuals.com>