

**WESTINGHOUSE ELECTRIC CORP.
DISTRIBUTION AND CONTROL BUSINESS UNIT
5 PARKWAY CENTER
PITTSBURGH, PA. 15220
1-800-WES-KITS**

**SL 33-DK2-1
DEC. 30, 1996**

SUPPLEMENTAL INSTRUCTIONS FOR IL33-861-5

FOR BREAKER: *Westinghouse DK-15.*

1. Use IL33-861-5 to retrofit Westinghouse DK-15 breakers.
2. Substitute the following:

The DK-15 uses 200:5 current sensors only:

Sensor Style No. 8259A38H01 X1-X2 = 200:5

Free Manuals Download Website

<http://myh66.com>

<http://usermanuals.us>

<http://www.somanuals.com>

<http://www.4manuals.cc>

<http://www.manual-lib.com>

<http://www.404manual.com>

<http://www.luxmanual.com>

<http://aubethermostatmanual.com>

Golf course search by state

<http://golfingnear.com>

Email search by domain

<http://emailbydomain.com>

Auto manuals search

<http://auto.somanuals.com>

TV manuals search

<http://tv.somanuals.com>