


# COOKTOP, BURNER AND GRATE PARTS

For Models: GLT3057RB03, GLT3057RQ03  
(Black) (Designer White)

30" SEALED GAS COOKTOP



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# COOKTOP, BURNER AND GRATE PARTS


For Models: GLT3057RB03, GLT3057RQ03  
(Black) (Designer White)

Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1		LITERATURE PARTS	4		Cap, Burner 6K (RR)	9	3191932	Seal, Foam
	8286304	Installation Instructions		8286153CB	Coal Matte Black	10		Holder, Orifice
	8304571	Undercounter, Installation Instructions		8286153CG	Cumberland Gray 9.5K (LR)		W10128448	6K (RR)
	W10162190	Use & Care Guide		8286154CB	Coal Matte Black		W10128451	12K (LF,RF)
		Safe Cooking Tips		8286154CG	Cumberland Gray 12.5K (LF,RF)	11	W10128450	9K (LR)
	9762761	English		8286155CB	Coal Matte Black		8286181	RF
	W10065852	French		8286155CG	Cumberland Gray		8286182	LF, RF
	8286620	L.P. Conversion Instructions	5		Grate Left		8286184	LR
2		Bowl, Burner 6K (RR)		8285892CB	Coal Matte Black	12	8273062	Screw
	3191307	Black		8285892CG	Cumberland Gray	13	3368921	Screw
	3191308	White			Right	14	9782116	Electrode
		9K,12K (LR,RF,LF)		8285894CB	Coal Matte Black	15		Orifice
	3191302	Black		8285894CG	Cumberland Gray		3192529	RR
	3191303	White	6		Cooktop		3192523	LR
3		Grommet, Glass		8286102	Black	Following Parts Not Illustrated		
	3180079	Black		8286103	White			Harness, Wire
	3180081	White	7		Knob, Control (4)			Ignitor
				8286058BL	Black		4456626	15"
				8286058WH	White		4456627	28"
			8		Grate, Center		4449809	Screw (4)
				8285893CB	Coal Matte Black		3400806	Screw (2)
				8285893CG	Cumberland Gray			

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# BURNER BOX, GAS VALVES, AND SWITCHES

For Models: GLT3057RB03, GLT3057RQ03  
(Black) (Designer White)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# BURNER BOX, GAS VALVES, AND SWITCHES

For Models: GLT3057RB03, GLT3057RQ03  
(Black) (Designer White)

<b>Illus. No.</b>	<b>Part No.</b>	<b>DESCRIPTION</b>
1	4455917	Bracket, (2) Cooktop Mounting
2	8286069	Pipe, Manifold
	3196160	Screw (2)
4	8522423	Spark Module
5		Valve, Burner
	8286559	Auxi (White)
	8286560	Rapid (Purple)
	4456817	Large (2)
6	9763116	Power Cord
8	3177991	Screw, Ground
9	8523704	Bolt, Gas Valve
10		Tubing, Burner
	W10071400	LF
	3191325	RR
	3191324	RF
	W10071390	LR
11	3192491	Bracket, Manifold
12	3400093	Screw
13	4455837	Bracket, Spark Module
14	8286098	Box, Burner
15	3191462	Shield, Heat
16	9759145	Bracket, Support
17		Rail
	8286099	Burner
	8285791	Center
18	3191387	Seal, (4) Switch Cover
19	8285788	Shield, Heat
20	3400843	Screw
21	3177991	Screw
22	4449809	Screw
23	4454571	Regulator, Pressure

---

Following Parts Not Illustrated  
and Optional Parts Not Included

---

8286320 Spud Kit  
4456905 Harness, Switch

## Free Manuals Download Website

<http://myh66.com>

<http://usermanuals.us>

<http://www.somanuals.com>

<http://www.4manuals.cc>

<http://www.manual-lib.com>

<http://www.404manual.com>

<http://www.luxmanual.com>

<http://aubethermostatmanual.com>

Golf course search by state

<http://golfingnear.com>

Email search by domain

<http://emailbydomain.com>

Auto manuals search

<http://auto.somanuals.com>

TV manuals search

<http://tv.somanuals.com>