




# COOKTOP PARTS

For Models: RS610PXGW3, RS610PXGN3, RS610PXGV3  
(White) (Almond) (Black on Biscuit)

30" DROP-IN  
ELECTRIC  
STANDARD CLEAN  
OVEN




Illus. No.	Part No.	DESCRIPTION
1	LIT3191799	Literature Parts Installation Instructions
	LIT3191537	Use & Care Guide
	LIT3192846	Tech Sheet
	LIT3191638	Safe Cooking Tips
2	3192459	Burner Box
4	3192575	Bracket, Mounting
5	3196537	Screw, 8-18 x 3/8
7	3192102	Trim, Extension
8	3191168	Cooktop White
	3191169	Almond
	8284709	Biscuit
9	3195210	Clip, Receptacle
10	3191228	Panel, Control
11	3183956	Seal, Switch (4)
12	3191471	Switch, Infinite Use W/ 6" Surface (Blue Shaft)
	3191472	Use W/ 8" Surface (Silver Shaft)
13	3191491	Light, Indicator
14	3195917	Clip, Element
15	3400855	Screw, 8-32 x 1/4
17	4448444	Grommet
19	3195208	Drip Bowl 6" (2)
	3195209	8" (2)
20	8053265	Element, Coil 6" LF-RR
	8053267	8" RF-LR
21	3400843	Screw, 8-18 x 3/8
22	3196231	Knob, Control (4)
23	3192330	Bracket, Switch Mounting

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# CONTROL PANEL PARTS

For Models:RS610PXGW3, RS610PXGN3, RS610PXGV3  
(White) (Almond) (Black on Biscuit)



<b>Illus. No.</b>	<b>Part No.</b>	<b>DESCRIPTION</b>
-------------------	-----------------	--------------------


NOTE: The screws and nuts required to attach a part are listed immediately following that part.

1	4456313	Control Panel Assy. W/Membrane Switch
	4449745	Screw
	3400832	Screw
2	4451034	Gasket, Control Panel
3	4453193	Microcomputer
	4449745	Screw

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# OVEN PARTS

For Models:RS610PXGW3, RS610PXGN3, RS610PXGV3  
(White) (Almond) (Black on Biscuit)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# OVEN PARTS


For Models:RS610PXGW3, RS610PXGN3, RS610PXGV3  
(White) (Almond) (Black on Biscuit)

Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
NOTE: The screws and nuts required to attach a part are listed immediately following that part.			14	4451740	Frame, Front	37	4451354	Fuse – Thermal
				4449040	Screw		4449809	Screw
				4450118	Nut	43	4455530	Base, Chassis
1		Trim, Side	15	4450493	Gasket, Door	49	4448933	Retainer
	4450844	RH Black	19	4451478	Support, Insulation		4449154	Screw
	4450847	LH Black		4449809	Screw	50	4451747	Cover, Back
	4449747	Screw	21		Rail, Side		4449809	Screw
2	4455509	Bracket, Support		4450579	Right Side	51	4448477	Trim, Bottom
3		Hinge Receiver		4450580	Left Side	53	4449845	Support, Bracket
	4455722	Left Hand		4448444	Grommet		4449154	Screw
	4455723	Right Hand	23	4450051	Deflector	<b>FOLLOWING PARTS NOT ILLUSTRATED</b>		
4	4448520	Bumper, Door		4449154	Screw	<b>INSULATION</b>		
7	4455286	Top, Chassis	25	4454691	Side, Chassis (R.H. & L.H.)		4449316	Insulation, Wrap
	4449809	Screw		4449809	Screw		4450365	Insulation, Back
9	4452159	Tube, Vent	26	4452234	Back, Chassis			
	3196176	Screw		4449809	Screw			
10	4451664	Fan & Bracket Assy	27		Liner, Oven (Not serviceable)			
	4449809	Screw						
11	4452368	Oven Light Assy	29	4455636	Sensor			
12	4452166	Bulb, Light		4449154	Screw			
13	4452165	Lens, Light						

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# OVEN DOOR PARTS

For Models: RS610PXGW3, RS610PXGN3, RS610PXGV3  
(White) (Almond) (Black on Biscuit)



Illus. No.	Part No.	DESCRIPTION
------------	----------	-------------


NOTE: The screws and nuts required to attach a part are listed immediately following that part.

1	4451719	Door Liner
2	4449259	Glass, Inner
3	4455523	Hinge, Door
	4449743	Screw (4)
4	4451671	Retainer, Glass
	4449809	Screw (4)
5	4450813	Bracket, Handle
	4451040	Screw (4)
	4449743	Screw (2)
6	4451674	Seal, Top
8	4452065	Assy, Door Glass
9	4448854	Handle, Door
10	4450863	Retainer, Glass
	4449743	Screw (2)

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# INTERNAL OVEN PARTS

For Models:RS610PXGW3, RS610PXGN3, RS610PXGV3  
 (White) (Almond) (Black on Biscuit)




Illus. No.	Part No.	DESCRIPTION
------------	----------	-------------

2	4452154	Element, Broil
	4449154	Screw
3	3147563	Grill, Broiler
4	3147845	Pan, Broiler
6	4448717	Rack, Oven
7	4452153	Element, Bake
	4449154	Screw

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# TOP VENTING PARTS

For Models:RS610PXGW3, RS610PXGN3, RS610PXGV3  
(White) (Almond) (Black on Biscuit)



Illus. No.	Part No.	DESCRIPTION
------------	----------	-------------

NOTE: The screws and nuts required to attach a part are listed immediately following that part.

1	4451759	Vent, Exhaust
	4449040	Screw
2	4454943	Plate, Mounting
11	4449868	Block, Terminal
	3400080	Screw
	112432	Nut
13	4448549	Vent, (Control Panel)
	4450038	Screw
14		Side, Control Compt.
	3191832	Right
	3191833	Left
	4449809	Screw
15	4452244	Back, Control
	4449809	Screw
16	3191842	Cover, Rear
	4449809	Screw

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# OPTIONAL PARTS

For Models:RS610PXGW3, RS610PXGN3, RS610PXGV3  
(White) (Almond) (Black on Biscuit)

Illus. No.	Part No.	DESCRIPTION
------------	----------	-------------

**PAINT, TOUCH-UP (1/2oz.)**

72017 White  
261869 Cord Brown  
72032 Black

**PAINT, SPRAY**

350930 White  
261900 Citrine White  
830864 Black

**ADHESIVE**

591014 Adhesive  
Loctite (1/3 oz.)  
482338 Sealer, Silastic  
(3 oz.)

Illus. No.	Part No.	DESCRIPTION
------------	----------	-------------

**SPLICING WIRES--25FT.**

**LENGTH**

242828 Wire (12 Ga.  
150 c Black)  
242820 Wire (14 Ga.  
150 c Black)  
242821 Wire (14 Ga.  
150 c Blue)  
242822 Wire (14 Ga.  
150 c Brown)  
242830 Wire (14 Ga.  
200 c Brown)  
242823 Wire (14 Ga.  
150 c Green)  
242824 Wire (14 Ga.  
150 c Orange)  
242829 Wire (12 Ga.  
150 c Red)  
242825 Wire (14 Ga.  
150 c Red)  
242831 Wire (14 Ga.  
200 c Red)  
242826 Wire (14 Ga.  
150 c White)  
242827 Wire (14 Ga.  
150 c Yellow)  
242832 Wire (14 Ga.  
200 c Yellow)

Illus. No.	Part No.	DESCRIPTION
------------	----------	-------------

**WIRING HARNESS PARTS**

4449809 Screw  
3191220 Harness, Wire  
(Main)  
4455745 Harness, Wire  
(EDC)  
4451163 Conduit  
3400015 Screw, Ground  
4448664 Clamp  
3192236 Harness, Wire  
(Infinite Switch)  
4455592 Harness, Wire  
(Light)  
4454384 Ground, Wire  
4452222 Spacer, Harness  
4454835 Tie, Cable

**Miscellaneous**

4448950 Screw, Install.  
8-14 x 1" (4)  
814381 Hinge Pin Kit

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST



## Free Manuals Download Website

<http://myh66.com>

<http://usermanuals.us>

<http://www.somanuals.com>

<http://www.4manuals.cc>

<http://www.manual-lib.com>

<http://www.404manual.com>

<http://www.luxmanual.com>

<http://aubethermostatmanual.com>

Golf course search by state

<http://golfingnear.com>

Email search by domain

<http://emailbydomain.com>

Auto manuals search

<http://auto.somanuals.com>

TV manuals search

<http://tv.somanuals.com>