




COOKTOP PARTS

For Models: RS675PXGB9, RS675PXGQ9, RS675PXGT9
(Black) (White) (Biscuit)

30" DROP-IN
ELECTRIC OVEN
SELF CLEAN

Illus. Part
No. No. DESCRIPTION



NOTE: The screws and nuts required to attach a part are listed immediately following that part.


COOKTOP PARTS

1	LIT4455995	Literature Parts Installation Instructions
	LIT8300666	Use & Care Guide
	LIT3192845	Tech Sheet
	LIT3191638	Safe Cooking Tips
2	3192459	Burner Box
3	3192330	Bracket, Mounting
	3177991	Screw
4		Cooktop
	8284709	Biscuit
	3191168	White
	3191167	Black
5	3192575	Clip, Mtg. (4)
	3400843	Screw
6		Panel, Control
	8284707	Biscuit
	3191229	White
	3191228	Black
7		Switch, Infinite
	3191471	Use W/6" Surface (Blue Shaft)
	3191473	Use W/8" Surface (Red Shaft)
	3400855	Screw, 8-32 x 1/4
8	3191491	Light, Indicator
11		Pan, Surface
	3195208	6" Pan
	3195209	8" Pan
12		Element, Surface
	8053266	6" Burner
	8053268	8" Burner
14		Knob, Control
	3196232	White
	8272506	Biscuit
	3196231	Black
15	3183956	Seal, Switch Shaft (4)
18		Trim, Extension
	3192103	White
	8300518	Biscuit
	3192102	Black
19	3195917	Clip, Element

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

CONTROL PANEL PARTS

For Models: RS675PXGB9, RS675PXGQ9, RS675PXGT9
 (Black) (White) (Biscuit)




Illus. No.	Part No.	DESCRIPTION
1		Control Panel Assy.
	4452845	White
	8300515	Biscuit
	4452844	Black
		W/Membrane Switch
	3400832	Screw
2	4451034	Gasket, Control Panel
3	4452892	Microcomputer
	4449745	Screw

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

OVEN PARTS

For Models: RS675PXGB9, RS675PXGQ9, RS675PXGT9
(Black) (White) (Biscuit)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

OVEN PARTS


For Models: RS675PXGB9, RS675PXGQ9, RS675PXGT9
(Black) (White) (Biscuit)

Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
NOTE: The screws and nuts required to attach a part are listed immediately following that part.			10	4452165	Lens, Light	29	4455636	Sensor
			11	4452368	Oven Light Assy		4449154	Screw
			12	4452166	Bulb, Light	30	4451537	Spring, Latch
			14	4455612	Frame, Front	37	4451442	Thermostat (TOD) (Temp.) SPST
				4449040	Screw	43	4455530	Base, Chassis
				4450118	Nut	49	4448933	Retainer, Gasket
			15	4455382	Gasket, Door		4449154	Screw
			19	4451478	Support, Insulation	50	4451747	Cover, Back
				4449809	Screw		4449809	Screw
				4450579	Rail, Side	53	4449845	Support, Bracket
	4450580	Right Side		4449809	Screw			
	4448444	Left Side		4449809	Screw			
	4449154	Grommet	55		Trim, Bottom			
	4449154	Screw		4448478	White			
22	4451896	Latch Assembly		4452415	Biscuit			
23	4452224	Solenoid		4448477	Black			
24	4452312	Micro Switch N.C.	FOLLOWING PARTS NOT ILLUSTRATED					
	4449154	Screw	INSULATION					
25	4455641	Side, Chassis (R.H. & L.H.)		4449316	Insulation, Wrap			
	4449809	Screw		4450365	Insulation, Back			
26	4452234	Back, Chassis						
	4449809	Screw						
27		Liner, Oven (Not serviceable)						
28	4451426	Micro Switch						

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

OVEN DOOR PARTS

For Models: RS675PXGB9, RS675PXGQ9, RS675PXGT9
(Black) (White) (Biscuit)




Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
		NOTE: The screws and nuts required to attach a part are listed immediately following that part.						
1	4455618	Door Liner	3	4449259	Glass, Inner	15		Door Assembly, Glass
2		Hinge, Door	4	4451722	Insulation, Door		4452066	White
	8300571	R.Side	7	4449263	Glass, Inner (2)		4452859	Biscuit
	8300572	L.Side	9	4451668	Retainer, Glass		4452065	Black
	4449743	Screw		4449809	Screw	19	4450362	Shield, Heat
			13		Door Handle		4449809	Screw
				4448855	White	20	8300778	Retainer, Glass
				4452860	Biscuit		4449809	Screw
				4448854	Black	21	8300820	Seal, Door Top
			14	4450813	Bracket, Handle	23		Retainer, Clip
				4451040	Screw		4450864	White
							4452119	Biscuit
							4450863	Black
						24	4455257	Glass, Inner

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

INTERNAL OVEN PARTS

For Models: RS675PXGB9, RS675PXGQ9, RS675PXGT9
 (Black) (White) (Biscuit)




Illus. No.	Part No.	DESCRIPTION
2	4452154	Element, Broil
	4449154	Screw
3	3147563	Grill, Broiler
4	3147845	Pan, Broiler
6	4448717	Rack, Oven
7	4452153	Element, Bake
	4449154	Screw

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

TOP VENTING PARTS

For Models: RS675PXGB9, RS675PXGQ9, RS675PXGT9
(Black) (White) (Biscuit)



Illus. No.	Part No.	DESCRIPTION
------------	----------	-------------

NOTE: The screws and nuts required to attach a part are listed immediately following that part.

1	4451759	Vent, Exhaust
	4449040	Screw, 8-18 x 3/8

Illus. No.	Part No.	DESCRIPTION
------------	----------	-------------

2	4455178	Elbow, Vent Top
3	8300788	Blower
4	4451758	Block, Foam
5	4455177	Elbow, Vent Bottom
6	4451761	Plate, Service
11	4449868	Block, Terminal
	3400080	Screw
13	4448549	Vent, (Control Panel)
	4450038	Screw

Illus. No.	Part No.	DESCRIPTION
------------	----------	-------------

14		Side, Control Compt.
	3191832	Right
	3191833	Left
	4449809	Screw
15	4452244	Back, Control
	4449809	Screw
20	3191842	Cover, Rear

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

OPTIONAL PARTS

For Models:RS675PXGB9, RS675PXGQ9, RS675PXGT9
(Black) (White) (Biscuit)

Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
<u>PAINT, TOUCH-UP (1/2oz.)</u>			<u>SPLICING WIRES--25FT.</u>			<u>WIRING HARNESS PARTS</u>		
	72017	White	<u>LENGTH</u>				3191220	Harness, Wire (Main)
	261869	Cord Brown	242828	Wire (12 Ga.		4455733	Harness, Wire (EDC)	
	72032	Black		150 c Black)		4451163	Conduit	
<u>PAINT, SPRAY</u>			242820	Wire (14 Ga.		4448664	Clamp	
	350930	White		150 c Black)		4449809	Screw	
	261900	Citrine White	242821	Wire (14 Ga.		112432	Nut	
	830864	Black		150 c Blue)		4450800	Screw, Ground	
<u>ADHESIVE</u>			242822	Wire (14 Ga.		3192236	Harness, Wire (Infinite Switch)	
	591014	Adhesive		150 c Brown)		4455592	Harness, Wire (Light)	
		Loctite (1/3 oz.)	242830	Wire (14 Ga.		4452222	Spacer, Harness	
	482338	Sealer, Silastic (3 oz.)		200 c Brown)		4454384	Ground, Wire	
			242823	Wire (14 Ga.		3400015	Screw, Ground	
				150 c Green)	<u>Miscellaneous</u>			
			242824	Wire (14 Ga.		814381	Hinge Pin Kit	
				150 c Orange)		4448950	Screw, Install (4)	
			242829	Wire (12 Ga.				
				150 c Red)				
			242825	Wire (14 Ga.				
				150 c Red)				
			242831	Wire (14 Ga.				
				200 c Red)				
			242826	Wire (14 Ga.				
				150 c White)				
			242827	Wire (14 Ga.				
				150 c Yellow)				
			242832	Wire (14 Ga.				
				200 c Yellow)				

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

Free Manuals Download Website

<http://myh66.com>

<http://usermanuals.us>

<http://www.somanuals.com>

<http://www.4manuals.cc>

<http://www.manual-lib.com>

<http://www.404manual.com>

<http://www.luxmanual.com>

<http://aubethermostatmanual.com>

Golf course search by state

<http://golfingnear.com>

Email search by domain

<http://emailbydomain.com>

Auto manuals search

<http://auto.somanuals.com>

TV manuals search

<http://tv.somanuals.com>