




COOKTOP PARTS

For Models: RS696PXGB14, RS696PXGQ14
(Black) (Designer White)

30" ELECTRIC
DROP-IN RANGE
SELF CLEANING
OVEN



Literature Parts

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

COOKTOP PARTS


For Models:RS696PXGB14, RS696PXGQ14
(Black) (Designer White)

<u>Illus.</u> <u>No.</u>	<u>Part</u> <u>No.</u>	<u>DESCRIPTION</u>
1		Literature Parts
	8300770	Installation Instructions
	8300666	Use & Care Guide
	9760536	Tech Sheet
	3191638	Safe Cooking Tips
2		Cooktop, Glass
	3191843	Black
	3191189	White
3	3191310	Bracket, Switch Mounting
4		Element, Surface
	8523698	1200W RF-LR
	8523696	1800W RR
	8523692	2500W LF
5	9759094	Spring, Locator
	246119	Screw (8)
7		Switch, Infinite
	3191049	1200W RR-LR (Silver Shaft)
	3191050	1800W RR (Yellow Shaft)
	4454541	2500W LF (Red Shaft)
	311865	Screw
8	3183956	Seal, Switch Cover
10		Knob, Control (4)
	3196231	Black
	3196232	White
13	8285469	Seal, Switch
15	3191515	Bracket, Support Element
16		Trim Ring, Cooktop
	3193228	Black
	3193227	White
	3196537	Screw
17	3192452	Frame, Cooktop
21	3191952	Lamp, Indicator
	3191953	Bumper, Rubber
	9750835	Bumper, Door

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

OVEN PARTS

For Models: RS696PXGB14, RS696PXGQ14
(Black) (Designer White)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

OVEN PARTS


For Models: RS696PXGB14, RS696PXGQ14
(Black) (Designer White)

Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1		Trim, Side (Right Hand)	10	4452165	Lens, Light	33	4457117	Deflector, Vent
	4450844	Black Model	11	4452368	Oven Light Assy		4449809	Screw
	4449747	Screw	12	4452166	Bulb, Light	37	9759243	Thermostat (TOD) (Temp.) SPST
	4450845	White Model (Left Hand)	14	9759060	Frame, Front	43	9759713	Base, Chassis
	4450847	Black Model		4449040	Screw	49	4448933	Retainer, Gasket
	8281236	Screw		4450118	Nut		4449154	Screw
	4450848	White Model Screw	15	4455382	Gasket, Door	50	4451747	Cover, Back
3		Hinge Receiver	19	4451478	Support, Insulation		4449809	Screw
	4455605	Left Hand	21		Rail, Side	53	4449845	Support, Bracket
	4455606	Right Hand		4450579	Right Side		4449809	Screw
4	4448520	Bumper, Door		4450580	Left Side	55		Trim, Bottom
5	9760535	Thermosat (TOD) SPST 98c-74c		4448444	Grommet		4448477	Black Model
	9760503	Bracket	22	9759481	Latch, Motorized		4448478	White Model
7	4455865	Top Chassis	25	4455641	Side, Chassis (R.H. & L.H.)	FOLLOWING PARTS NOT ILLUSTRATED		
	4449809	Screw		4449809	Screw	INSULATION		
9	4452158	Tube, Vent	26	4452234	Back, Chassis		4449316	Insulation, Wrap
	3196176	Screw		4449809	Screw		4450365	Insulation, Back
			27		Liner, Oven (Not serviceable)			
			29	4455636	Sensor			
				4449154	Screw			

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

CONTROL PANEL PARTS

For Models:RS696PXGB14, RS696PXGQ14
(Black) (Designer White)




Illus. No.	Part No.	DESCRIPTION
1		Control Panel Assy. W/Membrane Switch 4456312 Black Model 4456311 White Model
2		4449745 Screw 3400832 Screw 4451034 Gasket, Control Panel
3		8301919 Assy, Control 4449745 Screw

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

OVEN DOOR PARTS

For Models:RS696PXGB14, RS696PXGQ14
(Black) (Designer White)




Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1	4457127	Door Liner	14	4450813	Bracket, Handle	20	4457132	Retainer, Glass
2		Hinge, Door		4451040	Screw		4449809	Screw
	8300571	R.Side	15		Assy, Door Glass	21	8300820	Seal, Door Top
	8300572	L.Side		8300903	Black Model	22	4457114	Shield, Heat (Btm)
	4449743	Screw		8300899	White Model	23		Retainer, Clip
3	4449259	Glass, Inner	16	9759229	Bracket(2nd Glass)		4450863	Black Model
4	4451722	Insulation, Door	17	9759230	Bracket(3rd Glass)		4450864	White Model
7	9759225	Glass, Inner	19	4457103	Shield, Heat	24	9759228	Glass, Inner
13		Door Handle		4449809	Screw			
	4448854	Black Model						
	4448855	White Model						

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

TOP VENTING PARTS

For Models: RS696PXGB14, RS696PXGQ14
(Black) (Designer White)



Illus. No.	Part No.	DESCRIPTION
1	4451759	Vent, Exhaust
	4449040	Screw
2	4455178	Elbow, Vent-Top
3	4455334	Blower
4	4451758	Block, Foam
5	4455177	Elbow, Vent-Bottom


Illus. No.	Part No.	DESCRIPTION
11	4449868	Block, Terminal
	3400080	Screw
13	4448549	Vent, (Control Panel)
	4450038	Screw
14		Side, Control Compt.
	4451535	Right
	4451536	Left
	4449809	Screw

Illus. No.	Part No.	DESCRIPTION
15	9759135	Back, Control
	4449809	Screw
19	4451985	Suppressor
20	3191842	Cover, Rear
21	4451407	Plate, Support
	4452260	Spacer, Foam

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

INTERNAL OVEN PARTS

For Models: RS696PXGB14, RS696PXGQ14
(Black) (Designer White)



Illus. No.	Part No.	DESCRIPTION
2	4456103	Element, Broil
	4449154	Screw
3	4457277	Grill, Broiler
4	4457276	Pan, Broiler
6	4448717	Rack, Oven
	9759322	Pad, Rack
7	4452153	Element, Bake
	4449154	Screw

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

OPTIONAL PARTS

For Models:RS696PXGB14, RS696PXGQ14
(Black) (Designer White)

Illus. No.	Part No.	DESCRIPTION
------------	----------	-------------

PAINT, TOUCH-UP (1/2oz.)

72017 White
261869 Cord Brown
72032 Black

PAINT, SPRAY

350930 White
261900 Citrine White
830864 Black

ADHESIVE

591014 Adhesive
Loctite (1/3 oz.)
482338 Sealer, Silastic
(3 oz.)

Illus. No.	Part No.	DESCRIPTION
------------	----------	-------------

SPLICING WIRES--25FT.

LENGTH

242828 Wire (12 Ga.
150 c Black)
242820 Wire (14 Ga.
150 c Black)
242821 Wire (14 Ga.
150 c Blue)
242822 Wire (14 Ga.
150 c Brown)
242830 Wire (14 Ga.
200 c Brown)
242823 Wire (14 Ga.
150 c Green)
242824 Wire (14 Ga.
150 c Orange)
242829 Wire (12 Ga.
150 c Red)
242825 Wire (14 Ga.
150 c Red)
242831 Wire (14 Ga.
200 c Red)
242826 Wire (14 Ga.
150 c White)
242827 Wire (14 Ga.
150 c Yellow)
242832 Wire (14 Ga.
200 c Yellow)

Illus. No.	Part No.	DESCRIPTION
------------	----------	-------------

WIRING HARNESS PARTS

8301876 Harness, Wire
(Main)
4456646 Harness, Wire
(Infinite Switch)
9760502 Harness, Wire
(Burners)
4451163 Conduit
4448664 Clamp
4449809 Screw
112432 Nut
4450800 Screw, Ground
4451761 Support, Wiring
4454842 Tie, Cable
4452222 Spacer, Harness

Miscellaneous

814381 Pin Hinge Kit
4448950 Screw, Install (4)

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

Free Manuals Download Website

<http://myh66.com>

<http://usermanuals.us>

<http://www.somanuals.com>

<http://www.4manuals.cc>

<http://www.manual-lib.com>

<http://www.404manual.com>

<http://www.luxmanual.com>

<http://aubethermostatmanual.com>

Golf course search by state

<http://golfingnear.com>

Email search by domain

<http://emailbydomain.com>

Auto manuals search

<http://auto.somanuals.com>

TV manuals search

<http://tv.somanuals.com>