


# Philips Audio CD Recorder CDR 600: Getting started...

English



## General information

*This Quick Installation Card gives a rough overview and helps to quickly start with basic steps. Please read the supplied instruction manual for detailed information.*

## Mains

- 1 Check whether the mains voltage as shown on the type plate corresponds to your local mains voltage. If it does not consult your dealer or service organization.
- 2 **After all connections have been made** connect the mains cable to AC MAINS~ and to the wall socket. This switches on the mains supply.

**To disconnect the set from the mains completely, remove the mains plug from the wall socket.**

## Discs for recording

Use discs with the "Digital Audio" logo only:

- CD-Audio Recordable (CDR) discs, or
- CD-Audio ReWriteable (CDRW) discs.

Do not use computer CDR(W)s as recording would not work properly.




## Discs for playback

disc:	playback in:	standard CD player	CDRW compatible CD player	Philips CDR 600
finalized CDR		•	•	•
finalized CDRW			•	•
unfinalized CDR or CDRW				•

# Philips Audio CD Recorder CDR 600: Getting started...


English

## Playing a CD




- 1 Press OPEN/CLOSE ▲  
Insert a CD into the CD recorder tray.
- 2 Press OPEN/CLOSE ▲  
to close the tray.
- 3 Press PLAY/PAUSE ►/||  
to start playback.

## Recording an entire CD




- 1 Insert a blank Audio CDR(W) into the CD recorder tray.
- 2 Insert the CD to be copied into the tray of the external CD player.
- 3 Press SOURCE to select the correct input connection.
- 4 Press TYPE once.
- 5 Press PLAY on external CD player to start recording.

## Recording a single track



- 1 Insert a blank Audio CDR(W) into the CD recorder tray.
- 2 Insert a CD into the tray of the external CD player.
- 3 Press SOURCE to select the correct input connection.
- 4 Press TYPE twice.
- 5 Select the track on the external CD player.
- 6 Press PLAY on external CD player to start recording.

## Finalizing manually



- 1 Insert the CDR(W) to be finalized into the CD recorder.
- 2 Press FINALIZE.
- 3 Press RECORD to start the finalization.

## Free Manuals Download Website

<http://myh66.com>

<http://usermanuals.us>

<http://www.somanuals.com>

<http://www.4manuals.cc>

<http://www.manual-lib.com>

<http://www.404manual.com>

<http://www.luxmanual.com>

<http://aubethermostatmanual.com>

Golf course search by state

<http://golfingnear.com>

Email search by domain

<http://emailbydomain.com>

Auto manuals search

<http://auto.somanuals.com>

TV manuals search

<http://tv.somanuals.com>