

Fig. 1  
**Top left cover**  
Gently open the top left cover while lifting up the release lever.




Fig. 3  
If you cannot remove jammed paper, then inside the fuser unit, lift up the green lever and remove the jammed paper.



Fig. 5  
Remove the jammed paper.




Fig. 2  
If the edge of the jammed paper can be reached at the output tray, pull the jammed paper in the direction of the feed-out area.



Fig. 4  
**Duplex Module Cover**  
Open the tray 5 (Bypass) and gently open the duplex module cover.



Fig. 6  
**Tray 5 (Bypass)**  
Inspect the inside (paper feed entrance) of Tray 5 (Bypass), and remove any jammed paper.



Fig. 7  
**Duplex Module Cover**  
Remove the jammed paper.



Fig. 9  
**Paper Tray 1 to 4**  
Remove the jammed paper.




Fig. 8  
**Bottom left cover**  
Remove the jammed paper.

## Quick Start Guide

Removing Paper Jam



**DocuColor 2240/1632**

**THE DOCUMENT COMPANY**

**XEROX**

## Free Manuals Download Website

<http://myh66.com>

<http://usermanuals.us>

<http://www.somanuals.com>

<http://www.4manuals.cc>

<http://www.manual-lib.com>

<http://www.404manual.com>

<http://www.luxmanual.com>

<http://aubethermostatmanual.com>

Golf course search by state

<http://golfingnear.com>

Email search by domain

<http://emailbydomain.com>

Auto manuals search

<http://auto.somanuals.com>

TV manuals search

<http://tv.somanuals.com>