ACCUSPLIT. AX605SBL OPERATING INSTRUCTIONS

Twin Button Feature: The Left and Right buttons on new ACCUSPLIT stopwatches operate interchangeably, so both are labeled "A" for these instructions.

Event

A-Start

A-Stop ("Time Out")


A-Restart ("Time In")

A-Stop

C-Reset

Backlight

LED Backlight comes on for 10 minutes after each button push (light cannot be turned off).



RECHARGING

To recharge the stopwatch battery, use SBLCHARGER kit (included with each watch). SBLCHARGER includes provision for charging watch from normal 120 Volt electrical outlet, from cigarette lighter in car, or from USB port on a computer.

With continuous use of the backlight, the watch will last at least 10 hours before needing a recharge. If the backlight is never used, a single charge will last approximately six months (up to one year if stopwatch is used sparingly).

SERVICE

If service is needed, please return the watch to ACCUSPLIT. Please do not open the case, as the watch is not designed for service by the consumer.

WARNING —This watch uses a rechargeable battery—replacement of the battery with a non-rechargeable battery is unsafe and will result in damage to the watch, and could cause personal injury.

NO-PROOF-OF-PURCHASE LIMITED WARRANTY

See label on back of unit for details, or check http://support.ACCUSPLIT.com

ACCUSPLIT, Inc. • 3090 Independence Drive, Suite 148 • Livermore, CA 94551 USA 800-935-1996 • 925-290-1900 • FAX 925-290-1930 www.ACCUSPLIT.com • support@ACCUSPLIT.com Free Manuals Download Website

http://myh66.com

http://usermanuals.us

http://www.somanuals.com

http://www.4manuals.cc

http://www.manual-lib.com

http://www.404manual.com

http://www.luxmanual.com

http://aubethermostatmanual.com

Golf course search by state

http://golfingnear.com

Email search by domain

http://emailbydomain.com

Auto manuals search

http://auto.somanuals.com

TV manuals search

http://tv.somanuals.com