

# ACCUSPLIT®

# ALLIANCE™ 609T

## OPERATING INSTRUCTIONS

### RESET

- Two button Reset (press MIN and SEC at the same time).

### SETTING COUNTDOWN TIMER

- Enter Minutes by pressing MIN button in one min. increments (0 – 99).
- Enter Seconds by pressing SEC button in one sec. increments (0 – 59).
- Repeat as necessary.

### STARTING AND STOPPING COUNTDOWN FUNCTION

- Press the START-STOP button to START the countdown timer.
- Press the START-STOP button to STOP the countdown timer.

### STARTING AND STOPPING COUNT-UP FUNCTION

- Starting from 00:00,
- Press the START-STOP button to START count-up. (There is no alarm for this setting, as it will continue to count up until it is stopped.)
  - Press the START-STOP button to STOP count-up.

### PRODUCT SPECIFICATIONS

**Operating Temperature:**  
14°F – 138°F (-10°C – 59°C)

### Battery:

- When LCD Display becomes dim, replace battery with LR-44 or equivalent.
- 18-Month Circuit Battery Life (reduced dependent on extensive alarm usage).

**REGISTER NOW** Please return your AL609T Registration to the Repair Center address in the warranty, & we will let you know about future products.

Email (preferred) \_\_\_\_\_

User \_\_\_\_\_

ACCUSPLIT, Inc.  
3090 Independence Drive,, Suite 148  
Livermore, CA 94551 USA

800-935-1996 • 925-290-1900 • FAX 925-290-1930  
[www.ACCUSPLIT.com](http://www.ACCUSPLIT.com) • [support@ACCUSPLIT.com](mailto:support@ACCUSPLIT.com)

**NO-PROOF-OF-PURCHASE LIMITED WARRANTY**

See label on the back of your timer.

ASSEMBLED IN PRChina  
© 2005 ACCUSPLIT

## Free Manuals Download Website

<http://myh66.com>

<http://usermanuals.us>

<http://www.somanuals.com>

<http://www.4manuals.cc>

<http://www.manual-lib.com>

<http://www.404manual.com>

<http://www.luxmanual.com>

<http://aubethermostatmanual.com>

Golf course search by state

<http://golfingnear.com>

Email search by domain

<http://emailbydomain.com>

Auto manuals search

<http://auto.somanuals.com>

TV manuals search

<http://tv.somanuals.com>