

# Vacuum Pump and Brake Bleed Kit Model 2501

#### Features:

- Bleed brakes without the mess
- · Use kit alone for 2-man brake bleeding
- Use kit with Vacuum Pump for one-man brake bleeding
- 90 degree and tapered adapters fit wheel cylinder/ caliper and master cylinder
- · Air sealing lubricant (provided) eliminates bubbles in fluid
- · Can be used to siphon fluids

### Instructions for Use:

- Brake fluid should be changed every 2 years or when brake system work is done.
- Check fluid type for your car.
- Remove bleeder valve and apply small amount of lubricant (provided) to threads, then reinstall bleeder valve.
- Ättach Brake Bleeder Kit (with Vacuum Pump, if desired), lubricate jar lid, bleeder valve threads and adapter to seal out air.
- · Keep new fluid topped off in master cylinder.
- Check bleeding order for car; usual order is right rear, left rear, right front, left front.

# One-Man Operation:

- · Open bleeder valve and pump Vacuum Pump.
- Bleed fluid until clear, bubble free, new fluid appears in hose (remember to keep master cylinder topped).
- Tighten bleeder valve.
- · Dispose of used brake fluid properly.

# **Two-Man Operation:**

- 1st person pumps up brake pedal and holds.
- 2nd person opens bleeder valve to bleed fluid until 1st person says stop (just before pedal hits floor).
- · 2nd person then closes bleeder valve.
- Repeat until clear, bubble free, new fluid appears in hose (remember to keep master cylinder topped).
- Dispose of used brake fluid properly.
- Bleed master cylinder separately before mounting on car.

#### Note:


Support car on jack stands or solid wooden blocks, never on bumper jack. The jack supplied with vehicle should be used only for changing wheels. Never crawl under car or run engine while vehicle is on a jack.

### **CAUTION: Special Lubricant**

Dow Corning Molycote III, Permatex 67VR, Echlin ML-3, Motorcraft WA-10

Other lubricants may not be compatible with brake fluids.

DOWN BOARD AND THE BOARD SHOW DOWN BOARD SHOW BOARD SHOW DOWN BOARD SHOW BOAR



©2003 Actron Manufacturing Company. All Rights Reserved. Download from Www.Somanuals.com. All Manuals Search And Download.

Free Manuals Download Website

http://myh66.com

http://usermanuals.us

http://www.somanuals.com

http://www.4manuals.cc

http://www.manual-lib.com

http://www.404manual.com

http://www.luxmanual.com

http://aubethermostatmanual.com

Golf course search by state

http://golfingnear.com

Email search by domain

http://emailbydomain.com

Auto manuals search

http://auto.somanuals.com

TV manuals search

http://tv.somanuals.com