



1 - Main Housing	SX5.3-001	15 - Spool Spring Washer (2 req.)	SX5.3-015	31 - Dog	SX5.3-031	46 - Drive Washer	SX5.3-046	59 - Knob Washer (optional)	SX5.3-059
2 - Gear cover	SX5.3-002	16 - Spool Spring	SX5.3-016	32 - Dog Cover Screw (2 req.)	SX5.3-032	47 - Preset Washer	SX5.3-047	60 - Spring Washer	SX5.3-060
3 - Cover Screw (2 req.)	SX5.3-003	17 - Brake Bearing	SX5.3-017	33 - Dog Cover	SX5.3-033	48 - Preset Spring	SX5.3-048	61 - Lock Washer	SX5.3-061
4 - Spool Shaft	SX5.3-004	18 - Brake Disk	SX5.3-018	34 - Stop Pin (2 req.)	SX5.3-034	49A - Preset Knob Detent	SX5.3-049A	62 - Nut	SX5.3-062
4A - Shaft Shoulder	SX5.3-004A	20 - Antireverse Gear	SX5.3-020	35 - Pin Screw (2 req.)	SX5.3-035	49 - Preset Knob	SX5.3-049	63 - Knob Cap	SX5.3-063
4B - Shaft Pin	SX5.3-004B	21 - Disk Ring	SX5.3-021	36 - Handle Knob	SX5.3-036	50 - Crank Arm	SX5.3-050	64 - Knob Cap Screws (2 req.)	SX5.3-064
5 - Belleville Washers (4 req.)	SX5.3-005	22 - Pinion Gear	SX5.3-022	37 - Knob Screw	SX5.3-037	51 - Crank Arm Washer	SX5.3-051	65 - Clicker Pin	SX5.3-065
6 - Pusher Bushing	SX5.3-006	23 - Pinion Bearing	SX5.3-023	38 - End Housing Screw (3 req.)	SX5.3-038	52 - Acorn Nut	SX5.3-052	66 - Pin Support	SX5.3-066
7 - Spool Bearing	SX5.3-007	24 - Drive Shaft	SX5.3-024	39 - Drive Shaft Tube	SX5.3-039	53 - Locking Plate	SX5.3-053	67 - Pin Washer	SX5.3-067
8 - Spool Tube	SX5.3-008	25 - Connection Arm	SX5.3-025	40 - Drive Shaft Washer	SX5.3-040	54 - Locking Plate Screws (2 req.)	SX5.3-054	68 - Clicker Spring (2 req.)	SX5.3-068
9 - Clicker Gear Retainer Ring	SX5.3-009	26 - Friction Ring	SX5.3-026	41 - Male Cam	SX5.3-041	55A - Handle Shaft Washer	SX5.3-055A	69 - Clicker Arm	SX5.3-069
10 - Clicker Gear	SX5.3-010	27 - Friction Washer	SX5.3-027	42 - Male Cam Pin (2 req.)	SX5.3-042	55 - Handle Knob Shaft	SX5.3-055	70 - Pin E Clip	SX5.3-070
11 - Spool	SX5.3-011	28 - Drive Gear	SX5.3-028	43 - Female Cam	SX5.3-043	56 - Handle Shaft Bearing	SX5.3-056	71 - Reel Foot	SX5.3-071
12 - Brake Pad	SX5.3-012	29 - Drive Shaft Bearing (2 req.)	SX5.3-029	44 - Lever Arm	SX5.3-044	57 - Handle Knob	SX5.3-057	72 - Reel Foot Screw	SX5.3-072
14 - Spool Bearing	SX5.3-014	30 - End Housing	SX5.3-030	45 - Teflon Washer (2 req.)	SX5.3-045	58 - Knob Bearing	SX5.3-058	73 - Clamp	SX5.3-073
								74 - Clamp Screws (2 req.)	SX5.3-074

Free Manuals Download Website

<http://myh66.com>

<http://usermanuals.us>

<http://www.somanuals.com>

<http://www.4manuals.cc>

<http://www.manual-lib.com>

<http://www.404manual.com>

<http://www.luxmanual.com>

<http://aubethermostatmanual.com>

Golf course search by state

<http://golfingnear.com>

Email search by domain

<http://emailbydomain.com>

Auto manuals search

<http://auto.somanuals.com>

TV manuals search

<http://tv.somanuals.com>