
Black Box Tech Support: FREE! Live. 24/7.



Great tech support is just 30 seconds away at 724-746-5500 or blackbox.com.



About Black Box

Black Box provides an extensive range of networking and infrastructure products. You'll find everything from cabinets and racks and power and surge protection products to media converters and Ethernet switches all supported by free, live 24/7 Tech support available in 30 seconds or less.

© Copyright 2011. Black Box Corporation. All rights reserved. Black Box® and the Double Diamond logo are registered trademarks of BB Technologies, Inc. Any third-party trademarks appearing in this white paper are acknowledged to be the property of their respective owners.

LMC5210A-R2, Rev. 2 06-80040BB-00 C3

BLACK BOX NETWORK SERVICES

LMC5210A-R2 LMC5211A LMC5212A-R2 LMC5214A PS7412A

Power Supply Module Installation Guide

Add redundant or replacement AC or DC power to a media converter system.

Customer Support Information Order toll-free in the U.S.: Call 877-877-BBOX (outside U.S. call 724-746-5500)
FREE technical support 24 hours a day, 7 days a week: Call 724-746-5500 or fax
724-746-0746 • Mailing address: Black Box Corporation, 1000 Park Drive, Lawrence,
PA 15055-1018 • Web site: www.blackbox.com • E-mail: info@blackbox.com

Power Supply Module Power Supply Module

Requirements

Black Box's Power Supply Modules are only for use in chassis manufactured by Black Box. Always use the correct Power Supply Module in each chassis. Black Box is not responsible for any loss or damage resulting from misuse of this product.

Installation Instructions

Depending on the type of chassis and Power Supply Module, installation instructions vary slightly, as listed below. Refer to the installation manual for your chassis if you are unsure which type of power supply module you have.

- To install a power supply module, remove the blank bracket (if present), slide the power supply module into the chassis, click into place and attach the power cord. To remove a power supply module, disconnect the power source from the power supply, move the power supply release switch toward the right, and hold as you grasp the power supply module by the silver handle and slide out of the chassis.
- To install a power supply, slide the power supply module into the chassis and click into place. To remove a power supply, move the two power supply release switches inward and hold as you grasp the power supply by the silver handle and slide out of the chassis.
- To install, simply unscrew and remove the blank bracket covering the unused power supply slot then slide the Power Supply Module in until it fits securely in its socket at the rear of the slot. Secure the module in place by tightening the thumbscrews on the Power Supply Module bracket.

Attach the power cable, and if applicable, move the toggle switch to the ON position. If the power supply module has a Power LED, the LED will light when the unit is receiving power.

NOTE

Some power supplies are hot-swappable; if not, power down the unit before installing and removing power supply modules.

If the Power Supply Module has any configuration jumpers or DIP switches, they are configured at the factory; DO NOT CHANGE.

Contacting Black Box

Black Box Customer Service

Order toll-free in the U.S.: Call 877-877-BBOX (outside U.S. call 724-746-5500)

Free technical support, 24 hours a day, 7 days a week.

Call: 724-746-5500 or Fax: 724-746-0746

Mail order: Black Box Corporation

1000 Park Drive, Lawrence, PA 15055-1018

Web site: www.blackbox.com

E-mail: info@blackbox.com

Free Manuals Download Website

http://myh66.com

http://usermanuals.us

http://www.somanuals.com

http://www.4manuals.cc

http://www.manual-lib.com

http://www.404manual.com

http://www.luxmanual.com

http://aubethermostatmanual.com

Golf course search by state

http://golfingnear.com

Email search by domain

http://emailbydomain.com

Auto manuals search

http://auto.somanuals.com

TV manuals search

http://tv.somanuals.com