

ServSwitch EC for PS/2 and USB Servers and PS/2 Consoles

# Switch between multiple PS/2 and USB servers from a single PS/2 KVM workstation!



## FEATURES

- » Control up to 4, 8, or 16 PS/2® or USB servers.
- » Cascade additional ServSwitch EC units to control even more servers.
- » Switch manually or use AutoScan, which automatically scans and selects servers in sequential order.

## OVERVIEW

Bring economical KVM switching versatility to your mixed PS/2 and USB server environment. The **ServSwitch™ EC for PS/2 and USB Servers and PS/2 Consoles** enables you to control as many as 16 PS/2 or USB servers from a central location with a PS/2 keyboard, a PS/2 mouse, and a monitor. The switch is operating system independent and transparent to all applications.

To add more server connections, just cascade multiple ServSwitch EC switches—up to 136 servers in all! Use one ServSwitch EC as the master and the others as slaves.

Only 1U high, it can fit on the desktop or you can mount it in a rack or cabinet with the included brackets, providing an efficient way to manage multiple computers in server rooms where space is at a premium. And because the keyboard, monitor, and mouse circuitry is concentrated in a single HD15 connector at the server end, you have fewer cables to mess with when making your server connections. (Just be sure to order the cable for either PS/2 or USB servers at right.)

With its graphical on-screen display (OSD) features, it's easy to switch between and manage connections to your servers. You can also switch using front-panel buttons or hotkeys.

The front panel includes port LEDs, which light with the corresponding active port when you manually switch between servers.

Or set up the ServSwitch EC to scan and switch between servers, one by one, with the convenient AutoScan function. When AutoScan detects any keyboard or mouse activity, it suspends the scanning until activity stops, then resumes with the next computer in sequence.

You can also use the OSD interface to view connection status on each port, lock servers from unauthorized access, and even give names to servers for easy recognition. Edit a server's name entry with up to 14 characters. Nonvolatile memory stores all name entries until you change them, even if the unit is powered down.

The ServSwitch supports video resolutions of up to 1920 x 1440, and it's DDC2B compatible for connections to today's newer digital monitors.

*NOTE: When cascading multiple units, the master must have the same number as or more ports than the slave. The ServSwitch EC for PS/2 and USB Servers and PS/2 Consoles can be cascaded with PS/2 only models (KV9004A, KV9008A, and KV9016A).*

## TECH SPECS

**AutoScan Intervals** — 3, 8, 15, and 30 seconds

**Cable Length (Maximum)** — At console: 20 ft. (6 m);

At PC ports for PS/2 server: 30 ft. (9.1 m);

At PC ports for USB server: 15 ft. (4.5 m)

**Operating Systems Supported** — Windows® 98/Me/XP, Windows NT®, Windows 2000

**Resolution (Maximum)** — 1920 x 1440

**User Controls** — KV9104A: (4) port selection buttons;

KV9108A, KV9116A: (8) port selection buttons

**Connectors** —

KV9104A: Server: (4) HD15 F;

Console: Keyboard: (1) 6-pin mini DIN F;

Mouse: (1) 6-pin mini DIN F;

Monitor: (1) HD15 F;

KV9108A: Server: (8) HD15 F;

Console: Keyboard: (1) 6-pin mini DIN F;

Mouse: (1) 6-pin mini DIN F;

Monitor: (1) HD15 F;

KV9116A: Server: (16) HD15 F;

Console: Keyboard: (1) 6-pin mini DIN F;

Mouse: (1) 6-pin mini DIN F;

Monitor: (1) HD15 F

**Indicators** — KV9104A: (4) Port LEDs;

KV9108A: (8) Port LEDs;

KV9116A: (16) Port LEDs

**Power** — 115 VAC, 60 Hz, external


**Size** — KV9104A: 1.75"H (1U) x 8.6"W x 5.1"D (4.4 x 21.8 x 13 cm);

KV9108A, KV9116A: 1.75"H (1U) x 17.3"W x 7"D (4.4 x 43.7 x 17.8 cm)

**Weight** — KV9104A: 2.2 lb. (1 kg);

KV9108A: 4.8 lb. (2.2 kg);

KV9116A: 5.7 lb. (2.6 kg)



KV9108A: rear view

### Item

### Code

ServSwitch EC for PS/2 and USB Servers and PS/2 Consoles

4-Port

**KV9104A**

8-Port

**KV9108A**

16-Port

**KV9116A**

- ◆ All include (1) AC power adapter, (1) set of foot pads, (2) mounting brackets, and a user's manual.

### You may also need...

ServSwitch EC Server Cable

PS/2

6-ft. (1.8-m)

**EHN70001-0006**

10-ft. (3.0-m)

**EHN70001-0010**

15-ft. (4.5-m)

**EHN70001-0015**

30-ft. (9.1-m)

**EHN70001-0030**

USB

6-ft. (1.8-m)

**EHN9000U-0006**

10-ft. (3.0-m)

**EHN9000U-0010**

15-ft. (4.5-m)

**EHN9000U-0015**

## Free Manuals Download Website

<http://myh66.com>

<http://usermanuals.us>

<http://www.somanuals.com>

<http://www.4manuals.cc>

<http://www.manual-lib.com>

<http://www.404manual.com>

<http://www.luxmanual.com>

<http://aubethermostatmanual.com>

Golf course search by state

<http://golfingnear.com>

Email search by domain

<http://emailbydomain.com>

Auto manuals search

<http://auto.somanuals.com>

TV manuals search

<http://tv.somanuals.com>