



Illustrated Parts List

Model Series

128600

TYPE NUMBERS
0100 through 0902.

TABLE OF CONTENTS

Air Cleaner	6
Blower Housing/Shrouds	7
Camshaft	2
Carburetor	4
Controls	5
Crankshaft	2
Cylinder	2
Cylinder Head	3
Electric Starter	7
Engine Sump	2
Exhaust System	6
Flywheel	7
Flywheel Brake	5
Fuel Supply	4
Governor Spring	5
Ignition	5
Kits/Gaskets Sets	8
Lubrication	2
Piston Group	2
Rewind Starter	7



PRINTED IN U.S.A.


COPYRIGHT by BRIGGS & STRATTON CORPORATION
All rights reserved. No part of this material may be reproduced or transmitted, in any form or by any means, electronic or mechanical, including photocopying, recording or by any information storage and retrieval system, without permission in writing from Briggs & Stratton Corporation.





1319 WARNING LABEL

REQUIRED when replacing parts with warning labels affixed.





1019 LABEL KIT















Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.
 5116-2 Assemblies include all parts shown in frames. 05/29/2008













Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.
5116-3 Assemblies include all parts shown in frames. 05/29/2008













Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.
5116-4 Assemblies include all parts shown in frames. **05/29/2008**







Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.
 5116-5 Assemblies include all parts shown in frames. 05/29/2008



Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.
5116-6 Assemblies include all parts shown in frames. **05/29/2008**



Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.
 5116-7 Assemblies include all parts shown in frames. 05/29/2008



Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
1	692670	Cylinder Assembly	23	697610	Flywheel	26	795431	Ring Set
2	399269	Kit-Bushing/Seal (Magneto Side)			----- Note -----			(Standard)
3	★299819S	Seal-Oil (Magneto Side)			697586 Flywheel Used on Type No(s). 0111.			(Used After Code Date 07090300).
4	493279	Sump-Engine	24	222698S	Key-Flywheel			----- Note -----
		----- Note -----	25	795429	Piston Assembly (Standard)			791969 Ring Set (Standard)
		498983 Sump-Engine Used on Type No(s). 0111.			(Used After Code Date 07090300).			(Used After Code Date 04040400 and Before Code Date 07090400).
5	795501	Head-Cylinder (Used After Code Date 05110100).			----- Note -----			499631 Ring Set (Standard)
		----- Note -----			791968 Piston Assembly (Standard)			(Used Before Code Date 04040500).
		695276 Head-Cylinder (Used Before Code Date 05110200).			(Used Before Code Date 07090400).			795432 Ring Set (.020" Oversize)
7	★△697230	Gasket-Cylinder Head			795430 Piston Assembly (.020" Oversize)			(Used After Code Date 07090300).
8	495786	Breather Assembly			(Used After Code Date 07090300).			791324 Ring Set (.020" Oversize)
9	★699833	Gasket-Breather			791325 Piston Assembly (.020" Oversize)			(Used After Code Date 04102100 and Before Code Date 07090400).
10	691125	Screw (Breather Assembly)			(Used Before Code Date 07090400).			499427 Ring Set (.020" Oversize)
11A	499675	Tube-Breather			Date 07090400).			(Used Before Code Date 04102200).
12	★692232	Gasket-Crankcase						
13	691137	Screw (Cylinder Head)						
15	691680	Plug-Oil Drain (Square Socket)						
16	691457	Crankshaft						
		----- Note -----						
		691456 Crankshaft Used on Type No(s). 0112, 0113, 0116, 0149, 0150, 0151, 0259, 0304, 0339, 0445, 0514, 0551, 0552, 0629, 0660, 0809, 0873, 0901, 0902, 0993, 1102.						
20	★399781S	Seal-Oil (PTO Side)						
22	691092	Screw (Crankcase Cover/ Sump)						
						27	691866	Lock-Piston Pin
						28	499423	Pin-Piston
						29	499424	Rod-Connecting
						32	691664	Screw (Connecting Rod)
						32A	695759	Screw (Connecting Rod)
						33	499642	Valve-Exhaust
						34	499641	Valve-Intake
						35	691304	Spring-Valve (Intake)
						36	691304	Spring-Valve (Exhaust)
						37	694086	Guard-Flywheel
						40	692194	Retainer-Valve
						43	691997	Slinger-Governor/Oil
						45	690977	Tappet-Valve

★ Included in Engine Gasket Set-Ref. No.358.

● Included in Carburetor Overhaul Kit-Ref. No. 121.

◆ Included in Carburetor Gasket Set-Ref. No. 977.

△ Included in Valve Gasket Set-Ref. No 1095.

Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.

128600

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
46	694039	Camshaft	117	498981	Jet-Main (Standard) (Used After Code Date 03110600).	121	792383	Kit-Carburetor Overhaul
51	◆◆◆692668	Gasket-Intake				122	◆◆◆692799	Spacer-Carburetor
51A	◆◆◆697735	Gasket-Intake				122A	792382	Spacer-Carburetor
51B	◆◆◆692555	Gasket-Intake				125	790120	Carburetor (Primer System)
55	691421	Housing-Rewind Starter			----- Note -----	125D	698055	Carburetor (Choke System) (Used After Code Date 02050500). Used on Type No(s). 0111.
58	697316	Rope-Starter (Cut To Required Length) ----- Note -----			498978 Jet-Main (Standard) (Used Before Code Date 03110700).			
		791362 Rope-Starter Used on Type No(s). 0151.			694250 Jet-Main (Standard) (Used After Code Date 02050500). Used on Type No(s). 0111.			
60	281434S	Grip-Starter Rope			498978 Jet-Main (Standard) (Used Before Code Date 02050600). Used on Type No(s). 0111.			694203 Carburetor (Choke System) (Used Before Code Date 02050600). Used on Type No(s). 0111.
65	690837	Screw (Rewind Starter)						
78	691108	Screw (Flywheel Guard)						
95	691636	Screw (Throttle Valve)						
97	499682	Shaft-Throttle (Metal) ----- Note -----	118	497466	Jet-Main (High Altitude) (Used After Code Date 03110600).	127	◆694468	Plug-Welch
		790121 Shaft-Throttle (Plastic)			----- Note -----	130	691203	Valve-Throttle ----- Note -----
104	◆691242	Pin-Float Hinge			498975 Jet-Main (High Altitude) (Used Before Code Date 03110700).			696564 Valve-Throttle (Used With Plastic Throttle Shaft)
108	691182	Valve-Choke			497466 Jet-Main (High Altitude) (Used After Code Date 02050500). Used on Type No(s). 0111.	133	398187	Float-Carburetor
109C	499681	Shaft-Choke			498975 Jet-Main (High Altitude) (Used Before Code Date 02050600). Used on Type No(s). 0111.	134	◆398188	Kit-Needle/Seat
						137	◆◆693981	Gasket-Float Bowl
						146	690979	Key-Timing
						163	◆◆◆691894	Gasket-Air Cleaner
						187	791766	Line-Fuel (Cut to Required Length)
						188	691147	Screw (Control Bracket)
						190	690940	Screw (Fuel Tank)
						192	694543	Adjuster-Rocker Arm
						202	691303	Link-Mechanical Governor

★ Included in Engine Gasket Set-Ref. No.358.

● Included in Carburetor Overhaul Kit-Ref. No. 121.

◆ Included in Carburetor Gasket Set-Ref. No. 977.

△ Included in Valve Gasket Set-Ref. No 1095.

Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.

5116-10

Assemblies include all parts shown in frames.

05/29/2008

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION																																											
209	691851	Spring-Governor ----- Note ----- 691292 Spring-Governor Used on Type No(s). 0116, 0221, 0278, 0339, 0809. 691291 Spring-Governor Used on Type No(s). 0112, 0113, 0115, 0149, 0150, 0151. 691290 Spring-Governor Used on Type No(s). 0111. 791156 Spring-Governor Used on Type No(s). 0339, 0514, 0993. 690319 Spring-Governor Used on Type No(s). 0552, 0660, 0873, 0902.	222F	792398	Bracket-Control (Used After Code Date 05110100). ----- Note ----- 692617 Bracket-Control (Used Before Code Date 05110200). 222H	792397	Bracket-Control (Used After Code Date 05110100). Used on Type No(s). 0111. ----- Note ----- 692618 Bracket-Control (Used Before Code Date 05110200). Used on Type No(s). 0111. 222J	792404	Bracket-Control (Used After Code Date 05110100). Used on Type No(s). 0150, 0151, 0224, 0304, 0339, 0445, 0514, 0551, 0552, 1102. ----- Note ----- 697614 Bracket-Control (Used Before Code Date 05110200). Used on Type No(s). 0150, 0151, 0224, 0304, 0339, 0445, 0514, 0551, 0552. 227	691467	Lever-Governor Control 238	691300	Cap-Valve 259	691189	Bracket-Casing Clamp 265	690798	Clamp-Casing 267	691044	Screw 268	691025	(Casing Clamp) Casing-Control Wire (Cut To Required Length) 269	691026	Wire-Control (Cut To Required Length) 270	691027	Nut (Control Wire Casing) 271	691028	Lever-Control 276	◆ 271716	Washer-Sealing 287	690940	Screw (Dipstick Tube) 300	697590	Muffler-Exhaust 300B	699769	Muffler-Exhaust 304	695976	Housing-Blower ----- Note ----- 499677 Housing-Blower Used on Type No(s). 0113, 0115, 0629, 0902. 499676 Housing-Blower Used on Type No(s). 0111. 305	691108	Screw (Blower Housing) 306	691232	Shield-Cylinder 307	690345	Screw (Cylinder Shield) 309	695550	Motor-Starter (Used Before Code Date 07052900). 309A	795092	Motor-Starter (Used After Code Date 07052800). 310	692327	Bolt (Starter Motor) 332	690662	Nut (Flywheel)

★ Included in Engine Gasket Set-Ref. No.358.

● Included in Carburetor Overhaul Kit-Ref. No. 121.

◆ Included in Carburetor Gasket Set-Ref. No. 977.

△ Included in Valve Gasket Set-Ref. No 1095.

Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.

128600

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
333	802574	Armature-Magneto	529	692937	Grommet	677	690661	Screw
334	691061	Screw (Magneto Armature)	544	690786	Armature-Starter			(Muffler Deflector)
337	692051	Plug-Spark (Resistor)	545	492919	Washer Set (Starter Motor)	670	692294	Spacer-Fuel Tank
		----- Note -----	562	691119	Bolt (Governor-Control Lever)	684	690345	Screw (Breather Passage Cover)
		692720 Plug-Spark (EMS)	584	697734	Cover-Breather Passage	689	691855	Spring-Friction
356	692390	Wire-Stop	585	★691879	Gasket-Breather Passage	697	691127	Screw (Drive Cap)
358	792384	Gasket Set-Engine	592	690800	Nut (Rewind Starter)	703A	697625	Clip
363	19069	Puller-Flywheel	597	691696	Screw (Pawl Friction Plate)	718	690959	Pin-Locating
365	691129	Screw (Carburetor) (Used After Code Date 05110100).	601	791850	Clamp-Hose	741	794388	Gear-Timing (Use Without Woodruff Key) (Used After Code Date 07093000).
		----- Note -----	608	497680	Starter-Rewind			----- Note -----
		691136 Screw (Carburetor) (Used Before Code Date 05110200).			791363 Starter- Rewind Used on Type No(s). 0151.			790345 Gear-Timing (Use Without Woodruff Key) (Used Before Code Date 07100100).
383	19374S	Wrench-Spark Plug	613	691108	Screw (Muffler)			691830 Gear-Timing (Uses Woodruff Key)
404	690272	Washer (Governor Crank)	613A	691140	Screw (Muffler)	742	93941	Retainer-E-Ring
425A	690244	Screw (Air Cleaner Cover)	615	690340	Retainer-Governor Shaft	745	691648	Screw (Brake)
443B	690255	Screw (Air Cleaner Primer Base)	616	698801	Crank-Governor	783	691918	Gear-Pinion
445A	697029	Filter-Air Cleaner Cartridge	619	691108	Screw (Cylinder Head Plate)	783A	691269	Gear-Pinion
455	791960	Cup-Flywheel	621	692310	Switch-Stop	784	795095	Cover-Starter Gear
456	692299	Plate-Pawl Friction	633	◆693867	Seal-Choke/Throttle Shaft (Choke Shaft)	785	692352	Gasket-Starter Cover
459	281505S	Ratchet-Pawl	633A	◆691321	Seal-Choke/Throttle Shaft (Throttle Shaft)	789	696547	Harness-Wiring
474	691991	Alternator	635	66538S	Boot-Spark Plug	801	690782	Cap-Drive
478	697623	Panel	651	691660	Screw (Starter Gear Cover)	802	695267	Cap-End
505	691251	Nut (Governor Control Lever)	676A	393756	Deflector-Muffler	803	695266	Housing-Starter
510	795093	Drive-Starter				830	694544	Stud-Rocker Arm
513	692358	Clutch-Drive				832	691466	Guard-Muffler
523	499621	Dipstick				832C	695593	Guard-Muffler
524	★692296	Seal-Dipstick Tube				836	691147	Screw (Muffler Guard)
525	495265	Tube-Dipstick				836A	697551	Screw (Muffler Guard)

★ Included in Engine Gasket Set-Ref. No.358.

● Included in Carburetor Overhaul Kit-Ref. No. 121.

◆ Included in Carburetor Gasket Set-Ref. No. 977.

△ Included in Valve Gasket Set-Ref. No 1095.

Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.

5116-12

Assemblies include all parts shown in frames.

05/29/2008

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	
842	★691031	Seal-O Ring (Dipstick Tube)	925	795403	Cover-Linkage (Used After Code Date 07072200).	993	★△694088	Gasket-Cylinder Head Plate	
843	691884	Sleeve-Lever			----- Note -----	1005	691346	Fan-Flywheel	
847	692047	Dipstick/Tube Assembly			690595	Cover- Linkage	1019	697624	Kit-Label
851	493880S	Terminal-Spark Plug			(Used Before Code Date 07072300).	1022	★△691890	Gasket-Rocker Cover	
853	695268	Adaptor-Wire	930	692691	Guard-Rewind	1023	499624	Cover-Rocker Arm	
868	★△692044	Seal-Valve	930A	692675	Guard-Rewind	1026	692045	Rod-Push	
883	★△691893	Gasket-Exhaust	935	499421	Switch-Interlock	1029	691230	Arm-Rocker	
886	696268	Gasket Set-Cylinder Head/Plate	937	691325	Spline-Starter	1034	691343	Guide-Push Rod	
910	691094	Stud (Alternator)	946	396526	Guide-Rope	1036		Label-Emissions (Available From A Briggs & Statton Authorized Dealer)	
914	691108	Screw (Rocker Cover)	957	692046	Cap-Fuel Tank (Plastic)	1058	277102	Operator's Manual	
921	692699	Cover-Blower Housing	957B	699985	Cap-Fuel Tank (Plastic)	1059	692311	Kit-Screw/Washer	
921A	699633	Cover-Blower Housing	966B	690243	Base-Air Cleaner Primer	1095	792386	Gasket Set-Valve	
922	692135	Spring-Brake ----- Note -----	967A	273356S	Filter-Pre Cleaner	1102	691255	Pilot-Guide	
		691831	968A	691342	Cover-Air Cleaner	1119	692979	Screw (Alternator)	
		Used on Type No(s). 0113, 0115, 0629, 0902.	968C	692692	Cover-Air Cleaner	1160	690345	Screw (Interlock Switch)	
923	695891	Brake ----- Note -----	969	691138	Screw (Blower Housing Cover)	1210	498144	Pulley/Spring Assembly (Pulley)	
		691994	972	699374	Tank-Fuel (Plastic)	1211	498144	Pulley/Spring Assembly (Spring)	
		Used on Type No(s). 0113, 0115, 0629, 0902.	975	493640	Bowl-Float	1319	794467	Label-Warning	
			976	694395	Primer-Carburetor	1330	272147	Manual-Repair	
			977	792385	Gasket Set-Carburetor				

★ Included in Engine Gasket Set-Ref. No.358.

● Included in Carburetor Overhaul Kit-Ref. No. 121.

◆ Included in Carburetor Gasket Set-Ref. No. 977.

△ Included in Valve Gasket Set-Ref. No 1095.

Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.

5116-13

Assemblies include all parts shown in frames.

05/29/2008

Free Manuals Download Website

<http://myh66.com>

<http://usermanuals.us>

<http://www.somanuals.com>

<http://www.4manuals.cc>

<http://www.manual-lib.com>

<http://www.404manual.com>

<http://www.luxmanual.com>

<http://aubethermostatmanual.com>

Golf course search by state

<http://golfingnear.com>

Email search by domain

<http://emailbydomain.com>

Auto manuals search

<http://auto.somanuals.com>

TV manuals search

<http://tv.somanuals.com>