



326400

Illustrated Parts List

Model Series

326400

TYPE NUMBERS:

0010 through 0080,

0110 through 0399,

0611, 0620,

0630 through 0799,

0801, 0802, 0803, 0804, 0805,

1160, 2520, 2521, 2522, 2526, 2527,

2528, 2529, 2530, 2550, 2560, 2561,

2562, 2563, 2580, 2581, 2582, 2583, 2596.


Not for
Reproduction



PRINTED IN U.S.A.

COPYRIGHT by BRIGGS & STRATTON CORPORATION
All rights reserved. No part of this material may be reproduced or transmitted,
in any form or by any means, electronic or mechanical, including photocopying,
recording or by any information storage and retrieval system, without permission
in writing from Briggs & Stratton Corporation.


326400



REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
1	395663	Cylinder Assembly	308	691731	Cover-Cylinder Head (Used After Code Date 75060800). ----- Note ----- 221953 Cover- Cylinder Head (Used Before Code Date 75060900). Used on Type No(s). 0291, 0648.	870	691583	Seat-Valve (Exhaust)
5	691712	Head-Cylinder				871	231218	Bushing-Valve Guide
6	691261	Washer (Cylinder Head)				989	690578	Stop Switch- Spark Plug ----- Note ----- 293739 Stop Switch- Spark Plug Used on Type No(s). 0200.
7	692231	Gasket-Cylinder Head	322	692198	Screw (Cylinder Head Cover)			298926 Stop Switch- Spark Plug Used on Type No(s). 0028, 0062, 0138, 0187, 0195, 0220, 0232, 0237, 0238, 0243, 0266, 0295, 0320, 0327, 0658, 0663, 0675, 0680, 0681, 0687, 0691, 0729, 0730, 0735, 2528, 2562.
8	495738	Breather Assembly	337	802592s	Plug-Spark			390785 Stop Switch- Spark Plug Used on Type No(s). 0640, 0734.
9	27803s	Gasket-Breather	342	298125s	Plunger-Breaker			
10	690294	Screw (Breather Assembly)	362	793351	Shield-Spark Plug			
11	691512	Tube-Breather	383	89838	Wrench-Spark Plug			
13	691614	Screw (Cylinder Head) (1 3/4" Long) ----- Note ----- 691640 Screw (Cylinder Head) (2 1/16" Long)	406	690533	Spring-Breather Tube Plug			
13A	691441	Screw (Cylinder Head) (2 7/16" Long)	415	692882	Plug (Cylinder)			
14	691690	Stud (Cylinder Head)	552	393666	Bushing- Governor Crank			
15	692833	Plug-Oil Drain	626	690512	Spacer- Governor Crank			
306	299536	Shield-Cylinder	635	66538s	Boot-Spark Plug			
307	690294	Screw (Cylinder Shield)	645	692880	Bushing-Plunger			
			722	68768	Seal-Plunger			
			724	93516	Retainer-Seal			
			724A	221873	Retainer-Seal	989A	690633	Stop Switch- Spark Plug

Engine Gasket Set-Reference 358
Carburetor Overhaul Kit-Reference 121


Valve Gasket Set-Reference 1095



REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
25	792365	Piston Assembly (Standard) ----- Note ----- 792367 Piston Assembly (.020 Oversize)	42	494553	Keeper-Valve (Used After Code Date 80111200). ----- Note ----- 68283 Keeper-Valve (Used Before Code Date 80111300).	598	270516	Shim-End Play (Camshaft Bearing) (.009 Thick) ----- Note ----- 270517 Shim-End Play (Camshaft Bearing) (.007 Thick)
26	792366	Ring Set (Standard) ----- Note ----- 792368 Ring Set (.020 Oversize)	45	691594	Tappet-Valve	626	690512	Spacer-Governor Crank
27	691792	Lock-Piston Pin	46	692855	Camshaft	742	691080	Retainer-E Ring
28	299691	Pin-Piston	219	291192	Gear-Governor (Used Before Code Date 78062000).	743	691153	Gear-Drive
29	299632	Rod-Connecting	219A	393720	Gear-Governor	746	691803	Gear-Idler
30	691726	Dipper-Connecting Rod	221	841026	Cup-Governor	755	299706	Bearing-Camshaft
31	690396	Lock-Rod Screw	225	691357	Shaft-Governor Gear	900	691767	Shaft-Gear
32	692345	Screw (Connecting Rod)	407	690810	Screw (Camshaft Bearing)	900A	691768	Shaft-Gear
33	394436	Valve-Exhaust	511	690402	Washer (Camshaft Bearing)	1143	691081	Screw (Drive Gear Cover)
34	394435	Valve-Intake	552	393666	Bushing-Governor Crank	1144	690301	Washer (Drive Gear Cover)
35	691597	Spring-Valve (Intake)	553	690269	Retainer-Valve Spring			
36	691597	Spring-Valve (Exhaust)	591	691746	Plug-Camshaft			
40	691939	Retainer-Valve ----- Note ----- 690274 Retainer-Valve Used on Type No(s). 0722.						

Engine Gasket Set-Reference 358
Carburetor Overhaul Kit-Reference 121


Valve Gasket Set-Reference 1095



REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
16	691797	Crankshaft ----- Note ----- 690534 Crankshaft Used on Type No(s). 0237, 0133, 0190, 0252, 0315, 0788, 2582. 261222 Crankshaft Used on Type No(s). 0139, 0204, 0228, 0328, 0678. 690535 Crankshaft Used on Type No(s). 0050, 0116, 0130, 0143, 0147, 0149, 0150, 0151, 0156, 0167, 0170, 0172, 0173, 0174, 0185, 0186, 0188, 0192, 0193, 0208, 0219, 0231, 0248, 0257, 0286, 0290, 0310, 0317, 0318, 0329, 0337, 0343, 0371, 0636, 0638, 0666, 0669, 0684, 0690, 0706, 0721, 0751, 2550. 690536 Crankshaft Used on Type No(s). 0022, 0063, 0114, 0129, 0153, 0175, 0176, 0183, 0198, 0205, 0217, 0224, 0233, 0235, 0236, 0238, 0247, 0255, 0261, 0265, 0266, 0273, 0277, 0278, 0279, 0285, 0287, 0291, 0296, 0303, 0320, 0334, 0338, 0340, 0344, 0345, 0346, 0347, 0348, 0353, 0359, 0361, 0363, 0366, 0367, 0374, 0375, 0383, 0385, 0394, 0396, 0633, 0634, 0648, 0650, 0654, 0661,			0671, 0674, 0676, 0680, 0687, 0692, 0693, 0694, 0696, 0698, 0699, 0702, 0703, 0708, 0714, 0718, 0722, 0724, 0729, 0733, 0736, 0746, 0753, 0754, 0757, 0764, 0771, 0772, 0774, 0776, 0782, 0787, 2522, 2563, 2596. Crankshaft (NO LONGER AVAILABLE) Used on Type No(s). 0158, 0160, 0197, 0216, 0237. 690537 Crankshaft Used on Type No(s). 0210, 0262, 0630. 690540 Crankshaft Used on Type No(s). 0062, 0241, 0242, 0243, 0244, 0260, 0269, 0272, 0292, 0295, 0297, 0300, 0302, 0312, 0327, 0352, 0365, 0369, 0373, 0391, 0635, 0670, 0681, 0686, 0691, 0719, 0723, 0726, 0730, 0732, 0735, 0737, 0740, 0744, 0745, 0750, 0755, 0759, 0780, 0786, 2562. 690541 Crankshaft Used on Type No(s). 0061, 0124, 0246, 0253, 0305, 0308, 0335, 0341, 0342, 0646, 0710, 0711, 0713, 0728, 0781, 0785, 2529, 2561.			690543 Crankshaft Used on Type No(s). 0259, 0293, 0647, 0756. 691806 Crankshaft (Used After Code Date 77072410). Used on Type No(s). 0021, 0112, 0128, 0181, 0189, 0203, 0209, 0254, 0256, 0258, 0314, 0321, 0357, 0362, 0368, 0395, 0656, 0668, 0675, 0709, 0717, 0739, 0743, 0752, 0765, 0778, 0779, 0784, 0789, 0790, 0792, 0793, 0794, 0801, 0802, 0804, 2521, 2526, 2530. Crankshaft (Used Before Code Date 77072510). (NO LONGER AVAILABLE) Used on Type No(s). 0021, 0112, 0128, 0181, 0189, 0203, 0209, 0254, 0256, 0258, 0314, 0321, 0357, 0362, 0368, 0395, 0656, 0668, 0675, 0709, 0717, 0739, 0743, 0752, 0765, 0778, 0779, 0784, 0789, 0790, 0792, 0793, 0794, 0801, 0802, 0804, 2521, 2526, 2530. 690546 Crankshaft Used on Type No(s). 0682, 2560. 261944 Crankshaft Used on Type No(s). 0720, 0758, 0788.
						17	691938	Bearing-Ball
						24	222698s	Key-Flywheel
						357	691483	Key-Drive Pulley

Engine Gasket Set-Reference 358
Carburetor Overhaul Kit-Reference 121


Valve Gasket Set-Reference 1095



REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
15A	690946	Plug-Oil Drain	568	294751	Base-Engine	569	691569	Gasket-Engine Base
15B	691680	Plug-Oil Drain			Used on Type No(s).	998	690307	Pipe-Oil
21	281658s	Cap-Oil Fill			0062, 0120, 0121,	998A	690502	Pipe-Oil
567	691104	Screw			0123, 0126, 0127,			
		(Engine Base)			0133, 0135, 0136,			
568	294751	Base-Engine			0140, 0144, 0149,			
		Used on Type No(s).			0157, 0158, 0162,			
		0020, 0023, 0050,			0163, 0164, 0165,			
		0139, 0145, 0150,			0169, 0170, 0172,			
		0151, 0152, 0155,			0173, 0174, 0178,			
		0159, 0175, 0191,			0180, 0182, 0183,			
		0199, 0203, 0206,			0184, 0185, 0186,			
		0208, 0212, 0218,			0190, 0192, 0198,			
		0219, 0226, 0356,			0201, 0204, 0205,			
		0804, 2527, 2583.			0210, 0215, 0222,			
		----- Note -----			0223, 0227, 0228,			
		291404 Base-			0230, 0234, 0235,			
		Engine			0240, 0246, 0248,			
		Used on Type No(s).			0252, 0253, 0254,			
		0134, 0135.			0255, 0259, 0262,			
					0283, 0284, 0291,			
					0293, 0306, 0308,			
					0310, 0311, 0312,			
					0315, 0316, 0326,			
					0328, 0331, 0333,			
					0341, 0351, 0354,			
					0360, 0384, 0392,			
					0630, 0638, 0647,			
					0648, 0649, 0659,			
					0660, 0669, 0673,			
					0678, 0679, 0686,			
					0705, 0712, 0723,			
					0724, 0725, 0726,			
					0732, 0735, 0737,			
					0740, 0744, 0750,			
					0755, 0756, 0759,			
					0780, 0781, 0786,			
					2562, 2581, 2582.			

Engine Gasket Set-Reference 358
Carburetor Overhaul Kit-Reference 121


Valve Gasket Set-Reference 1095



REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
3	691948	Seal-Oil (Magneto Side)	525	690622	Tube-Dipstick	587	690389	Clamp-Cable
276	690258	Washer-Sealing			----- Note -----	665	298860	Minder-Oil
338	690270	Gasket-Dipstick			690623 Tube-Dipstick	665A	692939	Minder-Oil
366	690304	Screw (Timing Hole Plug)			Used on Type No(s).	704	691083	Screw
399	691310	Gasket- Counterweight Cover (Magneto Side)			0121, 0144, 0157, 0158, 0164, 0165, 0169, 0170, 0182, 0184, 0192, 0198, 0210, 0222, 0234, 0235, 0240, 0248, 0262, 0266, 0309, 0312, 0316, 0331, 0338, 0341, 0351, 0358, 0630, 0638, 0679, 0705, 0707, 0724, 0744, 0750, 0755, 0770, 1160, 2581.	749	391061	Cover-Counterweight
399A	692914	Gasket- Counterweight Cover (PTO Side)				749A	391361	Cover-Counterweight (Used on Alternator Equipped Engines)
523	691352	Dipstick				758	393164	Counterweight
523A	690620	Dipstick				1054	280275	Tie-Cable
524	281370s	Seal-Dipstick Tube						

Engine Gasket Set-Reference 358
Carburetor Overhaul Kit-Reference 121


Valve Gasket Set-Reference 1095



REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION			
90	391065	Carburetor ----- Note ----- 391068 Carburetor Used on Type No(s). 0121, 0144, 0157, 0158, 0164, 0165, 0169, 0170, 0184, 0192, 0240, 0331. 391070 Carburetor Used on Type No(s). 0127, 0133, 0134, 0135, 0136, 0139, 0140, 0149, 0162, 0163, 0166, 0172, 0173, 0180, 0185, 0186, 0201, 0204, 0206, 0211, 0212, 0213, 0226, 0227, 0228, 0229, 0249, 0251, 0271, 0298, 0326, 0328, 0332. 392035 Carburetor Used on Type No(s). 0182, 0210, 0222, 0309. 393431 Carburetor Used on Type No(s). 0262, 0630.	109	691353	Shaft-Choke ----- Note ----- 690617 Shaft-Choke Used on Type No(s). 0121, 0127, 0133, 0134, 0135, 0136, 0139, 0140, 0144, 0149, 0157, 0158, 0162, 0163, 0164, 0165, 0166, 0169, 0170, 0172, 0180, 0184, 0185, 0186, 0192, 0201, 0204, 0206, 0211, 0212, 0213, 0226, 0227, 0228, 0229, 0249, 0251, 0271, 0298, 0326, 0328, 0332, 2581, 2582.	134	394681	Kit-Needle/Seat ----- Note ----- 394682 Kit-Needle/ Seat (Includes Brass Seat) 394683 Kit-Needle/ Seat (Includes Brass Seat) (For Use With Impulse Pump)	1227	99525s	Valve-High Speed

Engine Gasket Set-Reference 358
Carburetor Overhaul Kit-Reference 121

Valve Gasket Set-Reference 1095




REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
50	691152	Manifold-Intake ----- Note ----- 692525 Manifold-Intake Used on Type No(s). 0248, 0308, 0358, 0638, 0707, 0770.	94	292681	Kit-Idle Mixture	150	691610	Gasket-Nozzle
51	27381	Gasket-Intake	95	691437	Screw (Throttle Valve)	158	27590	Plug- Carburetor Filter/Drain
51A	692214	Gasket-Intake	97	691944	Shaft-Throttle	186	691764	Connector-Hose
54	691681	Screw (Intake Manifold)	98	693942	Kit-Idle Speed	231	691437	Screw (Choke Valve)
90		Carburetor (See Previous Page)	101	691616	Pin-Shaft	267	691082	Screw (Casing Clamp)
91	299687	Body- Upper Carburetor ----- Note ----- 391067 Body- Upper Carburetor Used on Type No(s). 0121, 0144, 0157, 0158, 0164, 0165, 0169, 0170, 0182, 0184, 0192, 0240, 0309, 0331, 0630, 0707, 0724, 0770.	102	692215	Gasket- Carburetor Body	689	691591	Spring-Friction
			104	691775	Pin-Float Hinge	689A	691590	Spring-Friction Retainer- Carburetor Drain (NO LONGER AVAILABLE)
			107	391069	Body- Lower Carburetor	800		
			108	690621	Valve-Choke	971	691090	Screw (Air Cleaner Base to Carburetor)
			109		Shaft-Choke (See Previous Page)	1146	691587	Screw (Choke Shaft)
			110	691186	Washer (Choke Shaft)	1227		Valve-High Speed (See Previous Page)
			127	690627	Plug-Welch			
			130	691727	Valve-Throttle			
			132	691708	Stop-Throttle			
			133	692265	Float-Carburetor Kit-Needle/Seat (See Previous Page)			
			134					
			142	691966	Nozzle-Carburetor (Standard) (Labeled B) (Used After Code Date 81090800).			

Engine Gasket Set-Reference 358
Carburetor Overhaul Kit-Reference 121

Valve Gasket Set-Reference 1095


326400



REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
162	690267	Collar-Bell Crank	212	691791	Link-Throttle	268	691025	Casing-Control Wire (Cut to Required Length)
201	261027	Link-Air Vane Used on Type No(s). 0234, 0705.			----- Note ----- 691595 Link-Throttle Used on Type No(s). 0248, 0308, 0358, 0638, 0707, 0770.	269	691026	Wire-Control (Cut to Required Length)
203	690263	Crank-Bell	227	690607	Lever-Governor Control	270	691027	Nut (Control Wire Casing)
205	691681	Screw (Bell Crank) Used on Type No(s). 0136, 0139, 0204, 0228, 0234, 0248, 0328, 0678, 0705.			----- Note ----- 690616 Lever-Governor Control Used on Type No(s). 0611, 0630, 0647, 0651, 0684, 0690, 0706, 0721, 0660, 0671, 0675, 0681, 0683, 0685, 0689, 0692, 0694, 0697, 0699, 0801, 2520, 2527, 2528, 2529, 2550, 2561, 2581, 2582.	271	691028	Lever-Control ----- Note ----- 221987 Lever-Control Used on Type No(s). 0678, 0705.
205A	690810	Screw (Bell Crank)	232	690545	Spring-Governor Link	404	690264	Washer (Governor Crank)
206	691079	Nut-Governor Adjusting			----- Note ----- 692207 Spring-Governor Link Used on Type No(s). 0248, 0308, 0358, 0638, 0707, 0770.	414	692810	Washer (Bell Crank) Used on Type No(s). 0136, 0139, 0204, 0228, 0234, 0248, 0328, 0678, 0705.
206A	691584	Nut-Governor Adjusting	266	494554	Control-Throttle	505	691251	Nut (Governor Control Lever)
208	393613	Rod-Governor Control			----- Note ----- Control-Throttle (Dial Control) (NO LONGER AVAILABLE) Used on Type No(s). 0640, 0652, 0653, 0665.	562	92613	Bolt (Governor Control Lever)
209	691596	Spring-Governor				614	691620	Pin-Cotter
		----- Note ----- 691789 Spring-Governor Used on Type No(s). 0611, 0630, 0647, 0651, 0690, 0760, 0781, 0801, 2520, 2527, 2528, 2529, 2550, 2581, 2582.				616	291364	Crank-Governor
211	691790	Spring-Governed Idle Used on Type No(s). 0611, 0630, 0647, 0651, 0690, 0760, 0781, 0801, 2520, 2527, 2528, 2529, 2550, 2581, 2582.				629	690538	Spring-Throttle Return Used on Type No(s). 0234, 0631, 0632, 0637, 0641, 0642, 0705, 0803, 2580.
						668	690313	Spacer (Governor Control Rod)

Engine Gasket Set-Reference 358
Carburetor Overhaul Kit-Reference 121

Valve Gasket Set-Reference 1095




REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
163	67247	Gasket-Air Cleaner Used on Type No(s). 0308.	171	691331	Nut (Air Cleaner)	643	691730	Retainer-Air Filter
163A	270987	Gasket-Air Cleaner	171A	690284	Nut (Air Cleaner)	967	271794s	Filter-Pre Cleaner
166	691241	Stud-Air Cleaner (9 1/2" Long)	445	393957s	Filter- Air Cleaner Cartridge	968	691755	Cover-Air Cleaner
			467	691668	Knob-Air Cleaner	1158	690293	Screw (Carburetor) (Used to Plug Air Cleaner Stud Hole)
			536	391063	Cleaner-Air			Used on Type No(s). 0262, 0630.

Engine Gasket Set-Reference 358
Carburetor Overhaul Kit-Reference 121

Valve Gasket Set-Reference 1095


326400



REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
81	691178	Lock-Muffler Screw				677	794845	Screw (Muffler Deflector) (Metric)
237	690409	Retainer-Muffler Guard				677A	690661	Screw (Muffler Deflector) (SAE)
264	691105	Nut (Muffler Adapter)	346	794845	Screw (Spark Arrestor) (Metric)	725	690420	Shield-Heat
298	691808	Locknut-Muffler/Elbow	346A	690661	Screw (Spark Arrestor) (SAE)	823	690810	Screw (Muffler Adapter)
300	393232s	Muffler	613	691416	Screw (Muffler)	832	690648	Guard-Muffler
300A	498984s	Muffler	613A	690297	Screw (Muffler) (Used After Code Date 97012300).	834	691075	Washer (Muffler Adapter)
300B	392989	Muffler				836	691083	Screw (Muffler Guard) (1" Long)
300C	291519	Muffler				836A	690367	Screw (Muffler Guard) (2/3" Long)
300D	399635	Muffler				863	694016	Bracket-Muffler
301	93734	Pipe-Exhaust (8" Long)				864	394584	Adapter-Muffler
301B	91416	Pipe-Exhaust (1 1/2" Long) Used on Type No(s). 0163, 0327.				864A	690637	Adapter-Muffler
303	690281	Elbow-Exhaust				883	692236	Gasket-Exhaust
303A	91296	Elbow-Exhaust (1", 90 Degree) Used on Type No(s). 0391, 0686, 0726, 0732, 0737, 0744, 0750, 0759, 0781.				944	691690	Stud (Muffler Adapter)
			676	795036	Deflector-Muffler	994	794945	Arrestor-Spark
			676A	795038	Deflector-Muffler			
			676B	396903	Deflector-Muffler			

Engine Gasket Set-Reference 358
Carburetor Overhaul Kit-Reference 121


Valve Gasket Set-Reference 1095



REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
179	690280	Screw (Fuel Tank Strap)	187	841589	Line-Fuel (Cut to Required Length)	245	692190	Gasket-Fuel Bowl
182	691068	Bracket-Fuel Tank ----- Note ----- 222669 Bracket-Fuel Tank Used on Type No(s). 0205, 0291, 0648.			----- Note ----- 89248 Line-Fuel (2 1/4" Long) Used on Type No(s). 0080, 0386, 0387, 0393, 0395, 0396, 0397, 0631, 0640, 0641, 0662, 2580.	246	298683	Bowl-Fuel Filter
182A	690262	Bracket-Fuel Tank	195	91635	Nipple-Fuel	247	691700	Yoke-Bowl
183	691937	Strap-Fuel Tank ----- Note ----- 291367 Strap-Fuel Tank (4 Quart) Used on Type No(s). 0206, 0211, 0213, 0229, 0271.	199	692302	Valve-Fuel Shut Off	385	692198	Screw (Fuel Pump)
186	691764	Connector-Hose	199A	691940	Valve-Fuel Shut Off	378	808656	Pump-Fuel
186A	691609	Connector-Hose	210	691962	Strainer-Fuel	450	691075	Washer (Fuel Tank Bracket)
186B	231238	Connector-Hose	240	298090s	Filter-Fuel (Red) ----- Note ----- 394358s Filter-Fuel (White) Used on Type No(s). 0630, 0705, 0707, 0724, 0744, 0750, 0755, 0759, 0770, 0774, 2581.	601	791850	Clamp-Hose
			240A	690612	Filter-Fuel	670	690505	Spacer-Fuel Tank
						674	690303	Screw (Fuel Tank Bracket)
						707	690279	Nut (Fuel Tank Strap)
						788	224123	Bracket-Fuel Pump
						861	394462	Kit-Fuel Pump (Walbro) ----- Note ----- 791885 Kit-Fuel Pump Used on Type No(s). 0170, 0182, 0198, 0248, 0309, 0331, 0638, 0679, 0744, 0755, 0759.
						917	691737	Handle-Shut Off Valve
						918	393815	Hose-Vacuum (Cylinder To Impulse Pump) (Cut to Required Length)

Engine Gasket Set-Reference 358
Carburetor Overhaul Kit-Reference 121


Valve Gasket Set-Reference 1095



REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
180	291488	Tank-Fuel (6 Quart) ----- Note ----- 290816 Tank-Fuel (4 Quart) 292415 Tank-Fuel (8 Quart) Used on Type No(s). 0137, 0140, 0141, 0143, 0148, 0151, 0152, 0153, 0156, 0162, 0163, 0167, 0172, 0173, 0175, 0176, 0178, 0180, 0181, 0183, 0185, 0186, 0197, 0199, 0201, 0203, 0205, 0212, 0215, 0219, 0226, 0227, 0242, 0245, 0249, 0254, 0255, 0257, 0259, 0273, 0282, 0284, 0286, 0289, 0291, 0293, 0300, 0303, 0307, 0311, 0318,			0330, 0336, 0347, 0354, 0369, 0372, 0376, 0377, 0381, 0384, 0392, 0635, 0640, 0647, 0648, 0657, 0659, 0661, 0664, 0666, 0674, 0682, 0685, 0690, 0694, 0696, 0697, 0698, 0704, 0712, 0714, 0721, 0723, 0729, 0730, 0743, 0745, 0746, 0754, 0757, 0771, 0772.	181	791545	Cap-Fuel Tank (Chrome)

Engine Gasket Set-Reference 358
Carburetor Overhaul Kit-Reference 121


Valve Gasket Set-Reference 1095



REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	
23	395250	Flywheel (For Magnetron Ignition, Identified by Two Red Stripes) Used on Type No(s). 0611, 0620, 0632, 0633, 0635, 0637, 0640, 0641, 0642, 0644, 0645, 0646, 0647, 0648, 0650, 0651, 0652, 0655, 0656, 0657, 0659, 0662, 0664, 0670, 0674, 0677, 0681, 0683, 0686, 0689, 0690, 0691, 0694, 0695, 0696, 0700, 0706, 0709, 0710, 0713, 0717, 0722, 0723, 0727, 0728, 0730, 0734, 0735, 0737, 0739, 0743, 0744, 0745, 0747, 0750, 0755, 0756, 0757, 0759, 0762, 0763, 0766, 0775, 0778, 0780, 0785, 0786, 0790, 0791, 0792, 0793, 0794, 0799, 0801, 0802, 0803, 0804, 2520, 2521, 2522, 2529, 2530, 2550, 2560, 2561, 2562, 2580, 2581, 2582, 2583.	23A	395251	Flywheel (For Magnetron Ignition, Identified by Two Red Stripes) ----- Note ----- Flywheel (NO LONGER AVAILABLE) (For Magnetron Ignition, Identified by Two Red Stripes) Used on Type No(s). 0736. 391363 Flywheel (10 Amp) (Used With Breaker Points and Condenser System) Used on Type No(s). 0027, 0028, 0063, 0115, 0123, 0126, 0135, 0143, 0148, 0149, 0162, 0163, 0164, 0165, 0167, 0168, 0170, 0171, 0172, 0174, 0178, 0180, 0182, 0184, 0185, 0188, 0189, 0192, 0193, 0198, 0201, 0209, 0210, 0211, 0213, 0215, 0217, 0221, 0222, 0224, 0229, 0230, 0231, 0234, 0235, 0236, 0238, 0240, 0248, 0249, 0250, 0251, 0252, 0257, 0261, 0262, 0265, 0271, 0273, 0274, 0275, 0276, 0277, 0278, 0279, 0281,				0282, 0283, 0284, 0285, 0286, 0287, 0288, 0296, 0298, 0303, 0304, 0306, 0307, 0309, 0310, 0311, 0315, 0316, 0317, 0318, 0319, 0320, 0321, 0322, 0323, 0324, 0325, 0326, 0328, 0330, 0331, 0332, 0333, 0334, 0337, 0338, 0340, 0343, 0347, 0348, 0349, 0350, 0351, 0353, 0355, 0358, 0359, 0360, 0363, 0364, 0367, 0370, 0371, 0372, 0374, 0375, 0376, 0377, 0378, 0379, 0381, 0382, 0383, 0388, 0389, 0392, 0394, 0399.
	363	19203				363	19203	Puller-Flywheel	
						726	391362	Gear-Ring (Includes Mounting Hardware)	

Engine Gasket Set-Reference 358
Carburetor Overhaul Kit-Reference 121

Valve Gasket Set-Reference 1095




REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
73	691171	Screen-Rotating ----- Note ----- 690404 Screen-Rotating Used on Type No(s). 0127, 0133, 0182, 0190, 0210, 0222, 0252, 0262, 0315, 0333, 0630, 0649, 2582, 2583.	74	691655	Screw (Rotating Screen)	440	691076	Screw (Booster Fan)
			75	691056	Washer (Flywheel)	773	690265	Retainer
			321	691151	Fan-Booster	838	211983	Adapter- Blower Housing Ring
			321A	690377	Fan-Booster			
			321B	212000	Fan-Booster			
			331	691075	Washer (Booster Fan)			
73A	690410	Screen-Rotating	332	691059	Nut (Flywheel)			


Engine Gasket Set-Reference 358
Carburetor Overhaul Kit-Reference 121

Valve Gasket Set-Reference 1095

304



304A







305 

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
304	294698	Housing-Blower ----- Note ----- 297010 Housing-Blower Used on Type No(s). 0060, 0119, 0160, 0197, 0216, 0223, 0237. 297453 Housing-Blower Used on Type No(s). 0020, 0023, 0050, 0136, 0139, 0140, 0145, 0150, 0151, 0152, 0155, 0159, 0175, 0181, 0183, 0191, 0199, 0203, 0204, 0205, 0206, 0208, 0212, 0218, 0219, 0226, 0227, 0228, 0254, 0255, 0259. 391229 Housing-Blower Used on Type No(s). 0027, 0028, 0063, 0115, 0123, 0126, 0135, 0143, 0148, 0149, 0162, 0163, 0165, 0167, 0168, 0170, 0171, 0172, 0174, 0178, 0180, 0182, 0184, 0185, 0188, 0189, 0192, 0193, 0198, 0201, 0209, 0210, 0211, 0213, 0215, 0217, 0221, 0224, 0229, 0230, 0231, 0234, 0235, 0236, 0238,			0248, 0249, 0259, 0251, 0252, 0257, 0261, 0262, 0265, 0271, 0273, 0275, 0276, 0277, 0278, 0279, 0281, 0282, 0283, 0284, 0285, 0286, 0287, 0288, 0296, 0298, 0303, 0304, 0306, 0307, 0309, 0310, 0311, 0315, 0316, 0317, 0318, 0319, 0320, 0321, 0322, 0323, 0324, 0325, 0326, 0328, 0330, 0331, 0332, 0333, 0334, 0337, 0338, 0340, 0343, 0347, 0348, 0349, 0350, 0351, 0353, 0355, 0358, 0359, 0360, 0363, 0364, 0367, 0370, 0371, 0372, 0374, 0375, 0376, 0377, 0378, 0379, 0381, 0382, 0383, 0388, 0389, 0392, 0394, 0399, 0630, 0634, 0636, 0638, 0640, 0643, 0649, 0653, 0654, 0658, 0660, 0661, 0663, 0665, 0666, 0667, 0668, 0669, 0671, 0672, 0673, 0675, 0676, 0678, 0679, 0680, 0684, 0685, 0687, 0688, 0692, 0693, 0697, 0698, 0699,			0701, 0702, 0703, 0704, 0705, 0707, 0708, 0712, 0714, 0715, 0716, 0718, 0720, 0721, 0724, 0725, 0729, 0731, 0733, 0736, 0738, 0741, 0742, 0746, 0748, 0749, 0751, 0752, 0753, 0754, 0760, 0761, 0764, 0765, 0770, 0771, 0772, 0774, 0776, 0779, 0782, 0783, 0784, 0787, 0789, 0797, 2527, 2528, 2563, 2596. 692359 Housing-Blower Used on Type No(s). 0682. 395513 Housing-Blower Used on Type No(s). 0711, 0719, 0732, 0740, 0781, 2529. 399177 Housing-Blower Used on Type No(s). 0758, 0788.
						304A	392343	Housing-Blower (Low Profile) Used on Type No(s). 0713, 0744, 0750, 0755, 0759, 0780, 0785, 0786, 2561, 2562.
						305	692198	Screw (Blower Housing)

Engine Gasket Set-Reference 358
Carburetor Overhaul Kit-Reference 121

Valve Gasket Set-Reference 1095


326400



REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
197	90072	Screw (Back Plate)	452	92864	Washer (Back Plate)	668A	231065	Spacer Used on Type No(s). 0164, 0240.
215	222445	Guide-Air	452B	26404	Washer (Back Plate)	685	690661	Screw (Rectifier)
316	691612	Nut (Back Plate)	452C	691077	Washer (Back Plate)	727	692338	Cover-Starter Drive
318	691666	Screw (Mounting Bracket)	488	222211	Bracket-Fuse	729	690432	Clip-Wire (Alternator)
344	690305	Screw (Cable Clamp)	488A	222345	Bracket-Fuse	729A	690588	Clip-Wire
367	690305	Screw (Wire Clip)	573	391220	Plate-Back (Used on Engines With Electric Start Only)	732	93410	Screw (Starter Drive Cover)
384	690371	Washer (Back Plate)	573A	299450	Plate-Back	736	690302	Nut-Clip
405	690290	Screw (Back Plate)	587	690389	Clamp-Cable	895	692309	Switch-Rotary
			588A	690375	Bracket-Armature (Used on Engines With Electric Starter)			
			589	690300	Screw (Armature Bracket)			

Engine Gasket Set-Reference 358
Carburetor Overhaul Kit-Reference 121




Valve Gasket Set-Reference 1095



REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	
55	691355	Housing- Rewind Starter (Low Profile)		66574	Rope- Starter (99" Long) (Cut to Required Length) (Use With Metal Pulley)	289	230228s	Pin- Starter Grip	
56	392630	Pulley- Starter (Low Profile)		60	490652	Grip- Starter Rope	458	69932s	Kit- Handle/ Rope
56A	295871	Pulley- Starter (Wide Legs Starter Housing, Includes 63" Rope)	61	68848s	Bumper- Starter Pulley (Wide Legs Starter Housing)	592	690276	Nut (Rewind Starter)	
57	490179	Spring- Rewind Starter	63	690547	Spring- Ratchet Adapter- Ratchet Spring (Low Profile)	608	691958	Starter- Rewind	
58	692188	Rope- Starter (63" Long) (Use With Plastic Pulley)	64			655	691734	Anchor- Rewind Spring	
		----- Note -----				655A	221014	Anchor- Rewind Spring (Wide Legs Starter Housing)	
		695002 Rope- Starter (99" Long) (Cut to Required Length) (Use With Plastic Pulley)	64A	691920	Adapter- Ratchet Spring (Wide Legs Starter Housing)	678	490817	Spacer- Rewind	
		66564 Rope- Starter (63" Long) (Use With Metal Pulley)	65	691693	Screw (Rewind Starter) (3/8" Long)	1140	690286	Washer (Rewind Starter)	
			65A	93254	Screw (Rewind Starter) (7/16" Long)				

Engine Gasket Set-Reference 358
Carburetor Overhaul Kit-Reference 121


Valve Gasket Set-Reference 1095



REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
66	393127s	Clutch-Starter	69	690271	Washer (Starter Clutch)	71	691359	Cover-Ratchet Screw (Starter Clutch)
66A	399671	Clutch-Starter (Sealed)	69A	690260	Washer (Starter Clutch)	257	690309	Screw (Starter Clutch)
67	690542	Housing-Clutch	69B	690277	Washer (Starter Clutch)			
67A	394897	Housing-Clutch	70	691945	Ratchet-Clutch			
68	691604	Ball-Clutch						

Engine Gasket Set-Reference 358
Carburetor Overhaul Kit-Reference 121

Valve Gasket Set-Reference 1095




REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
323	68898	Belt-Vee (For Low Position Mounting) (35 3/4" Long) ----- Note ----- 68878 Belt-Vee (For High Position Mounting) (36 3/4" Long)	526	690297	Screw (Regulator)	890	221472	Bracket-Support
361	691681	Screw (Starting Switch)	575	692303	Switch-Starting	1217	690282	Washer (Starting Switch)
501		Regulator (Saddle Mount) (Delco Remy Number 1119577) (NO LONGER AVAILABLE)	606	221442	Strap-Adjusting	1225	691029	Nut (Starting Switch)
			636	696198	Nut (Starting Switch) (Terminal)			
			641	691075	Washer (Starting Switch) (Terminal)			
			652	693972	Screw (Support Bracket)			

Engine Gasket Set-Reference 358
Carburetor Overhaul Kit-Reference 121

Valve Gasket Set-Reference 1095


326400



REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
356	398808	Wire-Stop	795	298590	Switch-Toggle	1215	691075	Washer (Starter Bracket)
361	93415	Screw (Starting Switch)	840	298561	Kit-Panel (Generator Panel)	1216	691105	Nut (Starter Bracket)
493		Bracket-Mounting (NO LONGER AVAILABLE)	945	211785	Bracket-Starter Motor	1217	690282	Washer (Starting Switch)
574	295158	Ammeter (Stewart Warner Number 357-W)	1054	280275	Tie-Cable	1225	691029	Nut (Starting Switch)
575	692303	Switch-Starting	1142	690303	Screw (Starter Motor Bracket)			
578A	298582	Wire Assembly	1142A	691614	Screw (Starter Motor Bracket) (1 3/4" Long)			
636	696198	Nut (Starting Switch) (Terminal)	1150	691058	Screw (Adjusting Strap)			
641	691075	Washer (Starting Switch) (Terminal)	1151	690282	Washer (Adjusting Strap)			
			1152	691105	Nut (Adjusting Strap)			

Engine Gasket Set-Reference 358
Carburetor Overhaul Kit-Reference 121

Valve Gasket Set-Reference 1095









REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
51	27381	Gasket-Intake	500	691086	Washer (Key Switch)	775	690315	Nut (Toggle Switch)
51B	692917	Gasket-Intake	501A		Regulator (Flat Mount)	795A	496590	Switch-Toggle
215A	291871	Guide-Air			(Delco Remy No. 1118988)	840A	395408	Kit-Panel (Toggle Switch)
265	692179	Clamp-Casing			(NO LONGER AVAILABLE)			----- Note -----
267A	93107	Screw (Casing Clamp)			Used on Type No(s). 0199.			395409 Kit-Panel (Key Switch)
		----- Note -----	526	690297	Screw (Regulator)	892	392833	Switch-Key
		691044 Screw (Casing Clamp)	575	692303	Switch-Starting	945A	692132	Bracket-Starter Motor
		Used on Type No(s). 0644, 0672.	577	690630	Cable-Starter	990	691959	Key Set
310	690323	Screw (Starter Motor)	578C	690647	Wire Assembly	1113	691681	Screw (Panel)
		(4" Long)	621	297472s	Switch-Stop	1225	691029	Nut (Starting Switch)
310A	692329	Screw (Starter Motor)	627		Bracket-Stopswitch (NO LONGER AVAILABLE)			
		(5" Long)	636	696198	Nut (Starting Switch)			
361	93415	Screw (Starting Switch)			(Terminal)			
462	690282	Washer (Starter Cable)	641	691075	Washer (Starting Switch)			
478A	395410	Panel	664	691087	Nut (Key Switch)			
497	692198	Screw (Stopswitch Bracket)						

Engine Gasket Set-Reference 358
Carburetor Overhaul Kit-Reference 121

Valve Gasket Set-Reference 1095

326400

















USED BEFORE CODE DATE: 81080100


REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
24	222698s	Key-Flywheel	356	398808	Wire-Stop	507	690584	Insulator
333A	398811	Armature-Magneto (Breaker Ignition) (Used After Code Date 81073100).	356A	690650	Wire-Stop (Used With Magneto Armature, Reference 333A)	507A	66895	Insulator
333B	298968	Armature-Magneto (Breaker Ignition) (Used Before Code Date 81080100).	356B	396585	Wire-Stop (Used on Type No(s). 0643, 0646, 0735.			Note ----- 299598 Insulator Used on Type No(s). 0131.
334	691061	Screw (Magneto Armature)	359	691077	Washer (Ground Terminal)	520	691084	Terminal-Ground
340	26018	Spring-Breaker Arm	373	691612	Nut (Ground Terminal)	521	291508	Shield-Cable
343	298060	Condenser	375	298185	Breaker-Ignition	636A	230783	Nut (Starting Switch)
345		Cover-Breaker (NO LONGER AVAILABLE)	415	692882	Plug	639	692913	Gasket-Breaker Box
351	690292	Screw (Ground Terminal)	470	692836	Screw (Breaker Cover)	744	690277	Washer (Breaker Cover)
351A	690295	Screw (Ground Terminal)	484	690294	Screw (Condenser)	851	493880s	Terminal-Spark Plug
						888	690295	Screw (Insulator)
						897	394970	Kit-MAGNETRON® Ignition (Used After Code Date 81080100 and Before Code Date 85012200).
						989B		Stop Switch-Spark Plug (NO LONGER AVAILABLE)

Engine Gasket Set-Reference 358
Carburetor Overhaul Kit-Reference 121

Valve Gasket Set-Reference 1095

SEE REPAIR INSTRUCTION MANUAL FOR PROPER AMPERAGE OF ALTERNATOR

DUAL CIRCUIT	REGULATED	10 AMP	AC ONLY	DC ONLY
474  	474A  	474C  	474D  	474E  
878 	878C 	578A 	578 	




REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
474	696459	Alternator (Dual Circuit)	501B	691185	Regulator (10 Amp)	878	398661	Harness-Wiring
474A	696457	Alternator (Tri-Circuit)	526	690297	Screw (Regulator)	878C	691955	Harness-Alternator (Tri-Circuit)
474C	696458	Alternator (10 Amp) (Key Switch)	578	390867	Wire Assembly	1059	698516	Kit-Screw/Washer (Alternator)
474D	391595	Alternator (AC Only)	578A	692306	Wire Assembly	1119	691183	Screw (Alternator)
474E	696578	Alternator (DC Only)	844	261269	Spring-Diode			
475A	391507	Rectifier	877	393456	Wire/Connector-Alternator (Dual Circuit)			
481	230976	Bushing-Alternator	877A	393814	Wire/Connector-Alternator (DC Only)			
487	390888	Cap-Wire/Fuse	877B	393537	Wire/Connector-Alternator (Tri-Circuit)			
			877C	399916	Wire/Connector-Alternator (10 AMP)			

Engine Gasket Set-Reference 358
 Carburetor Overhaul Kit-Reference 121

Valve Gasket Set-Reference 1095


326400



REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
309	396306	Motor-Starter	668B	396515	Spacer	801		Cap-Drive (NO LONGER AVAILABLE)
310B	691263	Screw (Starter Motor) (4 3/4" Long)	675	691261	Washer (Brush Retainer)	802	691286	Cap-End
311	497608	Brush Set	697	691058	Screw (Drive Cap)	803		Housing-Starter (Serviced By 396306 Starter Motor Only)
510	696541	Drive-Starter	727	692338	Cover-Starter Drive (Starter Drive Cover)	1051	691265	Ring-Retaining
513	692024	Clutch-Drive	732	93410	Screw (Starter Drive Cover)	1090	691293	Retainer-Brush
544		Armature-Starter (Serviced By 396306 Starter Motor Only)	783	695708	Gear-Pinion			
			797	691029	Nut (Brush Retainer)			

Engine Gasket Set-Reference 358
Carburetor Overhaul Kit-Reference 121




Valve Gasket Set-Reference 1095



REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
309A		Motor-Starter (For Replacement Starter Motor, See Reference 309, Previous Page)	503	690406	Strap-Starter	801		Cap-Drive (NO LONGER AVAILABLE)
			510A	696540	Drive-Starter	802A	395537	Cap-End
			510B	696535	Drive-Starter	803A	494205	Housing-Starter
310A	692329	Screw (Starter Motor) (5" Long)	513	692024	Clutch-Drive	876	696539	Kit-Pinion Spring
			544A		Armature Starter (NO LONGER AVAILABLE)	896	691641	Pin-Drive Retainer (Copper)
311A	395538	Brush Set	697	691058	Screw (Drive Cap)	896A	94192	Pin-Drive Retainer (Black)
	442	Screw (Starter Strap)	773A	391462	Retainer			
			783	693059	Gear-Pinion			

Engine Gasket Set-Reference 358
Carburetor Overhaul Kit-Reference 121

Valve Gasket Set-Reference 1095



REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
3	691948	Seal-Oil (Magneto Side)	142	691966	Nozzle-Carburetor (Labeled B)	598	270516	Shim-End Play (Camshaft Bearing) (.009 Thick)
7	272166	Gasket-Cylinder Head	150	691610	Gasket-Nozzle			----- Note -----
9	27803s	Gasket-Breather	245	692190	Gasket-Fuel Bowl			270517 Shim-End Play (Camshaft Bearing) (.007 Thick)
20A	291675s	Seal-Oil (PTO Side)	338	690270	Gasket-Dipstick			270518 Shim-End Play (Camshaft Bearing) (.005 Thick)
51	27381	Gasket-Intake	358	299719	Gasket Set-Engine	639	692913	Gasket-Breaker Box
51A	692214	Gasket-Intake	398	691310	Gasket-Counterweight Cover (Magneto Side)	883	692236	Gasket-Exhaust
51B	692917	Gasket-Intake	399A	692914	Gasket-Counterweight Cover (PTO Side)	1095	498540	Gasket Set-Valve
94	292681	Kit-Idle Mixture	524	281370s	Seal-Dipstick Tube	1227	99525s	Valve-High Speed
102	692215	Gasket-Carburetor Body	569	691569	Gasket-Engine Base			
104	691775	Pin-Float Hinge	593	691311	Gasket-Bearing Support			
121	394989	Kit-Carburetor Overhaul (Used After Code Date 81090800).	593A	270513	Gasket-Bearing Support (.015 Thick)			
		----- Note -----			----- Note -----			
		391071 Kit-Carburetor Overhaul (Used Before Code Date 81090900).			270514 Gasket-Bearing Support (.010 Thick)			
127	690627	Plug-Welch			270515 Gasket-Bearing Support (.005 Thick)			
134	394681	Kit-Needle/Seat						

Engine Gasket Set-Reference 358
Carburetor Overhaul Kit-Reference 121

Valve Gasket Set-Reference 1095

Free Manuals Download Website

<http://myh66.com>

<http://usermanuals.us>

<http://www.somanuals.com>

<http://www.4manuals.cc>

<http://www.manual-lib.com>

<http://www.404manual.com>

<http://www.luxmanual.com>

<http://aubethermostatmanual.com>

Golf course search by state

<http://golfingnear.com>

Email search by domain

<http://emailbydomain.com>

Auto manuals search

<http://auto.somanuals.com>

TV manuals search

<http://tv.somanuals.com>