




# ELITE Series™

**PORTABLE GENERATOR  
GÉNÉRATEUR PORTATIF  
GENERADOR PORTÁTIL**

## Illustrated Parts List

**09801  
(10000W)**



Questions? Help is just a moment away!

Call: **Generator Helpline - 1-800-743-4115** M-F 8-5 CT

web: [www.briggsandstratton.com](http://www.briggsandstratton.com)


**BRIGGS & STRATTON POWER PRODUCTS GROUP, LLC  
JEFFERSON, WISCONSIN, U.S.A.**

Manual No. 191423A  
Revision 2 (03/10/2006)





# EXPLODED VIEW AND PARTS LIST – CONTROL PANEL




Item	Part #	Description
1	AB4432GS	PANEL, Control
2	B95906GS	BOX, Control
3	43437GS	OUTLET, 120/240V, 30A Locking
4	68759GS	OUTLET, 120V, 20A Duplex
5	68868GS	OUTLET, 120V, 30A Locking
6	B5112GS	ASSY, Diode
7	186102GS	ASSY, Engine Harness
8	90576GS	GROMMET, Rubber
9	B4262GS	OUTLET, 120/240V, 50A
10	87962GS	BREAKER, Circuit
11	93929GS	STAND OFF, 1/2" Hex
12	*	NUT, M4 - 0.7 Hex
13	*	WASHER, Lock, #8 M4
14	*	SCREW, M3 - .05 x 10mm
16	*	WASHER, Flat, #8
17	*	WASHER, #8 Shakeproof
18	90418GS	OUTLET, 12V DC Snap
19	*	WASHER, Lock, M3
20	75207AGS	BREAKER, Circuit, 30A
21	78653GS	SWITCH, Run - Stop
22	*	SCREW, M3 - 0.5 x 20mm
23	*	SCREW, M5 - .08 x 12mm
24	*	WASHER, Lock, M5

Item	Part #	Description
25	*	WASHER, Flat, M5
26	75207GS	BREAKER, Circuit, 20A
27	74190GS	OUTLET, 120V/20A
28	92953GS	BLOCK, 50 Amp, 3 - Terminal
29	*	SCREW, M4 x 20mm
30	94117GS	BOARD, Idle Control
31	84028GS	TRANSFORMER, Idle Control
32	65795GS	RECTIFIER, Battery Charge
33	84135GS	GROMMET, Rubber
34	*	SCREW, M5 - 0.8 x 30mm
35	186200GS	RESISTOR, .25 OHM, 25 Watt
36	B4893GS	STAND OFF
37	82538GS	SWITCH, On - Off
38	*	NUT, Hex, M3 - 0.5
39	*	NUT, Hex, M5 - 0.8
40	B4445GS	BREAKER, Circuit, 45A
41	B4894GS	RECTIFIER, Battery Charge
42	77314GS	RELAY, 3A Thermal
43	B4892GS	RESISTOR, 2 OHM, 25 Watt
44	27565GS	TAPE, Glass Insulation x 1.5"

\* - Items without part numbers are common fasteners and can be found at your local hardware store.


## EXPLODED VIEW AND PARTS LIST – WHEEL KIT



Item	Part #	Description
1	B193200GS	ASSY, Handle (Includes Item 2)
2	189718GS	GRIP
4	*	WASHER, Flat, 5/16 - M8
5	*	NUT, M8 Nylok
6	194034GS	KIT, Hardware Handle Fold-Down
7	B4135GS	PIN, with Lanyard
8	B93394GS	LEG, Mounting Support
9	191413GS	VIBE MOUNT, with Washer
10	192432GS	NUT, 1/4 - 20 Serrated Lock
11	*	WASHER, M8 Lock
12	*	HHCS, M8 - 1.25 x 20 Lg.
13	*	HHCS, 1/4 - 20 x 1.00 Lg.
14	191267BGS	AXLE, 5/8" x 28.74"
15	89635GS	SPACER, Wheel
16	89742GS	WHEEL
17	*	WASHER, 5/8
18	191265GS	E-RING

\* - Items without part numbers are common fasteners and can be found at your local hardware store.

## EXPLODED VIEW AND PARTS LIST – ALTERNATOR



Item	Part #	Description
1	B4906GS	SHIELD, Front
2	B4907GS	GRID, Front
3	B4908GS	BOLT, Shaft Stay
4	B4909GS	BOLT, Stay
5	B4910GS	ASSY, Housing
6	187049GS	PLUG, Domed
7	B4912GS	COVER, Blind End
8	B4913GS	COVER, Top Black
9	B4914GS	CAPACITOR
11	B4916GS	CAPACITOR, Diode + Varistor + EMC
12	191297GS	ASSY, Rotor (Includes Item 11)
14	B4919GS	SCREW
15	B4920GS	SCREW
16	49820GS	NUT, Lock
17	188928GS	CONNECTOR, 6-Pin
18	22473GS	WASHER
19	49813GS	NUT

## Free Manuals Download Website

<http://myh66.com>

<http://usermanuals.us>

<http://www.somanuals.com>

<http://www.4manuals.cc>

<http://www.manual-lib.com>

<http://www.404manual.com>

<http://www.luxmanual.com>

<http://aubethermostatmanual.com>

Golf course search by state

<http://golfingnear.com>

Email search by domain

<http://emailbydomain.com>

Auto manuals search

<http://auto.somanuals.com>

TV manuals search

<http://tv.somanuals.com>