


Cortelco 123 External Ringer

Features

- Loud Ringer Volume
- Visual Indication of Ringing
- Hi/Lo Ringer Volume Switch
- Desk/Wall Mountable

Installation

1. Connect the line cord from the telephone jack to the LINE JACK (2) of the 123 Ringer.
2. Using the supplied short line cord, connect the TEL JACK (1) of the 123 Ringer to the telephone. Note that it is not necessary to connect a telephone to use the 123 Ringer.
3. Adjust the volume to Hi or Lo using the volume switch (3).



Free Manuals Download Website

<http://myh66.com>

<http://usermanuals.us>

<http://www.somanuals.com>

<http://www.4manuals.cc>

<http://www.manual-lib.com>

<http://www.404manual.com>

<http://www.luxmanual.com>

<http://aubethermostatmanual.com>

Golf course search by state

<http://golfingnear.com>

Email search by domain

<http://emailbydomain.com>

Auto manuals search

<http://auto.somanuals.com>

TV manuals search

<http://tv.somanuals.com>