

TC 30 REMOTE CONTROL FUNCTIONS

(PREPROGRAMMED TO OPERATE THE AVR 745)

- 1** USB Connector
- 2** IR Emitter Window
- 3** Power Button
- 4** Activities Button
- 5** Devices Button
- 6** Help Button
- 7** Screen Buttons
- 8** LCD Screen
- 9** Page Left/Right Buttons
- 10** Transport Control Buttons
- 11** Device Control Buttons
- 12** Mute Button
- 13** Volume Controls
- 14** Navigation Buttons
- 15** OK/Enter Button
- 16** Glow Button
- 17** Channel Up/Down
- 18** Numeric Keys
- 19** Infrared Learning Port



Free Manuals Download Website

<http://myh66.com>

<http://usermanuals.us>

<http://www.somanuals.com>

<http://www.4manuals.cc>

<http://www.manual-lib.com>

<http://www.404manual.com>

<http://www.luxmanual.com>

<http://aubethermostatmanual.com>

Golf course search by state

<http://golfingnear.com>

Email search by domain

<http://emailbydomain.com>

Auto manuals search

<http://auto.somanuals.com>

TV manuals search

<http://tv.somanuals.com>