


## T8112, T8131, T8132; TD2200, TD2400; CT2800, CT3200, CT3300, CT3395 Thermostats

### INSTALLATION INSTRUCTIONS ADDENDUM

#### CYCLE RATES AND TIME FORMAT ADJUSTMENT

The adjustment for cycle rates and time format has changed from the current information in the Installation Instructions. See Fig. 1 and the tables for guidance.



M14829

Fig. 1. DIP switch positions.

Heating System	DIP Switch Position		Fuel Switch Position
Warm air furnace	1 - On	2 - On	F
Hot water or high efficiency warm air furnace	1 - Off	2 - On	F
Electric furnace	1 - On	2 - Off	E


Temperature Display	DIP Switch Position
Display °F	3 - On
Display °C	3 - Off

#### Automation and Control Solutions

Honeywell  
1985 Douglas Drive North  
Golden Valley, MN 55422

#### Automation and Control Solutions

Honeywell Limited-Honeywell Limitée  
35 Dynamic Drive  
Scarborough, Ontario  
M1V 4Z9



## Free Manuals Download Website

<http://myh66.com>

<http://usermanuals.us>

<http://www.somanuals.com>

<http://www.4manuals.cc>

<http://www.manual-lib.com>

<http://www.404manual.com>

<http://www.luxmanual.com>

<http://aubethermostatmanual.com>

Golf course search by state

<http://golfingnear.com>

Email search by domain

<http://emailbydomain.com>

Auto manuals search

<http://auto.somanuals.com>

TV manuals search

<http://tv.somanuals.com>