iPod + hp

User's Guide

Download from Www.Somanuals.com. All Manuals Search And Download.

The information in this document is subject to change without notice.

Hewlett-Packard® Company makes no warranty of any kind with regard to this material, including, but not limited to, the implied warranties of merchantability and fitness for a particular purpose.

Neither HP or Apple shall be liable for errors contained herein or for incidental or consequential damages in connection with the furnishing, performance, or use of this material.

THE WARRANTY TERMS CONTAINED IN THIS STATEMENT, EXCEPT TO THE EXTENT LAWFULLY PERMITTED, DO NOT EXCLUDE, RESTRICT OR MODIFY AND ARE IN ADDITION TO ANY MANDATORY STATUTORY RIGHTS APPLICABLE TO THE SALE OF THIS PRODUCT OR SERVICE TO YOU.

HP assumes no responsibility for the use or reliability of its software on equipment that is not furnished by HP.

This document contains proprietary information that is protected by copyright. All rights are reserved. No part of this document may be photocopied, reproduced, or translated to another language without the prior written consent of HP.

Hewlett-Packard Company
P.O. Box 4010
Cupertino, CA 95015-4010
USA

© 2004 Hewlett-Packard Development Company, L.P. All rights reserved.

Apple, the Apple logo, FireWire, iPod, and iTunes are trademarks of Apple Computer, Inc., registered in the U.S. and other countries. For legal or rightholder-authorized copying only. Don't steal music.

HP supports lawful use of technology and does not endorse or encourage the use of our products for purposes other than those permitted by copyright law.

Download from Www.Somanuals.com. All Manuals Search And Download.

Table of Contents

Quick Start 1
What You Need to Get Started 3
Setting Up iPod to Play Music 5
Using iPod 11
Using iPod Controls 11
Connecting and Disconnecting iPod 18
Organizing and Transferring Your Music 23
Adjusting iPod Settings 31
Using the Extra Features of Your iPod 35
Charging the iPod Battery 42
iPod Accessories 45
Tips and Troubleshooting 47
Learning More, Service, and Support 53
Safety and Cleaning 55
Index 63

Download from Www.Somanuals.com. All Manuals Search And Download.

Download from Www.Somanuals.com. All Manuals Search And Download.

Quick Start

Congratulations on purchasing your Apple iPod from HP. Read this section to get started using iPod quickly.

iPod works with the iTunes music software included on the iPod CD. Use iTunes to import songs from your CD or digital music collection to your PC, or use the iTunes Music Store (available in some countries/regions only) to purchase songs and download them to your PC. Then organize the songs and transfer them to iPod. iPod can be used with either desktop or laptop PCs.



Download from Www.Somanuals.com. All Manuals Search And Download.

arning to Use iPod

ıd this chapter to set up iPod and get started playing music quickly. To learn
·e about playing music on iPod and using some of its other features, see
ing iPod" on page 11.

ɔd Tutorial

an in-depth tutorial on transferring music to and playing music
iPod Tutorial on the iPod CD.

ɔd Features

ɨ is a music player and much more. With iPod, you c
ore thousands of songs from your CD or digital m
ı the go
sten to audiobooks purchased from the iTune
ɔuntries/regions only) or Audible.com
·range your music in On-The-Go playli
ɔre files and other data, using iPod
ıange equalizer settings to mak
ɔre and synchronize contact
ɔre text notes
ɨt an alarm
ecord voice memos
ɔre digital photo
ay games, and
ɔurchase a
://www

Download from Www.Somanuals.com. All Manuals Search And Download.

What You Need to Get Started

To use iPod with a PC, you must have:

- A PC with 500 MHz or higher processor speed
- Microsoft® Windows® 2000 with Service Pack 4 or later, or Windows XP Home or Professional
- iTunes 4.6 or later (iTunes is included on the iPod CD)

  To be sure you have the latest version of iTunes, go to http://www.hp.com/go/music/itunes
- iPod software (included on the iPod CD)
- Built-in FireWire® or a FireWire card installed, or built-in high-power USB 2.0 or a high-power USB 2.0 card installed

High-power USB 2.0 port

6-pin FireWire 400 port (IEEE 1394)

4-pin FireWire 400 port (with optional adapter, not included)

For more information about compatible FireWire and USB cards, go to http://www.hpshopping.com/musicaccessories

Download from Www.Somanuals.com. All Manuals Search And Download.

ur iPod includes the following components:

iPod



iPod Dock (v



l Dock Connector to FireWire Cabl

iPod

Download from Www.Somanuals.com. All Manuals Search And Download.

Setting Up iPod to Play Music

To set up iPod, you charge the battery, install software from the iPod CD, and import songs from your music CD collection to your PC. Then you transfer the songs to iPod and start listening to music.

Step 1: Charge the Battery

Connect iPod to the iPod Power Adapter using the iPod Dock Connector to FireWire Cable. The built-in battery is 80 percent charged in about two hours, and fully charged in about four hours.



Download from Www.Somanuals.com. All Manuals Search And Download.

Step 2: Install the Software

Insert the iPod CD into your PC and install iTunes and the iP

Step 3: Import Music to Your PC

Complete this step if you haven't already transferred m
import music from your audio CDs, or if you have an
buy music online and download it to your PC using
can browse hundreds of thousands of songs and
any song. The iTunes Music Store is available i

To import music to your PC from an a

1. Insert a CD into your PC. iTunes opens auto
iTunes Source list.
2. Uncheck songs you don't want to trans
3. Repeat for any other CDs with songs

To buy music online:

1. Open iTunes and click Music St
2. Click the Account button and
ount
or enter your existing Apple
information.

For an in-depth tutorial
g music on iPod, see
the *iPod Tutorial* on th

Dow oad from Www.Somanuals.com. All Manuals Search And Download.

Step 4: Connect iPod and Transfer Music

Connect iPod to your PC using the iPod Dock Connector to USB 2.0 Cable. Be sure the connectors on both ends of the cable are oriented correctly. They can only be inserted one way.

Note: If you have a PC with a 6-pin FireWire 400 port, you can use the iPod Dock Connector to FireWire Cable.

Note: USB 1.1 is not supported.

You can also use the optional iPod Dock (see page 21).



Use the iPod Dock Connector to USB 2.0 Cable to connect to a high-power USB 2.0 port.

Download from Www.Somanuals.com. All Manuals Search And Download.

nd transfers the

ect iPod to a high-
USB 2.0 hub that's
to a low-power USB 2.0
other peripherals.

, the iPod loses charge.
ently charged can cause

charge iP

ation on cables a
pshopping.com/

uick Start

Download

.een says “OK to
sconnect the cable

ror a song. Press the Play

re

napter to learn ma
, transferring musi
iPod, charging th

uick Start

Download

Download from Www.Somanuals.com. All Manuals Search And Download.



Download from Www.Somanuals.com. All Manuals Search And Download.

iPod Controls	
Reset iPod (For use during troubleshooting)	Toggle the Hold switch (set it to Hold, then turn it off again). Then press the Menu and Select buttons simultaneously for about 6 seconds, until the Apple logo appears.
Turn on iPod	Press any button.
Turn off iPod	Press and hold Play/Pause.
Turn the backlight on or off	Press and hold Menu or select Backlight from the main menu.
Select a menu item	Scroll to the item and press the Select button.
Go back to the previous menu	Press Menu.
Browse for a song	Select Music from the main menu.
Play a song	Highlight the song and press the Select or Play/Pause button. iPod must be disconnected from your PC to play songs.
Play all the songs in a list	Highlight the list title (an album title, or the title of a playlist, for example) and press Play/Pause.
Change the volume	From the Now Playing screen, use the Click Wheel. You can also use the optional iPod Remote (available at http://www.hpshopping.com/musicaccessories) from any screen.
Pause a song	Press Play/Pause when no song or list is highlighted.

Download from Www.Somanuals.com. All Manuals Search And Download.

iPod Controls	
Disable the iPod buttons (So you don't press them accidentally)	Set the Hold switch to Hold (an orange bar appears).
Skip to any point in a song	From the Now Playing screen, press the Select button to show the scrubber bar. Then scroll to any point in the song.
Skip to the next song	Press Next/Fast-forward.
Start a song over	Press Previous/Rewind.
Play the previous song	Press Previous/Rewind twice.
Fast-forward	Press and hold Next/Fast-forward.
Rewind	Press and hold Previous/Rewind.

Download from Www.Somanuals.com. All Manuals Search And Download.

ress the buttons or

ing iPod

Download

Making Playlists on iPod

You can set iPod to play the songs you want in the order you want. When you create a list of songs on your iPod, the songs appear in an On-The-Go playlist.

To create an On-The-Go playlist:

1. Highlight a song and press and hold the Select button until the song title flashes.
2. Repeat step 1 for other songs you want to add.
3. Select Music > Playlists > On-The-Go to view your list of songs.

You can also queue entire lists of songs at once. For example, to queue an album, highlight the album title and press and hold the Select button until the album title flashes.

To play songs in the On-The-Go playlist:

- Select Music > Playlists > On-The-Go and select a song.

To remove a song from the On-The-Go playlist:

- Highlight a song in the playlist, and hold down the Select button until the song title flashes.

To clear the entire On-The-Go playlist:

- Select Music > Playlists > On-The-Go > Clear Playlist.

Download from Www.Somanuals.com. All Manuals Search And Download.

To save On-The-Go playlists on your iPod:

- Select Music > Playlists > On-The-Go > Save Playlist > Save Playlist.

  The first playlist is saved as "New Playlist 1" in the Playlists menu. The On-The-Go playlist is cleared. You can save as many On-The-Go playlists as you like.

To transfer On-The-Go playlists to your PC:

- If iPod is set to transfer songs automatically (see page 27), and you create an On-The-Go playlist, the playlist automatically transfers to iTunes when you connect iPod. You see the new On-The-Go playlist in the iTunes Source list.

Rating Songs

You can assign a rating to a song (from 1 to 5 stars) to indicate how much you like it. You can use song ratings to help you create playlists automatically in iTunes (see "About Smart Playlists" on page 26).

To rate a song:

1. Start playing the song.
2. From the Now Playing screen, press the Select button twice.
3. Use the Click Wheel to select a rating.

Download from Www.Somanuals.com. All Manuals Search And Download.

ıd, in most cases, to

.or to USB 2.0 Cable. Be
.ienten correctly. They can

ıing iPod

Download

iPod:

- od the iTunes the Eject button.



ect button

co by clicking th rdwa ico Windo
m cting your iPo

disconn d:

- *iPod is conn an iPod cable,* e ctor
  o disconnect the from iPod.
- *If iPod is in the Dock,* nply remove it.

Important: Don't disconnect iPod if you
You could damage files on iPod. If you see
before disconnecting it.

Using i
nload from Www.Soma nd Download.

Connecting iPod Using the iPod Dock (Included With Some Models)

The iPod Dock holds iPod upright as it charges or transfers music. Co
Dock to your PC using the same cable you use with iPod, or connect
outlet using the FireWire cable and power adapter. Then put iPod in



Note: Be sure the connectors on the cable are oriented correctly. E ch connector can only be inserted one way.

Download from Www.Somanuals.com. All Manuals Search And Download.

powered

ndard

this type of

ut port using an audio cab

ols to play a s

is connected to

al source to cha

ing iPod

Download manuals.com. All Manuals Search And Download.

Organizing and Transferring Music

For instructions for getting started using iTunes and transferring music on iPod, see "Setting Up and Using iTunes" on page 5. Read this section for information about organizing your music library and transferring music.

About iTunes

iTunes is software application that you use to manage the music on your PC and transfer it to iPod. When you connect iPod to your PC, iTunes opens automatically.

Here are some of the things you can do with iTunes:

- Purchase and download songs and albums from the iTunes Music Store (available in some countries/regions only)
- Listen to CDs and digital music
- Add music from CDs to your music library as you play them in the drive to play music
- Make your own CDs (if your PC has a CD burner)
- Publish your playlists to the iTunes Music Store (available in some regions only)
- Create dynamic "Party Shuffle" playlists
- Listen to Internet radio stations

This guide explains how to transfer music to iTunes and iPod and how to use it on iPod. For information about using iTunes on your PC, open iTunes and choose Help > iTunes and Music Store Help.

Download from Www.Somanuals.com. All Manuals Search And Download.

About the iTunes Music Store

Using iTunes, you can preview, purchase, and download yo m the iTunes Music Store (available in some countries/regio hundreds of thousands of songs available for purchase Account to purchase songs from the music store, or if Online (AOL) account, you can use that.

To browse for and purchase music:

1 Open iTunes and click Music Store in the Sour

2 Click the Account button and follow the onsc or enter your existing Apple Account or AO

You can only have music from five differ

For more information about the iTunes Help > iTunes and Music Store Help

Audio File Formats Sup

- AAC (M4A, M4B, M4P) (up t
- Apple Lossless (a high-quali or later)
- MP3 (up to 320 Kbps)
- MP3 Variable Bit Rate
- WAV
- AA (Audible.com d 4)
- AIFF

Dow oad from Www.Somanuals.com. All Manuals Search And Download.

nverted

ou are iTunes 4.5 C, you can convert nonprotec
WMA fil C or MP3 f e useful if you have a librar
music e WMA forme nation. Open iTu and cho
lp > Music Store

do rt WMA, MP ver 2 or
ible.co .

bout Play

sing iTunes, you rganize songs
create a playlist with gs to listen to w o
particular mood.

You can create as many playlists as you like
music library. Putting a song a playlist does om

When you connect and upda d, the playlis nsfe
To browse through playlists, se ic > Playlis iP

nload from Www.Soma nd Download.

About Smart Playlists

Using iTunes, you can automatically create customized Smart Playlist
songs in your library. You can create a Smart Playlist that includes or
genres of music, songs by certain artists, or songs that match particu
For example, you could create a playlist that's no more than 3 gigab
size and includes only songs you have rated 3 stars or higher (see "
Songs" on page 17).

After you create a Smart Playlist, any songs on iPod that meet the Sm
criteria are automatically added to the Smart Playlist.

Creating Playlists on Your PC

To create a playlist:

- In iTunes, click the Add (+) button and type a name for the playlist, t
songs from the library or another playlist to the new playlist.

To create a Smart Playlist:

- In iTunes, choose File > New Smart Playlist and choose the criteria f
playlist. Any songs from your library that match the criteria you cho
automatically added to the playlist.

Download from Www.Somanuals.com. All Manuals Search And Download.

Transferring Songs and Playlists to iPod Automatically

By default, iPod updates automatically when you connect it to your PC. iTunes updates the iPod music library to match the songs and playlists in your PC's music library, transferring new songs to iPod and deleting songs from iPod that aren't in your music library.

You can set iPod to transfer only certain songs in your iTunes music library. This is useful if you have more music on your PC than will fit on your iPod.

To update iPod with only certain songs:

1. In iTunes, check the boxes next to songs you want to transfer (by default, all songs are checked).
2. Select iPod in the iTunes Source list and click the Options button.



Options button

3. Select "Only update checked songs."

To set iPod to update only selected playlists:

1. In iTunes, select iPod in the Source list and click the Options button.
2. Select "Automatically update selected playlists only."

Download from Www.Somanuals.com. All Manuals Search And Download.

Transferring Songs and Playlists to iPod Manually

You can set iPod to transfer songs manually, so you can transfer individual songs and playlists.

When iPod is set to transfer songs manually, iTunes won't update it automatically when you connect it to your PC.

To set iPod to transfer songs manually:

1 In iTunes, select iPod in the Source list and click the Options button.



Options button

2 Select "Manually manage songs and playlists."

To transfer a song or playlist to iPod manually:

- In iTunes, drag a song or playlist to iPod in the Source list.

Download from Www.Somanuals.com. All Manuals Search And Download.

Deleting Songs and Playlists From iPod Manually

If you have set iPod to transfer songs manually (see above), you can delete songs and playlists from iPod individually. Songs deleted from iPod manually are not deleted from the iTunes library.

To delete a song or playlist from iPod:

1. Select iPod in the iTunes Source list.
2. Select a song or playlist and press the Delete key on the keyboard.

   If you delete a playlist, the songs in the playlist remain on iPod.

Modifying Playlists on iPod Manually

If you have set iPod to transfer songs manually (see above), you can create new playlists on iPod, and add songs to or delete songs from playlists already on iPod.

To create a new playlist on iPod:

1. Select iPod in the iTunes Source list and click the Add (+) button.
2. Drag songs to the new playlist.

To modify a playlist on iPod:

- Drag a song to a playlist on iPod to add the song. Select a song in a playlist and press the Delete key on your keyboard to delete the song.

Download from Www.Somanuals.com. All Manuals Search And Download.

m the iTunes Music
ible.com and listen

he same way you transfer

go back to it later, the
ff

gs
elect Setti

ing iPod
Download

Adjusting iPod Settings

You can change settings directly on iPod in the Settings menu.

Setting iPod to Shuffle Songs

You can set iPod to shuffle (play songs or albums in random order). iPod shuffles songs within the list (album or playlist, for example) from which the songs are playing.

You can shuffle or reshuffle songs you are already playing, or you can set iPod to shuffle songs or albums every time you play a song.

To shuffle or reshuffle songs you are already playing:

- Select Shuffle Songs from the iPod main menu.

If you select Shuffle Songs when no songs are playing, iPod begins playing songs from your entire music library in random order.

To set iPod to shuffle songs or albums every time you play a song:

1. Select Settings from the iPod main menu.
2. Set Shuffle to Songs or to Albums.

When you set iPod to shuffle albums, it plays all the songs on an album in order, then randomly selects another album and plays through it in order.

Unless you're playing songs from within playlists, iPod skips audiobooks when set to shuffle.

Download from Www.Somanuals.com. All Manuals Search And Download.

Setting iPod to Repeat Songs

You can set iPod to repeat a song over and over, or to repeat a sequence of songs. iPod repeats songs within the list from which the songs are playing.

To set iPod to repeat songs:

- Select Settings from the iPod main menu.
  - *To repeat all songs in the list,* set Repeat to All.
  - *To repeat one song over and over,* set Repeat to One.

Setting the Click Wheel Sound

When you scroll through menu items, you can hear a clicking sound through the iPod internal speaker to let you know the Click Wheel is working. You can set the Click Wheel sound to play through the headphones instead, or you can turn it off.

To set how iPod plays the Click Wheel sound:

- Select Settings from the iPod main menu.
  - *To set the Click Wheel sound to play through the headphones,* set Clicker to Headphones.
  - *To turn off the Click Wheel sound,* set Clicker to Off.
  - *To set the Click Wheel sound to play through the iPod internal speaker,* set Clicker to Speaker.
  - *To set the Click Wheel sound to play through both the iPod internal speaker and the headphones,* set Clicker to Both.

Setting Songs to Play at the Same Relative Volume Level

iTunes can automatically adjust the volume of songs, so they play at the same relative volume level. You can set iPod to use the iTunes volume settings.

Download from Www.Somanuals.com. All Manuals Search And Download.

To set iTunes to adjust all songs to play at the same relative sound level:

1. In iTunes, choose Edit > Preferences.
2. Click Effects and select Sound Check.

To set iPod to use the iTunes volume settings:

- Select Settings > Sound Check.

If you have not activated Sound Check in iTunes, setting it on iPod has no effect.

Using the iPod Equalizer

You can use equalizer presets to change iPod sound to suit a particular music genre or style. For example, to make rock music sound better, set the equalizer to Rock.

- Select Settings > EQ and select an equalizer preset.

If you have assigned an equalizer preset to a song in iTunes and the iPod equalizer is set to Off, then the song plays using the iTunes setting. See iTunes and Music Store Help for more information.

Setting the Backlight Timer

You can set the backlight to turn on for a certain amount of time when you press a button or use the Click Wheel.

- Select Settings > Backlight Timer and select the time you want.

Even if you don't set the backlight timer, you can turn on the backlight at any time by pressing and holding the Menu button on iPod or selecting Backlight from the main menu. After a few seconds, the backlight turns off.

Download from Www.Somanuals.com. All Manuals Search And Download.

Adding or Removing Items From the Main Menu

You can add often-used items to the iPod main menu. For example, you can add a "Songs" item to the main menu, so you don't have to select Music before you select Songs.

To add or remove items from the main menu:

- Select Settings > Main Menu.

Setting and Viewing Date and Time

To set the date and time:

- Select Settings > Date & Time.

To view the date and time:

- Select Extras > Clock.

To set iPod to display the time in the title bar:

- Select Settings > Date & Time.

If you set iPod to display the time in the title bar, you can see the time from any iPod menu screen.

Setting the Language

iPod can be set to use different languages.

- Select Settings > Language and select a language.

Download from Www.Somanuals.com. All Manuals Search And Download.

Using iPod as an External Hard Disk

You can use iPod as a hard disk, to store and transfer data files.

To enable iPod as a hard disk:

1 In iTunes, select iPod in the Source list and click the Options button.



Options button

2 Select "Enable disk use."

When you use iPod as a hard disk, the iPod disk icon appears as the next available drive letter in Windows Explorer on a PC.

Note: Selecting "Manually manage songs and playlists" in the Options window also enables iPod to be used as a hard disk.

Note: To transfer music files to iPod, you must use iTunes. Songs transferred via iTunes do not appear on iPod in Windows Explorer. Likewise, if you copy music files to iPod in Windows Explorer, you won't be able to play them on iPod.

Download from Www.Somanuals.com. All Manuals Search And Download.

Preventing iTunes From Opening Automatically

If you use iPod primarily as a hard disk, you may want to keep iTunes from opening automatically when you connect iPod to your PC.

To prevent iTunes from opening automatically when you connect iPod to your PC:

1. In iTunes, select iPod in the Source list.
2. Click the Options button and deselect "Open iTunes when attached."



Options button

Setting the Sleep Timer

You can set iPod to turn off automatically after a specific period of time.

- Select Extras > Clock > Sleep Timer and select the time you want.

When you set the sleep timer, a clock icon and the number of minutes left until iPod turns off appear in the Now Playing screen on iPod.

Download from Www.Somanuals.com. All Manuals Search And Download.

C

You

You can

disk (see "

To import co

1 Connect iPod and

contacts works with

Eudora, among others.

2 Drag contacts from the appl

Download from Www.Somanuals.com. All Manuals

To import appointments and other calendar events manually:

1. Export calendar events from any calendar application that uses the standard vCal format (filenames end in .vcs).
2. Drag the files to the Calendars folder on iPod.

To view contacts on iPod:

- Select Extras > Contacts.

To view calendar events:

- Select Extras > Calendar.

Storing and Reading Notes and Other Information

You can store and read text notes on iPod. iPod must be enabled as a hard disk (see page 35).

1. Save a document in any word-processing application as a text (.txt) file.
2. Place the file in the Notes folder on iPod.

To view notes:

- Select Extras > Notes.

Download from Www.Somanuals.com. All Manuals Search And Download.

Recording Voice Memos

You can record voice memos using an optional iPod-compatible microphone (available for purchase at http//www.hpshopping.com/musicaccessories). You can store voice memos on your iPod and transfer them to your PC.

To record a voice memo:

1. Connect a microphone to the Headphones port on your iPod and select Record to begin recording.
2. Hold the microphone a few inches from your mouth and speak. To pause recording, select Pause.
3. When you're finished recording, select Stop and Save. Your recording is saved and listed by date and time recorded.

To play a recording:

- Select Extras > Voice Memos and select the recording.

Note: The Voice Memos menu item doesn't appear until you connect a microphone.

To transfer voice memos to your PC:

Voice memos are saved in a Recordings folder on iPod in the WAV file format. If you enable iPod for disk use, you can drag voice memos from the folder to copy them.

If iPod is set to transfer songs automatically (see page 27) and you record voice memos, the voice memos are automatically transferred to a playlist in iTunes when you connect iPod. You see the new Voice Memos playlist in the iTunes Source list.

Download from Www.Somanuals.com. All Manuals Search And Download.

Storing Digital Photos

Using an optional iPod-compatible photo card reader (available for purchase at http://www.hpshopping.com/musicaccessories) and a standard digital camera and photo card, you can store photos on iPod, then delete them from the photo card and take more pictures. Then later you can transfer the photos from iPod to your PC using a standard digital photo application.

To store photos on iPod:

1. Insert a photo card into the photo card reader and connect the photo card reader to the Dock connector port on iPod.
2. Select Import.

   Photos are listed on iPod by roll number.

   Note: Some digital photo storage devices may work differently. Consult the instructions that came with the device.

To view information about photos stored on iPod:

- Select Extras > Photo Import and select the roll number.
  The type of media, number of photos, and size of the roll are displayed. You can't view the photos on iPod.

  Note: The Photo Import menu item doesn't appear unless you connect a photo card reader.

Download from Www.Somanuals.com. All Manuals Search And Download.

To erase photos from a photo card:

1. Import photos from the card (see above).
2. Select Erase Card. All photos are deleted from the photo card.

To transfer photos to your PC:

- Connect iPod to your PC and open the application you use to transfer photos from your digital camera. See the documentation that came with the application for more information.

  Note: Photos are stored in a DCIM (digital camera images) folder on iPod. You can also transfer images to your PC by opening this folder and dragging the image files to the desktop. iPod must be enabled for use as a hard disk.

  For more information about using an iPod-compatible photo card reader, see the instructions that came with the reader.

Playing Games

iPod has a number of games.

To play a game:

- Select Extras > Games and select a game.

Download from Www.Somanuals.com. All Manuals Search And Download.

Charging the iPod Battery

iPod has an internal, nonremovable battery. If iPod isn't used for a while, the battery may need to be charged.

The iPod battery is 80-percent charged in about two hours, and fully charged in about four hours. If you charge iPod by connecting it to your PC, it may take longer to charge, especially if you are transferring files or playing music.

You can charge the iPod battery in two ways:

- In most cases you can charge iPod by connecting it to your PC.
- You can also charge iPod by connecting it to the power adapter and a working electrical outlet.

To charge the battery using your PC:

- Connect iPod to a 6-pin FireWire port or high-power USB 2.0 port on your PC using the appropriate cable. The PC must be turned on and not in sleep mode.

If the battery icon in the upper-right corner of the iPod screen shows a lightning bolt, the battery is charging.

If you don't see the lightning bolt, you must charge the battery using the iPod Power Adapter.

Download from Www.Somanuals.com. All Manuals Search And Download.

charge the battery using the iPod Power Adapter:

ınect the AC plug adapter to the power adapter (this may already be embled).

ınect the iPod Dock Connector to FireWire Cable included with iPod t ver adapter, and plug the other end of the cable into iPod.

g the power adapter into a working electrical outlet.



rning Make sure t
an electrical outl

Download from Www.Somanuals.com. All Manuals Search And Download.

Battery States

When iPod is not connected to a power source, a battery icon in the top right corner of the iPod screen shows about how much charge is left.

Battery about
halfway charged

If iPod is connected to a power source, the battery icon animates to show that the battery is charging.

Battery charging

If you connect iPod to a power source and the battery icon does not animate, the battery is fully charged.

Battery fully charged
(if not animated)

You can disconnect and use iPod before it is fully charged.

Note: Rechargeable batteries have a limited number of charge cycles and may eventually need to be replaced. Battery life and number of charge cycles vary by use and settings. For more information, go to http://www.hp.com/go/music/battery

Download from Www.Somanuals.com. All Manuals Search And Download.

iPod Accessories

iPod comes with some accessories, and many other accessories are available at http://www.hpshopping.com/musicaccessories

iPod Remote (Available Separately)

To use the iPod Remote, connect it to the iPod Remote port, then connect the Earphones (or another set of headphones) to the remote. Use the buttons on the remote just as you would use the iPod buttons.

When a song is playing on iPod, adjust the volume using the volume control on the remote.



Use the remote's Hold switch to disable the remote's buttons. The iPod Hold switch and the iPod Remote Hold switch do not affect one another.

Download from Www.Somanuals.com. All Manuals Search And Download.

Earphones

iPod comes with a pair of high-quality earbud headphones.

To use the earbud headphones:

- Plug them in to the Headphones port, then place the earbud in your ear as shown.

Warning Listening to music at high volume over extended periods of time can damage your hearing.

Download from Www.Somanuals.com. All Manuals Search And Download.

Tips and Troubleshooting

Most problems with iPod can be solved quickly by following the advice in this chapter.

Resetting iPod

Most problems with iPod can be solved by resetting it.

To reset iPod:

1. Connect iPod to a power outlet using the iPod Power Adapter.
2. Toggle the Hold switch on and off (set it to Hold, then turn it off again).
3. Press and hold the Select and Menu buttons for at least 6 seconds, until the Apple logo appears.

If Your iPod Won't Turn On or Respond

- Make sure the Hold switch is off.
- If you're using the iPod Remote, make sure the remote's Hold switch is off.
- If that doesn't work, connect iPod to the iPod Power Adapter and connect the adapter to a working electrical outlet. Your iPod battery may need to be recharged.
- If that doesn't work, your iPod may need to be reset (see above).
- If that doesn't work, you may need to restore iPod software. See "iPod Software Update and Restore" on page 51.

Download from Www.Somanuals.com. All Manuals Search And Download.

If You Want to Disconnect iPod, but the Screen Says "Do Not Disconnect"

- If iPod is transferring music, wait for the transfer to complete.
- Select iPod in the iTunes Source list and click the Eject button.
- If iPod disappears from the iTunes Source list, but you still see the "Do Not Disconnect" message on the iPod screen, go ahead and disconnect iPod.
- If iPod doesn't disappear from the iTunes Source list, click the Safely Remove Hardware icon in the system tray and select your iPod. If you still see the "Do Not Disconnect" message, restart your PC and eject iPod again.

If Your iPod Isn't Playing Music

- Make sure the Hold switch is off.
- If you're using the iPod Remote, make sure the remote's Hold switch is off.
- Make sure the headphones connector is pushed in all the way.
- Make sure the volume is adjusted properly.
- If that doesn't work, push the Play/Pause button. Your iPod may be paused.
- If you're using the iPod Dock, be sure the iPod is seated firmly in the Dock and make sure all cables are connected properly.
- If you are using the Dock Line Out port, make sure your external speakers or stereo are turned on and working properly.

Download from Www.Somanuals.com. All Manuals Search And Download.

ıappens

What You Need to

oth ends and make sure no
Then plug the cable back in
nectors on the cables are

ps and Troublesh

Download

If You Connect iPod to a USB Port and It Doesn't Work Correctly

- You must use a FireWire port or a USB 2.0 port to connect iPod. USB 1.1 is not supported and is significantly slower than FireWire and USB 2.0. If your PC doesn't have a FireWire port or USB 2.0 port, you can purchase a Windows-certified FireWire card or USB 2.0 card and install it. For more information, go to http://www.hpshopping.com/musicaccessories
- If you're connecting iPod to a portable or laptop PC using the iPod Dock Connector to USB 2.0 Cable, connect the PC to a power outlet before connecting iPod.
- If you're using a PC with a 6-pin FireWire port, connect iPod to a FireWire port using the FireWire cable that came with iPod.

If the Screen is Too Light or Too Dark

1. Select Settings > Contrast.
2. Use the Click Wheel to adjust the contrast.

If you accidentally set the screen contrast too light or too dark, you can reset it to the default by pressing and holding the Menu button for about 4 seconds.

If You Accidentally Set iPod to Use a Language You Don't Understand

You can reset the language.

1. Push Menu repeatedly until the main menu appears.
2. Select the fourth menu item (Settings).
3. Select the last menu item (Reset All Settings).
4. Select the second menu item (Reset) and select a language.

Download from Www.Somanuals.com. All Manuals Search And Download.

Other iPod settings, such as song repeat, are also reset.

Note: If you have added or removed items from the iPod main menu (see page 34), the Settings menu may be in a different place.

If Your iPod Remote Isn't Working

- Make sure the remote's Hold switch is off.
- Make sure the remote is plugged firmly into iPod, and that the headphones are plugged firmly into the remote.

The iPod Remote is included with some models of iPod, and can be purchased separately at http://www.hpshopping.com/musicaccessories

If You Want to Use Your iPod with a PC and a Mac

If you are using your iPod with a PC and you want to use it with a Mac (or vice versa), you must restore the iPod software for use with the other computer using iPod Software Update (see "iPod Software Update and Restore" below). Restoring the iPod software erases all data from iPod, including all songs.

You cannot switch from using iPod with a PC to using it with a Mac (or vice versa) without erasing all data on iPod.

iPod Software Update and Restore

Apple periodically updates iPod software to improve performance or add features. It is recommended that you update your iPod to use the latest software.

You can choose either to update or to restore the iPod software.

- *If you choose to update,* the software is updated, but your settings and songs are not affected.

Download from Www.Somanuals.com. All Manuals Search And Download.

- *If you choose to restore,* all data is erased from your iPod, including songs, files, contacts, photos, calendar information, and any other data. All iPod settings are restored to their original state.

To update or restore iPod with the latest software:

1. Go to http://www.hp.com/go/music/update and download the latest iPod Update.
2. Double-click the software install file and follow the onscreen instructions to install the iPod Update.
3. Connect iPod to your PC and open iTunes. If the iPod Update application doesn't open automatically, you can find the updater by clicking Start > All Programs > iPod.
4. Follow the onscreen instructions to update or restore iPod software.

   If you use the iPod Update application and it doesn't see that iPod is connected to your PC, reset iPod (see page 47).

   If you want to restore iPod software and you don't have an Internet connection, you can use the iPod Update that was installed on your PC when you installed the software from the iPod CD.

To restore iPod software using the updater that came on your iPod CD:

- You can find the updater by clicking Start > All Programs > iPod.

Download from Www.Somanuals.com. All Manuals Search And Download.

Learning More, Service, and Support

There is more information about using iPod on the iPod CD, in onscreen help, and on the Web.

iPod Tutorial

For an in-depth tutorial on transferring music to and playing music on iPod, s
the *iPod Tutorial* on the iPod CD.

Onscreen Help

- To learn more about using iPod and iTunes, open iTunes and cho
  Help > iTunes and Music Store Help.

Download from

Online Resources

For the latest information on iPod, go to http://www.hp.com/music

For iPod service and support information go to http://www.hp.com/support

To register iPod (if you didn't do it when you installed software from the iPod CD), go to http://register.hp.com. Please be sure to have your product number, model number, and serial number handy.

For an online iTunes tutorial (available in some areas only), go to http://www.apple.com/support/itunes

Obtaining Warranty Service

If the product appears to be damaged or does not function properly, please follow the advice in this booklet, the onscreen help, and the online resources.

If the unit still does not function, go to your *Warranty and Support Guide* for instructions on how to obtain warranty service.

Finding the Serial Number of Your iPod

The serial number is printed on the back of your iPod. You can also find it by selecting Settings > About.

Download from Www.Somanuals.com. All Manuals Search And Download.

- Follow all instructions and warnings dealing with your iPod.

Warning Electrical equipment may be hazardous if misused. Operation of this product, or similar products, must always be supervised by an adult. Do not allow children access to the interior of any electrical product and do not permit them to handle any cables.

Avoid Hearing Damage

Warning Permanent hearing loss may occur if earbuds or headphones are used at high volume. You can adapt over time to a higher volume of sound, which may sound normal but can be damaging to your hearing. Set your iPod volume to a safe level before that happens. If you experience ringing in your ears, reduce the volume or discontinue use of your iPod.

Do Not Use While Driving

Important: Use of headphones while operating a vehicle is not recommended and is illegal in some areas. Be careful and attentive while driving. Stop listening to your iPod if you find it disruptive or distracting while operating any type of vehicle or performing any other activity that requires your full attention.

Connectors and Ports

Never force a connector into a port. If the connector and port do not join with reasonable ease, they probably don't match. Make sure that the connector matches the port and that you have positioned the connector correctly in relation to the port.

Battery

Do not attempt to remove the iPod battery. iPod must be disposed of according to local environmental regulations.

Download from Www.Somanuals.com. All Manuals Search And Download.

Using the Power Adapter

- Use only the power adapter that came with your iPod. Adapters for other electronic devices may look similar, but they may damage your iPod.
- The only way to shut off power to your power adapter completely is to disconnect it from the power source.
- Always leave space around your power adapter. Do not use this equipment in a location where airflow around the power adapter is confined, such as a bookcase.
- When connecting or disconnecting your power adapter, always hold the power adapter by its sides. Keep fingers away from the metal part of the plug.
- Before connecting the FireWire cable to the power adapter, make sure there are no foreign objects inside the power adapter's FireWire port.
- The power adapter for your iPod is a high-voltage component and should not be opened for any reason, even when the iPod is off. If the power adapter needs service, see "Learning More, Service, and Support" on page 53.
- Never force a connector into the power adapter FireWire port. If the connector and port do not join with reasonable ease, they probably don't match. Make sure that the connector matches the port and that you have positioned the connector correctly in relation to the port.

Download from Www.Somanuals.com. All Manuals Search And Download.

About Operating and Storage Temperatures

- Operate your iPod in a place where the temperature is always between 0° and 35° C (32° to 95° F).
- Store your iPod in a place where the temperature is always between –20° and 45° C (–4° to 113° F). Don't leave iPod in your car, since temperatures in parked cars can exceed this range.
- iPod play time may temporarily shorten in low-temperature conditions.
- When you're using your iPod or charging the battery, it is normal for the bottom of the case to get warm. The bottom of the iPod case functions as a cooling surface that transfers heat from inside the unit to the air outside.

Avoid Wet Locations

Warning To reduce the chance of electric shock or injury, do not use your iPod in or near water or wet locations.

- Keep your iPod and power adapter away from sources of liquids, such as drinks, washbasins, kitchen sinks, shower stalls, and so on.
- Protect your iPod and the power adapter from direct sunlight and rain or other moisture.
- Take care not to spill any food or liquid on iPod or its power adapter. If you do, unplug iPod before cleaning up the spill.

In case of a spill, you may have to send your equipment to HP for service. See "Learning More, Service, and Support" on page 53.

Download from Www.Somanuals.com. All Manuals Search And Download.

Do Not Make Repairs Yourself

Warning Do not attempt to open your iPod or power adapter, disassemble it, or remove the battery. You run the risk of electric shock and voiding the limited warranty. No user-serviceable parts are inside.

For service, see “Learning More, Service, and Support” on page 53.

Cleaning

Follow these general rules when cleaning the outside of your iPod and its components:

- Make sure your iPod is unplugged.
- Use a damp, soft, lint-free cloth. Avoid getting moisture in openings.
- Don’t use aerosol sprays, solvents, alcohol, or abrasives.

About Handling

Your iPod may be damaged by improper storage or handling. Be careful not to drop your iPod when playing or transporting the device.

Download from Www.Somanuals.com. All Manuals Search And Download.

Communications

Regulation Information

FCC Compliance Statement

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. See instructions if interference to radio or television reception is suspected.

Radio and Television Interference

This PC equipment generates, uses, and can radiate radio-frequency energy. If it is not installed and used properly — that is, in strict accordance with HP's instructions — it may cause interference with radio and television reception.

This equipment has been tested and found to comply with the limits for a Class B digital device in accordance with the specifications in Part 15 of FCC rules. These specifications are designed to provide reasonable protection against such interference in a residential installation. However, there is no guarantee that interference will not occur in a particular installation.

You can determine whether your PC system is causing interference by turning it off. If the interference stops, it was probably caused by the PC or one of the peripheral devices.

If your PC system does cause interference to radio or television reception, try to correct the interference by using one or more of the following measures:

- Turn the television or radio antenna until the interference stops.
- Move the PC to one side or the other of the television or radio.
- Move the PC farther away from the television or radio.
- Plug the PC into an outlet that is on a different circuit from the television or radio. (That is, make certain the PC and the television or radio are on circuits controlled by different circuit breakers or fuses.)

If necessary, consult an HP-authorized service provider or HP. See the service and support information that came with your HP product. Or, consult an experienced radio/television technician for additional suggestions.

Important: Changes or modifications to this product not authorized by the Hewlett-Packard Company could void the EMC compliance and negate your authority to operate the product.

Download from Www.Somanuals.com. All Manuals Search And Download.

This product was tested for EMC compliance under conditions that included the use of HP peripheral devices and HP shielded cables and connectors between system components. It is important that you use HP peripheral devices and shielded cables and connectors between system components to reduce the possibility of causing interference to radios, television sets, and other electronic devices. You can obtain HP peripheral devices and the proper shielded cables and connectors through an HP Authorized Reseller. For non-HP peripheral devices, contact the manufacturer or dealer for assistance. Responsible party (contact for FCC matters only): Hewlett-Packard Company, P.O. Box 4010, Cupertino, CA 95015-4010, USA

Industry Canada Statement

This Class B digital apparatus complies with Canadian ICES-003.

Cet appareil numériqué de la classe B est conformé à la norme NMB-003 du Canada.

VCCI Class B Statement



European Community

Complies with European Directives 72/23/EEC and 89/336/EEC.

Download from Www.Somanuals.com. All Manuals Search And Download.

Download from Www.Somanuals.com. All Manuals Search And Download.

Index

A

AA file format 24
AAC file format 24
accessories 45
addresses 37
AIFF file format 24
alarm 37
Apple Lossless file format 24
audio file format
    AA 24
    AAC 24
    AIFF 24
    Apple Lossless 24
    converting 25
    MP3 24
    supported 24
    WAV 24

B

backlight 33
    turning off 13
    turning on 13
battery 56
    about 42
    charging 5, 42
    charging with iPod Power Adapter 43
    icons 42
    states 44
browsing for music 9

C

calendar events 37
cleaning 59
communications regulation information 60
connecting iPod 18

Download from Www.Somanuals.com. All Manuals Search And Download.

D

date
- setting 34
- viewing 34

digital photos
- erasing 41
- photo card reader 41
- storing 40
- transferring 41
- viewing information 40

disabling buttons 14, 15
disconnecting cable 9
disconnecting iPod 18, 19, 20
- messages 19

Dock Line Out port 22

E

earphones 46
ejecting iPod 20
equalizer 33
external hard disk 35

F

fast-forwarding 14
FireWire adapter
- 6-pin-to-4-pin 8

FireWire card 3
FireWire ports
- 4-pin 8

G

games, playing 41
getting started 1

H

handling 59
hearing damage, avoiding 56
Help 53
Hold switch 15, 45

I

importing
- addresses 37
- calendar events 37

installing software 6
iPod
- accessories 45
- backlight timer 33
- disconnecting 9
- equalizer 33
- features 2
- not responding 47
- remote 45
- resetting 47
- tutorials 2
- using as external hard disk 35
- using speakers 22
- using with a Mac 51

Download from Www.Somanuals.com. All Manuals Search And Download.

)ock, using 21

bout 23
reventing automatically
opening 36
sing, see tutorials
ersion 3
Music Store
rowsing for music 24
urchasing music 24

ıge 34
hanging 50
ut port 22

dding items 34
emoving items 34
electing 11
le format 24

ot playing 48
ganizing 23
ansferring 23

N

notes
reading 38
storing 38

O

online resources 54
On-The-Go playlists
clearing 16
playing song
removing
saving
trans

P

pau
pl

Download from Www.Somanuals.com. All Manuals Search And Download.

playlist
a
a
cr
cr
cr
de
m
O

tr
transferring manually 28
updating 31
odating selected 27
songs
dapter 43
deleting 29
power adapter 43, 57
number of played 26
purchas
R
rating s
register
remote
repairin
repeati
resetting
rewindi

arch And Download.

speakers 22
connecting 22
Dock Line Out port 22
spoken word audio 30
setting reading rate 30
stored songs 30
support 54
supported file formats 24

T

temperature
operating 58
storage 58
time
setting 34
viewing 34
tips 47
transferring music 6, 27
from a CD to iTunes 6
purchased songs 6
to iPod 7, 18
troubleshooting 47
turning off 13
turning on 13
tutorials 2, 53

U

USB
2.0 card 3
2.0 port 8

V

voice memos
playing 39
recording 39
transferring 39
volume
control 22
level 13, 32
remote control 45
settings 33

W

warranty service 54
WAV file format 24

Download from Www.Somanuals.com. All Manuals Search And Download.

http
ht
ed in Ching
034-2616-A

Free Manuals Download Website

http://myh66.com

http://usermanuals.us

http://www.somanuals.com

http://www.4manuals.cc

http://www.manual-lib.com

http://www.404manual.com

http://www.luxmanual.com

http://aubethermostatmanual.com

Golf course search by state

http://golfingnear.com

Email search by domain

http://emailbydomain.com

Auto manuals search

http://auto.somanuals.com

TV manuals search

http://tv.somanuals.com