

## 866102 STRENGTH BUILDING SYSTEM

### THANK YOU

FOR PURCHASING THE 866102 STRENGTH BUILDING SYSTEM. PLEASE SAVE THESE ASSEMBLY INSTRUCTIONS FOR YOUR PERSONAL REFERENCE, AND ADDITIONAL SERVICE INFORMATION.

### \*\*\*IMPORTANT\*\*\*

- THE 866102 STRENGTH BUILDING SYSTEM MUST BE ASSEMBLED ON A FLAT, LEVEL SURFACE TO ASSURE ITS PROPER FUNCTION.
- PARABODY INC. STRONGLY RECOMMENDS THAT THIS PRODUCT BE ASSEMBLED BY TWO PERSONS TO AVOID POSSIBLE INJURY.
- IF YOU EXPERIENCE ANY PROBLEM WITH THE ASSEMBLY OF THIS PRODUCT, PLEASE CONTACT YOUR DEALER OR YOUR PARABODY CUSTOMER SERVICE REPRESENTATIVE AT: 1-800-328-9714
- TOOLS REQUIRED: RATCHET, 3/4 SOCKET or WRENCH, 9/16 SOCKET or WRENCH, ADJUSTABLE WRENCH, and RUBBER MALLET or HAMMER

### ASSEMBLY INSTRUCTIONS

Part # 6611901

1

Revision: 04/30/96

**SORT AND COUNT ALL PARTS BEFORE BEGINNING ASSEMBLY**

**HARDWARE:**


ITEM	NAME/DESCRIPTION	QTY
1.	3 X 2" END CAP .....	2
2.	3/8" FLAT WASHER .....	6
3.	1/2" FLAT WASHER .....	6
4.	1/2" NYLOCK NUT .....	6
5.	3/8" NYLOCK NUT .....	1
6.	1/2" LOW HEIGHT NYLOCK NUT .....	1
7.	3/8 X 1-1/4" BOLT .....	4
8.	1/2 X 3" BOLT .....	6
9.	3/8 X 2-3/4" BOLT .....	1
10.	1/2 X 3-1/2" BOLT .....	1
11.	PAL NUT .....	1
12.	1-1/4" SQ. RUBBER BUMPER .....	1
13.	1/2" FLANGE BEARING .....	2
14.	1 X 1 GLIDE .....	2
15.	3 PRONG KNOB .....	2
16.	2" SQ. END CAP .....	4
17.	HINGE TAB .....	4
18.	U-PIN .....	1
19.	SPRING PIN ASSEMBLY .....	1
20.	1-1/2 X 3/4" GLIDE QTY8 .....	1
21.	2" SQ. COVER CAP .....	1

**WELDMENTS/PARTS:**

ITEM	NAME/DESCRIPTION	QTY
1.	WOLFF SLEEVE WLDMT .....	(6406601)..... 1
2.	HEIGHT ADJUSTMENT BAR WLDMT .....	(6428601)..... 1
3.	BENCH SLIDE WLDMT .....	(6428701)..... 1
4.	BACK PAD .....	(6452401)..... 1
5.	SEAT PAD .....	(6452501)..... 1
6.	CROSS BRACE WLDMT .....	(6606901)..... 1
7.	UPRIGHT FRAME WLDMT .....	(6607501)..... 2
8.	BENCH FRAME WLDMT .....	(6607701)..... 1
9.	SLIDE SUPPORT WLDMT .....	(6611701)..... 1
10.	UPRIGHT LABELS (1-25) .....	(6189501)..... 2

NOTE: BOLT LENGTH IS MEASURED FROM THE UNDERSIDE OF THE HEAD OF THE BOLT.

**BOLT LENGTH RULER:**




1. Insert one (1) 3 X 2 IN. END CAP into the top of the UPRIGHT FRAME, and two (2) 2 IN. SQ. END CAPS into the BASE of the UPRIGHT FRAME as shown on drawing. Repeat this step for the second UPRIGHT FRAME.
2. SECURELY assemble both UPRIGHT FRAMES to the CROSS BRACE as shown on drawing using four (4) 1/2 X 3 IN. BOLTS, four (4) 1/2 IN. WASHERS, and four (4) 1/2 IN. LOCK NUTS.  
**(IMPORTANT: THE ANGLE BRACKETS ON THE CROSS BRACE ARE OFFSET, PLEASE MAKE SURE THAT THE LONGEST END OF THE BRACKET IS FACING UP BEFORE ASSEMBLY)**
3. SECURELY assemble the BENCH FRAME to the CROSS BRACE as shown on drawing using two (2) 1/2 X 3 IN. BOLTS, two (2) 1/2 IN. WASHERS, and two (2) 1/2 IN. LOCK NUTS. Attach one 2" sq. cover cap to the BENCH FRAME as shown.
4. Insert two (2) 1/2 IN. FLANGE BEARINGS into each end of the BUSHING of the BENCH FRAME as shown on drawing.
5. SECURELY assemble the BENCH SLIDE to the BUSHING of the BENCH FRAME as shown on drawing, using one (1) 1/2 X 3-1/2 IN. BOLT one (1) 1/2 IN. LOW HT LOCK NUT.
6. Attach eight (8) 1-1/2 X 3/4" GLIDES to the WOLFF SLEEVE (FOUR ON EACH END) as shown in (DETAIL A) using the following steps:
  - Thoroughly clean all surfaces where the GLIDES are to be attached.
  - Remove the GLIDES from the paper backing and firmly apply them to all shown surfaces.
7. Insert one (1) U-PIN through the BUSHING of the WOLFF SLEEVE as shown on drawing, and attach one (1) PAL NUT to the end of the U-PIN.
8. SECURELY Assemble one (1) SPRING PIN ASSEMBLY to the SPRING PIN BARREL, of the WOLFF SLEEVE as shown in (DETAIL B). (!!! IMPORTANT !!! TIGHTEN THE NUT OF THE SPRING PIN ASSEMBLY SECURELY)
9. Pull back the SPRING PIN on the WOLFF SLEEVE and slide it over the end of the BENCH SLIDE as shown on drawing. Engage the SPRING PIN into one of the adjustment holes. Secure the WOLFF SLEEVE in place with one (1) 3-PRONG KNOB.
10. LOOSELY assemble one (1) 3 PRONG KNOB to the UPRIGHT TUBE of the BENCH FRAME as shown on drawing. (THIS WILL BE USED TO SECURE ATTACHMENTS IN PLACE)
11. Attach one (1) 1-1/4 IN. SQ. RUBBER BUMPER to the SLIDE SUPPORT as shown on drawing.
12. SECURELY assemble the SLIDE SUPPORT to the end of the BENCH SLIDE as shown on drawing using one (1) 3/8 X 2-3/4 IN. BOLT, two (2) 3/8 IN WASHERS, and one (1) 3/8 IN. LOCK NUT.
13. Attach two (2) 1 X 1 GLIDES to the top of the BENCH FRAME where the SLIDE SUPPORT makes contact. See drawing.
14. Assemble the SEAT PAD to the WOLFF SLEEVE, start by sliding two (2) HINGE TABS over the PIN of the WOLFF SLEEVE (ONE ON EACH SIDE) as shown on drawing, and SECURELY assemble each HINGE TAB to the SEAT PAD using two (2) 3/8 X 1-1/4 IN. BOLTS and two (2) 3/8 IN. WASHERS. (MAKE SURE BOTH HINGE TABS ARE ALL THE WAY ON THE PIN)

15. Assemble the BACK PAD to the WOLFF SLEEVE, slide the two (2) remaining HINGE TABS over the PIN of the WOLFF SLEEVE (ONE ON EACH SIDE) as shown on drawing, and SECURELY assemble each HINGE TAB to the BACK PAD using two (2) 3/8 X 1-1/4 IN. BOLTS and two (2) 3/8 IN. WASHERS. (MAKE SURE BOTH HINGE TABS ARE UP AGAINST THE OTHER HINGES)
16. Attach two sets of UPRIGHT LABELS (1 to 12) to the inside surfaces of both UPRIGHT FRAMES as shown on drawing.

## 866102 EXERCISE SET-UP

---

1. To perform FLAT BENCH EXERCISES, lift the BENCH SLIDE up and set the HEIGHT ADJUSTMENT BAR into the bottom rungs of the UPRIGHT FRAMES. Lower the BENCH SLIDE down on top of the HEIGHT ADJUSTMENT BAR. Adjust the WOLFF SLEEVE forward or backward until proper alignment with UPRIGHTS is reached, and tighten THUMBSCREW.
2. To perform INCLINE PRESSES, lower the BENCH SLIDE down onto the BENCH FRAME. Place the HEIGHT ADJUSTMENT BAR into the forth or fifth rungs (DEPENDING ON ANGLE OF INCLINE) of the UPRIGHT FRAMES. Adjust the WOLFF SLEEVE forward or backward until proper alignment with UPRIGHTS is reached, and tighten THUMBSCREW. Adjust the SEAT PAD, by pulling back the U-PIN and allow it to rest up again the SPRING PIN HOUSING on the WOLFF SLEEVE.
3. To perform MILITARY PRESSES, lower the BENCH SLIDE down onto the BENCH FRAME. Place the HEIGHT ADJUSTMENT BAR into the fifth rungs of the UPRIGHT FRAMES. Adjust the WOLFF SLEEVE backward to the last adjustment hole in the BENCH SLIDE, and tighten THUMBSCREW.
4. To perform DECLINE PRESSES, and AB CRUNCHES the OPTIONAL LEG CURL/EXTENSION PEDESTAL will be needed. Insert the U-PIN through the hole in the LEG EXTENSION NECK and the BUSHING on the LEG EXTENSION (AT THE SAME TIME). Insert the LEG EXTENSION NECK into the UPRIGHT TUBE of the BENCH FRAME and allow the U-PIN to rest on top, and tighten THUMBSCREW. Lower the BENCH SLIDE down onto the BENCH FRAME. Lock legs in behind the ROLLER PADS of the LEG CURL/EXTENSION PEDESTAL. The WOLFF SLEEVE may be adjusted for comfort.
5. To perform SQUATS, (MAKE SURE THAT NO ATTACHMENTS ARE IN THE UPRIGHT TUBE OF THE BENCH FRAME) slide the WOLFF SLEEVE to the front of the BENCH SLIDE. Rotate the BENCH SLIDE up and allow it to rest on the UPRIGHT TUBE. Allow the BACK PAD to hang down. (THE HANGING WEIGHT OF THE BACK PAD WILL KEEP THE BENCH SLIDE FORWARD)
6. Please follow the WORKOUT MANUAL for the correct way to use this product.



UNLESS OTHERWISE SPECIFIED	TOLERANCES	ParaBody, Inc.	Office (612) 372-4500
FRACTIONAL	$\pm \frac{1}{16}$	14150 Sunfish Lake Boulevard	10th Floor
DECIMAL	.007 ± .001	Ramsey, Minnesota 55303	1-800-328-9714
ANGULAR	+/- 1°		
TIME			
ASSY INST,	866102		
SCALE	1/14	DRAWING SIZE DRAWING NO.	
SHEET	1 OF 1	C	66119
DRAWN			DATE APPROVED
D.TAILLEFER			4/96
			DATE

Free Manuals Download Website

<http://myh66.com>

<http://usermanuals.us>

<http://www.somanuals.com>

<http://www.4manuals.cc>

<http://www.manual-lib.com>

<http://www.404manual.com>

<http://www.luxmanual.com>

<http://aubethermostatmanual.com>

Golf course search by state

<http://golfingnear.com>

Email search by domain

<http://emailbydomain.com>

Auto manuals search

<http://auto.somanuals.com>

TV manuals search

<http://tv.somanuals.com>