

storage

- Wrap the cord around the power handle for tidy storage 5.

cleaning

- Always switch off and unplug before cleaning.
- Don't touch the sharp blades.
- Take special care when preparing food for babies, the elderly and infirm. Always ensure that the hand blender shaft is thoroughly sterilised. Use a sterilising solution in accordance with the sterilising solution manufacturers instructions.
- Some foods, eg carrot, may discolour the plastic. Rubbing with a cloth dipped in vegetable oil helps remove discolouring.

power handle, chopper cover

- Wipe with a damp cloth, then dry.
- Never immerse in water or use abrasives.

blender shaft

either

- Part-fill the beaker with warm, soapy water. Then insert the blender shaft and switch on.
- Unplug, then dry. or see below.

blender shaft, chopper blade, beaker, bowl, base/lids

- Wash up, then dry. Or wash in your dishwasher.


service and customer care

- If the cord is damaged it must, for safety reasons, be replaced by KENWOOD or an authorised KENWOOD repairer.

If you need help with:

- using your hand blender or
 - servicing or repairs (in or out of guarantee)
- contact the Kenwood distributor or your authorised Kenwood repairer.
Have your model number ready - it's on the power handle.


KENWOOD



HB510 HB520 series



Kenwood Limited, New Lane • Havant • Hampshire • PO9 2NH • U.K.
www.kenwoodworld.com



safety

general

- Take special care when preparing food for babies, the elderly and infirm. Always ensure that the hand blender shaft is thoroughly sterilised. Use a sterilising solution in accordance with the sterilising solution manufacturers instructions.
- Never touch the blades while the machine's plugged in.
- Keep fingers, hair, clothing and utensils away from moving parts.
- Unplug after use and before changing attachments.
- Never blend hot oil or fat.
- Don't let children or infirm people use the hand blender without supervision.
- Never use a damaged hand blender. Get it checked or repaired: see 'service'.
- Never put the power handle in water or let the cord or plug get wet - you could get an electric shock.
- Never let the cord touch hot surfaces or hang down where a child could grab it.
- Never use an unauthorised attachment.
- Young children should be supervised to ensure that they do not play with this appliance.

chopper attachment

- Don't touch the sharp blades.
- Remove the chopper blade before emptying the bowl.
- Never remove the cover until the blade has completely stopped.

important

- With heavy mixtures, don't use your hand blender for longer than 50 seconds in any four minute period - it'll overheat.
- Only use your hand blender for its intended domestic use.

before plugging in

- Make sure your electricity supply is the same as the one shown on the power handle.

before using for the first time

1. Remove all packaging and throw away the blade covers.
2. Wash the parts: see 'cleaning'.

know your Kenwood hand blender

hand blender

- ① speed buttons
- ② power handle
- ③ blender shaft (removable)
- ④ beaker
- ⑤ beaker base/lid

chopper

- (HB520 series)
- ⑥ chopper cover
- ⑦ chopper blade
- ⑧ bowl
- ⑨ bowl base/lid

to use the hand blender

- You can blend baby food, soups, sauces, milk shakes and mayonnaise.

for beaker blending

- Put the base/lid on the bottom of the beaker. (This stops the beaker sliding on the worktop.)
 - Don't fill the beaker above 700ml (24fl oz).
1. Fit the power handle inside the blender shaft, turn and lock ①.
 2. Plug in. To avoid splashing, place the blade in the food before switching on.
 3. Hold the beaker steady. Then press either speed button (use speed 1 for slower blending and to reduce splashing).
 4. After use, unplug and dismantle.

for saucepan blending

- Take the pan off the heat and let it cool slightly. Otherwise your hand blender could overheat.
- Don't let liquid get above the join between the power handle and blender shaft.
- Move the blade through the food and use a stabbing action.
- If your blender gets blocked, unplug before clearing.

to use the chopper (if supplied)

- You can chop meat, cheese, vegetables, herbs, bread, biscuits and nuts.
 - Don't chop hard foods such as coffee beans, ice cubes, spices or chocolate - you'll damage the blade.
1. Remove any bones and cut food into 1-2cm (1/2-1") cubes.
 2. Put the base/lid on the bottom of the chopper bowl. (This stops the bowl sliding on the worktop.)
 3. Fit the chopper blade over the pin in the bowl ④.
 4. Add your food.
 5. Fit the chopper cover, turn and lock ③.
 6. Fit the power handle, turn and lock ②.
 7. Plug in. Hold the bowl steady. Then press speed 2.
 8. After use, unplug and dismantle.

processing guide

food	maximum amount	approx. time (in seconds)
Meat	300g (10 1/2oz)	10-30
Herbs	20g (3/4oz)	20
Nuts	200g (7oz)	30
Cheese	150g (5oz)	30
Bread	1 slice	20
Hardboiled eggs	2	5
Onions	100g (3 1/2oz)	10

Free Manuals Download Website

<http://myh66.com>

<http://usermanuals.us>

<http://www.somanuals.com>

<http://www.4manuals.cc>

<http://www.manual-lib.com>

<http://www.404manual.com>

<http://www.luxmanual.com>

<http://aubethermostatmanual.com>

Golf course search by state

<http://golfingnear.com>

Email search by domain

<http://emailbydomain.com>

Auto manuals search

<http://auto.somanuals.com>

TV manuals search

<http://tv.somanuals.com>