

## storage

- Wrap the cord around the power handle for tidy storage 5.

## cleaning

- Always switch off and unplug before cleaning.
- Don't touch the sharp blades.
- Take special care when preparing food for babies, the elderly and infirm. Always ensure that the hand blender shaft is thoroughly sterilised. Use a sterilising solution in accordance with the sterilising solution manufacturers instructions.
- Some foods, eg carrot, may discolour the plastic. Rubbing with a cloth dipped in vegetable oil helps remove discolouring.

### **power handle, chopper cover**

- Wipe with a damp cloth, then dry.
- Never immerse in water or use abrasives.

### **blender shaft**

either

- Part-fill the beaker with warm, soapy water. Then insert the blender shaft and switch on.
- Unplug, then dry. or see below.

### **blender shaft, chopper blade, beaker, bowl, base/lids**

- Wash up, then dry. Or wash in your dishwasher.


## service and customer care

- If the cord is damaged it must, for safety reasons, be replaced by KENWOOD or an authorised KENWOOD repairer.

If you need help with:

- using your hand blender or
  - servicing or repairs (in or out of guarantee)
- contact the Kenwood distributor or your authorised Kenwood repairer.  
Have your model number ready - it's on the power handle.


# KENWOOD



**HB510 HB520 series**



Kenwood Limited, New Lane • Havant • Hampshire • PO9 2NH • U.K.  
[www.kenwoodworld.com](http://www.kenwoodworld.com)



## safety

### general

- Take special care when preparing food for babies, the elderly and infirm. Always ensure that the hand blender shaft is thoroughly sterilised. Use a sterilising solution in accordance with the sterilising solution manufacturers instructions.
- Never touch the blades while the machine's plugged in.
- Keep fingers, hair, clothing and utensils away from moving parts.
- Unplug after use and before changing attachments.
- Never blend hot oil or fat.
- Don't let children or infirm people use the hand blender without supervision.
- Never use a damaged hand blender. Get it checked or repaired: see 'service'.
- Never put the power handle in water or let the cord or plug get wet - you could get an electric shock.
- Never let the cord touch hot surfaces or hang down where a child could grab it.
- Never use an unauthorised attachment.
- Young children should be supervised to ensure that they do not play with this appliance.

### chopper attachment

- Don't touch the sharp blades.
- Remove the chopper blade before emptying the bowl.
- Never remove the cover until the blade has completely stopped.

### important

- With heavy mixtures, don't use your hand blender for longer than 50 seconds in any four minute period - it'll overheat.
- Only use your hand blender for its intended domestic use.

### before plugging in

- Make sure your electricity supply is the same as the one shown on the power handle.

### before using for the first time

1. Remove all packaging and throw away the blade covers.
2. Wash the parts: see 'cleaning'.

## know your Kenwood hand blender

### hand blender

- ① speed buttons
- ② power handle
- ③ blender shaft (removable)
- ④ beaker
- ⑤ beaker base/lid

### chopper

- (HB520 series)
- ⑥ chopper cover
- ⑦ chopper blade
- ⑧ bowl
- ⑨ bowl base/lid

## to use the hand blender

- You can blend baby food, soups, sauces, milk shakes and mayonnaise.

### for beaker blending

- Put the base/lid on the bottom of the beaker. (This stops the beaker sliding on the worktop.)
  - Don't fill the beaker above 700ml (24fl oz).
1. Fit the power handle inside the blender shaft, turn and lock ①.
  2. Plug in. To avoid splashing, place the blade in the food before switching on.
  3. Hold the beaker steady. Then press either speed button (use speed 1 for slower blending and to reduce splashing).
  4. After use, unplug and dismantle.

### for saucepan blending

- Take the pan off the heat and let it cool slightly. Otherwise your hand blender could overheat.
- Don't let liquid get above the join between the power handle and blender shaft.
- Move the blade through the food and use a stabbing action.
- If your blender gets blocked, unplug before clearing.

### to use the chopper (if supplied)

- You can chop meat, cheese, vegetables, herbs, bread, biscuits and nuts.
  - Don't chop hard foods such as coffee beans, ice cubes, spices or chocolate - you'll damage the blade.
1. Remove any bones and cut food into 1-2cm (1/2-1") cubes.
  2. Put the base/lid on the bottom of the chopper bowl. (This stops the bowl sliding on the worktop.)
  3. Fit the chopper blade over the pin in the bowl ④.
  4. Add your food.
  5. Fit the chopper cover, turn and lock ③.
  6. Fit the power handle, turn and lock ②.
  7. Plug in. Hold the bowl steady. Then press speed 2.
  8. After use, unplug and dismantle.

## processing guide

| food            | maximum amount  | approx. time (in seconds) |
|-----------------|-----------------|---------------------------|
| Meat            | 300g (10 1/2oz) | 10-30                     |
| Herbs           | 20g (3/4oz)     | 20                        |
| Nuts            | 200g (7oz)      | 30                        |
| Cheese          | 150g (5oz)      | 30                        |
| Bread           | 1 slice         | 20                        |
| Hardboiled eggs | 2               | 5                         |
| Onions          | 100g (3 1/2oz)  | 10                        |

## Free Manuals Download Website

<http://myh66.com>

<http://usermanuals.us>

<http://www.somanuals.com>

<http://www.4manuals.cc>

<http://www.manual-lib.com>

<http://www.404manual.com>

<http://www.luxmanual.com>

<http://aubethermostatmanual.com>

Golf course search by state

<http://golfingnear.com>

Email search by domain

<http://emailbydomain.com>

Auto manuals search

<http://auto.somanuals.com>

TV manuals search

<http://tv.somanuals.com>