

Canon

MP1211-LTSC

USER INSTRUCTIONS
PENGGUNA INSTRUKSI




E-IM-2786

ENGLISH
BAHASA INDONESIA

Before Starting	P.1
General Maintenance	P.1
Decimal Point Selector Switch	P.2
Rounding Switch	P.2
Item Count Switch	P.2
Grand Total / Tax Rate Set Switch	P.3
Print Switch	P.3
Important Functions to Remember	P.3
Business Sales Calculation Function	P.4
Currency Conversion Function	P.4
Tax Calculation Function	P.5
Cash Change Function	P.5
Overflow	P.5
Specifications	P.5
Replacing the Ink Ribbon	P.6
Inserting Printing Paper	P.6
Backup Battery	P.7
Calculation Example	P.15-21

Before Starting

- 1) Remove the insulation tape at the back of calculator and press [RESET] key before use. (Figure **a**)
- 2) Turns power on. (Figure **b**)



General Maintenance

- Do not use or leave the calculator under direct sunlight. Areas subject to rapid temperature changes, high humidity, dust and dirt should also be avoided.
- Use a dry cloth to clean the casing of the unit. Do not use water or detergents.
- Activate the printer only when the paper roll is loaded.
- Avoid using the calculator in places where there are iron filings, as this may affect the electrical circuits of the calculator.
- Do not place anything on top of the machine, particularly on top of the printer mechanism.
- Turn the calculator off before removing the plug from the electrical outlet.
- Pull the main plug to the wall socket if you want to switch off the main power or in case of electrical fault (i.e. smoke), disconnect the plug from the electrical socket-outlet immediately.
- The AC outlet must be located near the equipment and easily accessible.
- Under the environment with electrostatic discharge, the sample may malfunction and require user to reset the sample.

Decimal Point Selector Switch



: Used for designating the decimal point position (0 2 3 4 6) for calculated results.



+ (Add-Mode) : Addition and subtraction functions are performed with an automatic 2-digit decimal. It is convenient for currency calculations.



F (Floating Decimal Point) : All effective numbers up to 12 digits are printed or displayed.

Rounding Switch



: Used for round-up [\uparrow], round-off [5/4], or round-down [\downarrow] to the pre-selected decimal digits in the result.

Item Count Switch



: At "n+" or "n+/-" position, the calculator count and print the number of calculation items up to 999.

< ITEM COUNTER >

When the "ITEM" switch is set at "n+", the calculator counts the number of times the $\boxed{+}$ and $\boxed{-}$ keys are pressed.

When the switch is set at "n+/-", the calculator counts the number of times the $\boxed{+}$ key is pressed and subtracts from the total numbers of times the $\boxed{-}$ key is pressed.

< MEMORY ITEM COUNT >

When the "ITEM" switch is set at "n+", the calculator counts number of times $\boxed{M+}$ and $\boxed{M-}$ keys are pressed.

When the switch is set at "n+/-", the calculator counts the number of times the $\boxed{M\pm}$ key is pressed and subtracts from the total number of times the \boxed{M} key is pressed.

< PRINTOUT OF ITEM COUNT >





When the PRINT switch is turned "ON", and the "ITEM" switch is at the "n+" or "n+/-" position, the number of items recorded by the counter can print up to three digits on the left-hand side of the paper by pressing either the $\boxed{\#}$ key or the $\boxed{\times}$ key for item count and $\boxed{M\pm}$ key or \boxed{M} key for memory item count.

Grand Total / Tax Rate Set Switch

ENGLISH

GRAND TOTAL



/  : When the calculations are performed with the GT switch set to "ON", the totals are accumulated in the grand total memory. Each time  is pressed, the subtotal number is printed with the symbols GT/\overline{GT} . When  is pressed, the intermediate grand total is printed with the symbols $G\Diamond/\overline{G\Diamond}$. Press  successively to get the grand total followed by the symbols $G\ast/\overline{G\ast}$.

TAX RATE SET



: Set switch to "TAX RATE SET" for setting or recalling the TAX rate.

Print Switch

PRINT OFF



: Entries and results will appear on the display, but will not be printed out.

PRINT ON



: Entries and results will appear on the display and will be printed out.

Important Functions to Remember



Memory Plus Equal Key: Used for obtaining a calculation result and adding the result automatically to the memory. This key is also used for adding number to the memory.



Memory Minus Equal Key: Used for obtaining a calculation result and subtracting the result automatically from the memory. This key is also used for subtracting a number from the memory.



Memory Subtotal Key: Used for obtaining intermediate result of the memory calculation. This key will not clear memory contents.



Memory Total and Memory Clear Key: Used for obtaining total of memory contents. This key will clear memory contents at the same time.



Clear Entry and Clear Key: Press once to clear last entered value. Press again to clear all entered values except memory. This key is also used for clearing the overflow error.



Equal Key: Used for obtaining multiplication and division results.



Non-Add / Subtotal Key: Used for printing out information which does not affect the calculation such as dates and serial numbers. Figure are printed on the left-hand side of the paper. It is also used for obtaining intermediate results.



Total Key: Used for obtaining addition and subtraction results.

COST **SELL** **MARGIN** : Used for calculating the cost, selling price and profit margin amount. Enter the value of any 2 items to obtain the balance value item. (e.g. enter the value of the cost and the selling price to obtain the profit margin %.)

Currency Conversion Function

- C₁** **RATE SET** **C1** or **C2** : Press **C₁** **RATE SET** and hold for 1 second, then enter the currency conversion rate and press **C1** or **C2** to store the rate.
- C₁** **C1** or **C2** : Press **C₁** **C1** or **C2** to recall the stored currency conversion rate.
- LOCAL** : Press **LOCAL** to convert currency figure displayed from **C1** or **C2** to the **LOCAL**.
- C1** or **C2** : Press **C1** or **C2** to convert displayed figure from **LOCAL** to **C1** or **C2**.

- *1 Specifying the Number of Decimal Places for Intermediate Local Currency Amounts. When you convert from one national currency to another, the calculator internally converts the original currency to Local Currency. This conversion result is the "intermediate Local Currency amount". Next, the intermediate Local Currency amount is converted to the target currency. The flow of the steps of the conversions will be shown on the printout. For such a calculation, you should use the following procedure to specify the number of decimal places for the intermediate Local Currency amount. You can specify from 0 (*2) to 9 decimal places, for a floating decimal point (F). The intermediate Local Currency amount is rounded off to the number of decimal places you specify.
- *2 0 is displayed when F (floating point) is set for the number of decimal places. F is the initial default setting.
- For rates of 1 or greater, you can input up to six digits. For rates less than 1 you can input up to 8 digits, including 0 for the integer digit and leading zeros (though only six significant digits, counted from the left and starting with the first non-zero digit, can be specified).

Tax Calculation Function

ENGLISH

TAX + **Add Tax Key** : Used for adding the tax amount to the displayed figure.

TAX - **Deduct Tax Key** : Used for deducting the tax amount from the displayed figure.

Cash Change Function

CHANGE : Used for calculating the change amount, it perform accurate and fast change calculation.

Overflow

In the following cases, "E" is displayed, • ERR • is printed, the keyboard is electronically locked, and further operation is impossible. Press **CE** to clear the overflow. The overflow function occurs when:

1. The result or the memory content exceeds 12 digits to the left of the decimal point.
 2. Dividing by "0".
 3. The sequential operation speed is faster than the calculation processing speed. (Buffer Register Overflow)
- Electromagnetic interference or electrostatic discharge may cause the display to malfunction or the memory currency rate and tax rate to be lost or altered. Should this occur, use the tip of a ballpoint pen (or similar sharp object) to press the [RESET] button on the back of the calculator. After resetting be sure to set the currency rate and tax rate again.



Specifications

Power source: AC100V – 240V 50/60Hz

Operation Temperature: 0°C to 40°C

Calculating Capacity: 12 digits maximum

Dimension: 334mm (W) x 219mm (L) x 74.5mm (H)

Weight: 1.6 kg

(Subject to change without notice)


Replacing The Ink Ribbon

ENGLISH


Note: Turn the power switch off. (Figure 1)


- 1) Lift up the tab on the back-side of the printer cover, and then remove the cover. (Figure 2)
- 2) While pinching together the ribbon lock (A) in the direction of arrow, lift ribbon spools off the shafts. Discard the old ribbon and spools. (Figure 3)
- 3) Separate the spools of new ribbon between the tape and printer head. Guide it around the four positions of the ribbon guide (B) and place the spools on the shafts. (Figure 4)
- 4) When the ribbon spools have settled, release the ribbon locks. If necessary, rotate the spools until the pegs on the bottom of the spool seat themselves in the holes of the spool holder. (Figure 5)
- 5) Rotate either spool to take up any ribbon slack, making sure that the ribbon is positioned around the four ribbon guides. Replace the printer cover. (Figure 6)

IMPORTANT: Use only the same type of ribbon spools.



Inserting Printing Paper

- 1) Lift up the paper arm (Figure 7).
 - When inserting the paper, cut the edge of the paper as shown.
- 2) Place the new paper roll on the arm. The edge of the paper should be positioned as shown (Figure 8).
- 3) Insert the paper into the slit located at the top of the machine as indicated (Figure 9).
- 4) Turn the power switch on. Press the paper feed key  to advance the paper (Figure 10).
 - Suitable paper roll – Width: 57mm (2-1/4") / Diameter: max. 86mm (3-3/8")
 - Paper: standard paper 45kg / 1000 sheets / 788 x 1091mm / (99.2lb / 1000 sheets / 31" x 43")




Memory backup battery retains the currency rate and tax rate, even if the power is off or the AC cord is disconnected.

Battery : 1 Lithium battery (Type : CR2032)

Battery life : Backup time 3 years

CAUTION: Risk of explosion if battery is replaced by an incorrect type dispose of used batteries according to the instruction.

Dispose of batteries according to local regulations. Do not dispose as household waste.




After replace the back-up battery, press the [RESET] button, after resetting be sure to set the currency rate and tax rate again.

Sebelum Memulai	P.8
Perawatan Umum.....	P.8
Tombol Pemilih Titik Desimal	P.9
Tombol Pembulatan	P.9
Tombol Jumlah Item	P.9
Nilai Total/Tombol Pengaturan Tarif Pajak.....	P.10
Tombol Cetak	P.10
Fungsi-Fungsi Penting Untuk Diingat.....	P.10
Kalkulasi Penjualan Usaha.....	P.11
Fungsi Konversi Mata Uang	P.11
Fungsi Kalkulasi Pajak	P.12
Fungsi Uang Kembalian	P.12
Limbah Atas	P.12
Spesifikasi	P.12
Mengganti Pita Tinta	P.13
Memasukkan Kertas Cetak	P.13
Baterai Cadangan	P.14
Contoh Kalkulasi	P.15-21

Sebelum Memulai

- 1) Lepaskan pita insulasi di belakang kalkulator dan tekan tombol RESET sebelum digunakan. (Gambar **a**)
- 2) Aktifkan daya. (Gambar **b**)



Perawatan Umum

- Jangan gunakan atau biarkan kalkulator di bawah sinar matahari langsung. Mesin pencetak tunduk pada perubahan suhu yang cepat. Kelembapan yang tinggi, debu dan kotoran juga harus dihindari.
- Gunakan kain kering untuk membersihkan tutup (casing) kalkulator. Jangan gunakan air atau detergen.
- Aktifkan pencetak ketika kertas rol sudah dipasang.
- Hindari penggunaan kalkulator di tempat-tempat di mana ada kikiran besi karena dapat memengaruhi sirkuit listrik kalkulator.
- Jangan taruh apa pun di atas kalkulator, khususnya di atas mekanisme pencetak.
- Matikan kalkulator sebelum mencabut kabel dari aliran listrik.
- Tarik keluar kabel utama dari soket dinding jika Anda ingin mematikan daya utama atau apabila terjadi kerusakan listrik (misalnya timbul asap). Cabut segera sambungan dari soket listrik arus bolak-balik (AC).
- Soket arus bolak-balik (AC) harus ditempatkan dekat dengan peralatan ini dan mudah diakses.
- Di lingkungan dengan pengosongan elektrostatis, contoh mungkin salah dan pengguna diminta untuk menyetal ulang contoh.

Tombol Pemilih Titik Desimal

BAHASA INDONESIA



- Digunakan untuk menentukan posisi titik desimal (+ 0 2 3 4 6 F) untuk hasil perhitungan.



+ (Mode-Tambah) – fungsi penambahan dan pengurangan dilakukan dengan 2 titik desimal. Hal ini baik untuk kalkulasi mata uang.



F (Titik Desimal Kambang) – semua angka efektif hingga 12 digit dicetak atau ditampilkan.

Tombol Pembulatan



- Digunakan untuk pembulatan ke atas (\uparrow), pembulatan (5/4), atau pembulatan ke bawah (\downarrow) terhadap digit desimal yang dipilih sebelumnya di dalam hasil.

Tombol Jumlah Item



: Pada posisi “n+” atau “n+/-”, kalkulator menghitung dan mencetak jumlah kalkulasi item hingga 999.

<PENGHITUNG ITEM>

Apabila tombol “ITEM” disetel pada “n+”, kalkulator menghitung berapa kali tombol \oplus dan \ominus ditekan.

Apabila tombol disetel pada “n+/-”, kalkulator menghitung berapa kali tombol \oplus ditekan dan mengurangi dari total berapa kali tombol \ominus ditekan.

<PENGHITUNG ITEM MEMORI>

Apabila tombol “ITEM” disetel pada “n+”, kalkulator menghitung berapa kali tombol $M\pm$ dan $M\mp$ ditekan.

Apabila tombol “ITEM” disetel pada “n+/-”, kalkulator menghitung berapa kali tombol $M\pm$ ditekan dan mengurangi dari total berapa kali tombol $M\mp$ ditekan.

<HASIL CETAK JUMLAH ITEM>

Apabila tombol “CETAK” diaktifkan dan tombol “ITEM” berada pada posisi “n+” atau “n+/-”, jumlah item yang disimpan oleh penghitung dapat dicetak hingga tiga digit di sisi kiri kertas dengan menekan baik tombol C maupun tombol X untuk jumlah item dan tombol $M\pm$ atau tombol $M\mp$ untuk jumlah item memori.

NILAI TOTAL



GT : Ketika kalkulasi dilakukan dengan tombol nilai total (GT) "AKTIF", angka total diakumulasikan di dalam memori nilai total. Setiap kali **GT** ditekan, angka subtotal dicetak dengan simbol GT. Apabila **GT** ditekan, nilai total antara dicetak dengan simbol GT. Tekan **GT** secara berturut-turut untuk mendapatkan nilai total diikuti dengan simbol G*.

PENGATURAN TARIF PAJAK



: Atur tombol ke "ATUR TARIF PAJAK" untuk menetapkan atau memanggil balik tarif pajak.

Tombol Cetak

CETAK TIDAK AKTIF



: Entri dan hasil akan muncul dalam tampilan, tetapi tidak akan dicetak.

CETAK AKTIF



: Entri dan hasil akan muncul dalam tampilan dan akan dicetak.

Fungsi-Fungsi Penting Untuk Diingat



Tombol Sama Dengan Memori Plus: Digunakan untuk mendapatkan hasil kalkulasi dan secara otomatis menambahkan hasil tersebut ke dalam memori. Tombol ini juga digunakan untuk menambahkan angka ke dalam memori.



Tombol Sama Dengan Memori Minus: Digunakan untuk mendapatkan hasil kalkulasi dan secara otomatis mengurangi hasil tersebut dari memori. Tombol ini juga digunakan untuk mengurangi angka dari memori.



Tombol Subtotal Memori: Digunakan untuk mendapatkan hasil antara kalkulasi memori. Tombol ini tidak akan menghapus isi memori.



Tombol Total Memori dan Hapus Memori: Digunakan untuk mendapatkan total isi memori. Tombol ini akan menghapus isi memori pada saat bersamaan.



Tombol Hapus Entri dan Tombol Hapus: Tekan satu kali untuk menghapus nilai yang terakhir kali dimasukkan. Tekan sekali lagi untuk menghapus semua nilai yang dimasukkan kecuali memori. Tombol ini juga digunakan untuk menghapus kesalahan limpah atas.



Tombol Sama Dengan: Digunakan untuk mendapatkan hasil perkalian dan pembagian.



Tombol Non-Tambah/Subtotal: Digunakan untuk mencetak informasi yang tidak memengaruhi kalkulasi seperti tanggal dan nomor seri. Angka-angkanya dicetak di sisi kiri kertas. Tombol ini juga digunakan untuk mendapatkan hasil antara.



Tombol Total: Digunakan untuk mendapatkan hasil penambahan dan pengurangan.

[COST] **[SELL]** **[MARGIN]** : Digunakan untuk menghitung biaya, harga jual, dan nilai margin laba. Masukkan nilai 2 item mana pun untuk mendapatkan item nilai saldo. (Misalnya masukkan nilai biaya dan harga jual untuk mendapatkan % margin laba).

Fungsi Konversi Mata Uang

- [CE/C]** **[RATE]** **[C1]** atau **[C2]** : Tekan **[CE/C]** **[RATE]** dan tahan selama 1 detik, kemudian masukkan nilai tukar konversi mata uang dan tekan **[C1]** atau **[C2]** untuk menyimpan nilai tukar.
- [CE/C]** **[C1]** atau **[C2]** : Tekan **[CE/C]** **[C1]** atau **[C2]** untuk memanggil balik nilai tukar mata uang yang disimpan.
- [LOCAL]** : Tekan **[LOCAL]** untuk mengonversi angka mata uang yang ditampilkan dari **[C1]** atau **[C2]** menjadi **[LOCAL]**.
- [C1]** atau **[C2]** : Tekan **[C1]** atau **[C2]** untuk mengonversi angka mata uang yang ditampilkan dari **[LOCAL]** menjadi **[C1]** atau **[C2]**.

- *1 Menentukan Jumlah Tempat Desimal untuk Jumlah Antara Mata Uang Lokal. Ketika Anda mengonversi mata uang satu negara dengan mata uang negara lain, secara internal kalkulator mengonversi mata uang asal ke Mata Uang Lokal. Hasil konversi ini adalah "Jumlah Antara Mata Uang Lokal". Selanjutnya, Jumlah Antara Mata Uang Lokal dikonversi ke mata uang target. Alur langkah-langkah konversi akan ditunjukkan di hasil cetak. Untuk kalkulus semacam ini, Anda harus menggunakan prosedur berikut untuk menetapkan tempat desimal untuk jumlah antara Mata Uang Lokal. Anda dapat menentukan dari 0 (*2) hingga 9 tempat desimal, untuk titik desimal kambang. Jumlah antara Mata Uang Lokal dibulatkan ke jumlah tempat desimal yang Anda tetapkan.
- *2 0 ditampilkan ketika F (titik kambang) disetel untuk jumlah tempat desimal. F adalah pengaturan default awal.
- Untuk nilai tukar 1 atau yang lebih besar, Anda dapat memasukkan hingga 6 digit. Untuk nilai tukar kurang dari 1, Anda dapat memasukkan hingga 8 digit, termasuk 0 untuk digit bilangan bulat dan angka nol di depan (meski hanya enam digit signifikan, dihitung dari kiri dan dimulai dari digit bukan nol yang pertama, dapat ditentukan).

Fungsi Kalkulasi Pajak

BAHASA INDONESIA

TAX + Tombol Tambah Pajak - Digunakan untuk menambahkan jumlah pajak ke angka yang ditampilkan.

TAX - Tombol Kurangi Pajak - Digunakan untuk mengurangi jumlah pajak dari angka yang ditampilkan.

Fungsi Uang Kembali

CHANGE : Digunakan untuk menghitung uang kembali, fungsi ini melakukan perhitungan uang kembali secara akurat dan cepat.


Limpah Atas

Dalam hal-hal berikut, apabila "E" ditampilkan, "ERR" dicetak, papan tombol terkunci secara elektronik dan operasi lebih lanjut tidak dapat dilakukan.

Tekan **CE** untuk menghapus limbah atas. Limbah atas terjadi ketika:

1. Hasil atau isi memori lebih dari 12 digit ke sebelah kiri titik desimal.
2. Membagi "0".
3. Kecepatan operasi berurutan lebih cepat dari kecepatan proses kalkulasi (Register Penyangga Limbah Atas).

■ Gangguan elektromagnetik atau pengosongan elektrostatik dapat menyebabkan mala fungsi tampilan atau hilangnya atau berubahnya memori, nilai tukar mata uang dan tarif pajak. Apabila ini terjadi, gunakan ujung bolpoin (atau benda tajam serupa) untuk menekan tombol "RESET" di bagian belakang kalkulator. Setelah melakukan reset, pastikan untuk menetapkan kembali kalender, jam dan tarif pajak.



Spesifikasi

Sumber Daya : AC 100V – 240V, 50/60Hz

Suhu Operasi : 0°C - 40°C

Kapasitas Kalkulasi : Maksimum 12 digit

Dimensi : 334 mm (panjang) X 219 mm (lebar) X 74.5mm (tinggi)


Berat : 1.6 kg

(Tunduk pada perubahan tanpa pemberitahuan)


Catatan: Matikan daya (Gambar 1)


- 1) Angkat tab di bagian belakang tutup pencetak, kemudian lepaskan tutup itu. (Gambar 2)
- 2) Ketika menjepit serentak pengunci pita (A) ke arah panah, angkat rol pita ke luar dari porosnya. Buang pita dan rol yang lama. (Gambar 3)
- 3) Pisahkan rol pita baru di antara pita dan kepala pencetak (printer head). Bawa ke empat posisi pengarah pita (B) dan taruh rol di dalam poros. (Gambar 4)
- 4) Apabila rol pita sudah terpasang, buka pengunci pita. Jika perlu, putar rol hingga pasak-pasak di bagian bawah dudukan rol berada di dalam lubang-lubang penyangga rol itu. (Gambar 5)
- 5) Putar kedua rol untuk mengencangkan kekenduran, memastikan bahwa pita berada di keempat pengarah pita. Taruh kembali tutup pencetak. (Gambar 6)

PENTING: Hanya gunakan rol pita yang sama jenis.



Memasukkan Kertas Cetak

- 1) Angkat sandaran kertas (Gambar 7).
 - Ketika memasukkan kertas, potong ujung kertas seperti yang ditunjukkan.
- 2) Taruh gulungan kertas baru di sandaran kertas. Ujung kertas harus diletakkan seperti yang ditunjukkan (Gambar 8)
- 3) Masukkan kertas ke dalam celah yang ada di belakang mesin seperti yang ditunjukkan (Gambar 9)
- 4) Hidupkan tombol daya . Tekan tombol pengisi kertas  untuk menaikkan kertas (Gambar 10).
 - Gulungan kertas yang sesuai – Lebar 57 mm (2 – 1/4")
Diameter: maksimum 86 mm (3-3/8")
 - Kertas: kertas standar 45kg/1000 lembar/788X1091 mm
(99,2 lb/1000 lembar/31"X43")




Baterai cadangan memori menyimpan tarif pajak, pengaturan kalender dan jam, bahkan jika daya mati atau kabel listrik dicabut.

Baterai : 1 baterai Litium (Tipe CR2032)

Umur baterai : 3 tahun

PERINGATAN: Risiko ledakan jika baterai diganti dengan jenis yang tidak sesuai. Buang baterai bekas sesuai petunjuk. Buang baterai sesuai dengan aturan lokal. Jangan buang sebagai limbah rumah tangga.



























Setelah mengganti baterai cadangan, tekan tombol [RESET] setelah melakukan pengaturan ulang untuk menetapkan mengatur tarif pajak, jam, dan kalender lagi.

Calculation Example / Contoh Kalkulasi




- E** • If switches on your calculator do not match the example below, please set switches as shown.
- DE** • Jika tombol-tombol dalam kalkulator Anda tidak sesuai dengan contoh-contoh di bawah ini, harap atur tombol-tombol seperti yang ditunjukkan.






Calculation	Operation	Print Out
$2+(3 \times 4)-5=9$	 2 $+$ 3 \times 4 $=$ $+$ 5 $-$ \times	0. C 2.00 + 3. x 4. = 12.00 * 12.00 + 5.00 - 9.00 *
$-2 \times 3 = -6$	2 $-$ \times 3 $=$	2.00 - 2.00 \times 3. = 6.00 \times
$3^3 = 27$	 3 \times $=$ $=$	0. C 3. x 3. = 9.00 * 9.00 = 27.00 *

$1/7=0.1428571428571$ (MP1411-LTSC)	DECIMAL  7   	$7. \div$ $7. =$ $1.000 \times$ $1.000 =$ $0.143 \times$
$\$12.55+\$15.75-\$5.30$ $=\$23.00$	DECIMAL  1255  1575  530  	$12.55 +$ $15.75 +$ $5.30 -$ $23.00 \times$
$8 \div 3 \times 3.7 + 9$ $=18.86666666666666$ (MP1411-LTSC)	DECIMAL  8  3  3  7  9  	$8. \div$ $3. \times$ $3.7 =$ $9.86666666666666 \times$ $9.86666666666666 +$ $9. +$ $18.86666666666666 \times$
$123 \times 756 \div 456 = 56,088$	DECIMAL  123  756  456 	$123. \times$ $456. =$ $56,088.00 \times$
$123 \times 45 \div 6 = 56,088$	DECIMAL  123  45  6 	$123. \times$ $456. =$ $56,088.00 \times$





Round-up / Pembulatan ke Atas

$28 \div 3 = 9.3333333333333$	ROUNDING  28  3 	$28. \div$ $3. =$ $9.34 \times$
-------------------------------	--	---------------------------------------














Round-off / Pembulatan

$11 \div 3 = 3.6666666666666$	ROUNDING  11  3 	$11. \div$ $3. =$ $3.67 \times$
-------------------------------	--	---------------------------------------







Round-down / Pembulatan ke Bawah

$11 \div 3 = 3.66666666666666$	<p>ROUNDING  () 11  3 </p>	$11. \div$ $3. =$ $3.66 *$
--------------------------------	--	----------------------------------

Data Printout / Hasil Cetak Data

<p>20 Nov. 2012</p> <p style="padding-left: 100px;">1,860</p> <p style="padding-left: 100px;">1,420</p> <p>21 Nov. 2012</p> <p style="padding-left: 100px;">2,380</p> <p style="padding-left: 100px;">+) <u>2,200</u></p> <p style="padding-left: 100px;">7,860</p>	<p>ROUNDING  () 20  11  2012  1860  1420  21  11  2012  2380  2200  </p>	<p>#20.11.2012</p> <p style="padding-left: 100px;">1,860.00 +</p> <p style="padding-left: 100px;">1,420.00 +</p> <p>#21.11.2012</p> <p style="padding-left: 100px;">2,380.00 +</p> <p style="padding-left: 100px;">2,200.00 +</p> <p style="padding-left: 100px;">7,860.00 *</p>
--	--	--

Business sales calculation / Kalkulasi Penjualan Usaha

<p>Calculating Cost</p> <p>Selling Price : \$2,000</p> <p>Profit Margin : 30%</p> <p>Cost = ? (\$1,400)</p> <p>Calculating Selling Price</p> <p>Cost : \$1,500</p> <p>Profit Margin : 20%</p> <p>Selling Price = ? (\$1,875)</p> <p>Calculating Profit Margin</p> <p>Cost : \$1,500</p> <p>Selling Price : \$2,000</p> <p>Profit Margin = ? (25%)</p>	<p>2000 </p> <p>30 </p> <p>1500 </p> <p>20 </p> <p>1500 </p> <p>2000 </p>	<p>2,000. S*</p> <p>30. M%</p> <p>1,400.00 C*</p> <p>1,500. C*</p> <p>20. M%</p> <p>1,875.00 S*</p> <p>1,500. C*</p> <p>2,000. S*</p> <p>25.00 M%</p>
--	---	---

Tax Calculation / Kalkulasi Pajak

Set Tax Rate Tax Rate = 5%		0. %
	5 ←	* 5. %
Add the Tax Amount Price \$2,000 without tax Tax= ? (\$100) Selling Price with tax = ? (\$2,100)	2000	2,000. 5. % 100.00 Δ+ 2,100.00 *
Deduct the Tax Amount Selling Price \$3,150 with tax Tax= ? (\$150) Price without tax = ? (\$3,000)	3150	3,150. 5. % 150.00 Δ- 3,000.00 *
Change Tax Rate Tax rate= 10%		5. %
	10 ←	* 10. %

Grand Total Calculation / Kalkulasi Nilai Total

$123+456 = 579$		123	123.00 +
$+) 488-390 = 98$		456	456.00 +
$\hline 677$		488	579.00 GT
$+) 655+188 = 843$		390	488.00 +
$\hline 1,520$		390	390.00 -
		GT	98.00 GT
		655	677.00 G◇
		188	655.00 +
		188	188.00 +
		GT	843.00 GT
		(Clear Grand Total / Hapus Nilai Total)	1,520.00 G◇
			1,520.00 G*

Item Counting Calculation / Jumlah Item

$\begin{array}{r} 1,860 \text{1) } \\ 1,420 \text{2) } \\ 2,380 \text{3) } \\ +) 1,475 \text{4,5) } \\ \hline 5,660 \end{array}$	<p>GT (OFF ON) W/MATE/SET ITEM (OFF ON) R+ R+/-</p> $\begin{array}{r} 1860 \text{ +} \\ 1420 \text{ +} \\ 2380 \text{ +} \\ 1475 \text{ +} \\ \hline 5660 \text{ -} \end{array}$	$\begin{array}{r} 1,860.00 \text{ +} \\ 1,400.00 \text{ +} \\ 2,380.00 \text{ +} \\ 1,475.00 \text{ +} \\ \hline 1,475.00 \text{ -} \\ 005 \\ 5,660.00 \text{ *} \end{array}$
$\begin{array}{r} 1,860 \text{1) } \\ 1,430 \\ 1,420 \text{2) } \\ +) 2,380 \text{3) } \\ \hline 5,660 \end{array}$	<p>ITEM (OFF ON) R+ R+/-</p> $\begin{array}{r} 1860 \text{ +} \\ 1430 \text{ +} \\ 1420 \text{ -} \\ 2380 \text{ +} \\ \hline 5660 \text{ +} \end{array}$	$\begin{array}{r} 1,860.00 \text{ +} \\ 1,430.00 \text{ +} \\ 1,430.00 \text{ -} \\ 1,420.00 \text{ +} \\ 2,380.00 \text{ +} \\ \hline 5,660.00 \text{ *} \\ 003 \end{array}$

Memory Calculation / Kalkulasi Memori

$\begin{array}{r} 243 \times 2 = 486 \\ +) 576 \times 5 = 2,880 \\ \hline 3,366 \\ -) 75 + 103 = 178 \\ \hline 3,188 \end{array}$	<p>ITEM (OFF ON) R+ R+/-</p> $\begin{array}{r} 243 \text{ X} \\ 2 \text{ M}\pm \\ 576 \text{ X} \\ 5 \text{ M}\pm \\ 75 \text{ +} \\ 103 \text{ +} \\ \hline 178 \text{ X} \end{array}$ <p>(Recall Memory/ Panggil Balik Memori) M◊ (Clear Memory/Hapus Memori) M*</p>	$\begin{array}{r} 243. \text{ x} \\ 2. = \\ 486.00 \text{ M+} \\ 576. \text{ x} \\ 5. = \\ 2,880.00 \text{ M+} \\ 3,366.00 \text{ M}\diamond \\ 75.00 \text{ +} \\ 103.00 \text{ +} \\ 178.00 \text{ *} \\ 178.00 \text{ M-} \\ 3,188.00 \text{ M}\diamond \\ 3,188.00 \text{ M*} \end{array}$
---	--	--

Currency Conversion Calculation / Kalkulasi Konversi Mata Uang

<p>Set Currency Rate</p> <p>Local = 1 (Euro) C1 = 1.45 (US\$) C2 = 0.7 (£)</p>	<p><input type="checkbox"/> <input type="checkbox"/> RATE SET (Hold 1 second)</p> <p>1 <input checked="" type="radio"/> 45 <input type="checkbox"/> C1</p> <p><input type="checkbox"/> <input type="checkbox"/> RATE SET (Hold 1 second)</p> <p>0 <input checked="" type="radio"/> 7 <input type="checkbox"/> C2</p>	<p>0. C</p> <p>1.45 C1</p> <p>0. C</p> <p>0.7 C2</p>
<p>Convert Currency</p> <p>Euro 35 = US\$? (US\$50.75)</p> <p>£ 58 = Euro ? (€ 82.86)</p>	<p><input type="checkbox"/> <input type="checkbox"/> RATE SET (Hold 1 second)</p> <p>35 <input type="checkbox"/> LOCAL</p> <p><input type="checkbox"/> C1</p> <p>58 <input type="checkbox"/> C2</p> <p><input type="checkbox"/> LOCAL</p> <p>58 <input type="checkbox"/> C1</p> <p><input type="checkbox"/> C2</p>	<p>0. C</p> <p>35. L</p> <p>1.45 C1</p> <p>50.75 *</p> <p>58.</p> <p>0.7 C2</p> <p>82.86 L*</p>
<p>US\$58 = £?</p> <p>US\$58 = Euro 40 = £ 28</p>	<p>58 <input type="checkbox"/> C1</p> <p><input type="checkbox"/> C2</p>	<p>58.</p> <p>1.45 C1</p> <p>40. L</p> <p>0.7 C2</p> <p>28.00 *</p>
<p>Recall Currency Rate</p>	<p><input type="checkbox"/> <input type="checkbox"/> RATE SET (Hold 1 second)</p> <p><input type="checkbox"/> C1</p> <p><input type="checkbox"/> <input type="checkbox"/> RATE SET (Hold 1 second)</p> <p><input type="checkbox"/> C2</p>	<p>0. C</p> <p>1.45 C1</p> <p>0. C</p> <p>0.7 C2</p>

Cash Change Calculation / Kalkulasi Uang Kembali

<p>Purchase price: \$250</p> <p>\$300</p> <p>+)</p> <hr/> <p>\$270</p> <p>\$820</p>	<p>250 <input checked="" type="checkbox"/></p> <p>300 <input checked="" type="checkbox"/></p> <p>270 <input checked="" type="checkbox"/></p> <p><input checked="" type="checkbox"/></p> <p>1000 <input type="checkbox"/> CHANGE</p>	<p>250.00 +</p> <p>300.00 +</p> <p>270.00 +</p> <p>820.00 *</p> <p>.....</p> <p>1,000.00 CC</p> <p>180.00 ΔC</p>
---	---	--

Cash Change with Memory Calculation / Uang Kembali dengan Kalkulasi Memori

Purchase price: \$1,770	1770 M± M◊	1,770.00 M+
Cash paid: \$1,800 Change price = ? (\$30)	1800 CHANGE	1,770.00 M◊
	M◊	1,800.00 CC 30.00 ΔC
Cash paid: \$2,000 Change price = ? (\$230)	2000 CHANGE
	M*	1,770.00 M◊
		2,000.00 CC 230.00 ΔC 1,770.00 M*

Percentage Calculation / Kalkulasi Persentase

$2,000 + (2,000 \times 12\%)$ $= 2,240$	2000 X 12 %± +	2,000. x 12. % 240.00 * 2,240.00 +%
$2,000 - (2,000 \times 15\%)$ $= 1,700$	2000 X 15 %± -	2,000. x 15. % 300.00 * 1,700.00 -%

Overflow / Limpah Atas

$55,000,000,000,000$ x) $2,300$ <hr/> 126500000000000000 (Error) _____ (MP1411-LTSC)	5500000000000000 X 2300 = CE CE 6 ÷ 0 = CE C	55,000,000,000,000. x 2,300. = • ERR • 1,265.0000000000 * 0. C
$6 \div 0 = 0$ (Error)		6. ÷ 0. = • ERR • 0. * 0. C

~ MEMO ~

CANON ELECTRONIC BUSINESS MACHINES (H.K.) CO., LTD.
17/F., Tower One, Ever Gain Plaza, 82-100 Container Port Road,
Kwai Chung, New Territories, Hong Kong

CANON MARKETING (MALAYSIA) SDN BHD.
Block D, Peremba Square, Saujana Resort, Section U2,
40150 Shah Alam, Selangor Darul Ehsan, Malaysia

Free Manuals Download Website

<http://myh66.com>

<http://usermanuals.us>

<http://www.somanuals.com>

<http://www.4manuals.cc>

<http://www.manual-lib.com>

<http://www.404manual.com>

<http://www.luxmanual.com>

<http://aubethermostatmanual.com>

Golf course search by state

<http://golfingnear.com>

Email search by domain

<http://emailbydomain.com>

Auto manuals search

<http://auto.somanuals.com>

TV manuals search

<http://tv.somanuals.com>