



*Need help getting started?*

# INSTRUCTIONS



 Toll Free 1800-898-6970

*Please visit [StoreBound.com](http://StoreBound.com)*

## Premium Juicer

 A STOREBOUND COLLABORATION



## *Table Of Contents:*

- 1 Safety Guidelines
- 2 Get To Know Your Juicer
- 3 Using Your Juicer
- 4 Speed Settings
- 5 Cleaning Your Juicer
- 6 Recipes

*Please Read and Save this Instruction Manual*

## **IMPORTANT SAFETY GUIDELINES**






**Read all instructions carefully.**

**When using electrical appliances, basic safety precautions should be followed, especially the following:**

- Read all instructions carefully.
- Remove all packaging and labels from appliance prior to use.
- To protect against risk of electrical shock do not put cord, plugs, or appliance in or near water or other liquid.
- Any maintenance other than cleaning please contact StoreBound directly at by phone 1-800-898-6970 from 7AM - 7PM PST Monday through Friday or by email at [info@storebound.com](mailto:info@storebound.com).
- Keep appliance away from children when in use.
- Only use fruit and vegetables with this product, other food may damage the appliance.
- Unplug from outlet when not in use, during assembly, during disassembly, and before cleaning.
- Avoid contact with moving parts.
- Do not operate this appliance with a damaged cord, damaged plug, after the appliance malfunctions, is dropped, or damaged in any manner.
- Use only attachments recommended or sold by the manufacturer. Others may result in fire, electric shock, or injury.
- Do not use outdoors.
- Do not leave unattended when on.
- Do not let cord hang over edge of table, hang over edge of counter, or touch hot surfaces.
- Always make sure that part 3 is locked securely in place before motor is engaged. Do not unlock lid before juicer has finished operation.
- Make sure to turn switch to 0 (off) position after each use of your juicer. Make sure the motor stops completely before disassembling.
- Do not put your fingers or other objects into the juicer while it is in operation. If food becomes lodged in the opening, use part 2 to move it through safely. If that doesn't work use another piece of fruit or vegetable to move it through. When neither is possible, turn the motor off, unplug, and disassemble juicer to remove stuck food.
- Do not use the appliance if any parts are damaged.
- Do not use without part 4 in place.
- Keep hands and utensils away from moving blades while processing food to reduce the risk of severe injury or damage to the juicer. A scraper may be used, but only when the juicer is off.
- Blades and part 8 are sharp. Handle carefully. Wash using brush or gloves. Do not touch small cutting blades in the base of part 8.
- Do not place on or near a hot gas, hot electric burner, or in a heated oven.
- When cleaning, do not submerge part 6 (with electrical parts) in any liquid, instead, use a soft wet cloth to wipe down.
- Be certain part 3 is securely locked in place before engaging appliance.
- Never feed food into the juicer by hand. Always use part 2.
- Appliance is not intended for use by children.

**Get to Know Your Juicer:**

- 1 Food Pusher
- 2 Feed Tube
- 3 Upper Housing Cover
- 4 Pulp Collector
- 5 Locking Arm
- 6 Main housing
- 7 Speed Buttons and On/Off Switch
- 8 Mesh Filter/Cutting Disk
- 9 Mesh Filter Holder
- 10 Juice Outlet
- 11 Juice Pitcher and Removable Froth Separator




## IMPORTANT - FIRST TIME, CLEAN THE JUICER VERY CAREFULLY BEFORE USING

- Place the unplugged part 6 on a flat surface and place switch in 0 (off) position.
  - Place part 9 on top of part 6 (make sure the spout is resting in the groove on the main housing).
  - Then attach part 8 fits into part 6. Ensure that the three pegs line up with the three slots in the base, make sure to lock in place. Rotate slightly to make it move smoothly.
  - Place part 3 on part 9. Use one hand to press part 3 down while using other hand to lock part 5 in place. Part 5 should snap into the grooves on part 3.
  - Place part 1 through the part 2. The pusher arrow needs to line up with the feed tube notch.
  - Place part 4 underneath part 3. Tilt slightly when putting in position.
  - Attach part 10 to the nozzle on part 9. This will eliminate juice splashing.
  - Put part 11 underneath part 10.
  - Plug in juicer.
  - Always turn juicer on before juicing.
- \* You can use part 10 when only juicing by the glass or with the juice pitcher.

### Safety While Using:

- Only feed the food through part 2 with part 1.
- Do not use the juicer for more than 5 minutes consecutively. Let the juicer have 5 minutes to rest and reset between uses.
- Do not put too much food in at any one time.
- When done juicing, make sure to turn the switch to the 0 setting. When appliance has stopped then it is safe to remove the juice pitcher.
- Make sure to unplug when finished juicing.

**IMPORTANT NOTE -** All food should be completely cleaned before being fed through part 2. For larger food cut it into a more suitable size. For some fruits remove peel and rind.



**I** For softer fruits and vegetables use.

**0** The 0 setting is for when Juicer is off.

**II** For harder fruits and vegetables.

If you aren't sure if it is a hard or soft fruit use the **II** setting.



**IMPORTANT** - AFTER EACH USE THE JUICER SHOULD BE CLEANED PROPERLY. KEEP THE JUICER IN A DRY AND WELL VENTILATED AREA. IF NOT USED FOR MORE THAN 3 DAYS MAKE SURE TO WASH BEFORE NEXT USE.

**TIP** : It is great to clean your juicer prior to drinking. This way the juicer is easier to clean and you can reward yourself with your juice after cleaning.

Clean juicer immediately after juicing as fruits and vegetables are much easier to remove at this time.

- Open part 5. Remove the part 2, part 3, part 9, part 8, and part 4.

**IMPORTANT** - Remove part 8 and part 9 together. Hold on base of part 9 and part 10 while pulling up.

- Clean the pulp from part 4 into a trashcan. Can be used as compost in your garden.
- Pull froth separator up from inside part 11. It should slide out making part 11 easier to clean with soap and water.
- Use clean, warm water, to wash all the non-electric parts.
- When you clean the part 8 it is important to use brush or wear gloves to prevent cutting yourself.
- After washing use a soft and dry cloth to dry all surfaces.

**IMPORTANT** - DO NOT IMMERSE THE MAIN HOUSING IN ANY LIQUID DURING CLEANING. ONLY USE A SOFT AND WET CLOTHE TO WIPE DOWN ANY SURFACE. DO NOT PLACE ACCESSORIES INTO DISHWASHER. AFTER DRYING REASSEMBLE THE APPLIANCE. KEEP IN A DRY AND VENTILATED AREA.

## Morning Fuel:



- ½ Cucumber
- 1-2 Oranges
- 2 Apples
- 1 Tsp Ginger
- 1 Kiwi

## Tropical Sunrise:



- 1 Beet
- 1 Orange
- 1 Celery Stalk
- ¼ Pineapple

## Get up and Go!:



- 4 Raspberries
- 1-2 Spinach Leaves
- 2 Pear
- 1 Apple
- 1 Carrot

Remove any rind or peel from the fruit. Place the fruit into part 2 using part 1 to push the fruit through. Add sugar or honey if you desire a sweeter juice.



## Free Manuals Download Website

<http://myh66.com>

<http://usermanuals.us>

<http://www.somanuals.com>

<http://www.4manuals.cc>

<http://www.manual-lib.com>

<http://www.404manual.com>

<http://www.luxmanual.com>

<http://aubethermostatmanual.com>

Golf course search by state

<http://golfingnear.com>

Email search by domain

<http://emailbydomain.com>

Auto manuals search

<http://auto.somanuals.com>

TV manuals search

<http://tv.somanuals.com>