

In the box


Emerson™
SmartCam HD



User Guide
EVC510




SmartCam




USB Cable

Adaptor



Reset Pin


Metal base



8GB
Micro SD card




User Guide



Anchors & screws

Location of controls



FRONT


BACK

- ① LED indicator
- ② Camera
- ③ Microphone
- ④ Magnet base

- ⑤ Micro SD card slot
- ⑥ Speaker
- ⑦ Reset button
- ⑧ Micro USB port

Inserting Micro SD card

Insert the included 8GB Micro SD card into your SmartCam's Micro SD card slot. (SmartCam supports up to 32GB of storage.)




Micro SD card

i Keep your camera unplugged when inserting or ejecting a Micro SD card.

Installing camera

1. Plug the USB cable into the back of the camera.
2. Attach the other end of the cable into the included adaptor to connect to a power outlet, or plug the USB cable directly into a computer.




3. Wait 30 seconds for the camera to boot up.

4. Camera must be reset after it starts up for the first time (see "Reset camera" on the right). If this is not the first time booting the camera, skip this step.

Reset camera

1. Insert the reset pin into the reset button on the back of the camera as shown below.
2. Press and hold the pin down for 5 seconds.
3. Wait for the camera to reboot and for the LED indicator to start blinking rapidly.



Reset pin

Downloading SmartCam Pro app



Open the App Store or Google Play store on your device and search for "SmartCam Pro", then download and install the app.



SmartCam Pro

The SmartCam Pro app is compatible with:


- iOS 6.0 and later
- Android 2.2 and later




Setting up the camera

Before proceeding, make sure your device is connected to a Wi-Fi network.

1. After installing SmartCam Pro, launch the app and tap "Add a camera."




2. Select "Set up camera."




3. Make sure the blue LED indicator is blinking rapidly before connecting. If it is not, reset your camera (see "Reset camera").




4. The name of the Wi-Fi network will automatically be filled in. Enter the Wi-Fi password or leave it blank if there is none, then tap "Next."



5. Wait for your camera to connect to the Wi-Fi network. If your camera fails to connect, reset the camera and repeat all the steps.



6. After a successful connection, you will be prompted to create a name and password for your camera.



Your password must meet the following requirements:


- At least 8 characters long
- Contain a number
- Contain an uppercase letter
- Contain a lowercase letter

App features

Camera list

A preview of your SmartCam will appear on the home screen.

Refresh all the camera previews at once




Refresh, edit, or remove a camera.

Tap the preview screen to view the live camera feed.

i If your camera is disconnected, reconnect the camera and wait for the blue LED indicator to remain constant.

Live camera feed

View and hear your SmartCam's live camera feed directly from your device. The Live camera feed can be viewed from several connected devices simultaneously.



Tap to change resolution
HD 1280X720
SD 640X360

Take snapshots
Record videos
View Recording history & Local albums
Access camera settings
Use camera microphone


i Rotate your device to view your camera in landscape mode.

FRONT

Recording history


Your SmartCam can detect motion and automatically record it directly into its Micro SD card.

When something triggers the alarm, your camera will begin to record. When the camera is done recording, the video will appear in the Recording history.



To view the Recording history, tap at the bottom, then select .


For the Apple iOS version, tap to go to the Recording history directly.



i Each camera has its own individual Recording history. To view another camera's Recording history, go back to "Camera list" and select which camera captured what you wish to see.


Notifications

When the motion detection alarm is triggered, you will be notified immediately on your device.



Tap View to see live feed

Enable notifications on your Apple or Android device to receive notifications even when the app is not active.



i You can turn the motion detection alarm off or change its sensitivity in Advanced Settings.


Local album

You can take snapshots or videos from your live camera feed. Tap to take a snapshot, or tap to record a video (tap again to stop recording).

To access your snapshots and recordings, tap and select .

To view snapshots or videos on the Apple iOS version, go to the "Photos" app.


Local album on Android OS



i The contents of the Local album is stored on your personal device.

Advanced settings

To modify the camera settings, change the password, format the Micro SD card, or update the firmware, access the Advanced settings from either Camera list or Live camera feed.



For the Apple iOS version, access Camera settings from Live camera feed.


Tap "Check for update" to update your SmartCam (it will reboot after an update).

View how much space is available on your SmartCam's Micro SD card (if the SD card info is incorrect, reconnect the SmartCam).


Reconnecting your camera

1. To connect your device to a camera that has already been set up, tap "Reconnect your camera."


Make sure the blue LED indicator is constant before connecting.



2. Scan the QR code on the SmartCam, or search for it via Wi-Fi (your device must be on the same Wi-Fi network as your SmartCam for this option).




3. Once your device is connected to the camera, you will be prompted to enter its password.



i If you relocate your camera to a different Wi-Fi network, you will need to reset your camera and follow the "Setting up the camera" instructions.

If you cannot access your camera because the password is incorrect, tap and select "Edit", then type in the correct password.




For the Apple iOS version, tap the preview to input the correct password.

i If you forget your password, you can reset the password by resetting the camera (see "Reset camera").

Wall-mount instructions

Use the included metal mount, wall anchors and screws to mount your SmartCam to a wall as shown below.



Legal information

FCC Part 15:
Caution:
Any changes or modifications not expressly approved could void the user's authority to operate the equipment.

This equipment has been tested and found to comply with the requirements for a Class B digital device under Part 15 of the Federal Communications Commission (FCC) rules. These requirements are intended to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Re-orient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

*This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.*

Shielded USB cables must be used with this unit to ensure compliance with the Class B FCC limits.

Android, Google and the Google Play store logo are registered trademarks of Google Inc., used with permission.

Apple, iOS, and the App Store are registered trademarks of Apple Inc., registered in the U.S. and other countries.

All other trademarks and trade names are those of their respective owners.

Limited Warranty

90 Days Limited Warranty
In the unlikely event that this product is defective, or does not perform properly, you may within ninety (90) days from your original date of purchase return it to the authorized service center for repair or exchange.

TO OBTAIN WARRANTY SERVICE:
• Provide proof of the date of purchase within the package (Dated bill of sale).
• Prepay all shipping costs to the authorized service center, and remember to insure your return.
• Include a return shipping address (no P.O. Boxes), a telephone contact number, and the defective unit within the package.
• Describe the defect or reason you are returning the product.

Your product will be repaired or replaced, at our option, for the same or similar model of equal value if examination by the service center determines this product is defective. Products received damaged as a result of shipping will require you to file a claim with the carrier.

The shipping address of the authorized service center is:

Southern Telecom, Inc.
Attention: Customer Service (2nd Floor)
14-C 53rd Street
Brooklyn, NY 11232

Should you have any questions or problems concerning this product, please contact our customer service department at:

Customer Support:
☎ 1-877-768-8481 (Toll Free)
Monday - Friday, 8AM - 10PM (EST)
🌐 www.southern telecom.com
Click on "Product Support"

Warranty service not provided
This warranty does not cover damage resulting from accident, misuse, abuse, improper installation or operation, lack of reasonable care, and unauthorized modification. This warranty is voided in the event any unauthorized person opens, alters or repairs this product. All products being returned to the authorized service center for repair must be suitably packaged.

Limitation of Warranty:
THE WARRANTY STATED ABOVE IS THE ONLY WARRANTY APPLICABLE TO THIS PRODUCT. ALL OTHER WARRANTIES, EXPRESS OR IMPLIED (INCLUDING ALL IMPLIED WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE) ARE HEREBY DISCLAIMED. NO VERBAL OR WRITTEN INFORMATION GIVEN BY SOUTHERN TELECOM, INC., ITS AGENTS, OR EMPLOYEES SHALL CREATE A GUARANTEE OR IN ANY WAY INCREASE THE SCOPE OF THIS WARRANTY.
REPAIR OR REPLACEMENT AS PROVIDED UNDER THIS WARRANTY IS THE EXCLUSIVE REMEDY OF THE CONSUMER. SOUTHERN TELECOM, INC. SHALL NOT BE LIABLE FOR INCIDENTAL OR CONSEQUENTIAL DAMAGES RESULTING FROM THE USE OF THIS PRODUCT OR ARISING OUT OF ANY BREACH OF ANY EXPRESS OR IMPLIED WARRANTY ON THIS PRODUCT. THIS DISCLAIMER OF WARRANTIES AND LIMITED WARRANTY ARE GOVERNED BY THE LAWS OF THE STATE OF NEW YORK. EXCEPT TO THE EXTENT PROHIBITED BY APPLICABLE LAW, ANY IMPLIED WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE ON THIS PRODUCT IS LIMITED TO THE APPLICABLE WARRANTY PERIOD SET FORTH ABOVE.

Some states do not allow the exclusion nor limitation of incidental or consequential damages, or limitations on how long an implied warranty lasts so the above limitations or exclusions may not apply to you. This warranty gives you specific legal rights, and you also may have other rights that vary from state to state.

Free Manuals Download Website

<http://myh66.com>

<http://usermanuals.us>

<http://www.somanuals.com>

<http://www.4manuals.cc>

<http://www.manual-lib.com>

<http://www.404manual.com>

<http://www.luxmanual.com>

<http://aubethermostatmanual.com>

Golf course search by state

<http://golfingnear.com>

Email search by domain

<http://emailbydomain.com>

Auto manuals search

<http://auto.somanuals.com>

TV manuals search

<http://tv.somanuals.com>