

# **Mainboard MS 6760 Vers.1**



## **FCC-B Radio Frequency Interference Statement**

---

This equipment has been tested and found to comply with the limits for a class B digital device, pursuant to part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference, in which case the user will be required to correct the interference at his own expense.


### **Notice 1**

The changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

### **Notice 2**

Shielded interface cables and AC. power cord, if any, must be used in order to comply with the emission limits.

**VOIR LA NOTICE D'INSTALLATION AVANT DE RACCORDER AU RESEAU.**



# Lithium Battery Statement

---

## CAUTION

Danger of explosion if battery is incorrectly replaced. Replace only with the same or equivalent type recommended by the manufacturer. Discard used batteries according to the manufacturer's instructions.

# Macrovision® Statement

---

This product incorporates copyright protection technology that is protected by method claims of certain U.S. patents and other intellectual property rights owned by Macrovision Corporation and other rights owners. Use of this copyright protection technology must be authorized by Macrovision Corporation, and is intended for home and other limited viewing users only unless otherwise authorized by Macrovision Corporation. Reverse engineering or disassembly is prohibited.



## Safety Instructions

---

1. Always read the safety instructions carefully.
2. Keep this User's Manual for future reference.
3. Keep this equipment away from humidity.
4. Lay this equipment on a reliable flat surface before setting it up.
5. The openings on the enclosure are for air convection hence protects the equipment from overheating. **DO NOT COVER THE OPENINGS.**
6. Make sure the voltage of the power source and adjust properly 115/230V before connecting the equipment to the power inlet.
7. Place the power cord such a way that people can not step on it. Do not place anything over the power cord.
8. Always Unplug the Power Cord before inserting any add-on card or module.
9. All cautions and warnings on the equipment should be noted.
10. Never pour any liquid into the opening that could damage or cause electrical shock.
11. If any of the following situations arises, get the equipment checked by a service personnel:
  - The power cord or plug is damaged.
  - Liquid has penetrated into the equipment.
  - The equipment has been exposed to moisture.
  - The equipment has not work well or you can not get it work according to User's Manual.
  - The equipment has dropped and damaged.
  - The equipment has obvious sign of breakage.
12. **DO NOT LEAVE THIS EQUIPMENT IN AN ENVIRONMENT UNCONDITIONED, STORAGE TEMPERATURE ABOVE 60°C (140°F), IT MAY DAMAGE THE EQUIPMENT.**



**CAUTION:** Danger of explosion if battery is incorrectly replaced.  
Replace only with the same or equivalent type recommended by the manufacturer.

## Copyright Notice

---

The material in this document is the intellectual property of **MICRO-STAR INTERNATIONAL**. We take every care in the preparation of this document, but no guarantee is given as to the correctness of its contents. Our products are under continual improvement and we reserve the right to make changes without notice.

## Trademarks

---

All trademarks are the properties of their respective owners.

Intel® and Pentium® are registered trademarks of Intel Corporation.

PS/2 and OS®/2 are registered trademarks of International Business Machines Corporation.

Windows® 95/98/2000/NT/XP are registered trademarks of Microsoft Corporation.

Netware® is a registered trademark of Novell, Inc.

Award® is a registered trademark of Phoenix Technologies Ltd.

AMI® is a registered trademark of American Megatrends Inc.

## Revision History

---

<b>Revision</b>	<b>Revision History</b>	<b>Date</b>
V1.0	First release	April 2003
V1.1	Add "Media Center" and "Appendix" Make update on p. 1-7 & 3-3 Replace v1.0	June 2003
v1.2	Special Edition for SI	July 2003
v1.3	Remove "Media Center" Replace v1.1	July 2003
v1.4	Update Chapter 3 Replace v1.3	Sep. 2003

# CONTENTS

<b>System Specification</b> .....	viii
<b>Chapter 1. Introducing Mainboard</b> .....	1-1
Mainboard Layout.....	1-2
CPU/Memory.....	1-3
Introduction to DDR SDRAM.....	1-3
Power Supply.....	1-4
Front Panel.....	1-5
IEEE 1394 Port: J1394-2.....	1-5
IEEE 1394 Port: J1394-1.....	1-6
USB Ports.....	1-6
Mic-in/Head-Phone.....	1-7
OPTICAL SPDIF-in.....	1-7
Back Panel.....	1-8
Serial Port.....	1-8
VGA Port.....	1-9
Mouse/Keyboard Connectors.....	1-9
RJ45 LAN Jack.....	1-10
USB Ports.....	1-10
OPTICAL SPDIF-out.....	1-10
Parallel Port.....	1-11
Audio Port.....	1-12
Connectors.....	1-13
IDE Connectors: CN22 & CN23.....	1-13
FDD Connector: CN10.....	1-13
CD-in Connector: CN16.....	1-14
TV-Tuner Card Connector: CN13.....	1-14
CPU Fan Connector: CN15.....	1-14
Front Panel Power Connector: CN4.....	1-15
USB Card Reader Connector: CN6.....	1-15
LCM Connector: CN18.....	1-16

Modem Module Connector: CN21.....	1-16
Jumper.....	1-17
Clear CMOS Jumper: J2.....	1-17
Slots.....	1-18
PCI Slot.....	1-18
AGP Slot.....	1-18
<b>Chapter 2: Setting BIOS Function.....</b>	<b>2-1</b>
Entering Setup.....	2-2
Control Keys.....	2-2
Getting Help.....	2-3
Main Menu.....	2-3
Sub-Menu.....	2-3
General Help<F1>.....	2-3
The Main Menu.....	2-4
Standard CMOS Features.....	2-6
Advanced BIOS Features.....	2-8
Advanced Chipset Features.....	2-11
Integrated Peripherals.....	2-13
Power Management Setup.....	2-19
PNP/PCI Configurations.....	2-23
PC Health Status.....	2-25
Frequency/Voltage Control.....	2-26

# SYSTEM SPECIFICATION

## ● M/B

- MS-6760 (Proprietary F/F), 185 x 290 mm (4 layer)

## ● CPU:

- Support Socket 478 for Pentium® 4, 2.8 GHz

## ● Chipset:

- SiS 651 + SiS 962

## ● Memory:

- DDR 333 x 2, support memory up to 2.0GB

## ● On-Board Audio:

- AC'97 Codec integrated in ALC 650, support 5.1 channel , SPDIF In/Out.

## ● On-Board VGA:

- Integrated (AGP 4X)

\*\* On-Board VGA memory: None

## ● On-Board Communication

- LAN: integrated in Realtek (10/100Mb)

- Modem: 56K MDC module

## ● On-Board USB

- Front x 2; Rear x 2; On-Board x 2 for Card Reader & RF K/B, M/S (MFG Option)

## ● On-Board IEEE 1394:

- RTL8801B PHY (2 ports), Front x 2 (4 pin, 6 pin)

## ● Expansion Slots:

- PCI 2.2 x 1, AGP (4X) x1

## ● Power Off Function:

- Playback Audio CD, MP3, AM/FM Radio Tuner (with Remote Controller)

## ● TV Tuner Function

- MS-8606 (Option PCI with remote controller)

## ● Power Supply:

- 200W (PFC 5V/12V SB) Full Range

## ● Chassis:

- 202(W) x 320(D) x 151(H) mm (9.76 Liters)



## ● **On-Board Headers & Connectors**

- Rear Panel: Parallel Port x 1, Serial Port x 1, VGA x 1, PS/2 x 2, Mic in/Line in/Line out x 1, USB x 2, LAN (RJ45) x 1, SPDIF/O x 1, Modem (RJ11) x 1
- Front Panel: Mic in/Headphone x 1, USB x 2, SPDIF/I x 1, 1394 x 1 (4-pin), 1394 x 1(6-pin)

## ● **BIOS**

- 2MB Flash

## ● **Others**

- Microsoft® PC 2001
- LAN Wake Up Function
- Suspend to RAM/DISK function
- Top Tech III (Thermal Overheat Protection Technology)
- PC Alert System Hardware Monitor
- On-Board BlueBird Module for Power-Off features
- On-Board Equalizer (LCM)

# **Introducing Mainboard**

**1.1 Mainboard Layout**

**1.2 CPU/Memory**

**1.3 Power Supply**

**1.4 Front Panel**

**1.5 Back Panel**

**1.6 Connectors**


**1.7 Jumper**

**1.8 Slots**

# Chapter 1

## 1.1 MAINBOARD LAYOUT

See the following for the mainboard layout:



**MS6760 v1.X Mainboard**




## Chapter 1

# 1.3 POWER SUPPLY

The system is equipped with a 200W(PFC) ATX power supply. The power cord of power supply has been connected to the connectors on the mainboard when shipped out. You can find two connectors (20-Pin & CN 20) on the mainboard.

**ATX Power Supply Pin Definition**

PIN	SINGAL	PIN	SIGNAL
1	3.3V	11	3.3V
2	3.3V	12	-12V
3	GND	13	GND
4	5V	14	PS_ON
5	GND	15	GND
6	5V	16	GND
7	GND	17	GND
8	PW_OK	18	
9	5V_SB	19	5V
10	12V	20	5V



**20-Pin Connector**

**CN20 Pin Definition**

PIN	SINGAL
1	GND
2	GND
3	12V
4	12V



**CN 20**


## Power Supply Specification

<b>Dimension</b>	<b>70 (H)x1450(W)x105(D) mm</b>
PFC	Yes (passive)
Wattage	200W Max
Electrical Design Specification	AC Output :100-127/200-240 VAC, Switch Selectable, <b>Auto Protection</b> DC Output :+3.3V 17A :+5V 12A :+12V 13.5A :-12V 0.5A :+5Vsb 3A :+12Vsb 2.5A  80 mm PWM Fan
Certificate	FCC/UL/CUL/BSMI/CB/NEMKO/TUV




### 1.4 FRONT PANEL

The Front Panel is independent and extended from the mainboard. It's connected to the Front Panel Connector on the mainboard. You can find the following ports on the Front Panel.



#### IEEE 1394 Port: J1394-2

The mainboard provides two IEEE 1394 ports. This smaller one is designed for you to connect the IEEE 1394 device with external power. The IEEE 1394 high-speed serial bus complements USB by providing enhanced PC connectivity for a wide range of devices, including consumer electronics audio/video (A/V) appliances, storage peripherals, other PCs, and portable devices.




#### **Software Support**

*IEEE 1394 Driver is provided by Windows® 98 SE, Windows® XP, Windows® ME and Windows® 2000. Just plug in the IEEE 1394 connector into the port. These Operating Systems will install the driver for IEEE 1394.*

## Chapter 1

### IEEE 1394 Port: J1394-1

The bigger 6-pin IEEE 1394 Port on the back panel is designed for you to connect to IEEE 1394 devices without external power. That means the mainboard can provide the power for the devices connected to this port.



---

---

#### Software Support





IEEE 1394 Driver is provided by Windows® 98 SE, Windows® XP, Windows® ME and Windows® 2000. Just plug in the IEEE 1394 connector into the port. These Operating Systems will install the driver for IEEE 1394.

---

---

### USB Ports

The mainboard provides an OHCI (Universal Host Controller Interface) Universal Serial Bus root for attaching USB devices such as keyboard, mouse or other USB-compatible devices. You can plug the USB device directly into the connector.



USB Port Description

PIN	SIGNAL	DESCRIPTION
1	VCC	+5V
2	-Data 0	Negative Data Channel 0
3	+Data 0	Positive Data Channel 0
4	GND	Ground
5	VCC	+5V
6	-Data 1	Negative Data Channel 1
7	+Data 1	Positive Data Channel 1
8	GND	Ground








## Chapter 1


# 1.5 BACK PANEL

The Back Panel provides the following ports:



## Serial Port

The mainboard offers a 9-pin male DIN serial port . The port is 16550A high speed communication ports that sends/receives 16 bytes FIFOs. You can attach a serial mouse or other serial devices directly to the connector.



9-Pin Male DIN Connector

### Pin Definition

PIN	SIGNAL	DESCRIPTION
1	DCD	Data Carry Detect
2	SIN	Serial In or Receive Data
3	SOUT	Serial Out or Transmit Data
4	DTR	Data Terminal Ready
5	GND	Ground
6	DSR	Data Set Ready
7	RTS	Request To Send
8	CTS	Clear To Send
9	RI	Ring Indicate








### Parallel Port

The mainboard provides a 25-pin female centronic connector as LPT. A parallel port is a standard printer port that supports Enhanced Parallel Port (EPP) and Extended Capabilities Parallel Port (ECP) mode.




Pin Definition

PIN	SIGNAL	DESCRIPTION
1	STROBE	Strobe
2	DATA0 Data0	
3	DATA1	Data1
4	DATA2	Data2
5	DATA3	Data3
6	DATA4	Data4
7	DATA5	Data5
8	DATA6	Data6
9	DATA7	Data7
10	ACK#	Acknowledge
11	BUSY	Busy
12	PE	Paper End
13	SELECT	Select
14	AUTO FEED#	Automatic Feed
15	ERR#	Error
16	INIT#	Initialize Printer
17	SLIN#	Select In
18	GND	Ground
19	GND	Ground
20	GND	Ground
21	GND	Ground
22	GND	Ground
23	GND	Ground
24	GND	Ground
25	GND	Ground

## Chapter 1

### Audio Port

**Speak-out** is a connector for Speakers or Headphones. **Line In** is used for external CD player, Tape player, or other audio devices. **Mic-in** is a connector for microphones.

















# Setting BIOS Function

**2.1 Entering Setup**

**2.2 The Main Menu**

**2.3 Standard CMOS Features**

**2.4 Advanced BIOS Features**

**2.5 Advanced Chipset Features**

**2.6 Integrated Peripherals**

**2.7 Power Management Setup**

**2.8 PnP/PCI Configurations**

**2.9 PC Health Status**

**2.10 Frequency/Voltage Control**

## Chapter 2

# 2.1 ENTERING SETUP

Power on the computer and the system will start POST (Power On Self Test) process. When the message below appears on the screen, press <DEL> key to enter Setup.

Press DEL to enter SETUP

If the message disappears before you respond and you still wish to enter Setup, restart the system by turning it OFF and On or pressing the RESET button. You may also restart the system by simultaneously pressing <Ctrl>, <Alt>, and <Delete> keys.

### Control Keys

<↑>	Move to the previous item
<↓>	Move to the next item
<<->	Move to the item in the left hand
<->>	Move to the item in the right hand
<Enter>	Select the item
<Esc>	Jumps to the Exit menu or returns to the main menu from a submenu
<+ /PU>	Increase the numeric value or make changes
<- /PD>	Decrease the numeric value or make changes
<F1>	General help, only for Status Page Setup Menu and Option Page Setup Menu
<F5>	Restore the previous CMOS value from CMOS, only for Option Page Setup Menu
<F6>	Load the default CMOS value from Fail-Safe default table, only for Option Page Setup Menu
<F7>	Load Optimized defaults
<F10>	Save all the CMOS changes and exit






## Chapter 2

# 2.2 THE MAIN MENU

Once you enter Phoenix-Award® BIOS CMOS Setup Utility, the Main Menu (Figure 1) will appear on the screen. The Main Menu allows you to select from twelve setup functions and two exit choices. Use arrow keys to select among the items and press <Enter> to accept or enter the sub-menu.



### Standard CMOS Features

Use this menu for basic system configurations, such as time, date etc.

### Advanced BIOS Features

Use this menu to setup the items of AWARD® special enhanced features.

### Advanced Chipset Features

Use this menu to change the values in the chipset registers and optimize your system's performance.

### Integrated Peripherals

Use this menu to specify your settings for integrated peripherals.








## Chapter 2

# 2.3 STANDARD CMOS FEATURES

The items in Standard CMOS Features Menu are divided into 12 categories. Each category includes no, one or more than one setup items. Use the arrow keys to highlight the item and then use the <PgUp> or <PgDn> keys to select the value you want in each item.



### Date

This allows you to set the system to the date that you want (usually the current date). The format is <day><month> <date> <year>.

### Time

This allows you to set the system time that you want (usually the current time). The time format is <hour> <minute> <second>.

### IDE Primary/Secondary Master/Slave

Press PgUp/<+> or PgDn/<-> to select *Manual*, *None* or *Auto* type. Note that the specifications of your drive must match with the drive table. The hard disk will not work properly if you enter improper information for this category. If your hard disk drive type is not matched or listed, you can use *Manual* to define your own drive type manually.


## 2-6





## Chapter 2

# 2.4 ADVANCED BIOS FEATURES



### Quick Boot

Setting the item to *Enabled* allows the system to boot within 5 seconds since it will skip some check items. Available options: *Enabled*, *Disabled*.

### Boot Sequence

The items allow you to set the sequence of boot devices where BIOS attempts to load the disk operating system.

**NOTE:** If you want to boot from USB device like USB FDD, please turn on either USB keyboard or mouse enable.

### CPU L1 & L2 Cache

Cache memory is additional memory that is much faster than conventional DRAM (system memory). When the CPU requests data, the system transfers the requested data from the main DRAM into cache memory, for even faster access by the CPU. This setting enables/disables the internal cache (also known as L1 or level 1 cache) and external cache (also known as L2 or level 2 cache). Settings are: *Enabled* and *Disabled*.

















### **USB 2.0 Supports**

Set to *Enabled* if you need to use any USB 2.0 device in the operating system that does not support or have any USB 2.0 driver installed, such as DOS and SCO Unix. Setting options: *Disabled*, *Enabled*.

### **USB Keyboard Support**

Select *Enabled* if you need to use a keyboard in the operating system. Setting options: *Enabled*, *Disabled*.

### **USB Mouse Support**

Select *Enabled* if you need to use a mouse in the operating system. Setting options: *Enabled*, *Disabled*.

### **SIS AC97 AUDIO**

*Auto* allows the motherboard's BIOS to detect whether you're using any audio device. If so, the onboard audio controller will be enabled. If not, the onboard audio controller will be disabled. If you want to use different controller cards to connect audio connectors, set the field to *Disabled*. Setting options: *Disabled*, *Auto*.

### **SIS S/W Modem**

*Auto* allows the mainboard to detect whether a modem is used. If a modem is detected, the onboard S/W modem controller will be enabled; if not, it is disabled. Disable the controller if you want to use other controller cards to connect a modem. Settings: *Auto*, *Disabled*.

### **SIS 1394 Controller**

This item allows you to enable/disable the onboard IEEE1394 controller. Setting options: *Enabled* and *Disabled*.





## Chapter 2

### Onboard LAN Device


This item is used to enable or disable the onboard LAN controllers. Setting options: *Enabled, Disabled*.

### Onboard Lan Boot ROM

The items enable or disable the initialization of the onboard LAN Boot ROMs during bootup. Selecting *Disabled* will speed up the boot process.



## 2.7 POWER MANAGEMENT SETUP



### Sleep State

This item specifies the power saving modes for ACPI function. If your operating system supports ACPI, such as Windows 98SE, Windows ME and Windows 2000, you can choose to enter the Standby mode in S1(POS) or S3(STR) fashion through the setting of this field. Options are:

- S1/POS**      The S1 sleep mode is a low power state. In this state, no system context is lost (CPU or chipset) and hardware maintains all system context.
- S3/STR**    The S3 sleep mode is a lower power state where the information of system configuration and open applications/files is saved to main memory that remains powered while most other hardware components turn off to save energy. The information stored in memory will be used to restore the system when a “wake up” event occurs.

## Chapter 2

### Power Management

This item is used to select the degree (or type) of power saving and is related to these modes: *Suspend Mode* and *HDD Power Down*. There are three options for power management:

*Min Saving* Minimum Power Management. Suspend Mode=1 Hour

*Max Saving* Maximum Power Management. Suspend Mode=1 Min

*User Define* Allows end users to configure each mode separately.

### Suspend Mode

After the selected period of system inactivity, all devices except the CPU shut off. Settings: *Disabled, 1Min, 2Min, 4Min, 8Min, 12Min, 20Min, 30Min, 40Min, 1 Hour*.

### MODEM Use IRQ

This determines the IRQ in which the MODEM can use. Activity of the selected IRQ always awakens the system. Settings: *3, 4, 5, 7, 9, 10, 11, NA*.

### Hot Key Function As

This setting specifies the function of the preset hot key. Settings: *Disabled, Power Off, Suspend*.

### HDD Off After

If enabled and after the set time of system inactivity, the hard disk drive will be powered down while all other devices remain active. Settings: *Disabled, 1 Min ~ 15Min*.

### Power Button Function

This feature sets the function of the power button. Settings are:

*Power Off* The power button functions as normal power off button.

*Suspend* When you press the power button, the computer enters the suspend/sleep mode, but if the button is pressed for more than four seconds, the computer is turned off.

### After AC Power Lost

This setting specifies whether your system will reboot after a power failure or interrupt occurs. Available settings are:

- Off* Leaves the computer in the power off state.
- On* Leaves the computer in the power on state.
- Last State* Restores the system to the status before power failure or interrupt occurred.

### PM Wake Up Events

Press <Enter> and the following sub-menu appears.

```
IRQ [3-7,9-15],NMI           [Enabled]
IRQ 8 Break Suspend         [Disabled]
Wake Up On Ring             [Disabled]
Wake Up On PME              [Enabled]
USB Wake up from S3         [Disabled]
PS2KB Wakeup from S3/S4/S5 [Hot Key]
PS2MS wakeup from S3/S4/S5 [Disabled]
Resume by Alarm              [Disabled]
x Month Alarm                NA
x Day of Month Alarm         0
x Time (hh:mm:ss) Alarm      0 : 0 : 0

** Reload Global Timer Events **
Primary IDE                  [Disabled]
Secondary IDE                 [Disabled]
FDD, COM, LPT Port          [Disabled]
PCI PIRQ[A-D]#              [Disabled]
```

### IRQ [3-7, 9-15], NMI & IRQ 8 Break Suspend

This setting enables/disables the monitoring of the specified IRQ line. If set to *Enabled*, the activity of the specified IRQ line will prevent the system from entering power saving modes or awaken it from power saving modes. Setting options: *Disabled*, *Enabled*.

### Wake Up On PME/Ring

These two fields specify whether the system will be awakened from power savings modes when activity or input signal of the specified hardware peripheral or components is detected. Setting options: *Disabled*, *Enabled*.



## Chapter 2

### USB Wake Up from S3

This item allows the activity of the USB device to wake up the system from S3 (Suspend to RAM) sleep state. Settings are: *Enabled* and *Disabled*.

### PS2KB Wake Up from S3/S4/S5

This setting allows you to enter "Any Key" (max. 8 numbers) to wake up the system from S3/S4/S5 state. Settings are: *Hot Key*, *Disabled*, *Password*.

### PS2MS Wake Up from S3/S4/S5

This setting allows the activity of the mouse to wake up the system from S3/S4/S5 state. Settings are: *Disabled*, *Click*, *Move & Click*.

### Resume By Alarm

This function is for setting date and time for your computer to boot up. During *Disabled*, you cannot use this function. During *Enabled*, choose the Month, Day, and Time Alarm:

**Month Alarm** You can choose which month the system will boot up.

**Day of Month Alarm** You can choose which day of the preset month the system will boot up. Set to 0, to boot every day.

**Time (hh:mm:ss) Alarm** You can choose what hour, minute and second the system will boot up.

### \*\*Reload Global Timer Events\*\*

#### **Primary/Secondary IDE 0/1, FDD, COM, LPT Port, PCI PIRQ [A-D] #**

The global timer is the hardware timer that counts down to the power saving modes. If the monitoring of the listed hardware peripherals or components is enabled, the activity of the specified peripherals or components will awaken the system or reload the original count of global timer when they are accessed.



## Chapter 2

by a “➤”). The settings are: *Auto (ESCD)*, *Manual*.

### IRQ Resources

The items are adjustable only when *Resources Controlled By* is set to *Manual*. Press <Enter> and you will enter the sub-menu of the items. IRQ Resources list IRQ 3/4/5/7/9/10/11/12/14/15 for users to set each IRQ a type depending on the type of device using the IRQ. Settings are:

*PCI Device* For Plug & Play compatible devices designed for PCI bus architecture.

*Reserved* The IRQ will be reserved for further request.

### PCI/VGA Palette Snoop


When set to *Enabled*, multiple VGA devices operating on different buses can handle data from the CPU on each set of palette registers on every video device. Bit 5 of the command register in the PCI device configuration space is the VGA Palette Snoop bit (0 is disabled).





## Chapter 2

# 2.10 FREQUENCY/VOLTAGE CONTROL



### CPU Clock Ratio

This setting controls the multiplier that is used to determine the internal clock speed of the processor relative to the external or motherboard clock speed.

### Auto Detect DIMM/PCI Clk

This option allows you to enable/disable the feature of auto detecting the clock frequency of the installed DIMM/PCI bus. The settings are: *Enabled*, *Disabled*.

### Spread Spectrum

When the motherboard's clock generator pulses, the extreme values (spikes) of the pulses creates EMI (Electromagnetic Interference). The Spread Spectrum function reduces the EMI generated by modulating the pulses so that the spikes of the pulses are reduced to flatter curves. If you do not have any EMI problem, leave the setting at *Disabled* for optimal system stability and performance. But if you are plagued by EMI, activate the Spread Spectrum for EMI reduction. Remember to disable Spread Spectrum if you are overclocking because even a slight jitter can introduce a temporary boost in clockspeed which may just cause your overclocked processor to lock up. Options: *Disabled*, *Enabled*.

### CPU Frequency

Use this item to select the appropriate frequency for your CPU FSB. Options: *Default, 100MHz, 133MHz.*

### DRAM Frequency

This setting shows the current frequency of DDR DRAM (read only). Options: *By SPD, 200MHz, 266MHz, 333MHz.*

## Free Manuals Download Website

<http://myh66.com>

<http://usermanuals.us>

<http://www.somanuals.com>

<http://www.4manuals.cc>

<http://www.manual-lib.com>

<http://www.404manual.com>

<http://www.luxmanual.com>

<http://aubethermostatmanual.com>

Golf course search by state

<http://golfingnear.com>

Email search by domain

<http://emailbydomain.com>

Auto manuals search

<http://auto.somanuals.com>

TV manuals search

<http://tv.somanuals.com>