

Kambook - Australia

Building 2, Port Air Industrial Estate
1A Hale Street
Botany NSW 2019
Australia
Customer Service Line 1300 139 798
Customer Service Fax 1800 621 337

www.kambook.com.au


Kambook - New Zealand

Private Bag 94411
Botany, Manukau
Auckland 2163
New Zealand
Customer Service Line/
Spare Parts 0800 273 845
Customer Service Fax 0800 288 513

www.kambook.co.nz

KAMBROOK

THE SMARTER CHOICE



Power Drive Blender

Suits all KBL120/KBL180 models

Instruction Booklet

Important

Please retain your instruction book for future use.

In the event that you need some assistance with your Kambrook appliance, please contact our Customer Service Department on 1300 139 798 (Australia) or 0800 273 845 (New Zealand). Alternatively, visit us on our website at www.kambrook.com.au or www.kambrook.co.nz

Contents

Kambrook Recommends Safety First	p4
Your Kambrook Power Drive Blender	p6
Using Your Kambrook Blender	p7
Hints and Tips	p11
Care, Cleaning and Storage	p13
Recipes	p14

IMPORTANT: Please retain your instruction book for future use.

At Kambrook, we believe that safe performance is the first priority in any consumer product, so that you, our valued customer can confidently use and trust our products. We ask that any electrical appliance that you use be operated in a sensible fashion with due care and attention placed on the following important operating instructions.

Important Safeguards For Your Kambrook Power Drive Blender

- Carefully read all instructions before operating the blender for the first time and save for future reference.
- Remove and safely discard any packaging material and promotional labels before using the blender for the first time.
- To eliminate a choking hazard for young children, remove and safely discard the protective cover fitted to the power plug of this blender.
- Do not place the blender near the edge of a bench or table during operation. Ensure the surface is level, clean and free of water and other substances. Vibration during operation may cause the blender to move.
- Do not use the blender on a sink drain board.
- Do not place the blender on or near a hot gas or electric burner, or where it could touch a heated oven.
- Handle the blender and attachments with care – remember the blades are razor-sharp and should be kept out of the reach of children.
- Always ensure the blender is completely assembled before operating. The blender will not operate unless properly assembled.
- Do not use attachments other than those provided with the blender.
- Do not attempt to operate the blender by any method other than those described in this booklet.
- Always secure the blade assembly onto the blender jug before attaching to the motor base.
- Ensure the Speed Control Dial is in the 'OFF' position and the blender is switched off at the power outlet and the power cord is unplugged before attaching the blender jug.
- Always operate the blender with the blender jug lid in position.
- Keep fingers, hands, knives and other utensils away from moving blades.
- Do not place hands or fingers into the blender jug unless the motor and blades have come to a complete stop. Ensure the Speed Control Dial is in the 'OFF' position and the blender is switched off at the power outlet and the power cord is unplugged before removing the lid from the blender.
- Ensure the motor and the blades have completely stopped before disassembling. Ensure the Speed Control Dial is in the 'OFF' position and the blender is switched off at the power outlet and the power cord is unplugged from the power outlet before attempting to move the blender, when not in use, if left unattended and before disassembling, cleaning or storing.
- Care should be taken when removing the food from the blender jug by ensuring the motor and the blades have completely stopped before disassembling.

Ensure the Speed Control Dial is turned to the 'OFF' position, the appliance is switched off at the power outlet and unplugged, before removing the lid from the blender jug. The blender jug should then be unlocked from the motor base and the food carefully removed before attempting to remove the blade assembly.

- Do not operate the blender continuously for periods longer than 1 minute on any setting or if processing a heavy load. None of the recipes in this book are considered a heavy load. If the blender is operated continuously for too long, it should be allowed to rest for 30 minutes before recommencing.
- Do not process hot or boiling liquids – allow liquids to cool before placing into the blender jug.
- Always switch off the blender and disconnect from the power outlet before changing accessories or approaching parts that move in use.
- Do not move the blender whilst in operation.
- Do not leave the blender unattended when in use.
- Do not place any part of the blender in a microwave oven.
- Do not wash any parts of the blender in a dishwasher.
- Do not place anything on top of the motor base and/or blender jug when the lid is on or off, when in use and when stored.
- Do not allow children to use the blender without supervision.
- Care should be taken when handling the sharp cutting blades, emptying the blender jug and during cleaning.
- Keep the blender clean. Follow the cleaning instructions provided in this book.

Important Safeguards For All Electrical Appliances

- Fully unwind the power cord before use.
- Connect only to a 230V or 240V power outlet.
- Do not let the power cord hang over the edge of a bench or table, touch hot surfaces or become knotted.
- To protect against electric shock, do not immerse the power cord, power plug or appliance in water or any other liquid or allow moisture to come in contact with the part, unless it is recommended in the cleaning instructions.
- The appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- Children should be supervised to ensure that they do not play with the appliance.
- It is recommended to regularly inspect the appliance. To avoid a hazard, do not use the appliance if power cord, power plug or appliance becomes damaged in any way. Return the entire appliance to the nearest authorised Kambrook Service Centre for examination and/or repair.
- Any maintenance other than cleaning should be performed at an authorised Kambrook Service Centre.
- This appliance is for household use only. Do not use this appliance for anything other than its intended use. Do not use in moving vehicles or boats. Do not use outdoors. **Misuse may cause injury.**
- The installation of a residual current device (safety switch) is recommended to provide additional safety protection when using electrical appliances. It is advisable that a safety switch with a rated residual operating current not exceeding 30mA be installed in the electrical circuit supplying the appliance. See your electrician for professional advice.
- Always turn the appliance to the OFF position, switch off at the power outlet and unplug at the power outlet when the appliance is not in use.
- Before cleaning, always turn the appliance to the OFF position, switch off at the power outlet, unplug at the power outlet and remove the power cord, if detachable, from the appliance and allow all parts to cool.
- Do not place this appliance on or near a heat source, such as hot plate, oven or heaters.
- Position the appliance at a minimum distance of 20cm away from walls, curtains and other heat or steam sensitive materials and provide adequate space above and on all sides for air circulation.

Your Kambrook Power Drive Blender

1. Powerful 600 watt motor
2. Large 1.5 litre glass jug with measurements
3. 2 speed control plus Pulse function
4. Removable Blade Holder with serrated blades and silicone seal located under the glass jug

5. Serrated stainless steel blades for ice crushing
6. Jug chute and inner cap
(Note: the inner cap is also a handy tool for assisting in removing the blade holder)
7. Sturdy non-slip feet

Not Shown

- Jug collar
(Note: found under the blender jug and cannot be removed)



KBL180 Model Shown

Using Your Kambrook Blender

Before First Use

Remove and safely discard any packaging material and promotional labels.

Disassemble the blender jug by following the steps in the 'Disassembling the Blender' section below. Wash the lid, inner cap, blender jug, silicone seal and Removable Blade Holder in warm, soapy water with a soft cloth. Rinse and dry thoroughly.

Wipe the motor base with a damp cloth and dry thoroughly.

Disassembling the Blender

1. Place the motor base on a flat, dry surface such as a bench top. Ensure that the Speed Control Dial is in the 'OFF' position, the appliance is switched off at the power outlet and the power cord is unplugged.
2. Hold the base with one hand and with the other hand turn the blender jug handle anti-clockwise and in the opposite direction of the 'Lock' symbol on the motor base.
3. Remove the lid and inner cap from the blender jug.
4. Place the jug upside down on a flat, dry surface such as a bench top.
5. Using the inner cap, insert the two tabs on the inner cap into the Removable Blade Holder (See Fig. 1).



6. Use one hand to hold the jug handle and the other hand to turn the inner cap clockwise to 'OPEN' the Removable Blade Holder (See Fig. 2).



7. Once loose, tilt the Removable Blade Holder at an angle and lift it up and out of the jug.



WARNING: Blades must be handled carefully as they are sharp!

Using Your Kambrook Blender continued

- Remove the silicone seal from the Removable Blade Holder (See. Fig. 3).



NOTE: The blending blades are extremely sharp. Avoid any contact with fingers and hands.

Assembling and Attaching the Blender Jug

- Place the motor base on a flat, dry surface such as bench top. Ensure the Speed Control Dial is in the 'OFF' position, the appliance is switched off at the power outlet and the power cord is unplugged.
- Ensure the lid is off the blender jug and place the blender jug upside down on a flat, dry surface such as a bench top.
- Place the silicone seal onto the Removable Blade Holder. Make sure the silicone seal sits under the grooves (See Fig. 4).



- Tilt the Removable Blade Holder at an angle and put it inside the jug.
- Using the inner cap, insert the two tabs on the Removable Blade Holder (See Fig. 1).
- Use one hand to hold the jug handle and the other to turn the inner cap anti-clockwise to '▲CLOSE' and secure the Removable Blade Holder in place.
- Turn the assembled blender jug upright and align the '▼' symbol on the blender jug collar with the '▲ALIGN' symbol on the motor base. Once aligned turn the blender jug clockwise in the direction of the '◀Lock' symbol on the motor base. Ensure the blender is securely positioned.
- Place the lid on top of the blender jug and push down to seal. Insert the inner cap into the middle opening of the blender jug lid and turn clockwise to lock.

NOTE: Ensure the lid is placed onto the blender jug firmly and the inner cap is in position before operating the blender. Do not operate the blender without the lid. Additional ingredients can be added whilst blending by removing the inner cap and placing or pouring ingredients through the middle opening in the lid.

NOTE: Liquids should be placed into the blender jug before solid ingredients, unless specified differently in a recipe.

NOTE: All foods should be cut into cubes (approx. 2-3cm square) to achieve an even result.

Operating Your Kambrook Blender

1. Place the motor base on a flat, dry surface. Ensure that the blender is switched off at power outlet and the power plug is unplugged from the power outlet.
2. Align the '▼' symbol on the blender jug collar with the '▲
ALIGN' symbol on the motor base. Once aligned turn the blender jug clockwise in the direction of the '◀Lock' symbol on the motor base. Ensure the blender is securely positioned.

NOTE: Liquids should be placed into the blender jug before solid ingredients, unless specified differently in a recipe.

3. Add food or liquid into the blender jug. Place the lid on the blender and push down to seal. Insert the inner cap into the middle opening of the blender jug lid and turn clockwise to lock.
4. Plug the power cord into a 230V or 240V power outlet and switch on at the power point.
5. Turn the Speed Control Dial clockwise for the LOW and HIGH speed settings. The light indicator on the Speed Control Dial will illuminate blue. The speed can be changed any time during the blending process. Ideally, start blending on 'LOW' speed and then increase to a 'HIGH' speed if necessary and blend until desired consistency.
6. For ingredients that require a short burst of power, use the 'PULSE' speed setting. Starting with the Speed Control Dial in the 'OFF' position, turn the Speed Control Dial in an anti-clockwise direction and hold it in this position. The light indicator on the Speed Control Dial will illuminate blue. This setting is ideal for thick liquids, or nuts.

Using Your Kambrook Blender continued

7. Use the 'PULSE' speed setting to crush ice. To crush ice, place no more than 1 cup of ice cubes into the blender jug and replace the lid tightly. Place blender jug on the motor base and switch on at the power point. Turn the Speed Control Dial in an anti-clockwise direction and hold it in this position for approximately 5-10 seconds, and release. Repeat until ice is crushed to the desired consistency. Switch off at the power point and remove ice from the blender jug.
8. After use, ensure the blender is switched off by turning the Speed Control Dial to the 'OFF' position. The indicator light on the Speed Control Dial will extinguish. Switch off at the power outlet and remove the power cord. Allow the blender to cool before storing.

NOTE: If the blades become stuck, immediately turn the Speed Control Dial to 'OFF' and switch the power off at the power outlet and remove the power cord. Remove the jug from the motor base and remove the lid. Use a plastic spatula to dislodge the food or liquid from the blades. Replace the lid before recommencing blending.



WARNING: Do not process boiling liquids or hot ingredients. Allow hot ingredients to cool before placing them into the blender jug.

NOTE: During the blending process, ingredients may stick to the sides of the blender jug. To push the food back on the blades, turn the Speed Control Dial to 'OFF' and switch off at the power outlet and remove the power cord. Remove the lid and use a plastic spatula to scrape down the sides of the jug. Replace the lid before recommencing blending.

Hints and Tips

- Ensure the maximum level of 1500ml on the blender jug is not exceeded. Ensure the lid fits securely and the inner cap is locked.
- When crushing ice cubes in the blender, always use the 'PULSE' speed setting and ensure the blender jug is completely dry.
- Use 'LOW' speed for dressings, marinades and foods that require blending until just combined.
- Use 'HIGH' speed for pureeing, smoothie or cocktail making.
- Use 'PULSE' for mixtures that require short bursts of power such as thick liquids, ice or chopping nuts.
- Ensure all removable parts have been thoroughly washed and dried before assembly.
- Ensure the blender is correctly assembled before operating.
- Ensure the blender is used on a clean and dry surface.
- Place liquids into blender jug before solid ingredients except where specified in recipes.
- Cut all food into small cubes (approx. 2-3 cm square) to achieve an even result.
- If mixing hard and soft foods together, begin with the hard foods and then add soft foods. Continue blending until you have reached the desired consistency and even texture.
- To add ingredients during blending, remove the inner cap on the lid and drop solid ingredients or pour liquids through the lid opening. Use a container with a pouring lip, such as a measuring cup, when adding liquids.
- Place one hand on top of the blender lid and hold it down when blending large quantities of thin liquids. This will prevent the lid from popping off due to excessive pressure.

NOTE: Do not blend dry, thick or heavy mixtures for more than 1 minute without switching off the blender and stirring the ingredients with a plastic spatula, and then continue blending.

- Do not use the blender to store food.
- Do not use the blender to beat egg whites as it will not incorporate air.
- Do not use the blender to mash potatoes.
- Do not use the blender to knead dough or other heavy mixtures.
- Do not place large pieces of solid or frozen foods into the blender jug. Always break pieces before blending.
- Do not remove the blender jug or lid while the blender is operating. Always switch off at the power outlet and unplug at the power point before removing the blender jug.
- Do not overfill by exceeding the '1500ml' mark on the blender jug. Some mixtures increase in volume during blending.
- Do not overload the blender with more than specified amounts. Overloading could cause the motor to stall.

Hints and Tips continued

- Do not process boiling liquids or hot ingredients. Allow hot ingredients to cool before placing them into the blender jug.
- Do not expose the glass jug to sudden temperature changes (i.e. immersing the jug into hot water directly after immersing it into cold water or vice versa).

Care, Cleaning and Storage

Cleaning After Use

1. Ensure the blender has stopped operation by turning the Speed Control Dial to 'OFF'.
2. Switch off at the power outlet and unplug the power cord.
3. Hold the motor base with one hand and with the other hand turn the blender jug anti-clockwise and in the opposite direction of the 'Lock' symbol on the motor base. Lift the blender jug upwards from the motor base to remove.
4. Ensure all liquids have been removed from the blender jug.
5. Follow the 'Disassembling the Blender' section on page 7 to remove the blade holder from the glass jug.
6. Wash the blender jug, lid, inner cap, silicone seal and Removable Blade Holder in warm, soapy water, rinse and dry thoroughly.



WARNING: Blades must be handled carefully as they are sharp!

NOTE: Do not place any part of the blender in the dishwasher.

NOTE: Do not immerse the motor base, power cord or power plug in water or any other liquid.

Cleaning the Motor Body

The motor body can be cleaned with a soft, damp cloth (do not use abrasive agents or cloths which can damage the surface). Dry and polish with a soft, lint free cloth.

Storage

Before storing, thoroughly wash and dry all removable parts.

Assemble the blender and store on the kitchen bench or in an easy to access cupboard.

Store out of reach of children.

Store the appliance upright.

Do not store anything on top of the appliance.

Recipes

Recipes

Antioxidants Overload

Makes 4 serves

1 cup strawberries, hulled
½ cup raspberries
½ cup blueberries
150g red grapes
300ml cranberry juice
300ml pomegranate juice
12 medium ice cubes

1. Place the strawberries, raspberries, blueberries, grapes, cranberry juice, pomegranate juice and ice cubes into the blender jug; securely seal the lid onto the blender.
2. Secure the blender jug onto the motor base and turn the speed control dial to the 'PULSE' setting for 15 seconds or until smooth.
3. Remove the lid and pour into four tall glasses. Serve immediately.

Banana Breakfast Drink

Makes 1 serve

1 ½ Weet-bix
375ml skim milk
½ banana
1 tsp honey

1. Place the Weet-bix, milk, banana and honey into the blender jug; securely seal the lid onto the blender.
2. Secure the blender jug onto the motor base and turn the speed control dial to the 'PULSE' setting for 15 seconds or until smooth.
3. Remove the lid and pour into a tall glass. Serve immediately.

NOTE: To make extra serves, repeat ingredients and blend for 5 seconds longer.

Raspberry Protein Booster

Makes 4 serves

3 cup frozen raspberries

400ml skim milk

250ml iced water

½ cup vanilla protein powder

2 tbsp honey

1. Place the raspberries, milk, water, protein powder and honey into the blender jug; securely seal the lid onto the blender.
2. Secure the blender jug onto the motor base and turn the speed control dial to the 'PULSE' setting for 15 seconds or until smooth.
3. Remove the lid and pour into four tall glasses. Serve immediately.

Mango Smoothie

Makes 4 serves

3 frozen mango cheeks

750ml milk

4 scoops ice cream

2 tbsp honey

1. Place the mango, milk, ice cream and honey into the blender jug; securely seal the lid onto the blender.
2. Secure the blender jug onto the motor base and turn the settings control dial to the 'PULSE' setting for 15 seconds or until smooth.
3. Remove the lid and pour into four tall glasses. Serve immediately.

Iced Coffee

Makes 4 serves

120ml espresso

900ml milk

4 scoops vanilla ice cream

1 tbsp vanilla syrup

1. Place the espresso, milk, ice cream and syrup into the blender jug; securely seal the lid onto the blender.
2. Secure the blender jug onto the motor base and turn the speed control dial to the 'PULSE' setting for 15 seconds or until smooth.
3. Remove the lid and pour into four tall glasses. Serve immediately.

Chocolate Milkshake

Makes 4 serves

750ml milk

4 scoops vanilla ice cream

½ cup chocolate syrup

1. Place the milk, ice cream and syrup into the blender jug; securely seal the lid onto the blender.
2. Secure the blender jug onto the motor base and turn the speed control dial to the 'PULSE' setting for 15 seconds or until smooth.
3. Remove the lid and pour into four milkshake glasses. Serve immediately.

Pina Colada

Makes 4 serves

500ml pineapple juice
100ml coconut cream
100ml coconut water
120ml white rum
2 tbsp caster sugar
12 medium ice cubes

1. Place the pineapple juice, coconut cream, coconut water, rum, sugar and ice cubes into the blender jug; securely seal the lid onto the blender.
2. Secure the blender jug onto the motor base and turn the speed control dial to the 'PULSE' setting for 15 seconds or until smooth.
3. Remove the lid and pour into four tall cocktail glasses. Serve immediately.

Frozen Margaritas

Makes 6 serves

12 medium ice cubes
150ml tequila
¼ cup orange liqueur
¼ cup lime juice
¼ cup lemon juice
½ cup sugar syrup

1. Place the ice cubes, tequila, liqueur, lime juice, lemon juice and sugar syrup into the blender jug; securely seal the lid onto the blender.
2. Secure the blender jug onto the motor base and turn the speed control dial to the 'PULSE' setting for 15 seconds or until smooth.
3. Remove the lid and pour into six margarita glasses. Serve immediately.

NOTE: To make sugar syrup, dissolve ½ cup of sugar with ½ cup of boiling water. Stir until sugar has dissolved and allow to cool. Store in the refrigerator in an air tight container for up to 3 months.

Balsamic and Caramelised Garlic Dressing

Makes 1 cup

- ½ cup balsamic vinegar
- ½ cup extra virgin olive oil
- 8 cloves garlic, oven roasted in skin
- 1 tbsp brown sugar
- 1 tbsp flaked salt

1. Place the vinegar, oil, garlic, sugar and salt into the blender jug; securely seal the lid onto the blender.
2. Secure the blender jug onto the motor base and turn the speed control dial to the 'LOW' setting for 10 seconds or until garlic is completely blended
3. Remove the lid and pour over a garden salad. Serve immediately.

NOTE: Wrap the cloves in aluminium foil and bake them for approximately 15 minutes at 190°C.

NOTE: If not serving dressing immediately, keep in an airtight jar in the refrigerator for up to 7 days.

Dill and Garlic Aioli

Makes 1 ½ cups

- 1 egg yolk (from 59g free range egg)
- 60ml lemon juice
- 250ml light olive oil
- 2 tsp dill, roughly chopped
- 1 clove garlic, minced

1. Place the egg and lemon juice into the blender jug; securely seal the lid onto the blender.
2. Secure the blender jug onto the motor base and turn the speed control dial to the 'HIGH' setting for 10 seconds or until the mixture is fluffy.
3. Remove the lid and slowly pour the olive oil in a thin stream over 60 seconds.
4. Add the dill and garlic and turn the settings dial to the 'LOW' setting for 5 seconds to combine.
5. Spread onto sandwiches, stir through potatoes or serve with salad.

NOTE: If not serving aioli immediately, keep it in an airtight jar in the refrigerator for up to 14 days.

Beetroot and Tahini Dip

Makes 2 cups

- 2 baby beetroots, peeled, cooked
- ¼ cup tahini
- 2 tbsp light olive oil
- 2 tbsp flat leaf parsley, roughly chopped
- 1 tbsp lime juice
- 2 tsp flaked salt

1. Place the beetroot, tahina, oil, parsley, lime juice and salt into the blending jug; securely seal the lid onto the blender.
2. Secure the blender jug onto the motor base and turn the speed control dial to the 'LOW' setting for 20 seconds or until completely blended
3. Remove the lid and serve with biscuits, vegetable batons or bread.

NOTE: Tahini is a paste made from blended sesame seeds and can be found in the spreads or health foods section of your local supermarket.

NOTE: If not serving dip immediately, it can be kept in an air tight container in the refrigerator for up to 5 days.

White Bean and Lemon Olive Oil Dip

Makes 2 cups

- ½ cup lemon olive oil
- 1 tbsp lemon juice
- 420g can white beans, drained, rinsed
- 2 tbsp basil leaves, roughly chopped
- 1 clove garlic, minced
- 2 tsp flaked salt

1. Place the oil, lemon juice, beans, basil, garlic and salt into the blending jug; securely seal the lid onto the blender.
2. Secure the blender jug onto the motor base and turn the speed control dial to the 'LOW' setting for 20 seconds or until completely blended
3. Remove the lid and serve with biscuits, vegetable batons or bread.

NOTE: If not serving dip immediately, it can be kept in an air tight container in the refrigerator for up to 5 days.

Thai Sweet Potato Soup

Makes 1 litre

2 tbsp peanut oil
1 brown onion, diced
2 cloves garlic, minced
2cm piece ginger, minced
1 tsp brown mustard seeds
1 tsp ground coriander seeds
1 tsp ground cumin seeds
1 tsp salt
600g sweet potato, roughly chopped
500ml vegetable stock
250ml water
100ml coconut milk

Bread, to serve

Fresh coriander, to serve

1. Using a 2 litre pot, heat the oil over a medium heat and sauté the onion, garlic and ginger until golden brown, approximately 5 minutes, stirring regularly.
2. Add the mustard seeds, coriander seeds, cumin seeds and salt and sauté for a further 5 minutes, stirring regularly.
3. Add the sweet potato, stock and water and allow to simmer over a medium to low heat for 40 minutes. Remove from the heat and pour over the coconut milk and allow to cool for 10 minutes.
4. Secure the blender jug onto the motor base and turn the speed control dial to the 'LOW' settings for 30 seconds or until completely blended.
5. Remove the lid and serve immediately with bread and coriander.

NOTE: If not serving soup immediately, pour into an air tight container to refrigerate for up to 5 days or freeze for up to 3 months.

Veggie Baby Food

Makes 4 serves

100g sweet potato, peeled, steamed
100g carrot, peeled, steamed
2 broccoli florets, steamed
 $\frac{2}{3}$ cup water

1. Place the sweet potato, carrot, broccoli and water into the blending jug; securely seal the lid onto the blender.
2. Secure the blender jug onto the motor base and turn the speed control dial to the 'LOW' setting for 20 seconds or until completely blended.
3. Remove the lid and serve immediately or store in air tight containers and put in the refrigerator or freezer.

NOTE: Store baby food in portion sizes in air tight containers in the refrigerator for up to 5 days or in the freezer for up to 3 months.

NOTE: You can add 1 tablespoon of grated cheddar cheese if the child is old enough to consume dairy products.

Notes

Notes

Free Manuals Download Website

<http://myh66.com>

<http://usermanuals.us>

<http://www.somanuals.com>

<http://www.4manuals.cc>

<http://www.manual-lib.com>

<http://www.404manual.com>

<http://www.luxmanual.com>

<http://aubethermostatmanual.com>

Golf course search by state

<http://golfingnear.com>

Email search by domain

<http://emailbydomain.com>

Auto manuals search

<http://auto.somanuals.com>

TV manuals search

<http://tv.somanuals.com>