

LCD MONITOR / 8 CHANNEL DVR COMBO

Overview - Audio

English Version 1.0



SERIES:
SG17LD800 & SG19LD800

 **LOREX**[®]

www.lorexcctv.com

Copyright © 2007 LOREX Technology Inc.

Audio Overview

How many Audio Channels are available Listen-in Audio?	3
How do I enable Listen-In Audio, and how do I set the Listen-in channel?	3
How do I set up Network Audio (for use with the Remote Agent software)?	4
How many channels will have recorded Audio?	4

If you have any additional questions or technical issues, please contact the Sentinel CCTV Help desk for further assistance at 1-888-425-6739 (Option 1 - 1) or mail your questions to support@strategicvista.com

How many Audio Channels are available Listen-in Audio?

There are 8 available camera ports on the system - how many can be used for Listen-In audio, and how many can be used to record sound?

How do I enable Listen-In Audio, and how do I set the Listen-in channel?

Listen-In Audio is the ability to listen to live audio on ONE channel at a time, between channels 1~4. To listen to live audio on a channel:

1. Enter MENU mode by pressing the MENU button on the front panel of the system (or on the Remote Control). Select the SYSTEM SETUP Option.



2. Select the SOUND menu from the MAIN menu. Navigate using the up and down arrows on the front panel (or remote control). Highlight the selection in Green, and press the ENTER button to enter the SOUND Menu.



3. Select the AUDIO Option. Navigate using the up and down arrows, and press the ENTER key to select the AUDIO Option:

- **Live Audio** - Turns Live System Audio (from the Audio on the terminal) to ON/OFF.
- **Audio Monitoring Channel** - Select the channel for Listen-in Audio (Channels 1~4 ONLY).



NOTE: Once the LIVE AUDIO Feature has been set to ON, the Remote Control can be used to select the Listen-In Audio Channel. Press the AUDIO SEL button on the Remote Control to switch between Channels 1~4. An Audio Icon will appear onscreen next to the current Live Audio Channel.


How do I set up Network Audio (for use with the Remote Agent software)?

Setting the Network Audio Transmit and Receive to ON allows the system to send Audio data through the network. Live listen-in audio can then be accessed using the Remote Agent software (refer to your Remote Agent Manual for further information on this feature).

1. Enter MENU mode by pressing the MENU button on the front panel of the system (or on the Remote Control). Select the SYSTEM SETUP Option.



2. Select the SOUND menu from the MAIN menu. Navigate using the up and down arrows on the front panel (or remote control). Highlight the selection in Green, and press the ENTER button to enter the SOUND Menu.



3. Select the AUDIO Option. Navigate using the up and down arrows, and press the ENTER key to select the AUDIO Option:

- Network Audio TX - Sets Network Audio Transmission to ON
- Network Audio RX - Sets Network Audio Receive to ON



How many channels will have recorded Audio?

Only the FIRST 4 CAMERAS will record audio (simultaneously). Recorded audio will be available when the video playback is selected. Channels 5~8 do NOT record audio.

It's all on the web

 **Product Information**

 **Specification Sheets**

 **User Manuals**

 **Software Upgrades**

 **Quick Start Guides**

 **Firmware Upgrades**



VISIT
www.lorexcctv.com

www.lorexcctv.com

Lorex Technology Inc.

Free Manuals Download Website

<http://myh66.com>

<http://usermanuals.us>

<http://www.somanuals.com>

<http://www.4manuals.cc>

<http://www.manual-lib.com>

<http://www.404manual.com>

<http://www.luxmanual.com>

<http://aubethermostatmanual.com>

Golf course search by state

<http://golfingnear.com>

Email search by domain

<http://emailbydomain.com>

Auto manuals search

<http://auto.somanuals.com>

TV manuals search

<http://tv.somanuals.com>