



User Guide

BT DIVERSE 5100

ADDITIONAL HANDSET AND CHARGER

SIEMENS


digitally
enhanced



This equipment is not designed for making emergency telephone calls when the power fails. Alternative arrangements should be made for access to emergency services.

And Download.


At a glance



Please open this page for an 'At a glance' guide to your BT Diverse 5200 Additional Handset and Charger.

Handset display

When in **IDLE SCREEN** mode and the clock has been set.




Press the left side of the button for ↑ and right side of the button for ↓ when going through the menu options.

Press the right side of the button to confirm (OK) menu selection.


Display option buttons

The **OPTION** buttons allow you to select options within each menu that are shown on the display.

Charger



Charger underside



In this guide

At a glance	1	Caller Display and other BT Calling Features	23
Menu structure	4	Caller Display	23
Quick guide	6	Calls list	23
Quick guide to handset display icons	7	Call Waiting	26
Introduction	8	Call Divert	27
Unpacking your Diverse 5100		Withhold number	27
Additional Handset and Charger	8	Ring Back	28
For your records	8	Voice Mail	28
Safety information	9	Handset settings	30
Setting up	10	Keyguard	32
Registering and charging the handset	10	Help	33
Using the telephone	15	General information	34
Making and ending calls	15	Guarantee	34
Call timer	16	Technical information	35
Name and number directory	16	Index	36
Extra directory	18		
Redial	19		
Secrecy	20		
Paging and Internal calls	20		

Hints and tips boxes


In this user guide, we've included helpful tips and important notes. They are shown in boxes like this.

Helpline


*If you experience any difficulties with your Diverse 5100 Additional Handset and Charger, please call the BT Diverse Helpline on **08457 908 070**.*

Menu Structure


Please note that you will only see all the below menu options if you are registered to a BT Diverse 5110 base station.




Menu structure for directory, redial list, extra directory



Messages

Press  to get to your Mailbox and access your voicemail and Calls list.




































IMPORTANT

*If you make a mistake, you can return to the previous menu by pressing the **RED PHONE** button. If you keep pressing the **RED PHONE** button you will return to the idle screen.*

Quick guide

Commonly used handset functions and settings

		Page no.
Switch handset on/off	Hold down 	15
Switch keyguard on/off	Hold down 	32
Switch handset ringer on/off	Hold down 	30
Make an external call	 	15
To end a call		15
Redial a number	   Select one of last 5 numbers 	19
To store a name and number in the directory	 MENU  NEW ENTRY OK Enter number OK Enter name OK SAVED	16
Dial from the directory	   	17
Dial from the Calls list	  CALLS OK   	24
Handset earpiece volume	MENU   AUDIO SET OK H/SET VOL OK   OK SAVED	31
Make internal call	INT Call all or   	20
Transfer call to handset	INT Handset no. (e.g. 2) 	21
Set date	MENU  BASE SET OK DATE/TIME OK DATE SET OK Enter the date OK	14
Set time	MENU  BASE SET OK DATE/TIME OK  CLOCK SET OK Enter time OK AM/PM OK 	14

Quick guide to handset display icons



Redial, lists up to the last 5 dialled number.



Flashes to indicate new messages (if a mailbox service is used) or missed calls.

INT

For calling other handsets.

MENU

Opens the menu.



Shows the status of the handset battery.



Scroll through the menu.

OK

Confirms the function displayed.



Scroll left and right when entering numbers or messages.



Deletes numbers/characters (from left to right).



Do not disturb/Ringer off.



Handset locked.

eg. 

Shows the number of the handset and is displayed in top left hand corner.

Introduction

Unpacking your BT Diverse 5100 Additional Handset and Charger

If anything is missing, please contact your place of purchase immediately.

One BT Diverse 5100
Charger



One BT Diverse 5100
handset




One power supply
for the charger



Two AAA rechargeable
batteries



Battery
compartment cover



For your records

Date of purchase:

Place of purchase:

For guarantee purposes proof of purchase is required so please keep your receipt.

BT Accessories and Replacement Items

For a full range of accessories and replacement items for BT products please call 0870 240 5522, or visit:



With **and** WithoutWires.com

BT Diverse Helpline – 08457 908 070

Safety information

General

Only use the power supply included with the product. Using an unauthorised power supply will invalidate your guarantee and may damage the telephone. Power supply number is C39280-Z4-C478.

For the handset use only nickel-metal hydride (NiMH) AAA rechargeable batteries. Never use other batteries or conventional alkaline batteries. They could lead to a short circuit or destroy the battery casing. The batteries should have a power rating of at least 700mAh 1.2V. Batteries and accessories are available from withandwithoutwires.com or call **0870 240 5522**.

If the Keyguard is switched on, it is NOT possible to make calls, including emergency numbers (**999/112**).

Do not open the charger or handset (other than to change batteries). This could expose you to high voltages or other risks.

Radio signals transmitted between the handset and base may cause interference to hearing aids.

This product should not be used near emergency/intensive care medical equipment and should not be used by people with pacemakers.

Never dispose of batteries in a fire. There is a serious risk of explosion and/or the release of highly toxic chemicals.

Cleaning

Simply clean the handset and charger with a damp (not wet) cloth, or an anti-static wipe. Never use household polish as this will damage the product. Never use a dry cloth as this may cause a static shock.

Environmental

Do not expose to direct sunlight.

The product may heat up when the batteries are being recharged. This is normal. However, we recommend that you do not place the product on antique/veneered wood to avoid damage.

Do not stand your product on carpets or other surfaces which generate fibres, or place it in locations preventing the free flow of air over its surfaces.

Do not submerge any part of your product in water and do not use it in damp or humid conditions, such as bathrooms.

Do not expose your product to fire, explosive or other hazardous conditions.

There is a slight chance that your phone could be damaged by an electrical storm. We recommend that you unplug the power and telephone line cord during an electrical storm.

Setting up

IMPORTANT

Please note that your handset is NOT registered to a base station. The BT Diverse 5100 handset will be easily registered once you complete the steps 1 to 3 below.

Plan the location


Situate your product close enough to a mains power socket so that the cable will reach.

Make sure it is at least 1 metre away from other electrical products to avoid interference.


Do not situate the product in the bathroom or other humid areas.

1 Connect the charger

Plug the power supply cable into the power socket at the back of your charger.




2 Plug the power supply unit into the wall socket



3 Registering and charging the handset


The display is protected by a plastic film. You can remove this protective plastic film from the display.



BT Diverse Helpline – 08457 908 070

Insert the batteries

Insert the two batteries supplied, as indicated inside the battery compartment and slide the battery compartment cover shut.



The battery cover may be found in the packaging with the batteries.

WARNING

Under no circumstances should non-rechargeable batteries be used. Using incorrect batteries will invalidate your guarantee and may damage the telephone.

Registering the handset

To register your handset to a BT Diverse 5110 base station, place it in the main BT Diverse 5110 base station with the display facing upward. After approx. one minute, the handset's internal number is displayed (e.g. 2). Successful registration is signalled by a confirmation tone.

Replace the newly registered handset into the charger and leave to charge for approximately 16 hours. The charging status icon flashes on the handset to indicate that the batteries are being charged.

When the handset is registered the display will show:



If the icons on the display flash continuously...

It means that the handset is not registered with the base station.

Ensure you have correctly carried out step 3 above. If the product is still not registered see Registering Manually on page 12.

All additional handsets you purchase will need to be individually registered with the base station before they will work.


Leave the handset for approx. 16 hours in the base station to charge the batteries, as they are not charged in the factory. The battery status icon flashes on the handset to indicate that the batteries are being charged.

To manually register a BT Diverse 5100 handset to another base station


If you want to register your handset to another base station you will need to manually register it.

On the handset to be registered:

MENU Press the **MENU** options button.

 Press the **DOWN** button until the display shows REGISTER HS.

OK Press the **OK** button. Display show PIN.


 Enter your 4-digit Pin (original setting 0000).

OK Press the **OK** button. Display flashes REGISTER HS.


Following the user guide for the base station you are registering to place the base into registration mode.

To de-register a handset


INT Press the **INT** options button.

 Press the **UP** or **DOWN** button to select the handset to be de-registered (1-6).

MENU Press the **MENU** options button.

 Press the **DOWN** button until the display shows DE-REG H/SET.

OK Press the **OK** button. Display will show PIN ****.

 Enter your 4-digit PIN (original setting 0000).

OK Press the **OK** button. Display shows DE-REGISTER?

OK Press the **OK** button to confirm. SAVED is displayed.

 Press the **RED PHONE** button until you reach the idle screen.

Battery level icons

When the batteries are almost flat a beep sounds and the display shows the empty battery icon. You will need to recharge your handset before you can use it. The various states of charge are shown below:

 Batteries fully charged

 Batteries at 66%

 Batteries at 33%

 Batteries empty

Battery performance

Batteries and case may become warm during charging. This is normal.

Under ideal conditions, the handset batteries should give about 13 hours talktime or 170 hours standby time on a single charge. However, new NiMH batteries do not reach their full capacity until they have been in normal use for several days.




The charge capacity of rechargeable batteries will reduce with time as they wear out, so reducing the talk/standby time of the handset. Eventually they will need to be replaced. New batteries are available from www.withandwithoutwires.com or call 0870 240 5522.

If you replace the handset batteries with ones that have been fully charged, the battery indicator will not show full until the next charge cycle has been completed. Charge the handset until the batteries register full again. From then on the display will be correct.

Out of range?

If you go out of range of a base station for a long time while your handset is switched ON, it may take more than 20 minutes to 'find' the base station again when you come back within range. However, by simply switching the handset OFF for a moment, then ON again, it will find the base station within a few seconds.


Setting the date and time

- MENU** Press the **MENU** options button.
- ↓** Press the **DOWN** button until the display shows **BASE SET**.
- OK** Press the **OK** button. The display will show **DATE/TIME**.
- OK** Press the **OK** button. The display will show **DATE SET**.
- OK** Press the **OK** button.
-  Use the keypad to enter the date (DD/MM/YY).
- OK** Press the **OK** button.
- ↓** Press the **DOWN** button until the display shows **CLOCK SET**.
- OK** Press the **OK** button.
-  Use the keypad to enter the time in 12-hour clock format (HH/MM).
- After entering the time in the 12-hour clock format, press the **OK** button.
- OK** Press the **OK** button.
- ↓** Press the **DOWN** button to choose **AM** or **PM**.
- OK** Press the **OK** button.
-  Press the **RED PHONE** button until you return to the idle screen.

Please note

If you subscribe to a Caller Display Service the time and date will be set with the first incoming call. However, the year setting will have to be changed manually, see opposite.

To set the time mode (12 or 24-hour clock)

- The handset's default setting is 12-hour clock. To change the clock to the 24-hour setting:
- MENU** Press the **MENU** options button.
- ↓** Press the **DOWN** button until the display shows **BASE SET**.
- ↓** Press the **DOWN** button until the display shows **DATE/TIME**.
- OK** Press the **OK** button.
- ↓** Press the **DOWN** button until the display shows **CLOCK MODE**.
- OK** Press the **OK** button.
- ↓** Press the **DOWN** button to switch between 24 H and 12 H settings.
- OK** Press the **OK** button to confirm the setting you want.
-  Press the **RED PHONE** button until you reach the idle screen.

Using the telephone

Your BT Diverse 5100 Handset and Charger has a menu driven display. The **OPTION** buttons below the display allow you to select options within each menu and make adjustments to their settings. When the phone is in idle mode, press the **MENU** button to enter the main menu. During a call, if you press the **MENU** button it will open the menu for that particular situation.

Note

*To quit a menu at any time, press the **RED PHONE** button. This will take you back one step. Keep pressing the **RED PHONE** button to get back to the idle screen.*

To switch the handset power on and off



Press and hold the **RED PHONE** button to switch the handset off.



Press and hold the **RED PHONE** button to switch the handset on again.

Making and ending calls

To make an external call

Ensure the handset is switched ON.



Press the **GREEN PHONE** button. You will hear the dial tone.



Dial the number.

Preparatory dialling



Enter the phone number first. If you make a mistake press the **DELETE** button to remove any incorrect digits.



Press the **GREEN PHONE** button to dial the number.

To end a call



Press the **RED PHONE** button.

Call timer

Your handset automatically times the duration of all external calls, showing it on the display during your call and for a few seconds after it is finished.

To receive an external call



Press the **GREEN PHONE** button to answer the call.

Or

If the handset is on the base, simply lift it up and speak. You do not need to press the **GREEN PHONE** button.

This is called auto-talk. You can switch autotalk off so you always have to press the **GREEN PHONE** button to answer a call, *see page 31*.

Name and number directory

You can store up to 20 of your most frequently used names (up to 12 letters) and numbers (up to 22 digits long).

To store a name and number in the directory



Press the **DIRECTORY** button.

MENU

Press the **MENU** options button.



Press the **DOWN** button until the display shows **NEW ENTRY**.

OK

Press **OK** to confirm.



Enter the telephone number you want to store.

OK

Press **OK** to confirm.

Entering names

Enter the name using the letters on the keypad. (See 'Character map' on the following page for how to enter special characters). For example, to enter the name **TOM**:



Press the **8** button until **T** appears on the display.



Press the **6** button until the display shows **□**.



Then press **6** until the display shows **□**.

OK

Press **OK** to confirm. The display will show **SAVED** and **TOM**.



Press the **GREEN PHONE** button to dial the number.

Or



Press the **RED PHONE** button until you reach the idle screen.

Character map

As well as the standard letters and numbers you can include special characters in the directory entry.

Press	1	0	*	#
1 st press	Space	+	*	□
2 nd press	1	0	/	
3 rd press		-	<	
4 th press			>	
5 th press		?	,	
6 th press		—		

To dial a number from the directory



Press the **DIRECTORY** button.

A B C

If you wish, you can use the keypad to enter the first letter of the name, for example to find TOM, press the **8** button.

8 TUV



Press the **DOWN** button to scroll to the entry you want.



Press the **GREEN PHONE** button to dial the number.

To edit a directory entry



Press the **DIRECTORY** button.

A B C

Use the keypad to enter the first letter of the name you wish to edit.

When the name you wish to edit is displayed, press the **MENU** options button.

MENU

Press the **DOWN** button until **SHOW ENTRY** is displayed.

OK

Press the **OK** button.

Edit the number.

OK

Press the **OK** button.

<NAME> is displayed.

If the name is correct, press the **OK** button.

OK

Or



If you wish to edit the name, enter a new name now.

OK

Press the **OK** button. The display will show **SAVED**.

You can either press the **GREEN PHONE** button to dial the number or the **RED PHONE** button until you reach the idle screen.



To delete an entry from the directory



Press the **DIRECTORY** button.

A B C

Use the keypad to enter the first letter of the name.

Or



Use the **DOWN** button to find the entry you want.

MENU

Press the **MENU** options button.



Press the **DOWN** button to display **DELETE**.

OK

Press the **OK** button to confirm. The number is deleted.



Press the **RED PHONE** button until you reach the idle screen.

Note

*To cancel any procedure, press the **RED PHONE** button until the display returns to the idle screen.*

To delete all entries from the directory



Press the **DIRECTORY** button.

MENU

Press the **MENU** options button.



Press the **6** button, **DELETE?** is displayed.

OK

Press the **OK** button to confirm. All directory numbers are deleted.



Press the **RED PHONE** button until you reach the idle screen.

Extra directory

This is an additional directory where you are able to store up to 10 additional names and numbers.

To store names and numbers in the Extra directory



Press the **EXTRA DIRECTORY** button.

MENU

Press the **MENU** button.

The structure for this directory menu is the same as the main name and number directory.

You can follow the instructions starting on page 16 for storing, dialling, editing and deleting numbers in this directory.




Note

This Extra directory does not 'name and number match' when used with Caller Display.




Redial

Your handset automatically saves the last five telephone numbers dialed into a redial list.

To dial a number in the redial list

-  Press the **REDIAL** options button. The last number dialed will be displayed.
-  Press the **DOWN** button to scroll through the redial list.
-  Press the **GREEN PHONE** button to dial the number.

To copy numbers shown in the redial list to the directory

-  Press the **REDIAL** options button.
-  Press the **DOWN** button until the number you want is displayed.
- MENU** Press the **MENU** button.
-  Press the **DOWN** button until the display shows **COPY TO DIR.**
- OK** Press the **OK** button. The number is shown on the display.
- OK** Press **OK** to confirm. **NAME** is displayed.



Enter the name to the number you want to copy into the directory.

OK Press **OK** to confirm.



The display will show **SAVED** and the name of the entry.



You can dial this number by pressing the **GREEN PHONE** button or return to the idle screen by pressing the **RED PHONE** button.



To delete the redial list

-  Press the **REDIAL** options button.
- MENU** Press the **MENU** options button. Display shows **EDIT ENTRY.**
-  Press the **6** button. Display shows **DELETE ?**
- OK** Press **OK** to confirm deletion of the list. You hear a confirmation tone.
-  Press the **RED PHONE** button until you reach the idle screen.

Note

*To cancel any procedure, press the **RED PHONE** button until the display returns to the idle screen.*

Secrecy

When on a call you can talk to someone in the same room, without your caller hearing.

To switch secrecy on/off

During a call:

INT Press the **INT** options button.

The call is put on hold and your caller will hear music.

To resume the call:

MENU Press the **MENU** options button. Display shows **GO BACK**.

OK Press **OK** to confirm. You can now speak to your caller again.

Paging and internal calls

You can alert handset users that they are wanted, or locate a missing handset.

If you have multiple handsets registered to the base you can make internal calls between handsets.

INT Press the **INT** button.



Use the **DOWN ARROW** on the options button to find the handset number you want to page or call.



Press the **GREEN PHONE** button to call the handset.

If you want to page all the handsets registered to the base, highlight **CALL ALL** on the display and press the **GREEN PHONE** button.



You can also page all handsets by pressing the **PAGE** button on the base station

To transfer an external call between handsets

You can transfer an external call to another handset registered to the base.

INT Press the **INT** options button.



Enter the number of the handset to which you wish to transfer the call, or scroll to



find using the **UP** or **DOWN** option buttons. When the other handset answers you can tell them you are transferring the call and press the **RED**



PHONE button. The call is transferred and the original handset shows **LINE IN USE** on the display.

To return to an external call if the internal call is not transferred

To speak to your external caller again:

MENU Press the **MENU** options button. Display shows **GO BACK**.

OK Press the **OK** options button.

To switch 3-way conversation function on/off

You can allow your BT Diverse 5110 to hold 3-way calls between handsets.

MENU Press the **MENU** options button.



Press the **DOWN** options button until the display shows **BASE SET**.

OK Press the **OK** options button.



Press the **DOWN** options button until the display shows **ADD FEATURES**.

OK Press the **OK** options button.



Press the **DOWN** options button until the display shows **BARGE IN**.

OK Press the **OK** options button to switch the function on.

SAVED is displayed **BARGE IN** is then displayed with a tick next to it.

OK Press the **OK** options button again to switch off, tick is deleted.



Press the **RED PHONE** button until you reach the idle screen.

To hold a 3-way conversation

You can talk to one external caller and another internal caller at the same time on your BT Diverse 5110 handset.

While another handset user is talking to an external caller the display shows **LINE IN USE**.



Press the **GREEN PHONE** button to join the conversation. Display shows **LISTENING IN**.

A tone is heard by all three parties when one party enters or leaves the call.



Press the **RED PHONE** button to end your call.

Caller Display and other BT Calling Features

IMPORTANT

*To use Caller Display and Call Waiting you must first subscribe to the Services from your Network Provider. For more information on BT's Calling Features call BT free on **0800 800 150**.*

Please note

Calls that are 'withheld', 'unavailable' or 'international' are not stored in the Calls list, as there is no telephone number sent via the network.

If you subscribe to a Caller Display Service you can see who is calling you on your handset display, as well as the date and time of their call (unless the number has been withheld).

If you have stored a name to go with the number in your handset directory, the name will be displayed instead.

Please ensure that you have stored the full telephone number, including the area code, otherwise the name will not match the number stored in the directory.

If the caller has withheld their number, the display will show WITHHELD.

If you call from another handset, the display shows the handset number and INT.


Calls list

The Calls list contains the telephone numbers of your last 10 callers.

The caller's details are stored in the Calls list. You can display, scroll through and dial numbers in the list and copy them into the directory.

If a call is received when the Calls list is full then the oldest entry will be deleted automatically.

Please note

If you have a new call in your Calls list, the  icon will flash.

To view the Calls list



Press the **ENVELOPE** options button. A flashing envelope indicates new calls. New calls are displayed immediately.

If there are no new entries, continue to open the Calls list.

The display will show the type of calls you have received in your Calls list, e.g. **CALLS 02/06** means you have received 2 new calls and have 6 old calls.

OK

Press the **OK** button to display the most recent number to call you.



Press the **UP** and **DOWN** buttons to scroll backwards and forwards through the Calls list.

When you have found the entry you want, you have the options to:

Call a number from the Calls list:

When the number you wish to call is displayed, press the **GREEN PHONE** button.

The number will be dialled automatically.



Display the time of the call:

MENU

Press the **MENU** options button.



Press the **DOWN** button to highlight **TIME**.

OK

Press the **OK** options button. The date and time of the call are displayed.



To return to the beginning of the calls list, press the **RED PHONE** button repeatedly until it is displayed.

Display the status of the call:

MENU

Press the **MENU** options button.



Press the **DOWN** button to highlight **STATUS**.

OK

Press the **OK** button.


NEW = New call.

OLD = Previously viewed.



Press the **RED PHONE** button until you reach the idle screen.


Remember

If you have missed a call the  icon will flash on the display.

Store a number from the Calls list into the directory:

When the number you want to store is displayed:

MENU Press the **MENU** options button.

 Press the **DOWN** button to highlight COPY TO DIR.

OK Press the **OK** button. The number is displayed.

OK Press the **OK** button again.

Enter a name, *see page 16* for instructions.

OK Press the **OK** button.

The display shows **SAVED**. You can either copy another entry from the Calls list or press the **RED PHONE** button until you reach the idle screen.

**Delete a number from the Calls list.**

When the number you want to delete is displayed:

MENU Press the **MENU** options button.

DELETE is displayed.

OK Press the **OK** button to confirm. The display shows **DELETED**.

Delete the whole Calls list:

When any number is displayed, press the **MENU** options button.

MENU



Press the **DOWN** button to highlight **DELETE LIST**.

OK

Press the **OK** button. The display shows **NO CALLS**.



Press the **RED PHONE** button until you reach the idle screen.

Call Waiting

If you also subscribe to a Call Waiting Service, when you are on a call and another person tries to call you, the second caller's number will appear on the handset display and you will hear an intermittent beep through the handset. This is to alert you to the other caller waiting to speak to you.

To accept a waiting call

During a call when you hear the Call Waiting beeps:

The number (or name if stored in the directory) of the second caller will flash on the display.

MENU Press the **MENU** options button. Display shows **ACCEPT**.

OK Press the **OK** options button. Your current call is put on hold and you are connected to the second caller.

(R) Press the **RECALL** button to toggle between callers.

To switch Call Waiting on/off

You can choose whether to have your Call Waiting service switched on or off depending on what you are doing i.e. if you are using the Internet via your PC and do not want Call Waiting to interrupt you.

MENU Press the **MENU** options button, **SEL SERVICES** is displayed.

OK Press the **OK** options button.

↓ Press the **DOWN** until the display shows **CALL WAITING**.

OK Press the **OK** options button.

↑ ↓ Use the **UP** or **DOWN** button to select whether you want the service on or off.

OK Press the **OK** options button.

You will hear a Network message confirming your divert request.

(R) Press the **RED PHONE** button until you reach the idle display.

Call Divert

You can divert all incoming calls to another number where you can be reached.

Please note

Call Divert requires subscription from your Network provider. You may be charged a subscription fee.

To divert calls

MENU Press the **MENU** options button, **SEL SERVICES** is highlighted.

OK Press the **OK** options button.

↓ Use the **DOWN** arrow on the options button until **CALL DIVERT** is highlighted.

OK Press the **OK** options button.

You now have a choice of when you want calls to be diverted:

AUTOMATIC – calls are put straight through to the number you have set.

NO ANSWER – calls are diverted if your phone is not answered.

IF BUSY – calls are forwarded if your phone is engaged.

OK

Select your required option and press the **OK** options button, **DN** is displayed.

OK

Press the **OK** options button again.



Enter the phone number where you want the calls to be diverted to.

OK

Press the **OK** options button. You will hear a Network message confirming your divert request.



Press the **RED PHONE** button until you reach the idle display.

Withhold number

Your number appears on the display of the person you call if they subscribe to a Caller Display service. You are able to withhold your telephone number from the next call you make if you wish.

To withhold your number from being sent

MENU Press the **MENU** options button, **SEL SERVICES** is displayed.

OK Press the **OK** options button, **WITHHOLD NO** is displayed.

OK Press the **OK** options button.



Enter the telephone number you want to call.

OK Press the **OK** options button, the number will be dialled but your number will not be sent to your caller.

Ring Back

If you want to make a call and the number is engaged you can set your telephone to ring you back when the caller has finished their call by pressing the **5** button. To switch this service off before your call is returned i.e. if you have to go out before your caller has returned your call.

To switch Ring Back off if set

MENU Press the **MENU** options button, **SEL SERVICES** is highlighted.

OK Press the **OK** options button.



Use the **DOWN** arrow on the options button until **RINGBACK OFF** is highlighted.

OK Press the **OK** options button. This will cancel your ringback call.

You will hear a Network message confirming your divert request.



Press the **RED PHONE** button until you reach the idle display.

Voice Mail

If you have a Voice Mail message service i.e. Call Minder or Meridian Mail on your telephone line you can set the **1** button to access your messages directly via one button.

To set up quick access to your Voice Mail service

MENU Press the **MENU** options button.



Press the **DOWN** options button. Display shows **MAILBOX**.

OK Press **OK**.
Display shows **SET KEY 1**.

OK Press the **OK** button.

Enter the telephone number of your messaging service. For example, 1571 to access 'BT Answer' voice mail service.

OK Press **OK**.
The display shows **SAVED**.



Press the **RED PHONE** button until you reach the idle screen.

To set up quick access to your Voice Mail service when behind a switchboard eg. Meridian Mail.

Follow the steps on the previous page, but when you come to enter the telephone number of your messaging service, you will need to follow the example below:



Enter the access number for your messaging service, e.g. 7000.



Press *and hold* the **RECALL** button to enter a pause in the dialling sequence, P.



Enter your extension number, followed by a hash, e.g. 1234 #.



Press *and hold* the **RECALL** button to enter another pause in the dialling sequence, P.



Enter your PIN followed by a hash, e.g. 000000 #.

The entire number should look like this:

7000P1234nP000000n

Please note

If you store your security PIN as part of the quick access number, anyone with access to the handset will be able to retrieve your messages.

To retrieve messages from your Voice Mail service



Press and hold down the **1** button.

When set up as opposite this will take you into your message service. If during the set up you entered your security PIN as well as the telephone number you will be taken quickly into your messages. If the security PIN was not included you will have to enter this number now.



Press the **OK** button.

You will be taken into your messages.

Handset settings

To adjust the handset ringer volume

You can choose from 5 levels (1–5), a 'crescendo' ring (6) that increases in volume, or you can switch the ringer off altogether (0).

MENU Press the **MENU** options button.

↓ Use the **DOWN** button to highlight **AUDIO SET**.

OK Press the **OK** button.

↓ Press the **DOWN** button to highlight **RINGER**.

OK Press the **OK** button.




You hear the current volume level and the level is shown on the display.

↑↓ Press the **UP/DOWN** button to select the level you want.

OK Press the **OK** button to confirm. **SAVED** is displayed.

 Press the **RED PHONE** button until you reach the idle screen.

Shortcut button

If you want to switch the handset ringer off quickly you can also press and hold the  button. The  icon is displayed. To turn the handset ringer back on press and hold down the  button again and the symbol will disappear.

To adjust the handset ringer melody

There are 10 melodies to choose from (1–10).

MENU Press the **MENU** options button.

↓ Press the **DOWN** button to highlight **AUDIO SET**.

OK Press the **OK** button.

↓ Press the **DOWN** button to highlight **MELODY**.

OK Press the **OK** button.

You hear the current melody and its number is shown on the display.

↓ Press the **DOWN** button to select the melody you want.

OK Press the **OK** button.

 Press the **RED PHONE** button until you reach the idle screen.

To adjust the earpiece volume

There are 3 volume levels to choose from and you can even adjust the volume during a call.

MENU Press the **MENU** options button.

↓ Press the **DOWN** button to highlight **AUDIO SET**.

OK Press **OK** to confirm. The display show **H/SET VOL**.

OK Press **OK** to confirm.

You hear the current volume and the level is displayed.

↑ ↓ Select the required level.

OK Press **OK** to confirm. **SAVED** is displayed.

 Press the **RED PHONE** button until you reach the idle screen.

To switch autotalk on and off


If autotalk is switched on you do not need to press the **GREEN PHONE** button to answer a call you can simply pick the handset up from the charger.


If you switch autotalk off you always have to press the **GREEN PHONE** button to answer a call.

The default setting for autotalk is on.

MENU Press the **MENU** options button.


To switch autotalk on:


 Press the **9** button.


 Press the **1** button.

 Press the **1** button again.

To switch autotalk off:

 Press the **9** button.

 Press the **1** button.

 Press the **0** button.

To reset your handset to the original settings

MENU Press the **MENU** options button.

9 WXYZ

Press the **9** button.

3 DEF

Press the **3** button.
The display shows **RESET?**.

OK Press **OK** to confirm.

This will reset:

Earpiece volume **1**

Ringer volume **5**

Ringer melody **1**

Autotalk **ON**

Battery low beep **ON**

Redial list **DELETED**

This will not delete the directory or Calls list.

This will not reset:

Handset PIN

Registration to the base station.

Keyguard

You can lock the keypad so that it cannot be used accidentally while carrying it around.

To switch keyguard on



Press and hold the **#** button to switch keyguard on. You hear a confirmation tone.

The keypad is now locked and you cannot dial out. You can answer calls as normal by pressing the **GREEN PHONE** button.



To switch keyguard off, press and hold the **#** button again. You hear a confirmation tone and the handset is now unlocked.



IMPORTANT

*If the keyguard is active, the emergency numbers **999** and **112** can **NOT** be dialled.*

Help

Problem	Possible cause	Solution
Handset not registering.	The charger is not powered. There are no batteries in the handset.	Make sure that the power supply is plugged in at the charger and switched on. Make sure that the rechargeable batteries (included) are fitted in the handset correctly. Switch the handset off and then back on again, place the handset on to the charger again and leave for approx. 1 minute to try registering again.
You have forgotten your base station PIN number.	You have changed the PIN.	Try entering the default PIN (0000). If you have changed the PIN and cannot remember the number you will need to contact the BT Diverse Helpline on 08457 908070.
No display	Handset not switched on. Batteries exhausted.	Hold down the RED PHONE button for 1 second. Charge or replace batteries.
When you press a button, nothing happens.	Keyguard may be switched on.	Hold down the # button for 1 second.
No radio signal to the base – all displays flashing.	Handset out of range. Handset not registered.	Move closer to the base. Register the handset (<i>see page 11</i>).
Handset in charger doesn't charge.	Charger is not connected to the power supply.	Make sure that the power supply is in at the charger and the power source is switched on. Check that the batteries are fitted correctly.
Handset does not ring.	Ringer is switched off.	Switch ringer back on, <i>see page 30</i> .
Your caller cannot hear you.	The INT button has been pressed, muting the microphone.	Select GO BACK option via the MENU button to switch the microphone back on.
Caller's number is not displayed even though you have subscribed to Caller Display.	The number has been withheld.	Callers can stop their number being sent over the network.
The error beep – a descending tone – is played.	You have pressed the wrong button.	Retry. If necessary, check the instructions.

General information

Guarantee

Your BT Diverse 5100 Additional Handset and Charger is guaranteed for a period of 12 months from the date of purchase.

Subject to the terms listed below the guarantee will provide for the repair of, or at BT's or its agent's discretion the option to replace the BT Diverse 5100 Handset and Charger, or any component thereof, (other than batteries), which is identified as faulty or below standard, or as a result of inferior workmanship or materials. Products over 28 days old from the date of purchase may be replaced with a refurbished product.

The conditions of this guarantee are:

- The guarantee shall only apply to defects that occur within the 12 month guarantee period.
- Proof of purchase is provided.
- The equipment is returned to point of purchase.
- This guarantee does not cover any faults or defects caused by accidents, misuse, fair wear and tear, neglect, tampering with the equipment, or any attempt at adjustment or repair other than through approved agents.
- This guarantee does not affect your statutory rights.

Within the 12-month guarantee period:

If you experience difficulty using the product, prior to returning your product, please read the Help section beginning on page 33, or contact the BT Diverse Helpline on **08457 908070** for assistance.

In the unlikely event of a defect occurring, please follow the Helpline's instructions for replacement or repair.

Outside the 12-month guarantee period:

If your product needs repair after the guarantee period has ended, the repair must meet the approval requirements for connection to the telephone network. We recommend that you call the Helpline on **08457 908070** and ask for details of our recommended repair agents.

BT Accessories and Replacement Items

For a full range of accessories and replacement items for BT products please call 0870 240 5522, or visit:



BT Diverse Helpline – 08457 908 070

Technical information

How many telephones can you have?

All items of telephone equipment have a Ringer Equivalence Number (REN), which is used to calculate the number of items that may be connected to any one telephone line. The BT Diverse 5110 base station (with up to 6 handsets) has a REN of 1. Any other instrument provided by BT may be assumed to have a REN of 1 unless stated otherwise.

A total REN of 4 is allowed. (For example: if BT Diverse 5110 is used in conjunction with three extension telephones, each with a REN of 1, the total REN is 4.)

Only use approved power supply item code: C39280-Z4-C478.

R&TTE

This product is intended for use within the UK for connection to the public telephone network and compatible switchboards.

This equipment complies with the essential requirements for the Radio Equipment and Telecommunications Terminal Equipment Directive (1999/5/EC). In demonstration with the Essential Requirement for the efficient use of the radio spectrum, the product complies with TBR6.

If you would like a copy of the Declaration of Conformity please contact the BT Diverse Helpline.

BT Diverse Helpline – 08457 908 070

Index

Autotalk on/off	31	Date set	14
Batteries		Delete	
charging	11	all directory entries	18
installing	11	calls list	25
performance	13	directory entry	18
replacing	12	redial list	19
warning beeps	12	De-register handset	12
Call divert	27	Directory	16
Call timer	16	delete an entry	18
Call Waiting	26	delete all entries	18
Caller Display	23	dial a number	17
Calls list	23	edit an entry	17
delete	25	extra directory	18
dialling a number	24	store name and number	16
display status of call	24	Display icons	7
display time of call	24	Earpiece volume	31
store number to directory	25	Ending calls	15
view	24	External calls	15
Calls		Extra directory	18
end	15	Guarantee	34
external	15	Handset	
holding	21	display	2
internal	20	on/off	15
making	15	reset	32
on hold	22	ringer melody	30
receiving	16	ringer volume	30
redial	19	Handset quick guide	6
secrecy	20	Help	33
three-way	21	Helpline	3
transferring	21	Holding calls	21
Character map	17	Internal calls	20

Keyguard	32	Technical information	35
Making calls	15	Three-way conversation	21
Melody		Time set	14
handset	30	Transferring calls	21
Menu structure	4	Voice Mail	28
Music on hold	20	Volume	
On/off		earpiece	31
auto talk	31	handset ringer	30
handset power	15	Withhold number	27
keyguard	32		
secrecy	20		
Page a handset	20		
Power connection	10		
Preparatory dialling	15		
Quick guide			
display icons	7		
handset settings	6		
Range warning	13		
Receiving calls	16		
Redial	19		
copy to directory	19		
delete	19		
dial number in redial list	19		
Registering handset	11		
Registration – manual	12		
REN, how many phones can I have?	35		
Reset			
handset settings	32		
Ring back	28		
Ringers on/off	30		
Safety information	9		
Secrecy	20		
Setting up	10		

Visit us at www.bt.com



Offices worldwide

The telecommunications services described in this publication are subject to availability and may be modified from time to time. Services and equipment are provided subject to British Telecommunications plc's respective standard conditions of contract. Nothing in this publication forms any part of any contract.

© British Telecommunications plc 2003.
Registered Office: 81 Newgate Street, London EC1A 7AJ.
Registered in England No. 1800000.
Diverse 5100 Handset & Charger (05/03) 4
Designed by The Art & Design Partnership Limited.

Siemens number: A31008-A002-P001-1-7619

CE 0682

CE compliant to R&TTE Directive (1999/5/EC)

Free Manuals Download Website

<http://myh66.com>

<http://usermanuals.us>

<http://www.somanuals.com>

<http://www.4manuals.cc>

<http://www.manual-lib.com>

<http://www.404manual.com>

<http://www.luxmanual.com>

<http://aubethermostatmanual.com>

Golf course search by state

<http://golfingnear.com>

Email search by domain

<http://emailbydomain.com>

Auto manuals search

<http://auto.somanuals.com>

TV manuals search

<http://tv.somanuals.com>