


HDMI Switch Box




Features

- Allows up to 4 HDMI components to be connected to one HDMI input simultaneously
- 1080p compatible
- Supports auto-switching and includes IR remote
- Supports Dolby® TrueHD and DTS®-HD Lossless audio formats
- Plug-and-play, easy to install

Package contents


- HDMI switch box
- 5V DC 1A power adapter
- Remote control with battery

Front



#	Description
1	Device LEDs: The LED of the selected device lights green.
2	Power LED: Lights red when the switch box is turned on.
3	POWER/SELECT: Press and hold for 3 seconds to turn the switch box on or off. Press and release quickly to switch between devices.

Back



Connecting your HDMI switch box

- 1 Connect an HDMI cable from the HDMI output of each component to one of the HDMI inputs on the switch box.
- 2 Connect an HDMI cable from the HDMI output on the switch box to an HDMI input on your TV.
- 3 Connect the included power adapter to the DC input jack on the HDMI switch box and plug it into a standard 110V AC outlet.

Using your HDMI switch box

Remove the plastic tab that extends past the bottom edge of the remote control. This tab protects the battery. The remote control will not work until it is removed.

Your HDMI switch box operates in three modes: Auto-detect (default), manual, and remote control.


Notes:

- When remote control or manual mode is used, auto-detect mode becomes disabled. Use the remote control or press **POWER/SELECT** on the switch box to select an HDMI device.

- To return to auto-detect mode, turn the switch box OFF, then ON or connect a new HDMI device.
- Your HDMI switch box memorizes the last HDMI device used. The switch box detects and connects to that HDMI device first.

Auto-detect mode

Your HDMI switch box will automatically switch to the most recently powered-on device. When a device is powered off, the switch box will automatically switch to the next device that is powered on in the following sequential order:



Note: Not all HDMI devices support auto-switching. If the switch box fails to switch to the desired input when the device is turned on, use the remote control or manual switching mode.

Manual mode

Press **POWER/SELECT** on your switch box to switch to a different device. The corresponding LED lights green.




Remote control mode

- 1 Press **POWER ON/OFF** on the remote control. The power LED lights red.
- 2 Press a number button or **◀/▶** to switch between devices.

To replace the battery in your remote control:

- 1 Remove the battery holder from the remote control.



- 2 Remove the old battery, then insert a CR2025 battery into the battery holder, positive (+) side up.
- 3 Slide the battery holder back into the remote control.



Troubleshooting

Symptom	Possible solution
There is no picture.	<ul style="list-style-type: none"> • Make sure all cables are securely connected. • Check the HDMI switch box power • Turn the switch box off and then back on. • Replace damaged cables.
There is picture but no sound.	<ul style="list-style-type: none"> • Make sure all cables are securely connected. • Press and hold Power/Select for 3 seconds to turn the switch box off and then on. • Do not connect the switch box output to a video recorder. Doing so will automatically lock up the audio transmission as required by HDCP (High Definition Content Protection). • Replace damaged cables.
The display resolution is not 1080p.	<ul style="list-style-type: none"> • Make sure your display and connected devices support 1080p. • Make sure your HDMI cables are capable of transmitting 1080p
The device LEDs are flashing.	<ul style="list-style-type: none"> • You may have the wrong connection. Follow the steps under <i>Connecting your HDMI switch box</i>. • Make sure all cables are securely connected.
The power LED is flashing.	<ul style="list-style-type: none"> • The switch box is detecting and connecting to the device. Once the device is connected, the flashing stops. • If the flashing continues: <ul style="list-style-type: none"> ○ Turn the switch box off and then back on. ○ Make sure all cables are securely connected.
The remote control does not work.	<ul style="list-style-type: none"> • Make sure the protective plastic insert has been removed. • Replace the battery.

NOTICE

- Manufacturer reserves the right to make changes in the hardware, packaging and any accompanying documentation without prior written notice.
- HDMI, the HDMI Logo and High-Definition Multimedia Interface are trademarks or registered trademarks of HDMI Licensing LLC.
- "Dolby" and the double-D symbol are trademarks of Dolby Laboratories.
- DTS and DTS Digital Surround are registered trademarks and the DTS logos and Symbol are trademarks of DTS, Inc. © 1996-2007 DTS, Inc. All Rights Reserved.



One-Year Limited Warranty

Rocketfish Products ("Rocketfish") warrants to you, the original purchaser of this new **RF-HDMI4** ("Product"), that the Product shall be free of defects in the original manufacture of the material or workmanship for one (1) year from the purchase of the Product ("Warranty Period"). This Product must be purchased from an authorized dealer of Rocketfish brand products and packaged with this warranty statement. This warranty does not cover refurbished Product. If you notify Rocketfish during the Warranty Period of a defect covered by this warranty that requires service, terms of this warranty apply.

How long does the coverage last?

The Warranty Period lasts for one year (365 days), beginning on the date you purchased the Product. The purchase date is printed on the receipt you received with the product.

What does this warranty cover?

During the Warranty Period, if the original manufacture of the material or workmanship of the Product is determined to be defective by an authorized Rocketfish repair center or store personnel, Rocketfish will (at its sole option): (1) repair the Product with new or rebuilt parts; or (2) replace the Product at no charge with new or rebuilt comparable products or parts. Products and parts replaced under this warranty become the property of Rocketfish and are not returned to you. If service of Products and parts are required after the Warranty Period expires, you must pay all labor and parts charges. This warranty lasts as long as you own your Rocketfish Product during the Warranty Period. Warranty coverage terminates if you sell or otherwise transfer the Product.

How to obtain warranty service?

If you purchased the Product at a retail store location, take your original receipt and the Product to the store you purchased it from. Make sure that you place the Product in its original packaging or packaging that provides the same amount of protection as the original packaging. If you purchased the Product from an online web site, mail your original receipt and the Product to the address listed on the web site. Make sure that you put the Product in its original packaging or packaging that provides the same amount of protection as the original packaging.

Where is the warranty valid?

This warranty is valid only to the original purchaser of the Product in the United States, Canada, and Mexico.

What does the warranty not cover?

This warranty does not cover:

- Customer instruction
- Installation
- Set up adjustments
- Cosmetic damage
- Damage due to acts of God, such as lightning strikes
- Accident
- Misuse
- Abuse
- Negligence
- Commercial use



- Modification of any part of the Product, including the antenna

This warranty also does not cover:

- Damage due to incorrect operation or maintenance
 - Connection to an incorrect voltage supply
 - Attempted repair by anyone other than a facility authorized by Rocketfish to service the Product
 - Products sold as is or with all faults
 - Consumables, such as fuses or batteries
 - Products where the factory applied serial number has been altered or removed
- REPAIR REPLACEMENT AS PROVIDED UNDER THIS WARRANTY IS YOUR EXCLUSIVE REMEDY. ROCKETFISH SHALL NOT BE LIABLE FOR ANY INCIDENTAL OR CONSEQUENTIAL DAMAGES FOR THE BREACH OF ANY EXPRESS OR IMPLIED WARRANTY ON THIS PRODUCT, INCLUDING, BUT NOT LIMITED TO, LOST DATA, LOSS OF USE OF YOUR PRODUCT, LOST BUSINESS OR LOST PROFITS. ROCKETFISH PRODUCTS MAKES NO OTHER EXPRESS WARRANTIES WITH RESPECT TO THE PRODUCT, ALL EXPRESS AND IMPLIED WARRANTIES FOR THE PRODUCT, INCLUDING, BUT NOT LIMITED TO, ANY IMPLIED WARRANTIES OF AND CONDITIONS OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, ARE LIMITED IN DURATION TO THE WARRANTY PERIOD SET FORTH ABOVE AND NO WARRANTIES, WHETHER EXPRESS OR IMPLIED, WILL APPLY AFTER THE WARRANTY PERIOD. SOME STATES, PROVINCES AND JURISDICTIONS DO NOT ALLOW LIMITATIONS ON HOW LONG AN IMPLIED WARRANTY LASTS, SO THE ABOVE LIMITATION MAY NOT APPLY TO YOU. THIS WARRANTY GIVES YOU SPECIFIC LEGAL RIGHTS, AND YOU MAY ALSO HAVE OTHER RIGHTS, WHICH VARY FROM STATE TO STATE OR PROVINCE TO PROVINCE.

Contact Rocketfish:

For customer service please call 1-800-620-2790

www.rocketfishproducts.com

Distributed by Best Buy Purchasing, LLC

7601 Penn Avenue South, Richfield, Minnesota, U.S.A. 55423-3645

© 2009 Best Buy Enterprise Services, Inc.

All rights reserved. ROCKETFISH is a trademark of Best Buy Enterprise Services, Inc. Registered in some countries. All other products and brand names are trademarks of their respective owners.

Free Manuals Download Website

<http://myh66.com>

<http://usermanuals.us>

<http://www.somanuals.com>

<http://www.4manuals.cc>

<http://www.manual-lib.com>

<http://www.404manual.com>

<http://www.luxmanual.com>

<http://aubethermostatmanual.com>

Golf course search by state

<http://golfingnear.com>

Email search by domain

<http://emailbydomain.com>

Auto manuals search

<http://auto.somanuals.com>

TV manuals search

<http://tv.somanuals.com>