

USB 2.0, 3.5 inch Portable External Enclosure



USER MANUAL

PROPRIETARY NOTICE

We makes no warranty of any kind with regard to this material, including, but not limited to, the implied warranties of merchantability and fitness for a particular purpose. We shall not be liable for errors contained herein or for incidental or consequential damages in connection with the furnishing, performance, or use of this material.

This document contains proprietary information which is protected by copyright. All rights are reserved. No part of this document may be photocopied, reproduced, or translated to another language without our written consent. The information contained in this document is subject to change without notice.

TRADEMARKS

MS-DOS, Windows, Windows 98SE/NT/2000/Me/XP are trademarks of Microsoft Corporation.

PC is a trademark of International Business Machines Corporation.

Macintosh and Mac are trademarks of Apple Computer, Inc.

All of the third-party brands and names are the property of their respective owners.

USB 2.0, 3.5 inch Portable External Enclosure VP-9258(T) USER MANUAL

Rev. 1.0 Date: June 14, 2004

Contents

1. Introduction	4
1-1 Features and Specifications	4
1-2 USB 2.0 External Drive	5
1-3 Package Checklist	6
2. Temperature Control Jumper Settings (Only VF	9-9258T) 6
3. Power LED indicator	6
4. Hardware Installation	8
4-1 System Requirements	8
4-2 Assembly	8
4-3 Connect the USB 2.0 External Enclosure	
VP-9258(T) to Your Computer	11
5. Drivers Installation	12
5-1 Windows 98SE	12
5-2 Windows Me/2000/XP	
5-3 Mac OS 9.X or Above	17
6. Using The USB 2.0 External Enclosure	17
6-1 Connect the USB 2.0 External Enclosure	
VP-9258(T) to Computer	17
6-2 Disconnect the USB 2.0 External Enclosure	
VP-9258(T) from Computer	18
7. Partitioning the External USB 2.0 Hard Disk	20
7-1 Partition Under Windows 98/ME	20
7-2 Partition under Windows 2000/XP	22

1. Introduction

Congratulation on your purchase of VP-9258(T) USB2.0 Portable 3.5 inch External Enclosure.

This External Enclosure has been designed to provide portable hot-swapping (Plug-n-Play) operation of internal 3.5 inch hard drives.

Supplied with this enclosure is a USB 2.0 cable, AC/DC adapter, stand for enclosure and a CD containing installation driver(s). The CD also contains a copy of this installation guide.

The USB 2.0 cable enables connection of the Enclosure to your PC, Notebook or MAC.

1-1 Features and Specifications

Features

- 1. USB 2.0/1.1 compliant with data transfer rates up to 480 Mbit/sec
- 2. Compatible with both the standard specification of USB 2.0 and USB 1.1
- 3. Native Plug-n-Play support for Windows Me/2000/XP (software drivers for Windows 98SE and Mac OS included)
- 4. Build-in temperature controller of VP-9258T
- 5. Reduce fan noise of VP-9258T
- 6. Adjustable temperature sensor of VP-9258T

Specifications

- 1. Supports USB 2.0 transfer rates up to 480 Mbit/sec.
- Native Hot-Swap and Plug-n-Play support for Windows Me, Windows 2000/XP (software drivers for Windows 98SE and Mac OS 9.X included)
- 3. Fully compatible with 3.5 inch HDD

- 4. USB 2.0/IDE compliant:
 - a) Integrated USB transceiver
 - b) High speed (480 Mbit) and full speed (12 Mbit) support
 - c) USB suspend/resume, remote wake up support.
- 5. Supports ATA PIO modes 0-4: ATA interface operation mode is automatically selected during device initialization or manually programmed with configuration data
- 6. Supports UDMA modes 0-4
- 7. Supports 48-bit LBA (large HDD), when the VP-9258(T) connects with one 3.5 inch HDD
- 8. Supports 16-bit Multiword DMA mode and Ultra DMA mode interface
- 9. Supports Power Down mode and USB suspend indicator

1-2 USB 2.0 External Drive

The USB 2.0 External Drive is a portable compact storage drive that incorporates the USB 2.0 (Universal Serial Bus 2.0) high speed interface. The USB 2.0 External Drive provides a fast and easy way to add more storage space to your computer.

Its hot-swapping and Plug-n-Play features gives you a great convenience on the road, where it can be connected/disconnected without powering down your system. The VP-9258(T) USB 2.0 External Drive is compatible with Apple Macintosh and Windows computers.

<u>Note:</u>

In order to reach USB 2.0 speed, your computer must have a host adapter card with USB 2.0 support. The VP-9258(T) will auto detect the speed of your USB port and adjust between USB 1.0 and USB 2.0 speed.

1-3 Package Checklist

The USB 2.0 external enclosure VP-9258(T) package contains the following items:

- 1) The VP-9258(T) Case
- 2) A User's Manual
- 3) One "Drivers and Utility Installation" CD
- 4) One USB 2.0 Cable
- 5) One +5V/+12V Power Adapter
- 6) One Power Adapter Power Cord
- 7) Screws bag

If any of these items are missing or damaged, please contact your dealer or sales representative for assistance.

2. Temperature Control Jumper Settings (Only VP-9258T)

Jumpers JP7 and JP8, located on the rear PCB panel of the VP-9258T, are used to set the cooling fan for controlling the operating temperature. The default setting is JP8 pins 1-2 ON. The fan will always run continuously to disperse the heat.

<u>Note:</u> Only one jumper can be set at the same time.



The following identifies the jumper options for setting the operation of the cooling fan.

JP7	JP8	Temperature
(Clear) 0 1 0 2 0 3	1-2 :ON	(Default)
1-2:ON 1 2 0 3	(Clear)	50°C
2-3 :ON 1 2 3	(Clear)	40°C
(Clear) 1 2 3	(Clear)	60°C

JP8 (2-pin) Jumper

When JP8 pins 1-2 are jumpered (ON), the fan will always run continuously to disperse the heat. *(Default)* When the jumper is removed, operation of the fan will always be controlled by the JP7 jumper setting.

JP7 (3-pin) Jumper

1) Set JP7 pins 1-2 to ON. Controls temperature at 50 °C

2) Set JP7 pins 2-3 to ON. Controls temperature at 40 °C

3) Clear JP7 setting (no jumper). Controls temperature at 60 °C

3. Power LED indicator

The power LED indicator is located on the front panel of the VP-9258(T). The power LED will be green light when connect with the power cable. When you write the data to the VP-9258(T), the power LED will be orange light.



4. Hardware Installation

4-1 System Requirements

Hardware

Notebook or desktop computer with support for USB or USB 2.0.

Operating System

Windows 98SE/Me/2000/XP, and Mac OS 9.X or above.

4-2 Assembly

1. Remove the two retaining screws securing the upper case of the Enclosure to the rear face.



2. Carefully lift the rear of the case. Then, slide it away from the rear face of the front panel.



3. Remove the four screws retaining the hard drive cradle to the base unit of the Enclosure.



4. Lift out the cradle.



5. Position the hard drive into the cradle.



6. Secure the hard drive into the cradle using the four retaining screws.



7. Locate the IDE port and power port situated on the rear face of the hard drive. Plug the IDE cable and power cable into the appropriate port ensuring that they fit securely.



VP-9258(T) USER MANUAL

9

8. Position the cradle/hard drive onto the Enclosure base unit.



9. Secure the cradle with the four retaining screws.



10. Replace the upper case. Note Ensure that the groove in the upper case aligns with the slot in the base unit.



11. Slide the upper case forward ensuring that it abuts the rear face of the front panel.



12. Finally, secure the upper case with the two retaining screws.



4-3 Connect the USB 2.0 External Enclosure VP-9258(T) to Your Computer

<u>Step1:</u>

Boot-up your computer. Make sure the USB/USB 2.0 host adapter and driver are installed in your computer.

<u>Step2:</u>

Connect one USB connector end of the USB cable into the USB Port of your USB 2.0 External Enclosure VP-9258(T).

<u>Step3:</u>

Connect the Power Adapter Power Cord to the +5V/+12V Power Adapter. Then, plug one end of power cord into an AC power outlet, and the other end to the power inlet of your USB 2.0 External Enclosure VP-9258(T).

<u>Step4:</u>

Power ON your USB 2.0 External Enclosure VP-9258(T).

<u>Step5:</u>

Proceed to the next "Driver Installation" section and follow the instructions for your operating system after plugging the USB connector end of the USB cable into a USB port on your computer.

<u>Note:</u>

This device will auto-detect the speed of your USB port and adjust between USB 1.0 and USB 2.0 speed once the driver is installed.

5. Drivers Installation

5-1 Windows 98SE

If this is the first time using your USB 2.0 External Drive, you must first run the [SETUP.EXE] from the USB 2.0 "Drivers and Utility Installation" CD after you connect your USB 2.0 External Drive to your computer. Then proceed with the following:

- 1. Connect your USB 2.0 external drive to an available USB port on your computer.
- 2. An "Add New Hardware Wizard" screen will appear. Click [Next].



3. Select "Display a list of all drivers" then click [Next].



4. Click [Browse].



5. Double click on the ViPowER CD icon of the [My Computer] directory.



6. Select "Win98" under the "Drivers" directory, then click [OK].



VP-9258(T) USER MANUAL

13

7. Click [Next].



8. Click [Next].



9. The system will request you to restart your computer. Click [FINISH].



- 10. After the system restart, the installation is complete. You can now connect your USB 2.0 External Drive to the computer.
- 11. After connecting the USB 2.0 External Drive, double click on [My Computer]. A new drive [Usbdisk] icon should have been added. This identifies the USB 2.0 External Drive you just installed.



12. A green Unplug or Eject hardware icon will also be added in the system tray.



<u>Note:</u>

If the new drive does not appear in [My Computer], it means this USB 2.0 External Drive is a brand new hard disk drive which does not contain a partition. Please refer to Chapter 6 "Partitioning an External USB 2.0 Hard Disk" to prepare your USB 2.0 External Disk.

VP-9258(T) USER MANUAL

15

5-2 Windows Me/2000/XP

Step1:

If you are plugging the USB External Drive into your computer for the first time, the system will detect a USB 2.0 Storage Device and install the [USB Mass Storage Device] driver from system files automatically.

<u>Step2:</u>

After the system installs the USB mass storage device driver, double click on [MyComputer]. A new drive [Usbdisk] icon should have been added. It is the USB 2.0 External Drive which just installed.



<u>Notes:</u>

This USB 2.0 External Drive is supported by the Mass Storage Device Driver in Windows Me/2000/XP operating systems. You do not need to install any drivers.

¹⁷ If the new drive does not appear in [My Computer], it means this USB 2.0 External Drive is a brand new hard disk drive which does not contain a partition. Please refer to Chapter 7 "Partitioning an External USB 2.0 Hard Disk" to prepare your USB 2.0 External Disk.

5-3 Mac OS 9.X or Above

- 1. This USB 2.0 External Drive is supported by Mass Storage Support Mac OS 9.X or above. You do not need to install any drivers.
- 2. When you plug this USB 2.0 Hard Disk into the USB port of your Mac computer, the mass storage volume should automatically appear on the desktop in a few seconds.

6. Using The USB 2.0 External Enclosure

After the first time installation, you can connect or disconnect the USB 2.0 External Enclosure VP-9258 without powering off the computer.

Please follow the steps below when using the VP-9258.

6-1 Connect the USB 2.0 External Enclosure VP-9258(T) to Computer

<u>Step1:</u>

Plug the first USB port connector of the USB cable into the USB port of your USB 2.0 External Enclosure VP-9258(T).

<u>Step2:</u>

Plug the second USB port connector of the USB cable into an USB port on your computer.

<u>Step3:</u>

Plug the power adapter power cord to the power inlet of your USB2.0 External Enclosure VP-9258(T). Turn the power of the VP-9258(T) ON.

<u>Step4:</u>

On the Monitor screen, click on [Start] and select [Control Panel] in [Settings]. Double click [System] and open [Hard disk controllers].

<u>Step5:</u>

You should see the external Hard Disk you just added. Highlight the external Hard Disk and choose [Properties], select [Settings]. Set the external Hard Disk to [Removable].

<u>Step6:</u>

After restarting the system, a removable HDD is added to [My Computer]. Choose the removable HDD and right click button of mouse. Select [Format] to format your external Hard Disk Drive.

You can only set the external Hard Disk Drive to one partition using this method.

<u>Step7:</u>

USB 2.0 External Enclosure VP-9258(T) is ready for use immediately.

6-2 Disconnect the USB 2.0 External Enclosure VP-9258(T) from Computer

6-2.1 Windows 98:

Step1:

Double click the green Unplug or Eject hardware icon in system tray and click the drive that you want to remove and click on [STOP].



<u>Step2:</u>

When the system prompts 'Confirm device to be stopped', click [OK]. When the green arrow icon disappears, you may safely unplug the USB cable from the USB port of computer.

6-2.2 Windows Me/2000/XP

<u>Step1:</u>

Double-click on the [Unplug or Eject Hardware] icon in the system tray. A dialog box appears.



<u>Step2:</u>

Highlight the [USB Mass Storage Device] in the dialog box, click [STOP]. Choose the USB 2.0 External Enclosure VP-9258(T) that you want to disconnect, then click [STOP] again on the next screen.

<u>Step3:</u>

Wait a few seconds until the system prompts "You may safely remove this device". Then, disconnect the USB 2.0 External Drive from the computer.

6-2.3 MAC OS

When disconnecting your USB 2.0 External Drive from a Mac computer, first close all windows and quit all running applications that are stored on the USB 2.0 External Drive. Next, drag the USB 2.0 External Drive's icon into the "Trash" to dismount it from the Desktop. You can now safely disconnect the USB 2.0 External Drive from the USB port.

CAUTION!!

Do not unplug the USB 2.0 External Drive from the USB port of your computer or HUB while copying files to/from the device or while files or applications stored on the USB 2.0 External Drive are in use.

DOING SO MAY RESULT IN LOSS OF DATA.

VP-9258(T) USER MANUAL

19

7. Partitioning the External USB 2.0 Hard Disk

7-1 Partition Under Windows 98/ME

Boot-up the computer into Windows 98/ME. Next, connect your USB 2.0 Hard Disk Drive to the USB port.

<u>Step1:</u>

Go into MS-DOS mode by clicking on [Start], then choose the [MS-DOS Prompt] in [Programs].

<u>Step2:</u>

At the DOS prompt, type [FDISK] and press Enter.

<u>Step3:</u>

If FDISK quits without any message, go back to the Windows 98 screen, disconnect the USB 2.0 Hard Disk and re-boot the computer. Reconnect the USB 2.0 HDD and go back to Step 1 to proceed.

<u>Step4:</u>

For the first screen of FDISK, answer the question:

Do you want to enable large disk support?

- [Y] if you want to build a partition larger than 2GB.
- [N] if you want to build a partition small than 2GB.

<u>Step5:</u>

The next screen is [FDISK OPTIONS]. Type [5] to select the disk.



Important:

You must type [5] in this screen to change the current fixed disk drive to build a partition. The default fixed drive set by FDISK is your internal hard disk drive.

<u>WARNING!!</u> If you don't change the fixed disk drive to the USB 2.0 Hard Disk, the data of your internal hard disk will be destroyed!

<u>Step6:</u>

In the [Change Current Fixed Disk Drive], type the disk drive number that is assigned to the USB 2.0 Hard Disk.

<u>Step7:</u>

Go back to [FDISK OPTIONS] screen, Now you can create or delete a partition of the USB 2.0 Hard Disk.

<u>Step8:</u>

After you finish FDISK, go back to the Windows screen, disconnect and then reconnect the USB 2.0 Hard Disk again to activate these changes. Double click on [My Computer]. The USB 2.0 Hard Disk Drive icon that you have now partitioned should be seen.

7-2 Partition under Windows 2000/XP

<u>Step1:</u>

To partition the USB 2.0 Hard Disk Drive under Windows 2000, connect the USB 2.0 Hard Disk to the USB port on your computer. Next, click [Start], select [Control Panel], [Settings], open [Administrative Tools] and double click [Computer Management].

Price Action View Window Help	🛱 Computer Nanogement	_				_					×۱۰
★ → DE D 2 C 45 First Sector Management (Local) → DE D 2 C 45 First Sector Management (Local) Painter Sector Management (Local) → D 2 C 5 Sector Management (Local) Painter Sector Management (Local) → D 2 C 5 Sector Management (Local) Painter Sector Management (Local) → D 2 C 5 Sector Management (Local) Painter Sector Management (Local) → D 2 Sector Management (Local) Painter Sector FAT32 → D 2 Sector Management (Local) Painter Sector FAT32 → D 2 Sector Management (Local) Painter Sector FAT32 → D 2 Sector Management (Local) Painter Sector FAT32 → D 2 Sector Management (Local) Painter Sector FAT32 → D 2 Sector Management (Local) Painter Sector FAT32 → D 2 Sector Management (Local) Painter Sector FAT32 → D 2 Sector Management (Local) Painter Sector FAT32 → D 2 Sector Management (Local) Painter Sector FAT32 → D 2 Sector Management (Local) Painter Sector FAT32 → D 2 Sector Management (Local) Painter Sector FAT32 → D 2 Sector Management (Local) Painter Sector FAT32 → D 2 Sector FAT32 Painter Sector FAT32 → D 2 Sector FAT32 Painter Sector FAT32 → D 2 Sector FAT32 Painter Sector FAT32	E File Action View Window H	ekp								کلہ ا	2×
System Total Volume Layout, Type, File System, Status Capadry, Fires Space, Sk, Firet, Fout Totals B 10 System Totals D (1:) Patition Read: FAT32 Healthy Layout, Size (Sk, Firet, Fout Totals B 11 System Totals D (1:) Patition Read: FAT32 Healthy Layout, Size (Sk, Firet, Fout Totals B 12 System Totals D (1:) Patition Read: FAT32 Healthy Layout, Size (Sk, Firet, Fout Totals B 12 System D (1:) Patition Read: FAT32 Healthy (System) Li4.45 GB Li4.65 GB 97.% B 12 Stronge D (1:) Patition Read: FAT32 Healthy (System) Li4.45 GB 111.45 GB 114.45 GB B 13 Stronge D (1:) D (1:) Patition Read: FAT32 Healthy (System) Li4.45 GB 97.% B 13 Stronge D (1:) D (1:) Stronge D (1:) 114.45 GB 114.45 GB 114.45 GB B 14 (S) D (1:) D (1:) D (1:) 114.45 GB 114.45 GB 114.45 GB B 14 (S) D (1:) D (1:) D (1:) D (1:) 114.45 GB 114.45 GB B 14 (S) D (1:) D (1:) D (1:) D (1:) 114.45 GB 114.45 GB B 14 (S) D (1:) D (1:) D (1:) D (1:)											
Image: Second Status Image: Second Status	Di Computer Nanogement (Local) 국 語 System Took 전 월 20met Yaneer 국 월 20met Yaneer 문 월 24met Folden 문 권 Device Manager 국 권 25mage	Yolune Ə(c:) Əvdeower.(Q)	Layout Pertition Partition	Type Sealc Basic	File System PAT32 FAT32	Status Healthy Healthy (System)	Capacity 13:63 68 114:46 68	Free Space 13.56 GB 111.65 GB	93 % 97 %	Fault To Na Ha	oler an
SPOrt& I Box [6] 316.44 GB [6] 316.45 GB [6] 316.45 GB SPOrt& I Box [6] 316.45 GB [6] 316.45 GB [6] 316.45 GB State CB [6] 316.45 GB [6] 316.45 GB [6] 316.45 GB State CB [6] 316.45 GB [6] 316.45 GB [6] 316.45 GB [6] 316.45 GB State CB [6] 316.45 GB [6] 316.45 GB [6] 316.45 GB [6] 316.45 GB State CB [6] 316.45 GB [6] 316.45 GB [6] 316.45 GB [6] 316.45 GB State CB [6] 316.45 GB [6] 316.45 GB [6] 316.45 GB [6] 316.45 GB State CB [6] 316.45 GB [6] 316.45 GB [6] 316.45 GB [6] 316.45 GB State CB [6] 316.45 GB [6] 316.45 GB [6] 316.45 GB [6] 316.45 GB State CB [6] 316.45 GB [6] 316.45 GB [6] 316.45 GB [6] 316.45 GB State CB [6] 316.45 GB [6] 316.45 GB [6] 316.45 GB [6] 316.45 GB State CB [6] 316.45 GB [6] 316.45 GB [6] 316.45 GB [6] 316.45 GB State CB [6] 316.45 GB [6] 316.45 GB	Harrowski Starsje Goldenmanner Goldenmagenert Goldenmagenert	CPDHske Sast: 114,19 GB Drahm	VIPOTE 114,19 Healthy	TR (C) GBFAT) १८						
CPUHK 2 East 18.64 GB Drive Drop Rotete Drop Option Drop Rotete Drop Option Drop Rotete Drop Option Drop Pring parking Drop Rotete Drop Option Drop Pring parking Drop Rotete Drop Option Drop Pring Parking Drop Rotete Drop Option Drop		SPonde I Basic 16.64 GB Online	1 (E.) 38.64 G Healthy	BPATS	2						-
Stor-Rome brock) E Understad E Pring patien (1) Found here Handware (1)		EPDHsk 2 Seatc 18.64 GB Draine	18.64 G Unilse	8 4 od //							
Your new hardware is installed and ready to use.	<u>عالماً المحالماً المح</u>	GDD-RDHI® DVO(D1) ∰ Unalscated ■	Pinay p	ulišan	(i, 10) Found New Ha Ir newhardware is	dware Installed and] Iready to use			×

<u>Step2:</u>

Click on [Disk Management]. All connected disk drives will be listed. Find the USB 2.0 Hard Disk that you added and to the right of the disk, view the status of the partitions of this disk drive. You can create a new or delete an existing partition by right-clicking on this area.

<u>Step3:</u>

Right-click on the partition status area of the USB 2.0 Hard Disk Drive. Click on [Create Partition....] and the "Create partition wizard" will appear.



<u>Step4:</u>

Follow the instructions of the wizard to partition and format your USB 2.0 Hard Disk Drive.

After you have completed the partitioning and formatting of the USB 2.0 Hard Disk Drive, you can write data to it.

Free Manuals Download Website <u>http://myh66.com</u> <u>http://usermanuals.us</u> <u>http://www.somanuals.com</u> <u>http://www.4manuals.cc</u> <u>http://www.4manuals.cc</u> <u>http://www.4manuals.cc</u> <u>http://www.4manuals.com</u> <u>http://www.404manual.com</u> <u>http://www.luxmanual.com</u> <u>http://aubethermostatmanual.com</u> Golf course search by state

http://golfingnear.com Email search by domain

http://emailbydomain.com Auto manuals search

http://auto.somanuals.com TV manuals search

http://tv.somanuals.com