

A series of blurred, overlapping rectangular shapes in various colors (red, orange, yellow, green, blue) arranged in a stepped pattern, resembling the elements of a camera lens.

13mm Ultra Wide Aspherical Lens  
INSTRUCTION MANUAL

VIV-13MM-C

**Vivitar**  
SERIES 1

and Download.

## Limited One Year Warranty

Vivitar warrants this quality product to be free of defects in material and workmanship for a period of one year from the date of purchase. During the period, Vivitar will repair or replace the product at no charge for parts or labor.

### TIME PERIOD OF THIS WARRANTY

The time period of this warranty starts from the date of the original purchase and expires on the first anniversary date of purchase.

### WHAT IS NOT COVERED BY THIS WARRANTY

No express or implied warranty is made for any defects in this product which result from accident, abuse, misuse, failure to operate the product in accordance with relevant instructions, neglect, immersion in or exposure to chemicals or liquids, extremes of climate, fungus, excessive wear and tear/cosmetic damage and defects resulting from other extraneous causes such as unauthorised disassembly, repair or modification.

This warranty shall not extend to any incidental or consequential damages arising from the purchase, use or inability to use this product even if Vivitar has been advised of such damages. The laws of some countries and some States thereof do not allow the limitation of incidental or consequential damages, so the above limitation or exclusion may apply to you.

## WHAT TO DO WHEN SERVICE IS NEEDED

STEP 1. Package the product and relevant accessories carefully, using ample padding materials and a sturdy mailing container to prevent damage in transit.

STEP 2. Include in package:

- a) Evidence of date and place of original purchase (for example, a copy of your sales receipt).
- b) Detailed description of your problem.
- c) When possible, a sample evidencing the problem.

STEP 3. Return item (insured) to: (in the U.S.):

Vivitar  
Attn: Technical Support  
195 Carter Drive  
Edison NJ 08817

(in the U.K.)

Sakar UK  
2D Siskin Parkway East  
CV3 4PE, UK

When service is complete, the product will be returned to you shipping prepaid. In the event the product is deemed to be not faulty or the defect is a result in wear and tear, Vivitar may levy a handling charge for the return of the product. This warranty gives you specific legal rights. You may also have other rights which vary from country and State to State thereof. For more information visit our website [www.vivitar.com](http://www.vivitar.com)

### TECHNICAL SUPPORT

For technical support issues please visit our website at [www.vivitar.com](http://www.vivitar.com). You can find manuals, software and FAQ's at the website. Can't find what you are looking for? E-mail us at [support@vivitar.com](mailto:support@vivitar.com) and one of our technical support team members will answer your questions. For phone support in the US please call 1-800-592-9541, in the UK call 0800 917 4831. If you would like to call from anywhere else, please visit [www.vivitar.com](http://www.vivitar.com) for your local toll free number.

## Introduction

Thank you for purchasing the VIV-13MM-C Ultra Wide Aspherical Lens. This lens will provide you with many unique and exciting photo taking opportunities which we hope you will enjoy.


### **Features of Your Lens:**

- Super Spectra coatings
- 113.8° diagonal angle
- Uses hybrid aspherical lens
- Reduces flare and ghost
- Minimum focusing distance of 12 inches
- Fixed petal-type hood
- Can be used with Canon film and digital SLR cameras

Your 13mm Ultra Wide Aspherical Lens is designed with its own mount. Users can take photographs easily without installing an additional adaptor by mounting the lens directly onto the camera.

Please read these directions prior to using your lens.

## A Quick Look at Your Device



1. Depth of Field Scale
2. Focus Scaling Ring
3. Focusing Ring

4. Hood Locking Area
5. Mount
6. Aperture Adjustment Ring

Your VIV-13MM-C lens is uniquely designed for Canon cameras.

### **Attaching Your Lens to Your Camera**

Hold the hood locking area of the lens gently, and align the lens mounting reference point or line with the lens ring mount of the camera. Next, push the lens into the camera and turn the lens softly until it makes a clicking sound, and the depth of field scale is positioned on the upper part of the camera.

### **Detaching Your Lens from Your Camera**

Hold the hood locking area of the lens gently, and press the lens release button on the camera. Turn the lens in the opposite direction as when attaching, and carefully pull it out.

## Focus Adjustment


You can adjust the focus of the subject you are photographing by turning the focus adjustment ring on your lens, as it is an MF (manual focus) adjustment lens. To do so, please follow the steps below:

1. When focusing on a subject from a long distance, turn the focus ring to the right ( $\infty$  to 1) and focus on the clearest subject by using the indication signal on the camera or by checking visually.
2. When focusing on a subject from a short distance, turn the focus ring to the left (1 to  $\infty$ ) and focus on the clearest subject by using the indication signal on the camera or by checking visually.


## Brightness Control

You can set the amount of brightness you want by turning the aperture adjustment ring when using your lens.


[Aperture adjustment ring markings]



When you turn the aperture adjustment ring between 22, 16, 11, 8, 5.6, 4, 2.8, 2 and 1.4 you are making 1 stop each turn. Brightness can be set more precisely by making half stops as well (see below).



*5.6 and 8 are 1 stop apart (1EV).*



*Set a 0.5 stop (0.5EV) between 5.6 and 8*



## Camera Settings

Some cameras require special settings when using this lens. Please read the information below and set your camera accordingly.

The aperture of the 13mm Ultra Wide Aspherical Lens is not specifically geared to your camera.

If the F stop is set above 8, you may not be able to set the correct focus due to difficulty in viewing the subject through the camera's viewfinder. Turn the aperture adjustment ring and fully open it when attaching this lens to the camera, and then turn the aperture adjustment ring again to set the depth of focus and brightness you want prior to shooting.

## Camera Settings (continued)

1. Set the camera mode dial to 'M'
2. Adjust the shutter speed to achieve the appropriate brightness.



The shutter speed of some Canon cameras changes automatically if the shooting mode dial is set to Av and the brightness is set by turning the aperture adjustment ring. Therefore the shutter speed is not required to be set additionally as when using the M mode.

(The camera settings discussed apply to the Canon 40D camera. Settings for the camera or the menu may be changed depending on the model or due to a menu upgrade. Refer to your camera manual or contact the camera manufacturer for more detailed information.)

## Specifications

Filter size: None

F/stop range: F2.8 ~ 22

Maximum diameter: 87.0mm

Angle of View: 115.7 ° (APS-C: 89.9 °)

Group/Elements: 10/14

Length: 3.78" (96.1mm)

Weight: 19.47 oz (552g)

## Troubleshooting

Phenomena	Causes	Measures
A lens can't be attached to the camera.	The lens ring mount and the camera mount are not aligned.	Align the lens ring mount and the camera mount.
A lens can't be detached from the camera.	Incorrect rotation direction for detaching. If the user turns the lens while holding the camera, it may cause damage to the lens.	Press the lens release button on the camera, and lightly turn the lens to the lens attaching and detaching reference points, in the direction as marked on the camera, and then pull the lens forward.
Dark image	Incorrect focusing. Insufficient shutter speed or camera shake.	Turn the focus ring while checking the indication or checking an object visually, set the focus until it reaches a clear point, and then press the shutter. Steady the camera and take a photograph at a shutter speed of 1/125 secs.
Autofocus failure	Autofocus failed with a manual control focus lens.	Set focus by turning the focus ring.
Dark or too bright pictures	Inappropriate exposure	Adjust the aperture size.

## Troubleshooting (continued)

Phenomena	Causes	Measures
Dark or too bright pictures	Inappropriate exposure	Adjust the aperture size.
The periphery gets dark when using a manual camera or a digital camera for 1:1 image sensor.	As this lens is optimized for APS-C size images, so the periphery gets dark when using a digital camera for 1:1 size images.	Use a digital camera for APS-C size images.
The camera flash is not geared to the camera.	The manual control lens may not be compatible, depending on the camera.	See the camera manual.
The camera finder indication or the display is not displayed.	This lens doesn't have an electric contact signal, so there is no communication with the camera through electric signals.	No problem with shooting.
Zooming failure	This lens is a single lens.	
The lens hood can't be detached.	This lens hood and the lens body are a fixed type, so the lens hood can't be detached.	
This lens can't be mounted on other cameras.	This lens is designed for its own mount.	Purchase the required lens mount.

## Caution

The following precautions are divided into two types according to the level of danger.

### ⚠ WARNING

If this instruction is not followed, it may cause death or severe injury to the user.

### ⚠ CAUTION

If this instruction is not followed, it may cause death or severe injury to the user.

The following pictograms are used in the below precautions:



Requires caution. Inside the pictogram it shows contents of precautions. (It shows outbreak of fire in the pictogram on the left.)



Shows prohibition. Inside the pictogram it shows contents of prohibition. (It shows prohibition of dismantling in the pictogram on the left.)



Shows instruction. Inside the pictogram it shows contents of instructions. (It shows instruction of precaution in the pictogram on the left.)

### ⚠ WARNING

- ⊘ Don't look at the sun through the lens. It may cause blindness.



### ⚠ CAUTION

- ⚠ Attach the lens to the camera correctly and ensure the lens is held in place properly; otherwise the lens may not be removable, or may become loose and cause an accident.



- ⊘ Don't put excessive pressure on the lens attached to the camera; otherwise it may cause damage to the lens or to the camera mount. Be sure to hold the lens when operating or moving.



- ⚠ Ensure that the camera operates properly by checking the lens beforehand or by test shooting for important events such as a wedding ceremony and an overseas trip.



- ⊘ Don't leave the lens within reach of babies, as it may cause injury to the baby if the lens falls or is dropped.



- ⊘ Don't attempt to modify or alter the lens. It may lead to failure of the camera. Modified or altered lenses may not be repaired.



- ⊘ Don't leave the lens in direct sunlight. It may cause a fire, depending on lenses that concentrate light on a close object.



- ⊘ Don't look at the sun directly through a camera with a lens attached. It may cause damage to one's eyesight.



## Caution

### WARNING!

Don't wet this product or expose it to a moist environment. It may cause a fire or electric shock.

### CAUTION!

- Don't use this product or store it close to devices that generate heat i.e., heaters, thermal regulators, stoves, stereo amplifiers.
- Don't leave the lens in conditions where drastic temperature changes can occur.
- Don't touch the surface of the lens by hand, and avoid making contact with sharp objects.
- Avoid dropping the lens.
- Don't soak the lens in water, and avoid water splashing onto the lens.
- If there are foreign bodies on the lens, use a lens cleaning kit only.
- If the lens hood is cut by the user, it may cause damage to the surface of the lens, as the surface of the lens may make contact with the floor.

**Vivitar**<sup>®</sup>  
SERIES 1



## Free Manuals Download Website

<http://myh66.com>

<http://usermanuals.us>

<http://www.somanuals.com>

<http://www.4manuals.cc>

<http://www.manual-lib.com>

<http://www.404manual.com>

<http://www.luxmanual.com>

<http://aubethermostatmanual.com>

Golf course search by state

<http://golfingnear.com>

Email search by domain

<http://emailbydomain.com>

Auto manuals search

<http://auto.somanuals.com>

TV manuals search

<http://tv.somanuals.com>