Model 1260 Slimline Memory phone User's guide



Equipment Approval Information

Switched Telephone Network and is in compliance with parts 15 and 68, FCC Rules and Regulations and the Technical Requirements for Telephone Terminal Equipment published by ACTA.

1. Notification to the Local Telephone Company

On the bottom of this equipment is a label indicating, among other information, the US number and Ringer Equivalence Number (REN) for the equipment. You must, upon request, provide this information to your telephone company

The REN is useful in determining the number of devices you may connect to your telephone line and still have all of these devices ring when your telephone number is called. In most (but not all) areas, the sum of the RENs of all devices connected to one line should not exceed 5. To be certain of the number of devices you may connect to your line as determined by the REN, you should contact your local

A plug and jack used to connect this equipment to the premises wiring and telephone network must comply with the applicable FCC Part 68 rules and requirements adopted by the ACTA. A compliant telephone cord and modular plug is provided with this product. It is designed to be connected to a compatible modular jack that is also compliant. See installation instructions for details.

This equipment may not be used on coin service provided by the

Party lines are subject to state tariffs, and therefore, you may not be able to use your own telephone equipment if you are on a party line. Check with your local telephone company. Notice must be given to the telephone company upon permanent

disconnection of your telephone from your line. If your home has specially wired alarm equipment connected to the

telephone line, ensure the installation of this product does not disable your alarm equipment. If you have guestions about what will disable alarm equipment, consult your telephone company or a qualified

US Number is located on the cabinet bottom REN Number is located on the cabinet bottom.

2. Rights of the Telephone Company

Should your equipment cause trouble on your line which may harm the telephone network, the telephone company shall, where practicable, notify you that temporary discontinuance of service may be required. Where prior notice is not practicable and the circumstances warrant such action, the telephone company may temporarily discontinue service immediately. In case of such temporary discontinuance, the telephone company must: (1) promptly notify you of such temporary discontinuance; (2) afford you the opportunity to correct the situation; and (3) inform you of your right to bring a complaint to the Commission pursuant to procedures set forth in Subpart E of Part 68, FCC Rules and Regulations.

The telephone company may make changes in its communications facilities, equipment, operations or procedures where such action is required in the operation of its business and not inconsistent with FCC Rules and Regulations. If these changes are expected to affect the use or performance of your telephone equipment, the telephone company must give you adequate notice, in writing, to allow you to maintain uninterrupted service.

Interference information

interference in a residential installation.

This device complies with Part 15 of the FCC Rules. Operation is subject o the following two conditions: (1) This device may not cause harmfu interference; and (2) This device must accept any interference received. including interference that may cause undesired operation. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful

Privacy of Communications may not be ensured when using this product. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or nore of the following measures: • Reorient or relocate the receiving antenna (that is, the antenna for radio or television that is "receiving" the interference).

• Reorient or relocate and increase the separation between the telecommunications equipment and receiving antenna

· Connect the telecommunications equipment into an outlet on a circuit different from that to which the receiving antenna is connected. If these measures do not eliminate the interference, please consult your dealer or an experienced radio/television technician for additional suggestions. Also, the Federal Communications Commission has prepared a helpful booklet, "How To Identify and Resolve Radio/TV Interference Problems." This booklet is available from the U.S. Government Printing Office, Washington, D.C. 20402. Please specify stock number 004-000-00345-4 when ordering copies.

Notice: The changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the

Uniden

Model 1260 Printed in China

Visit our Website at: www.uniden.com

Uniden America Corporation

Ft. Worth, TX

should re-set your memory locations. IMPORTANT: If you're not going to use the telephone for more than 30 days, remove the batteries because

Hearing Aid Compatibility (HAC)

This telephone system meets FCC standards for Hearing Aid

Licensing

PREVENT FIRE OR ELECTRICAL SHOCK HAZARD, DO NOT PRODUCT TO RAIN

Introduction

WARNING:TO

EXPOSETHIS

CAUTION: When using telephone equipment, there are basic safety instructions that should always be followed. Refer to the IMPORTANT SAFETY INSTRUCTIONS provided with this product and save them for future reference.

Before You Begin

Parts Checklist

Make sure your package includes the following items:



Wall plate

Telephone Jack Requirements

To use this phone, you need an RJ11C type modular telephone jack, which might look like Modular the one pictured here, installed in your home. If you don't have a modular jack, call your local phone company to find out how to get

Important Installation Information

- Never install telephone wiring during a lightning storm. • Never install telephone jacks in wet locations unless the jack is
- specifically designed for wet locations. Never touch non-insulated telephone wires or terminals, unless the telephone line has been disconnected at the
- · Use caution when installing or modifying telephone lines.

Handset Layout

network interface.






Installing and Replacing the Batteries

IMPORTANT: You will have approximately 60 seconds to replace the batteries before the memories stored in the handset are lost. Please read the instructions before replacing the batteries and have the batteries ready to be inserted beforehand. As a precaution, you may want to write down any stored information you do not want erased.

Your Caller ID phone uses 3 AA-size alkaline batteries for receiving and storing Caller ID records and for the numbers you use for memory dialing.

- 1. If the telephone line cord is connected, disconnect it from the
- 2. Open the battery compartment door with your finger or



- . Insert 3 AA-size alkaline batteries (not included) as shown on the diagram inside the compartment.
- 4. Replace the battery compartment door. 5. Re-attach the line cord to the wall and check your memory locations. If installation takes longer than 60 seconds, you

they can leak and damage the unit.

Setting Up the Caller ID Menu

IMPORTANT: Do not plug the telephone into the wall jack

while setting up the Caller ID menu because an incoming call may invalidate the information not yet saved.

1. Place the handset in the cradle on the base.

3. Press either ▲ (+) or ▼ (-) button to scroll among the 7 menu

2. Press the menu button. SET ▲ OR ▼ appears in the display.

•SET ▲ OR ▼ • Local Area Code (default - - -)

- Regional AC's-1 (default -----)
- CID LANGUAGE (default English)
- SELECT CONTRAST (default 3)
- T/P DIAL MODE (default tone)

screens, which are:

NOTE: You may press dial anytime to exit the Caller ID Set Up menu. If no buttons are pressed within 10 seconds, the phone automatically exits the Caller ID Set Up menu and returns to the NO CALLS summary screen.

Local Area Code

The telephone uses the programmed area code to determine the number format to display when a valid Caller ID signal is received. It is also used for the Dialback feature.

- 1. Press the menu button. SET ▲ OR ▼ appears in the display. 2. Press the (+) button until LOCAL AREA CODE:___ appears in
- the display. 3. To enter or change the area code, press the **menu** button. The
- display shows the area code stored in memory. The left-most digit, or a minus sign (-) flashes, indicating the unit is ready to accept the area code entry.
- 4. Press the (+) button and select a number from 0-9 in ascending order. Or press the ▼ (-) button to select numbers from 9-0 in descending order.
- 5. Press the menu button to advance to the next digit. 6. After the 3rd and last digits entered, press the menu button to store the area code and go to the next setting. NOTE: If you make a mistake, you can simply repeat

the previous steps until your area code is set. Regional Area Codes for 10-Digit Dialing

Like the Local Area Code, the telephone uses the programmed area codes to determine the number format to display when a valid Caller ID signal is received. Calls that match any of the programmed regional area codes are displayed as 10 digits. This is helpful in areas that have multiple or overlapping area codes and require 10-digit dialing

- Press the menu button. SET ▲ OR ▼ appears in the display. 2. Press the A (+) button until REGIONAL AC'S-1:
- shows in the display.
- 3. To enter or change the area code, press the **menu** button. The display shows the area code stored in memory. The left-most digit, or minus sign (-), flashes, indicating the unit is ready to accept the area code entry.
- 4. Press the ▼ (-) button, and select a number from 9-0 for the first digit of the are code.
- 5. When the desired digit is flashing, press the (+) button to advance to the next digit.
- 6. Press the **menu** button again to enter the next three-digit regional area code and repeat steps 4 and 5 until all the REGIONAL AC'S-1 (RAC#1) and REGIONAL AC'S-2 (RAC#1) are entered. A total of 6 sets of Regional Area Codes may be
- 7. Press the **menu** button to store the setting and return to the REGIONAL AREA CODE display.
- 8. Press dial to exit.

CID Language

This setting allows you to display Caller ID display prompt messages in English, French or Spanish

- 1. Press the menu button. SET ▲ OR ▼ appears in the display. 2. Press the (+) button until CID LANGUAGE appears in the
- 3. Press the **menu** button to show the current language setting.
- The default is English.
- 5. Press the menu button to store the language and return to the

CID LANGUAGE display. Select Contrast

This adjustment allows you to select the contrast of the display. 1. Press the menu button until SET ▲ OR ▼ appears.

- 2. Press the (+) button until SELECT CONTRAST appears in the
- 3. Press the **menu** button to show the current contrast setting. There are 5 levels of contrast, with the default set to 3. 4. To decrease the contrast, press ▼ (-). To increase the contrast,
- press \blacktriangle (+). 5. Press the **menu** button to store the contrast setting and return to the SELECT CONTRAST display.

T/P Dial Mode

This adjustment allows you to select Tone (touch-tone) or Pulse (rotary) dialing.

- 1. Press the **menu** button until **SET ▲ OR ▼** appears. 2. Press the (+) button until *T/P DIAL MODE* appears in the
- display. 3. Press the **menu** button to show the current dial mode. The default is set to tone
- 4. To change the dialing mode, press the \blacktriangle (+) or \blacktriangledown (-) button. The display will alternate between the two dialing modes. 5. Press the **menu** button to store the dialing mode and return to the

T/P DIAL MODE display. Exit Setup

To immediately exit the setup mode, select the *EXIT SETUP* menu and press the menu button.

REMINDER: The time and date is programmed automatically when the first Caller ID record is successfully received after the unit is setup.

Telephone Basics

Connecting the Telephone Line

1. Plug the long straight line cord into a modular wall telephone


- Place the handset in the cradle. NOTE: The unit is properly installed if you pick up the

handset and hear the dial tone. Otherwise, recheck all

the installation steps. **Wall Mount Installation**

Your telephone may also be mounted on a wall plate (not in-

NOTE: To prevent the handset from falling out of the cradle while the phone is hanging on the wall, you must reverse the handset hook (located on the base).



- 1. Push the handset hook up and out of the slot on the base with your thumb, rotate the hook 180°, and replace it back in the
- 2. Feed the line cord through the groove and wrap the cord around the track on the bottom of the base
- 3. Feed the line cord through the groove on the opposite side of the track, and plug the end into the modular telephone jack. 4. Slip the mounting holes (on the bottom of the base) over the

Adjusting the Ringer Volume You may control the ringer volume level with the switch located on the side of the base.

wall plate posts and firmly slide the unit down into place.

- 2 = ringer tone will be loud
- 1 = ringer tone will be low

Adjusting the Volume

You may control the listening level with the VOLUME switch, which has three levels. It remains at the last level set until you

Redialing a Number

If you want to call the last number you dialed again (up to 32 digits), use the redial feature.

1. Pick up the handset.

2. Press the redial button. 3. The last number called is automatically redialed.


Using One Touch Redial

If the last call you dialed was busy, you can redial it immediately by just pressing the redial button and without hanging up the

Caller ID (CID)

IMPORTANT: In order to use this unit's Caller ID features, you must subscribe to either the standard Name/Number Caller ID Service or Call Waiting Caller ID Service. To know who is calling while you are on the phone, you must subscribe to Call Waiting Caller ID

This unit receives and displays information transmitted by your local phone company. This information can include the phone number, date, and time; or the name, phone number, date, and



Call Waiting Caller ID

Provided you subscribe to Call Waiting Caller ID service form your phone company; if you receive an incoming call and you are using Uniden's multi handset system, a beep indicates the presence of a Call Waiting call on the line. The Call Waiting Caller ID information will be displayed and stored in the history of all

· When you hear the call waiting beep in the handset receiver, press the **flash** button to put the current call on hold and answer the incoming call. Press **flash** again to return to the original call.

Receiving CID Records

When you receive a call, the Caller ID information is transmitted between the first and second ring. The Caller ID information appears on the display while the phone rings, giving you a chance to monitor the information and decide wheather or not to answer the call.

Storing CID Records (In CID Memory)

If you are not at home or cannot answer, your telephone's Caller ID memory stores the data for the 50 most recent calls you received so you can see who called while you were unavailable When the 51st call is received, the oldest Caller ID record (1st call) is automatically deleted.

You may review the stored information at any time. Calls received since your last review show as NEW in the display. Calls that have not been previously reviewed but were received from the same number more than once show as REPT in the display.

Reviewing CID Records

As calls are received and stored, the display is updated to let you

- know how many calls have been received. To scroll CID records: 1. Press either the ▲ (+) or ▼ (-) down button to view the
- newest call record.
- 2. Press the ▼ (-) button to scroll through the call records from the most recent to the oldest.
- 3. Press the \blacktriangle (+) button to scroll through the call records from the oldest to the newest
- 4. When all of the messages have been viewed, START/END

appears in the display.

- **Deleting CID Records** • To delete the record showing in the display, press the delete
- button once. • To delete all records while reviewing, press and hold the delete button until ERASE ALL? shows in the display, then

press the delete button again to confirm. **Dialing Back**

When reviewing Caller ID records, you may dialback the phone numbers shown on the display by pressing the dial button.

NOTE: Depending on (a) how the incoming caller's phone number is formatted when it is received, and (b) whether or not you previously pre-programmed your local area code into the set up menu, you may need to adjust the format of the incoming caller's stored phone number before making the call, press the dial button to adjust the number, and try again.

If you programmed your local area code in the setup menu

- 1. Use the ▲ (+) and ▼ (-) buttons to scroll to the number you want to dial.
- If you see a number with 7 digits (i.e. 555-1234), then the call was received from within your area code. However, this does
- not guarantee the call is a local call. • If you see a number with 11 digits (i.e. 1-234-555-1234), then
- the call received was not from your area code. 2. Press the dial button and the display shows PICKUP or ADJUST. A 10 second timer also starts in the upper right side of the display, letting you know the time remaining until the unit returns to the Summary Screen. If you adjust the number to be
- 3. To adjust the phone number, press the dial button. For instance, a 7-digit local number sometimes cannot be dialed because it requires a 10-digit or 11-digit format. Press the dial button repeatedly to scroll through the 7, 10, and 11-digit

dialed, the timer automatically resets itself

- numbers. 7-digits: 7-digit telephone number (i.e. 555-5555)10-digits: 3-digit area code + 7-digit telephone number
- (i.e. 425-555-5555) 11-digits: long distance code 1 + 3-digit area code + 7-digit telephone number (i.e. 1-425-555-555)
- timer reaches 0. NOW DIALING shows in the display and the number is dialed. If you did not program your local area code in the setup menu
- 1. Use the ▲ (+) and ▼ (-) buttons to display the number you want to dial. You will only see 10-digit numbers (i.e. 234-555-1234).

4. To dial the displayed number, pick up the handset before the

2. See steps 2 through 4 in the above section to complete the dialback sequence. NOTE: If PICKUP PHONE shows on the display, no other changes to the number can be made. The information sent from the telephone company is known to be a valid number to dial back (available only in limited

areas). Once you pickup the phone, the number is

automatically dialed.

Memory Before you store a telephone number in memory, make sure the dialing mode is correctly set for the type of service you have. The default dialing mode is tone (touch-tone), so if you have pulse (rotary) service, you must first change the dialing mode. See "T/P

- **Storing Frequently Called Numbers**
- 1. Pick up the handset.
- 2. Press the store button 3. Push the desired memory location button (0-9). 4. Press the store button.
- 5. Use the handset number keys to enter the telephone number (up to 16- digits) and press the store button. 6. Hang up the handset.
- NOTE: If you make a mistake, use the delete button to delete wrong digits. **Changing a Stored Number**

Repeat the storage sequence above. The new number replaces

the old number at the memory location.

Erasing a Stored Number Pick up the handset.

the display is erased.

5. Hang up the handset.

- 2. Press the mem button.
- 3. Press the ▲ (+) or ▼ (-) buttons for the desired memory location to be erased. 4. Press and hold **delete** for three seconds until the number in

NOTE: If you want to erase more than one location, use the ▲ (+) or ▼ (-) arrow buttons to scroll to each

memory location you want to erase.

- Dialing Frequently Called Numbers 1. Pick up the handset and press the mem button. 2. Press 0-9 for the memory location. The number dials
- OR 1. Pick up the handset and press the dial button. 2. Press the ▲ (+) or ▼ (-) buttons for the desired memory
- location. 3. Press the dial button to dial the number.

automatically.

- 1. Press dial button while the handset is still in the cradle. 2. Press the ▲ (+) or ▼ (-) buttons for the desired memory
 - location, lift the handset and the number dials automatically. Reviewing Numbers Stored in Memory

2. Press 0-9 for the memory location. The number shows on the

1. Press the **store** button.

Copy Caller ID Memory to User Memory

3. Press the **store** button.

memory location is occupied.

6. Press the hook switch to exit.

memory location is occupied

Storing a Pause in Memory

4. Press the store button again to confirm.

6. Press the **flash** button or the hook switch to exit.

to 9 seconds. The default setting is 4 seconds.

4. Press 1-9 (1 = 1 second, 2 = 2 seconds, etc.)

a telephone company long distance provider

Local access number of long distance company

2. Press the **mem** button and then press 6

instructions on how to use flash.

call can be answered.

the second call is put on hold.

Using Temporary Tone Dialing

automatically returns to pulse service.

or the unit:

NO CALLS

PRIVATE NAME

START/END

Caller ID Display Messages

6. Press the **flash** button or the hook switch to exit.

This process allows you to dial a succession of stored numbers

from separate memory locations. This is useful when you must

3. When you hear the access tone, press the **mem** button and

4. At the next access tone, press the **mem** button and then 8.

mem button, or your call may not go through.

TIP: Wait for the access tones before pressing the next

This feature is used to activate customer calling services available

through your local phone company, such as Call Waiting. These

services generally require an extra monthly fee. If you subscribe

to any of these services, please refer to the phone company's

After you hear the Call Waiting tone, press and release the

To return to your first call and put the second call on hold:

flash button. The first call is placed on hold while the second

• Press and release **flash** again. The first call can continue while

If you have pulse service, you can temporarily change from pulse

to tone service. After dialing the telephone number, press and

phone services that require a tone, such as banking and long-

release the *tone button on the telephone. This allows access to

distance services. After you hang up the handset, the telephone

The following special messages indicate the status of a message

UNKNOWN NAME The incoming call does not have Caller ID

The caller memory is empty.

service or their service area is not linked

to yours. If the screen displays UNKNOWN

name information for that number was not

NAME along with a calling number, the

Battery power level is low. Please replace

maintain Caller ID operation.

withheld

Caller ID memory log.

are on the phone.

more than once.

the batteries as soon as possible in order to

The incoming caller is registered as "Private

You are at the beginning or the end of the

flashes when you receive a call while you

Repeat call message, indicates that a new

call from the same number was received

Number" and Caller ID information is

If you subscribe to Call Waiting

Caller ID Service, this icon

To answer an incoming call while having a conversation:

dial several sequences of numbers, such as with frequent calls via

Memory location

1. Pickup the handset.

1. Pickup the handset.

2. Press the **store** button.

3. Press the redial button

5. Press store again.

Chain Dialing

For example

Authorization code (ID)

1. Pick up the handset.

then press 7.

Using Flash

Long distance phone number

2. Press store

- 1. Pickup the handset.
- 2. Press the \blacktriangle (+) or \blacktriangledown (-) buttons to display the number you want to copy.

5. Press the **store** button twice to replace the new information

empty location. The number is automatically stored.

3. Press 0-9 for the memory location. Press the ▲ (+) or ▼ (-)

buttons to select a different location. The display flashes if the

5. Press the **redial** button, and then press the **store** button again.

The redial button has dual functionality. It becomes a pause but-

ton if the store button is pressed first. It is valid only when storing

a number into memory. Use the redial button to insert a pause

example, when you must dial a 9 to get an outside line, or when

you enter codes to access your long distance company. You may

need to adjust the length of the pause. It can be adjusted from 1

when a delay is needed in an automatic dialing sequence. For

Copy Redial Memory to User Memory

with the old, or press the \blacktriangle (+) or \blacktriangledown (-) buttons to select an

No Information is shown after the phone rings • In order to receive Caller ID records, you must subscribe to the 4. Press 0-9 for the memory location. The display flashes if the standard name and number Caller ID service available through

Make sure the batteries are properly installed.

your local telephone company. Be sure to wait until the second ring before answering.

Indicates call of calls have not been

• Check all cabling to make sure that all connections are secure

Check hook switch: Does it fully extend when handset is lifted

Phone does not ring

Troubleshooting Tips

No Dial Tone

and not damaged

Replace the batteries.

from cradle?

No Display

- Make sure the ringer switch is set to 1 or 2.
- You may have too many extension phones on your line. Try unplugging some extension phones.
- Check for dial tone. See Troubleshooting Tips for No Dial Tone.
- Other parties cannot hear you
- Make sure phone cord is securely plugged in. Make sure extension phones are on the hook at the same time

you're using the phone. It's normal for the volume to drop

when additional extension phones are used at the same time. Cannot dial out Make sure the T/P dialing mode is set to the type of phone

service you are subscribed to.

If trouble is experienced with this equipment, for repair or warranty information, please contact customer service at 1-800-297-1023. If the equipment is causing harm to the telephone network, the telephone company may request that you disconnect the equipment until the problem is resolved. This product may be serviced only by the manufacturer or its authorized service agents. Changes or modifications not expressly approved by Uniden America Corporation could void the user's authority to operate this product. For instructions on how to obtain service, refer to the warranty included in this guide

or call customer service at 1-800-297-1023. Or refer inquiries to: Uniden America Service 4700 Amon Carter Blvd.

Forth Worth, TX 76155

Service

down the date this product was purchased or received as a gift. This information will be valuable if service should be required during the warranty period. Name of Store _____

Attach your sales receipt to the booklet for future reference or jot

Purchase Date _

Industry Canada (I.C.) Notice Terminal equipment

NOTICE: This equipment meets the applicable Industry Canada Terminal Equipment Technical Specifications. This is confirmed by the registration number. The abbreviation, IC, before the registration number signifies that registration was performed based on a Declaration of Conformity indicating that Industry Canada technical specifications were met. It does not imply that

Industry Canada approved the equipment. NOTICE: The Ringer Equivalence Number (REN) for this terminal equipment is marked on the equipment itself. The REN assigned to each terminal equipment provides an indication of the maximum number of terminals allowed to be connected to a telephone interface. The termination on an interface may consist of any combination of devices subject only to the requirement that the sum of the Ringer Equivalence Numbers of all the

limitations or exclusions set out below.

devices does not exceed five.

One-year limited warranty **IMPORTANT:** Evidence of original purchase is required for warranty service, WARRANTOR: UNIDEN AMERICA CORPORATION ("Uniden") ELEMENTS OF WARRANTY: Uniden warrants, for one year, to the original retail owner, this Uniden Product to be free from defects in materials and craftsmanship with only the

WARRANTY DURATION: This warranty to the original user shall terminate and be of no further effect 12 months after the date of original retail sale. The warranty is invalid if the Product is (A) damaged or not maintained as reasonable or necessary, (B) modified, altered, or used as part of any conversion kits, subassemblies, or any configurations not sold by Uniden, (C) improperly installed, (D) serviced or repaired by someone other than an authorized Uniden service center for a defect or malfunction covered by this warranty, (E) used in any conjunction with equipment or parts or as part of any system not manufactured by Uniden, or (F) installed or programmed by anyone other than as detailed by the owner's manual for this

STATEMENT OF REMEDY: In the event that the product does not conform to this warranty at any time while this warranty is in effect, warrantor will either, at its option, repair or replace the defective unit and return it to you without charge for parts, service, or any other cost (except shipping and handling) incurred by warrantor or its representatives in connection with the performance of this warranty. Warrantor, at its option, may replace the unit with a new or refurbished unit. THE LIMITED WARRANTY SET FORTH ABOVE IS THE SOLE AND ENTIRE WARRANTY PERTAINING TO THE PRODUCT AND IS IN LIEU OF AND EXCLUDES ALL OTHER WARRANTIES OF ANY NATURE WHATSOEVER, WHETHER EXPRESS, IMPLIED OR ARISING BY OPERATION OF LAW, INCLUDING, BUT NOT LIMITED TO ANY IMPLIED WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE, THIS WARRANTY DOES NOT COVER OR PROVIDE FOR THE REIMBURSEMENT OR PAYMENT OF INCIDENTAL OR CONSEQUENTIAL DAMAGES.

Some states do not allow this exclusion or limitation of incidental or consequential damages so the above limitation or exclusion

may not apply to you. LEGAL REMEDIES: This warranty gives you specific legal rights, and you may also have other rights which vary from state to state. This warranty is void outside the United States of America. and Canada. PROCEDURE FOR OBTAINING PERFORMANCE OF WARRANTY: If, after following the instructions in the owner's manual you are certain that the Product is defective, pack the Product carefully (preferably in its original packaging). The Product should include all parts and accessories originally packaged with the Product. Include evidence of original purchase and a note describing the defect that has caused you to return it. The Product should be shipped freight prepaid, by traceable means, to warrantor at:

Uniden America Service 4700 Amon Carter Blvd Fort Worth, TX 76155







Free Manuals Download Website

http://myh66.com

http://usermanuals.us

http://www.somanuals.com

http://www.4manuals.cc

http://www.manual-lib.com

http://www.404manual.com

http://www.luxmanual.com

http://aubethermostatmanual.com

Golf course search by state

http://golfingnear.com

Email search by domain

http://emailbydomain.com

Auto manuals search

http://auto.somanuals.com

TV manuals search

http://tv.somanuals.com