



FP099

LCD Display

Caller ID

OWNERS

MANUAL

Uniden

CONTENTS

Important Safety Instructions	1
Introduction	
Features	2
Included in your package.	2
Location and Controls	3
Setup	
Battery Installation	4
Connecting Line Cords	4
Setting Time and Date	4
LDS Code Setting	4
Telephone Key Function	5
Display Messages	6
Receiving Call Records	7
Caller ID Operation	7
Troubleshooting	8
Warranty	9

IMPORTANT SAFETY INSTRUCTIONS

When using your telephone equipment, these basic safety precautions should always be followed to reduced the risk of fire, electrical shock, and injury:

1. Read and understand all instructions.
2. Follow all warnings and instructions marked on the product.
3. Unplug this product from the wall outlet before cleaning. Use a damp (not wet) cloth. Never use abrasive or strong cleaners or solvents.
4. Do not use this product near water; for example, near a bathtub, shower, washbowl, kitchen sink or laundry tub, in a wet basement or near a swimming pool.
5. Do not place this product on an unstable stand or table. The telephone may fall, causing serious damage to the unit.
6. Never spill liquid of any kind on the product.
7. Do not disassemble this product. Take it to qualified service personnel when service or repair work is required. Opening or removing covers may expose you to dangerous voltages or other risks. Incorrect reassembly can cause electric shock when the appliance is subsequently used.
8. Unplug this product from the wall outlet and refer servicing to qualified service personnel under the following conditions:
 - A. If liquid has been spilled into the product.
 - B. If the product has been exposed to rain or water.
 - C. If the product does not operate normally when following the operating instructions.

INTRODUCTION

Features

Caller display
80 memory caller display
Out of area / Private / Repeat indicator
NEW CALL light
Battery Low indicator
Last number redial
Last 5 numbers redial
FLASH button
Message waiting icon (New Zealand Only)
Visual ringer
Mute button
Timer

Included in your package

- 1 - Handset with curly cord and phone base
- 1 - Telephone line cord
- 4 - AAA size 1.5V batteries
- 1 - Owner's manual
- 1 - Wall mounting bracket




To get the most from your phone, please read the Owner's Manual thoroughly. Be sure to complete and mail the product registration form.

LOCATION OF CONTROLS



This unit is not waterproof. Do not expose this product to rain, water, moisture or any other liquid.



- 1. mute button
- 2. redial button
- 3. pause button
- 4. flash button
- 5. del button

- 6. call back button
- 7. new call button
- 8. review up button
- 9. review dn button
- 10. Visual ringer

SETUP

NOTE

Match the + / - symbols in the battery compartment with each battery.

NOTE

If you have subscribed to the Caller ID service, the Time and Date will automatically be set when you receive a call.

NOTE

Australian Customers:
Setting the LDS code is not required.

Battery Installation

The Caller ID phone requires four 1.5V AAA size batteries for the LCD display to operate.

1. Remove the screw and open the battery compartment under the base.
2. Insert four 1.5V AAA size batteries.
3. Position the batteries in the compartment and replace the battery compartment cover.

Connecting Line Cords

Plug one end of the supplied modular cord into the telephone line wall jack. Then plug the other end into the telephone line jack located under the base.

Setting Time and Date

With handset in cradle follow these steps:

1. While holding down the **del** button, press the **review dn** button once.
2. Use **review up** or **dn** button to select the correct number - **HH : MM MM / DD**
(hours : minutes) (month/day)
3. Press **call back** button to confirm and move to the next digit.
4. Press **del** button to store and exit.

8:06 2/27

SET TIME

Digit Insert Caller ID (LDS Code)

To correctly display and dial Call ID numbers, you may need to insert a digit at the beginning of your telephone number. (eg: in New Zealand, Telecom requires a '0' to be inserted.)

New Zealand:

If you subscribe to Telecom New Zealand, this code has already been set for you to '0'.
If you subscribe to another telephone company, please set the LDS code as blank ' - - '.

If this phone is used with a business PABX - consult the PABX manufacturer for the correct setting.

Australia:

For private household telephone lines, it is not necessary to set this code.

If this phone is used with a business PABX - consult the PABX manufacturer for the correct setting.

1. While holding down the **del** button, press the **review up** button once.

8:06 2/27

SET LDS CODE

2. Press **review up** or **dn** to select the correct number to be inserted, press **call back** to set the next digit, then press **del** to store and exit.

TELEPHONE KEY FUNCTION

Ringer Select Switch

If you do not wish the phone's ringer to interrupt you, move the Ringer Selector Switch (located under the base) to OFF.

Regular dialling

Lift the handset and listen for dial tone. Then enter the telephone number you wish to call. The dialled number will appear on the LCD screen whenever you make a call.

Redial function

To redial the previous number you called. Lift the handset and press the redial button.

Pause function

To insert a temporary pause, press the **pause** button during a dialling sequence. For example, in some cases when dialling an international number you need to place a pause between the clusters of numbers to allow the telephone company, relaying the call, time to process it. The number 011-886-22-795-1234 would need to be dialled 011 (pause) 886 (pause) 22 (pause) 795 (pause) 12345.

Mute button

For privacy when you are required to consult with a person standing next to you and do not wish the party on the line to hear your conversation, press and hold the **mute** button. The call resumes on releasing the button.

Flash button - Call Waiting

If the call Waiting tone sounds while you are on a call -
New Zealand: Press the **flash** button to switch between callers.
Australia: Press **flash** then **2** to switch between callers.



NOTE

For 'Call Waiting' to operate you must subscribe to this service through your local telephone company.

If you do not have this service, then pressing the flashing button during a call may disconnect the caller.

DISPLAY MESSAGES



For LCD messages to operate, you must first subscribe to the caller ID service through your local telephone company.


Message Waiting (New Zealand Only) MSG

If you have arranged a voice mail service with your telephone company, the LCD screen will display **MESSAGE WAITING** for a few seconds after a call is received. The screen will then display **MSG** in the upper left corner until you retrieve the message from the voice mail service.



Total & New Calls

This displays the total calls received and which of those are new calls. This example shows 10 calls which include 2 new calls.



No Calls

When all calls have been deleted the screen will display **NO CALL**.



Private

If a caller has exercised the option which prevents the caller's name and number from being sent, the screen will display **PRIVATE**.




Repeat Calls

If a call is received repeatedly, **REPEAT** will be displayed in the top right of the LCD screen.



End of List

This is displayed when you use the review **up** or **dn** and have reached the top end of the call history list. If there are no calls in the list the LCD screen displays **NO CALL**.




Out of Area

This will be displayed when the caller's telephone company does not provide caller ID services or does not provide name and number services via the long distance network.




Battery Low Indicator LOW

This icon is displayed when the batteries require replacing.



RECEIVING CALL RECORDS

A caller ID record consists of the following information:



The LCD display will not operate if the batteries are flat or not installed.

CALLER ID OPERATION

New Call Indicator

The red indicator light of your phone will flash when you have New Calls. It will continue to flash until you have reviewed the calls displayed on the LCD screen.

Review Call Records

Use the **review up** or **dn** buttons to scroll through the caller list. At the end of the call record list, END OF LIST will be displayed.

Call Records

Your phone stores up to 80 Call records. When the list is full a new incoming call will automatically delete the oldest call record.

Using the CALL BACK feature

You can automatically dial the number of a person who has recently called.

- 1) Lift the handset and listen for dial tone.
- 2) Select the caller that you wish to call back by pressing the **review up** or **dn** button.
- 3) Press call back to automatically dial the number of the person displayed in the LCD screen.

Last 5 Numbers Redial

- 1) With the handset on the cradle, press the **callback** button once..
- 2) Use the **review up** or **dn** buttons to select one of the last 5 numbers you have dialled.
- 3) Pick up the handset and press **callback**, the number you have chosen will automatically be dialled.

Del button - for deleting Caller ID records

To delete numbers from your Caller ID number memory.

With the handset in its cradle, press **review up** or **dn** buttons to select the number you wish to delete. Now press the **del** button. The LCD screen will show DEL?. To confirm the number chosen is to be deleted, press **del** again. The number will be deleted.

Timer

During a call, press the **del** button to start and stop the timer.



For call ID features to operate you must first subscribe to this service through your local telephone company.

TROUBLESHOOTING

Blank or faint screen

Check the line cord.

Connect telephone cord.

Replace batteries.

Caller ID will not work properly

Call your telephone company to verify that your caller ID service is active.

Phone will not ring

You may have too many communication devices connected to a single line. A communication device can be a phone, a modem or fax machine. Disconnect some devices.

No dial tone

Verify that you are using the correct line cord and that it is plugged in correctly.

No data sent

If you have an answering machine or fax connected to this phone, ensure it is set to answer after at least two rings.

You have answered the call before two rings.

Contact your telephone company if the problem continues for more than 24 hours. The telephone company may be experiencing a temporary line fault.

No response on LCD display

If you have experienced a power failure when using the optional AC adaptor, the batteries for memory backup may have become weak or dead. If the power is restored and the display screen does not respond then you need to replace the batteries.

Please refer to our website for further information and frequently asked questions.

New Zealand - www.uniden.co.nz

Australia - www.uniden.com.au

WARRANTY

One Year Limited Warranty

Important: Evidence of original purchase is required for warranty service.

Warrantor: Uniden Australia Pty Limited ACN 001 865 498
Uniden New Zealand Limited

ELEMENT OF WARRANTY: Uniden warrants to the original retail owner for the duration of this warranty, its FP099 (herein after referred to as the Product), to be free from defects in materials and craftsmanship with only the limitations or exclusions set out below.

WARRANTY DURATION: This warranty to the original retail owner only, shall terminate and be of no further effect 12 months after the date of original retail sale. This warranty will be deemed invalid if the product is; (A) Damaged or not maintained as reasonable and necessary, (B) Modified, altered or used as part of any conversion kits, subassemblies, or any configurations not sold by Uniden, (C) Improperly installed, (D) Repaired by someone other than an authorised Uniden Repair Agent for a defect or malfunction covered by this warranty, (E) Used in conjunction with any equipment or parts or as part of a system not manufactured by Uniden. (F) Only available in the original country of sale.

PARTS COVERED: This warranty covers for one (1) year, the FP099 Unit and Handset only. All accessories (AC Adaptor, Cables etc) are covered for 90 days only.

STATEMENT OF REMEDY: In the event that the product does not conform to this warranty at any time while this warranty is in effect, the warrantor at its discretion, will repair the defect or replace the product and return it to you without charge for parts or service. **THIS WARRANTY DOES NOT COVER OR PROVIDE FOR THE REIMBURSEMENT OR PAYMENT OF INCIDENTAL OR CONSEQUENTIAL DAMAGES. THIS GUARANTEE IS IN ADDITION TO AND DOES NOT IN ANY WAY AFFECT YOUR RIGHTS UNDER THE CONSUMER GUARANTEE ACT.**

WARRANTY CARD: If a warranty card has been included with this product then please fill it in and return to us within 14 days of purchase. Your name and the Serial number of the product will then be registered in our database and this will help us process your claim with greater speed and efficiency should you require warranty

PROCEDURE FOR OBTAINING PERFORMANCE OR

WARRANTY: In the event that the product does not conform to this warranty, the Product should be shipped or delivered, freight pre-paid, with evidence of original purchase (eg. a copy of the sales docket), to the warrantor at:

UNIDEN AUSTRALIA PTY LIMITED
SERVICE DIVISION
345 Princes Highway,
Rockdale NSW 2216
Ph (02) 9599 3577 Fax (02) 9599 3278
Toll Free 1300 366 895

www.uniden.com.au

UNIDEN NEW ZEALAND LIMITED
SERVICE DIVISION
150 Harris Road,
East Tamaki, Auckland
Ph (09) 273 8383 Fax (09) 274 4253
Toll Free 0800 4 UNIDEN
(864 336)

www.uniden.co.nz

Customers in other States should ship or deliver the Product freight pre-paid to their nearest Uniden Authorised Repair Centre (Contact Uniden for the nearest Warranty Agent to you)

WARRANTY

THANK YOU

FOR PURCHASING A UNIDEN PHONE

Uniden

© 2001

Uniden Australia Pty Limited

Uniden New Zealand Limited

Free Manuals Download Website

<http://myh66.com>

<http://usermanuals.us>

<http://www.somanuals.com>

<http://www.4manuals.cc>

<http://www.manual-lib.com>

<http://www.404manual.com>

<http://www.luxmanual.com>

<http://aubethermostatmanual.com>

Golf course search by state

<http://golfingnear.com>

Email search by domain

<http://emailbydomain.com>

Auto manuals search

<http://auto.somanuals.com>

TV manuals search

<http://tv.somanuals.com>