

THE OFFICIAL



PLAYERS DICTIONARY

User's Guide  
[www.franklin.com](http://www.franklin.com)

# License Agreement

---

READ THIS LICENSE AGREEMENT BEFORE USING THE ELECTRONIC REFERENCE. YOUR USE OF THE ELECTRONIC REFERENCE DEEMS THAT YOU ACCEPT THE TERMS OF THIS LICENSE. IF YOU DO NOT AGREE WITH THESE TERMS, YOU MAY RETURN THIS PACKAGE WITH PURCHASE RECEIPT TO THE DEALER FROM WHICH YOU PURCHASED THE ELECTRONIC REFERENCE AND YOUR PURCHASE PRICE WILL BE REFUNDED. ELECTRONIC REFERENCE means the software product and documentation found in this package and FRANKLIN means Franklin Electronic Publishers, Inc.

## Limited Use License

All rights in the ELECTRONIC REFERENCE remain the property of FRANKLIN. Through your purchase, FRANKLIN grants you a personal and nonexclusive license to use this ELECTRONIC REFERENCE. You may not make any copies of the ELECTRONIC REFERENCE or of the data stored therein, whether in electronic or print format. Such copying would be in violation of applicable copyright laws. Further, you may not modify, adapt, disassemble, decompile, translate, create derivative works of, or in any way reverse engineer the ELECTRONIC REFERENCE. You may not export or reexport, directly or indirectly, the ELECTRONIC REFERENCE without compliance with appropriate governmental regulations. The ELECTRONIC REFERENCE contains Franklin's confidential and proprietary information which you agree to take adequate steps to protect from unauthorized disclosure or use. This license is effective until terminated. This license terminates immediately without notice from FRANKLIN if you fail to comply with any provision of this license.

# Introduction

---

Congratulations! You now have a powerful and portable way to improve your SCRABBLE® skills and scores. With *The Official SCRABBLE® Players Dictionary* you can:

- check if your word is a valid SCRABBLE® word according to *The Official SCRABBLE® Players Dictionary* from Hasbro® and view its definition (when available);
- check word spellings;
- build words from your letter and blank tiles;
- enter patterns of letters appearing on the board and fit your tiles to those patterns;
- include double and triple letter and word scores in your patterns;
- play three fun word games.

To learn how to use *The Official SCRABBLE® Players Dictionary*, read this manual and then keep it handy for reference.

# Getting Started

---

Your unit is powered by four AAA batteries. You must install the batteries before you can use the unit. The battery compartment is located on the back of the unit at the top. Please have a small Phillips screwdriver at hand before following the steps below to install or change the batteries.

- 1. Turn the unit off (if necessary) and turn it over.**
- 2. Unscrew the tiny screw at the bottom of the battery compartment.**
- 3. Using your thumbs, push the latches in and lift the cover off.**
- 4. Install four new AAA batteries following the markings in the compartment.**
- 5. Replace the battery cover and the screw.**
- 6. Using a paper clip, gently press the Reset button located on the back of the unit.**

## **CAUTION:** TO AVOID BATTERY LEAKAGE...

- Be sure to insert the batteries correctly and always follow the product and battery manufacturer's instructions;
- Do not mix old and new batteries or alkaline, standard (carbon-zinc) or rechargeable (nickel-cadmium) batteries;
- Always remove weak or dead batteries from the product.

### ✓ Adjusting the Contrast

You can make the screen lighter or darker to suit your viewing needs. Press  $\uparrow$  or  $\downarrow$  to adjust the contrast at the Ready screen. If the screen remains blank, you may need to replace the batteries.

### ✓ Resuming Where You Left off

To save battery life, this product will automatically shut off within two minutes if no key is pressed.

Each time you turn the product on, you will return to the last screen you viewed.

**Note:** This will only work if you have turned the demonstration off.














### ✓ Viewing the Demonstration

Each time you turn the unit on, the Quick Demo appears. You can stop the demo at any time by pressing **CLEAR**.

If you do not wish to have the Demo run each time you turn the product on, you can disable it at any time. To do so, type **\*\*d** at the Ready screen, then press **ENTER**. To re-enable the demo, type **\*\*d** and press **ENTER** again.

# Key Guide

---

-  Builds words from entered letters.
-  Goes to the pattern entry screen.
-  Shows the Games menu.
-  Sets the skill level for the games.
-  Displays a help message.
-  Cycles through the double and triple letter and word scores.
-  Types **\*** to stand for any series of letters.
-  Types **□** to stand for one unknown letter or a blank tile. In games, ends a round.
-  Clears to the Ready screen or stops the demonstration.
-  Enters a word.
-  Goes back or erases a typed letter.
-  Scrolls up and down. Adjusts screen contrast at the Ready screen.
-  Moves left or right.

# Building Words

---


To build words from your letter tiles, type the tiles you have at the Ready screen and then press **BUILD**. You will see a list of words ranked by their SCRABBLE® scores. Here is an example.

## 1. Type the tiles in your tray.

For example, type the letters *ypxbtro*.


To erase a letter, press **BACK**.

## 2. Press **BUILD** to build your SCRABBLE® list.



The number shows the word's SCRABBLE® score. If no words can be built from your tiles, you'll see the message *Sorry can't help*.

## 3. Press to see more words and scores.





## 4. Press **CLEAR** when done.


### ✓ Viewing More Words

Blinking arrows to the right of the screen indicate that there are more words to see. To scroll the list of words, just press the arrow keys that are shown.


### Building Words with Blank Tiles

To build words with blank tiles, press  for each blank tile and then press **BUILD**. For example:



1. Type *asde*.
2. Press **BUILD**.



**Note:** The blank tile letter is not counted in the word score.

3. Press  to see more words.
4. Press **CLEAR** when done.

#### ✓Helpful Hint

You can build words using as many blank tiles as you like. However, you cannot build words using . If you type  and then press **BUILD**, the message *Invalid query* appears.

#### ✓Help is at Hand

At most displays, you can view an appropriate help message by pressing **HELP**. To exit a help message, press **BACK**.



# Filling Patterns

---

Using **PATTERN** you can type patterns of letters appearing on the SCRABBLE® board and then fit your tiles around them. For example, say you have the tiles *pleorkn* and your board looks like this:

|  |                |   |   |   |                  |
|--|----------------|---|---|---|------------------|
|  |                |   | P |   |                  |
|  | TRIPLE<br>WORD | A | R | T | DOUBLE<br>LETTER |
|  |                |   | Y |   |                  |

## 1. Press **PATTERN** to see the **Pattern** entry screen.

You can enter a combination of 15 letters and the following designated squares.

One empty square



A series of empty squares



Double letter square



Triple letter square




Double word square



Triple word square



Press  to enter an empty square.

Press **SCORE** to cycle through the double and triple word choices.

### 2. Type your pattern.

To make a word using *ART*, your pattern will look like this.


### 3. Press ENTER.

### 4. Type your tiles *pleorkn* and press ENTER.

### 5. Press to view more words.

### 6. Press CLEAR when done.

## Adding Letters to the Beginning or End of Words

At the Pattern entry screen, you can use  to find words either ending or beginning with the tiles on the board. For example, say you have the tiles *eknjsuh* and your board looks like this:

## Filling Patterns

---

|  |  |  |   |   |
|--|--|--|---|---|
|  |  |  | A | H |
|--|--|--|---|---|

To find words ending with *ah*, do the following:

1. Press **PATTERN** and type **⌘ah**.



2. Press **ENTER**.
3. Type your tiles *eknjsuh* and press **ENTER**.



4. Press **⏵** to view more words.
5. Press **CLEAR** when done.

### ✓ Cleaning and Storage

To clean, spray a mild glass cleaner onto a cloth and wipe the screen. Do not spray liquids directly on this product. Do not use or store this product in extreme or prolonged heat, cold, humidity, or other adverse conditions.

# Correcting Misspellings

---

You can use *The Official SCRABBLE® Players Dictionary* to check the spellings of words. When you enter a misspelled word at the Ready screen, a list of corrections appears. When you enter a word not in this product, the message *Sorry Can't Help* appears.

When you enter a correctly spelled word, the word *Dictionary* flashes and you go to a brief definition. Please see “Defining Words” on page 13 for more information.


To correct misspellings at the Ready screen, do the following:

**1. Type a misspelled word.**

For example, type *chinon*.

To erase a letter, press **BACK**.

**2. Press ENTER to see a corrected word.**



**3. Press  repeatedly to view more words.**

**4. Press CLEAR when done.**

# Finding Spellings

---

You can also use *The Official SCRABBLE® Players Dictionary* to find the spelling of a word even when you don't know all the letters in that word. Just type  for each unknown letter, or type  for any number of letters. Here is an example.

1. **At the Ready screen, type  and  to take the place of one letter and a series of letters respectively.**

For example, type *qvt*.

2. **Press ENTER.**

ivivut

3. **Press  to see more words (if any).**

When more words are available, you will see an arrow pointing down.

## ✓ Finding Unusual Words

Use  and  to find unusual words. For example, type *a* to see two-letter words beginning with **A**. To see words beginning and ending with **H**, type *hh*.

# Defining Words

---

You can see the definition of a word, when available. When *The Official SCRABBLE® Players Dictionary* does not contain a complete definition for the word you look up, you will see the part of speech. If the word you enter is an inflection, you will see the definition for the root word. If the word you enter is not in *The Official SCRABBLE® Players Dictionary* you will go to a spell correction list. Here's how you look up a word.

**1. At the Ready screen, type a word.**

For example type *agone*.

To erase a letter, press **BACK**.

**2. Press ENTER.**

agone [adv] ago

To see the full definition, press ⏪ and ⏩.

**3. Press CLEAR when done.**

This unit may change operating modes due to Electrostatic Discharge. Normal operation of this unit can be re-established by pressing the reset key, **ON/OFF** or by removing/replacing batteries.

# Playing the Games

---

There are three challenging word games: *Jumble*, *Mystery Word* and *Word Deduction*.

## Selecting a Game

1. Press **GAMES**.
2. Press **↑** or **↓** to find the game you want.
3. Press **ENTER** to select it.

## Selecting the Skill Level

There are three skill levels to choose from: *Beginner*, *Intermediate* and *Advanced*.

1. Press **SKILL**.
2. Press **↑** or **↓** to find the skill level you want.
3. Press **ENTER** to select it.


### ✓Understanding Skill Levels

The skill level you choose changes the number of guesses in *Mystery Word* and the length of words in *Jumble* and *Word Deduction*.

## Mystery Word

*Mystery Word* selects a word and challenges you to guess it letter by letter. The letters of the mystery word are hidden by blank tiles. The number of guesses remaining is indicated at the right of the screen.

1. Select *Mystery Word* on the Games menu.



**2. Type letters and press ENTER.**

Press \* to reveal a letter.

Press  to reveal the word.

**3. Press ENTER to play another round.**

**4. Press BACK to return to the Games menu.**

### Jumble

In *Jumble*, a jumbled word appears and you must unscramble the letters to spell a word or words.

**1. Select *Jumble* on the Games menu.**

**2. Type a word and press ENTER.**

Press \* to shuffle the letters.

Press  to reveal the word.

**3. Press ENTER to play another round.**

**4. Press BACK to return to the Games menu.**

### Word Deduction

*Word Deduction* challenges you to guess a three, four or five letter word depending on the skill level you choose. You have twelve tries in which to win.

**1. Select *Word Deduction* on the Games menu.**

**2. Type a word.**

For example, type *gal*.



### 3. Press ENTER.


|                 |
|-----------------|
| 1 GAL P=1 M=0 ↓ |
|-----------------|

The 1 means this is your first guess. **P** stands for *perfect*. **M** stands for *misplaced*. In the above example, **P=1** means that one of the letters you typed is in the mystery word and in the perfect place. **M=0** means that there are no matching letters that are misplaced.

### 4. Type another word.

Keep one or two letters from your previous guess if you have numbers next to the **P** or **M**. For example, type *jab*.

### 5. Continue typing words, evaluating what the correct letters are and where they are placed.

Use  to see your previous guesses.

Press  to give up.

### 6. Press ENTER to play another round.

### 7. Press BACK to return to the Games menu.

Press **CLEAR** to exit the Games

### ✓ Resetting the Unit

If the keyboard fails to respond, or if the screen performs erratically, perform a system reset. Use a paper clip to gently depress the reset button. The reset button is recessed in a pin-sized hole on the back of your unit beneath the battery compartment.

# Specifications

---

**Model** SCR-226: *The Official SCRABBLE® Players Dictionary*

**Battery:** 4 AAA

**Size:** 13.13 x 13.13 x 2.16 cm.

ISBN 1-59074-200-1

FOR HOME OR OFFICE USE.

©1992-2003 Franklin Electronic Publishers, Inc. Burlington N.J.

08016-4907 U.S.A. All rights reserved.

SCRABBLE® the distinctive game board and letter tiles, and all associated logos are trademarks of Hasbro in the United States and Canada used with permission.

© 1995 Hasbro, Inc. All Rights Reserved.

U.S. Patents: 4,830,618; 4,891,775; 5,113,340; 5,218,536;

5,396,606; 5,435,564.

## Limited Warranty (outside U.S.)

This product, excluding batteries and liquid crystal display (LCD), is guaranteed by Franklin for a period of one year from the date of purchase. It will be repaired or replaced with an equivalent product (at Franklin's option) free of charge for any defect due to faulty workmanship or materials.

Products purchased outside the United States that are returned under warranty should be returned to the original vendor with proof of purchase and description of fault. Charges will be made for all repairs unless valid proof of purchase is provided.

This warranty explicitly excludes defects due to misuse, accidental damage, or wear and tear. This guarantee does not affect the consumer's statutory rights.

# Limited Warranty (U.S. only)

---

## LIMITED WARRANTY, DISCLAIMER OF WARRANTIES AND LIMITED REMEDY

(A) LIMITED WARRANTY. FRANKLIN WARRANTS TO THE ORIGINAL END USER THAT FOR A PERIOD OF ONE (1) YEAR FROM THE ORIGINAL DATE OF PURCHASE AS EVIDENCED BY A COPY OF YOUR RECEIPT, YOUR FRANKLIN PRODUCT SHALL BE FREE FROM DEFECTS IN MATERIALS AND WORKMANSHIP. THIS LIMITED WARRANTY DOES NOT INCLUDE DAMAGE DUE TO ACTS OF GOD, ACCIDENT, MISUSE, ABUSE, NEGLIGENCE, MODIFICATION, UNSUITABLE ENVIRONMENT OR IMPROPER MAINTENANCE. THE SOLE OBLIGATION AND LIABILITY OF FRANKLIN, AND YOUR EXCLUSIVE REMEDY UNDER THIS LIMITED WARRANTY, WILL BE REPAIR OR REPLACEMENT WITH THE SAME OR AN EQUIVALENT PRODUCT OF THE DEFECTIVE PORTION OF THE PRODUCT, AT THE SOLE OPTION OF FRANKLIN IF IT DETERMINES THAT THE PRODUCT WAS DEFECTIVE AND THE DEFECTS AROSE WITHIN THE DURATION OF THE LIMITED WARRANTY. THIS REMEDY IS YOUR EXCLUSIVE REMEDY FOR BREACH OF THIS WARRANTY. THIS WARRANTY GIVES YOU CERTAIN RIGHTS; YOU MAY ALSO HAVE OTHER LEGISLATED RIGHTS THAT MAY VARY FROM JURISDICTION TO JURISDICTION.

(B) DISCLAIMER OF WARRANTIES AND LIMITATION OF LIABILITY. EXCEPT FOR THE LIMITED WARRANTIES EXPRESSLY RECITED ABOVE, THIS FRANKLIN IS PROVIDED ON AN "AS IS" BASIS, WITHOUT ANY OTHER WARRANTIES OR CONDITIONS, EXPRESS OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, WARRANTIES OF MERCHANTABILITY, MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE, OR THOSE ARISING BY LAW, STATUTE, USAGE OF TRADE, OR COURSE OF DEALING. THIS WARRANTY APPLIES ONLY TO PRODUCTS MANUFACTURED BY FRANKLIN AND DOES NOT INCLUDE BATTERIES, CORROSION OF BATTERY CONTACTS OR ANY OTHER DAMAGE CAUSED BY BATTERIES. NEITHER FRANKLIN NOR OUR DEALERS OR SUPPLIERS SHALL HAVE ANY LIABILITY TO YOU OR ANY OTHER PERSON OR ENTITY FOR ANY INDIRECT, INCIDENTAL, SPECIAL, OR CONSEQUENTIAL DAMAGES WHATSOEVER, INCLUDING, BUT NOT LIMITED TO, LOSS OF REVENUE OR PROFIT, LOST OR DAMAGED DATA OR OTHER COMMERCIAL OR ECONOMIC LOSS, EVEN IF WE HAVE BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES, OR THEY ARE OTHERWISE FORESEEABLE. WE ARE ALSO NOT RESPONSIBLE FOR CLAIMS BY A THIRD PARTY. OUR MAXIMUM AGGREGATE LIABILITY TO YOU, AND THAT OF OUR DEALERS AND SUPPLIERS, SHALL NOT EXCEED THE AMOUNT PAID BY YOU FOR THE FRANKLIN PRODUCT AS EVIDENCED BY YOUR PURCHASE RECEIPT. YOU ACKNOWLEDGE THAT THIS IS A REASONABLE ALLOCATION OF RISK. SOME STATES/COUNTRIES DO NOT ALLOW THE EXCLUSION OR LIMITATION OF LIABILITY FOR CONSEQUENTIAL OR INCIDENTAL DAMAGES, SO THE ABOVE LIMITATION MAY NOT APPLY TO YOU. IF THE LAWS OF THE RELEVANT JURISDICTION DO NOT PERMIT FULL WAIVER OF IMPLIED WARRANTIES, THEN THE DURATION OF IMPLIED WARRANTIES AND CONDITIONS ARE LIMITED TO THE DURATION OF THE EXPRESS WARRANTY GRANTED HEREIN.

(C) WARRANTY SERVICE: UPON DISCOVERING A DEFECT, YOU MUST CALL FRANKLIN'S CUSTOMER SERVICE DESK, 1-800-266-5626, TO REQUEST A RETURN MERCHANDISE AUTHORIZATION ("RMA") NUMBER, BEFORE RETURNING THE PRODUCT (TRANSPORTATION CHARGES PREPAID) TO:  
FRANKLIN ELECTRONIC PUBLISHERS, INC.

ATTN: SERVICE DEPARTMENT  
ONE FRANKLIN PLAZA  
BURLINGTON, NJ 08016-4907

IF YOU RETURN A FRANKLIN PRODUCT, PLEASE INCLUDE A NOTE WITH THE RMA, YOUR NAME, ADDRESS, TELEPHONE NUMBER, A BRIEF DESCRIPTION OF THE DEFECT AND A COPY OF YOUR SALES RECEIPT AS PROOF OF YOUR ORIGINAL DATE OF PURCHASE. YOU MUST ALSO WRITE THE RMA PROMINENTLY ON THE PACKAGE IF YOU RETURN THE PRODUCT, OTHERWISE THERE MAY BE A LENGTHY DELAY IN THE PROCESSING OF YOUR RETURN. WE STRONGLY RECOMMEND USING A TRACKABLE FORM OF DELIVERY TO FRANKLIN FOR YOUR RETURN.

# FCC Notice

---

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) This device must accept any interference received, including interference that may cause undesired operation.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

NOTE: This unit was tested with shielded cables on the peripheral devices. Shielded cables must be used with the unit to insure compliance.

NOTE: The manufacturer is not responsible for any radio or TV interference caused by unauthorized modifications to this equipment. Such modifications could void the user's authority to operate the equipment.

## Free Manuals Download Website

<http://myh66.com>

<http://usermanuals.us>

<http://www.somanuals.com>

<http://www.4manuals.cc>

<http://www.manual-lib.com>

<http://www.404manual.com>

<http://www.luxmanual.com>

<http://aubethermostatmanual.com>

Golf course search by state

<http://golfingnear.com>

Email search by domain

<http://emailbydomain.com>

Auto manuals search

<http://auto.somanuals.com>

TV manuals search

<http://tv.somanuals.com>