

USER GUIDE

Fusion 2925

Digital Cordless Telephone with Answer Machine



TECHNICAL DETAILS

Standard	Digital Enhanced Cordless Telecommunication (DECT)
Frequency range	1.88 to 1.9 GHz (bandwidth = 20 MHz)
Channel bandwidth	1.728 MHz
Operating range	Up to 300m outdoors; up to 50m indoors
Operating time	Standby: 100 hours Talking: 10 hours Battery charge time: 15 hours
Temperature range	Operating 0°C to 40°C Storage: 20 to 60°C
Electrical power	HANDESET – 500mAh 2.4V NiMH rechargeable battery pack Base unit: Typ. Pwr.: 500mAh/0.000045 / 500mAh/0.000045 Input: 100-240VAC 50/60Hz 150mA, output: 6VDC 400mA Charger unit: Typ. Pwr.: 500mAh/0.000030 / 500mAh/0.000030 Input: 100-240VAC 50/60Hz 150mA, output: 6VDC 300mA

Port specification The **SELV** port (connected to the mains power supply) is a SELV port with respect to ENA1003. The **TN** port (connected to the telephone line) is a TNV port with respect to EN41003.

CLEANING AND CARE
Do not clean any part of your Fusion 2925 system with benzene, thinners or other solvent chemicals as this may cause permanent damage which is not covered by the Guarantee.
When necessary, clean it with damp cloth.
Keep your Fusion 2925 system away from hot, humid conditions or strong sunlight, and don't let it get wet.
Every effort has been made to ensure high standards of reliability for your Fusion 2925 system. However, if something does go wrong, please do not try to repair it yourself, but consult your supplier or the Helpline.

THIS EQUIPMENT IS NOT DESIGNED FOR MAKING EMERGENCY TELEPHONE CALLS WHEN THE POWER FAILS. ALTERNATIVE ARRANGEMENTS SHOULD BE MADE FOR ACCESS TO DIAL EMERGENCY SERVICES.

Before operating this set, please read these instructions carefully.

Binatone Helpline (for UK only)
Monday to Friday from 9.00am to 5.00pm
Tel: 0845 345 9677
*Please note that all calls are charged at local rate
Or visit our website: www.binatoneonline.com

Table of Contents

1. IMPORTANT SAFETY INSTRUCTIONS	3
2. INSTALL YOUR PHONE	4
2.1 CHANGE THE BASE STATION	4
2.2 INSTALL AND CHARGE THE BATTERIES	4
3. GET TO KNOW YOUR PHONE	5
3.1 BASE STATION OVERVIEW	5
3.2 HANDESET OVERVIEW	5
3.3 DISPLAY ICONS AND SYMBOLS	5
3.4 BASE STATION WITH TELEPHONE ANSWERING MACHINE (TAM) CONTROL	5
3.5 MENU STRUCTURE	8
3.6 TEXT AND DIGIT ENTRY TABLES	9
4. USE YOUR PHONE	12
4.1 POWER ON THE HANDESET	12
4.2 MAKE AN EXTERNAL CALL	12
4.2.1 PREPARATORY DIALING	12
4.2.2 DIRECT DIALING	12
4.2.3 CALL FROM THE PHONEBOOK	12
4.2.4 CALL FROM THE CALL LIST	12
4.2.5 CALL FROM THE REDIAL LIST	12
4.2.6 CALL TIMER	12
4.3 ANSWER A CALL	12
4.4 END A CALL	12
4.5 ADJUST EARPIECE AND HANDSFREE VOLUME	12
4.6 MUTE A CALL	12
4.7 TURN OFF THE HANDESET RINGER	12
4.8 REDIAL	12
4.8.1 REDIAL A NUMBER FROM THE REDIAL LIST	12
4.8.2 SAVE A REDIAL NUMBER INTO THE PHONEBOOK	12
4.8.3 DELETE A REDIAL NUMBER	12
4.8.4 DELETE ALL REDIAL NUMBERS	12
4.9 KEYPAD LOCK	13
4.10 FIND HANDESET	13
4.11 MAKE AN INTERNAL CALL	13
4.11.1 INTERCOM ANOTHER HANDESET	13
4.11.2 TRANSFER AN EXTERNAL CALL TO ANOTHER HANDESET	13
4.11.3 SWITCH CALLS BETWEEN AN EXTERNAL CALL AND AN INTERNAL CALL	13
4.11.4 MAKE A 3-WAY CONFERENCE CALL	13
5. PHONEBOOK	14
5.1 ADD A NEW ENTRY	14
5.2 EDIT AN ENTRY	14
5.3 VIEW AN ENTRY	14
5.4 DELETE AN ENTRY	14
5.5 DELETE ALL PHONEBOOK ENTRIES	14
5.6 VIEW PHONEBOOK CAPACITY	15
5.7 CALL LIST	15
5.8 VIEW THE CALL LIST	15
5.9 STORE A CALL LIST NUMBER INTO THE PHONEBOOK	15
5.10 DIAL A CALL LIST NUMBER	15
5.11 DELETE AN ENTRY IN THE CALL LIST	15
5.12 DELETE ALL CALL LIST ENTRIES	15
6. REMOTE OPERATION	16
6.1 TURN THE ANSWERING MACHINE ON/OFF	16
6.2 LISTEN TO THE MESSAGES IN THE ANSWERING MACHINE	16
6.3 DELETE ALL MESSAGES IN THE ANSWERING MACHINE	16
6.4 RECORD MESSAGES	16
6.5 ANSWERING MACHINE SETTINGS	16
6.5.1 SET THE ANSWER MODE	16
6.5.2 SET THE OUTGOING MESSAGE (OGM) LANGUAGE	16
6.5.3 RECORD YOUR OWN OUTGOING MESSAGE (OGM)	16
6.5.4 PLAYBACK (OGM)	16
6.5.5 SET THE ANSWER ONLY DELAY	16
6.5.6 SET THE RECORDING TIME OF INCOMING MESSAGE	16
6.5.7 ACTIVATE REMOTE ACCESS	16
6.5.8 CALL SCHEDULING	16
7. TROUBLESHOOTING	27
7.1 DECLARATION OF CONFORMITY	28
7.2 REMOTE OPERATION	29
7.3 GUARANTEE AND SERVICE	30

7.1 DATE & TIME	17
7.1.1 CHANGE DATE FORMAT	17
7.1.2 CHANGE TIME FORMAT	17
7.1.3 SET THE DATE	17
7.1.4 SET THE TIME	17
7.2 ALARM	17
7.2.1 TURN OFF THE ALARM	17
7.2.2 SET AND TURN ON THE ALARM	17
7.2.3 SET THE ALARM MELODY	17
8. SETTINGS	19
8.1 HANDESET SETTINGS	19
8.1.1 SET THE AUDIO VOLUME	19
8.1.2 SET THE INTERNAL RINGER MELODY	19
8.1.3 SET THE EXTERNAL RINGER MELODY	19
8.1.4 ADJUST THE RINGER VOLUME	19
8.1.5 SET THE ALERT TONES	19
8.1.6 SET THE HANDESET LANGUAGE	19
8.1.7 NAME THE HANDESET	19
8.1.8 SELECT A COLOUR THEME	20
8.1.9 SET THE CONTRAST LEVEL	20
8.1.10 TURN ON OR OFF THE AUTO ANSWER	20
8.1.11 SELECT BASE STATION	20
8.1.12 RESET HANDESET SETTINGS TO DEFAULT	20
8.2 BASE SETTINGS	21
8.2.1 DE-REGISTER A HANDESET	21
8.2.2 CHANGE THE DIAL MODE	21
8.2.3 CHANGE THE RECALL (FLASH) TIME	21
8.2.4 CHANGE THE SYSTEM PIN CODE	21
8.2.5 RESET BASE SETTINGS TO DEFAULT	21
8.3 REGISTRATION	22
8.4 ANSWERING MACHINE	23
9.1 TURN THE ANSWERING MACHINE ON/OFF	23
9.2 LISTEN TO THE MESSAGES IN THE ANSWERING MACHINE	23
9.3 DELETE ALL MESSAGES IN THE ANSWERING MACHINE	23
9.4 RECORD MESSAGES	23
9.5 ANSWERING MACHINE SETTINGS	24
9.5.1 SET THE ANSWER MODE	24
9.5.2 SET THE OUTGOING MESSAGE (OGM) LANGUAGE	24
9.5.3 RECORD YOUR OWN OUTGOING MESSAGE (OGM)	24
9.5.4 PLAYBACK (OGM)	24
9.5.5 SET THE ANSWER ONLY DELAY	24
9.5.6 SET THE RECORDING TIME OF INCOMING MESSAGE	24
9.5.7 ACTIVATE REMOTE ACCESS	25
9.5.8 CALL SCHEDULING	25
10. TROUBLESHOOTING	27
10.1 DECLARATION OF CONFORMITY	28
10.2 REMOTE OPERATION	29
10.3 GUARANTEE AND SERVICE	30

IMPORTANT SAFETY INSTRUCTIONS

When using your telephone equipment, basic safety precautions should always be followed to reduce the risk of fire, electric shock and injury, including the following:


- Read and understand all the instructions.
- Follow all warnings and instructions marked on the product.
- Unplug this product from the wall outlet before cleaning. Do not use liquid cleaners or aerosol cleaners. Use a damp cloth for cleaning.
- Keep phone away from hot, humid conditions or strong sunlight, and don't let it get wet or use this product near water (for example, near a bath tub, kitchen sink, swimming pool).
- Do not use the telephone to report a gas leak in the vicinity of the leak.
- Unplug this product from the wall outlet and refer servicing to the following conditions:
 - When the power supply cord or plug is damaged or frayed.
 - If the product does not operate normally following the operating instructions.
 - If the product has been dropped and the cabinet has been damaged.
 - If the product exhibits a distinct change in performance.
- NEVER use your phone outdoors during a thunderstorm-unplug the base from the telephone line and the mains socket when there are storms in your area. Damage caused by lightning is not covered by the guarantee.
- Do not use the telephone to report a gas leak in the vicinity of the leak.
- Use only the supplied NiMH (Nickel Metal Hydride) batteries! The operation periods for the handsets are only applicable with the default battery capacities.
- The use of other battery types or non-rechargeable batteries/primary cells can be dangerous. These may cause interference and/or damage to the unit and surroundings. The manufacturer will not be held liable for damage arising from such non-compliance. The manufacturer will not be held liable for damage arising from such non-compliance.
- Do not use third party charging bays. Damage may be caused to the batteries.
- Please ensure the battery plug is fully inserted into the battery compartment.
- Dispose of batteries safely. Do not immerse them in water, burn them, or put them where they could get punctured.

CAUTION: RISK OF EXPLOSION IF BATTERY IS REPLACED BY AN INCORRECT TYPE. DISPOSE OF USED BATTERIES ACCORDING TO THE INSTRUCTIONS

Package contents
The package contains the following items:
Single
• 1 Handset
• 1 Mains power adapter
• 1 Telephone line cord
• 1 Rechargeable battery pack
• 1 User manual

Note: If you have a Twin, Triple or Quad system, you will also have the requisite extra handset(s) and batteries, and a charger pad for your extra handset.

Connection and conditions for use:
You can connect your phone to a direct exchange line (DEL) on a local exchange with its own phone number; or to an extension socket connected to a DEL; or to an extension on an approved compatible PEX. Do not connect as an extension to a payphone. The ringer equivalence numbers (REN) of all equipment (phones, fax machines, modems, etc.) connected to an exchange line must not add up to more than 4, otherwise one or more of them may not ring and/or answer calls correctly. The phone has a REN of 1, and most other telephones have a REN of 1, unless marked otherwise. To use your handset and base together, you must be able to establish a radio link between them. The signal between the handset and the base is in accordance with the normal standards for a DECT phone. Maximum range up to 300 metres outdoors or 50 metres indoors. The signal strength may decrease if there is any large metal object between the handset and the base, such as a refrigerator, a mirror, a filing cabinet, metallic doors or reinforced concrete. The signal strength may also be reduced by other solid structures like walls, or by other radio or electrical interference.



3 GET TO KNOW YOUR PHONE

3.1 Handset Overview

In lists: move up the options
During calls/ringing: increase the volume.

UP ▲
Use to select function given on display above - PB (phonebook), Back, Clear.

RIGHT SOFT KEY —
Use to select function given on display above - PB (phonebook), Back, Clear.

LEFT SOFT KEY —
Use to select function given on display above - Menu, Select, OK, Mute, Unmute.

TALK ON TALK —
Make or answer calls.

RIGHT/CALL LIST —
In editing/predialing mode: move the cursor to the right.

DOWN / REDIAL LIST —
From idle: access the Redial List
In lists: move down the options
During calls / ringing: decrease the volume.

ALPHANUMERIC KEYPAD, (STAR), # (HASH) —
For dialling and entering names, with additional long press functions for:
* key - keypad lock and to switch character sets.
0 key - to insert a dialling pause
key - handset ringer on/off and to switch character cases.

MICROPHONE —
Turns the speakerphone on/off.

SPEAKERPHONE —
Turns the speakerphone on/off.


INTERCOM —
Make an intercom call or conference call.

3.2 Display Icons and Symbols

The screen display gives you information on the current status of the telephone.

Icons	Description
[Signal strength bars]	Steady when the handset is in range of the base. More bars will show when the signal strength is strong. Flashes when the handset is not registered to the base, or out of range of the base.
[Alarm icon]	Indicates that the alarm is set. Flashes when the alarm time is reached.
[Intercom icon]	Indicates an intercom is in progress.
[Incoming call icon]	Indicates a call is in progress. Flashes when there is an incoming call. Indicates that speakerphone is being used.
[Ringer icon]	Indicates that the handset ringer is switched off.
[Answering machine icon]	Indicates the answering machine is turned on.
[Volume icon]	Flashes when the answering machine memory is full. Indicates when new VMWI message is received. (This is a Caller Display service and is not usually available on UK network providers.) Indicates that the keypad is locked.
[Battery icon]	Indicates when the battery is fully charged. Indicates when the battery is 2/3 charged. Indicates when the battery is 1/3 charged. Flashes when low battery is detected to indicate that it needs charging. Battery icons cycle during charging.
[Keypad lock icon]	Indicates when the keypad is locked.
[Call timer icon]	Indicates when the call timer is active.
[Redial icon]	Indicates when the redial function is active.
[Flash icon]	Indicates when the flash function is active.
[Intercom icon]	Indicates when intercom is active.


3.3 Base Station with Telephone Answering Machine (TAM) Control



- DELETE X**
Press once to delete the message during playback.
Press and hold to delete all the messages.
Note: New voice messages will not be deleted.
- VOLUME UP (+)**
Increase (+) speaker volume during message playback.
- TAM ON/OFF** **(*)**
Press to turn on the answering machine.
Press again to turn off the answering machine.
- SKIP FORWARD** **(▶)**
Press to skip the current message and play the next message.
- PLAY/STOP** **(▶/■)**
Press to play the message.
Press again to stop the message playback.
- SKIP BACKWARD** **(◀)**
Press to skip back to the beginning of the current message. Press twice to skip backward to the previous message.
- VOLUME DOWN (-)**
Decrease (-) speaker volume during message playback.
- PAGE** **(*)**
Press the Page on the base station to page your registered handset(s).
Press and hold to start registration process.

3.4 Base Two Digit-LED Display Information

Display	Meaning
0F-> --	Displayed when the answering machine is turned OFF
0n-> XX	Displayed when the answering machine is turned ON where XX is number of messages in TAM memory
00	Steady ON: No voice messages in the TAM.
XX	Flashing: There are XX new messages recorded where XX is from 01 to 59.
ZZ	Steady ON: There are ZZ old messages in the TAM memory and no new messages.
XXFF	Flashing XX alternately with FF: There are XX new voice messages recorded and the TAM memory is full.
FF	Flashing FF: The TAM memory is full and there are no new messages.
-/XX	Flashing XX alternately with -: The Time/Date is not set and there are XX new messages recorded.
XX	Flashing -: The Time/Date is not set and there are no new messages recorded.
A1/A2	Steady ON: Playing the current outgoing message (OGM) where A1 is the Answer & Record OGM and A2 is the Answer Only OGM.
XX/An	Flashing XX alternately with An: Currently recording the new XX incoming message.
rA	Flashing: Remote access is in progress from a handset or via the external line.
LX	Steady ON: Indicates the current volume level where X is from 1 to 8.



Or you can press <OFF> and leave the external call ringing the called handset. If the called handset does not answer the call within 60 seconds the call will be returned to the calling handset and it will ring.

4.1.1.3 Switch calls between an external call and an internal call
1. Press <INT> and select the handset you want to call.
2. The external call is put on hold automatically and the called handset rings.
3. Press <TALK> <SPEAKERPHONE> <Accept> on the called handset to establish an internal call.
4. Press <INT> on the calling handset to switch between the external call and the internal call.

4.1.1.4 Make a 3-way conference call
The conference call feature allows one external call to be shared with two handsets (in intercom). The three parties can share the conversation and no additional network subscription is required.
1. Follow Steps 1 to 3 in section 4.1.1.2.
2. Press and hold <INT> to establish the 3-way conference.
Note: If the handset can exit from the conference by pressing <OFF>, leaving the other handset still connected to the external call.

5. PHONEBOOK
Your phone can store up to 30 private phonebook entries with names and numbers. Each phonebook entry can have a maximum of 24 digits for the phone number and 12 characters for the name. You can also select different ringtones for your phonebook entries. (Note: The different ringtone only apply if you subscribe to Caller Display and the incoming number matches the stored number) Phonebook entries are stored alphabetically by name.

5.1. Add a New Entry
In idle:
1. Press <Menu> and <UP/DOWN> to scroll to **Phonebook**
2. Press <Select> to access the phonebook menu.
3. Press <UP/DOWN> and <Select> to select **Edit**.
4. Enter the name and press <OK> then enter the number.
Note: When entering the name you can press and hold <C> to toggle between upper case and lower case letters, and you can switch between different character sets (see 3.6) if you press and hold the <C> key.
You must enter something in both the name and number fields to be able to save an entry.
5. Press <OK> to go to the first melody and <RIGHT/LEFT> to select the melody. Each melody will play as it is selected.
6. Press <OK> to confirm the melody and to save the phonebook entry.
Note: If the name is the same as one already in the phonebook, the screen will display **Name Existed**, and then return to the name entry screen.

5.2. Edit an Entry
In idle:
1. Press <Menu> and <UP/DOWN> to scroll to **Phonebook**
2. Press <Select> to access the phonebook menu.
3. Press <UP/DOWN> and <Select> to select **Edit**.
4. Press <UP/DOWN> and <Select> to select the phonebook entry you want to change.
5. Enter the revised name, phone number and Melody.
6. Press <OK> to confirm.

5.3. View an Entry
In idle:
1. Press <Right Soft Key/PB> to access the phonebook.
2. Enter the first character of the name by pressing the appropriate digit key a number of times, for example for C press the 2 key three times.
3. Press <UP/DOWN> to highlight the phonebook entry you want to view.
4. Press <Select> to view the details of the selected phonebook entry.
OR
1. Press <Menu> and <UP/DOWN> to scroll to **Phonebook**
2. Press <Menu> and <UP/DOWN> to scroll to **Phonebook**
3. Press <Select> to access the phonebook menu.
4. Press <UP/DOWN> and <Select> to select **View**.
5. Press <UP/DOWN> to highlight the phonebook entry you want to view.
6. Press <Select> to view the details.

5.4. Delete an Entry
In idle:
1. Press <Menu> and <UP/DOWN> to scroll to **Phonebook**
2. Press <Select> to access the phonebook menu.
3. Press <UP/DOWN> and <Select> to select **Delete**.
4. Press <UP/DOWN> and <Select> to select the phonebook entry you want to delete.
5. Press <Select> to view the details.

3.6.3 Greek Character Table (Uppercase)

0	SP	0	-	+	=	_	()	"	'	[]	{ }	<	>	/	\	^	~	
1	1	-	.	:	;	!	?	~	#	&	%	\$	€	@	£	¤	¥	§
2	A	B	Γ	Δ	Ε	Ζ	Η	Θ	Ι	Κ	Λ	Μ	Ν	Ξ	Ο	Π	Ρ	Σ
3	Τ	Υ	Φ	Χ	Ψ	Ω	Α	Β	Γ	Δ	Ε	Ζ	Η	Θ	Ι	Κ	Λ	Μ
4	Ν	Ξ	Ο	Π	Ρ	Σ	Τ	Υ	Φ	Χ	Ψ	Ω	Α	Β	Γ	Δ	Ε	Ζ
5	Η	Θ	Ι	Κ	Λ	Μ	Ν	Ξ	Ο	Π	Ρ	Σ	Τ	Υ	Φ	Χ	Ψ	Ω
6	Α	Β	Γ	Δ	Ε	Ζ	Η	Θ	Ι	Κ	Λ	Μ	Ν	Ξ	Ο	Π	Ρ	Σ
7	Τ	Υ	Φ	Χ	Ψ	Ω	Α	Β	Γ	Δ	Ε	Ζ	Η	Θ	Ι	Κ	Λ	Μ
8	Ν	Ξ	Ο	Π	Ρ	Σ	Τ	Υ	Φ	Χ	Ψ	Ω	Α	Β	Γ	Δ	Ε	Ζ
9	Η	Θ	Ι	Κ	Λ	Μ	Ν	Ξ	Ο	Π	Ρ	Σ	Τ	Υ	Φ	Χ	Ψ	Ω

4 USE YOUR PHONE

- 4.1 Power on the Handset**
If your handset is powered off, press and hold <OFF> to turn on the handset. You can press and hold <OFF> again to power off the handset.
- 4.2.2 Direct dialling**
Press <TALK> to connect to the line and then enter the phone number.
(Note: If you enter a wrong digit you cannot correct it with the <Clear> key.)
- 4.2.3 Call from the phonebook**
Press <Right Soft Key> to access the phonebook and press <UP/DOWN> to select the desired phonebook entry.
Press <TALK> or <#> to dial out the selected phonebook entry.
- 4.2.4 Call from the call list (Only available with Caller Display)**
Press <Call> to access the call list and press <UP/DOWN> to select the desired call list entry.
Press <TALK> or <#> to dial out to the selected call list entry.
- 4.2.5 Call from the redial list**
Press <Redial> to access the redial list and press <UP/DOWN> to select the desired redial number.
Press <TALK> or <#> to dial out to the selected redial number.
- 4.2.6 Call timer**
Your handset automatically times the duration of every call. The call timer is displayed when you make one or answer a call and remains on the screen for 5 seconds after the end of the call. It is shown in hours, minutes and seconds format (HH:MM:SS).
- 4.3 Answer a call**
If the handset is not on the charging cradle:
When the phone rings, press <TALK> <#> / <Accept> to answer a call.
Note: If AUTO ANSWER is set to ON, then ringing the handset off the base or charger will answer the call automatically, and no buttons need to be pressed.
- 4.4 End a Call**
During a call connection, press <OFF> to end the call.
OR
Put the handset on the base station or charger to end the call.
- 4.5 Adjust Earpiece and Handfree Volume**
The volume level can be adjusted over 5 levels for each of the earpiece and handfree volumes.
During a call:
Press <UP> or <DOWN> to increase or decrease the volume level respectively. The current setting is shown. When you end the call, the volume settings will still remain at the last selected level.
- 4.6 Mute a Call**
You can talk to someone nearby without letting the caller hear you during a call.
During a call:
Press <Mute/Left Soft Key> to mute the microphone. Your caller cannot hear you. Press <Unmute/Left soft key> again to unmute the microphone.
- 4.7 Turn Off the Handset Ringer**
In idle, press and hold <R> to turn off the ringer. The ringer off icon is displayed on the LCD.
Note: When there is an incoming call, the display will still flash the Call icon and show "Incoming Call", with any Caller Display number, even if the ringer is turned off.
To turn the ringer back on, press and hold <R> again.
- 4.8 Redial**
You can redial any of the last 20 numbers called. If you have stored a name in the phonebook to go with the number, the name will be displayed instead.

- 4.8.1 Redial a number from the redial list**
1. Press <DOWN/REDIAL> to access the redial list.
2. Press <UP/DOWN> to browse the redial list.
3. Press <Select> to dial to the selected redial number.
- 4.8.2 Save a redial number into the phonebook**
Note: If there are no numbers in the redial list, the display shows "List Empty"
1. Press <DOWN> and then <UP/DOWN> to find the redial number you want to save.
2. Press <Select> to select the redial number.
3. Press <Menu> and <UP/DOWN> to select **Add to PB**.
4. Press <TALK> to browse the ringtone list. The respective ringtone will be played when browsing the ringtone list. (Note: the selected melody will only be played if you subscribe to Caller Display and the incoming number matches the stored number.)
- 4.8.3 Delete a redial number**
1. Press <DOWN> and then <UP/DOWN> to find the redial number you want to delete, and then press <Select>.
2. Press <Menu> and <UP/DOWN> to select **Delete**.
3. Press <OK> to confirm. All

If you subscribe to Caller Display, the time and date settings will be automatically updated by the network when you receive a call, although the year is not set, so you may need to set it. You can also change the format of how the time and date are displayed, and set an alarm on your handset.

- 7.1 Date & Time**
- 7.1.1 Change date format**
- Press <Menu> and <UP/DOWN> to select **Clock/Alarm**.
 - Press <Select> and <UP/DOWN> to select **Date & Time**.
 - Press <Select> and <UP/DOWN> to select **Date Format**.
 - Press <Select> and <UP/DOWN> to select your desired date format from **DD-MM-YYYY** or **MM-DD-YYYY**.
 - Press <Select> to confirm.
- 7.1.2 Change time format**
- Follow steps 1 to 2 in Section 7.1.1.
 - Press <Select> and <UP/DOWN> to select **Time Format**.
 - Press <Select> and <UP/DOWN> to select your desired time format from **12 Hours** or **24 Hours**.
 - Press <Select> to confirm.
- 7.1.3 Set the date**
- Follow steps 1 to 2 in Section 7.1.1.
 - Press <Select> and <UP/DOWN> to select **Set Date**.
 - Press <Select> and then enter the date according to the date format you set in Section 7.1.1
- Note: If an incorrect input is detected, an error tone will be emitted, the date will not be saved and you can try again to enter a valid date.
4. Press <OK> to confirm.

- 7.1.4 Set the time**
- Follow steps 1 to 2 in Section 7.1.1.
 - Press <Select> and <UP/DOWN> to select **Set Time**.
 - Press <Select> and then enter the time according to the time format you set in Section 7.1.2.
- Note: If an incorrect input is detected, an error tone will be emitted and the cursor will stop at the incorrect input.
- When the cursor is at the AM/PM field, press <UP/DOWN> to select **AM** or **PM**.
 - Press <OK> to confirm.

7.2 Alarm

You can set an alarm on the handset. When an alarm is set, the <🔔> displays on the LCD. When the alarm time is reached, the <🔔> and <Alarm On> flash on the handset display, and the alarm melody rings for a duration of 4 seconds. You can press any key to stop the alarm. If the snooze function is activated, the alarm will sound again at the end of the snooze period of two minutes. When the alarm time is reached, you can press <Off> or <OFF> to stop the alarm and turn off the snooze function.

Note:

- A key press will still disable the alarm even if the handset keypad is locked when the alarm rings.
- The alarm volume level is the same as the settings of the handset ringer volume. If the handset ringer is set to **Volume Off**, the alarm still sounds at **Volume 1** level.
- During an external call or internal call, if an alarm is set and when the alarm time is reached, the <🔔> and <Alarm On> will still flash. You can press <On> or <OFF> to turn off the alarm or any other key to activate the snooze. If set, and the display will revert to the call duration operations.
- During ringing, the alarm will not sound when the alarm time is reached. However, if the snooze function is enabled at the end of the snooze period provided that it is not ringing or in paging mode at the end of the snooze period.

- 7.2.1 Turn off the alarm**
- Press <Menu> and <UP/DOWN> to select **Clock/Alarm**.
 - Press <Select> and <UP/DOWN> to select **Alarm On**.
 - Press <Select> and <UP/DOWN> to select **Alarm Off**.
 - Press <Select> to confirm.

9 ANSWERING MACHINE

Your phone includes a telephone answering machine (TAM) that records unanswered calls when it is on. The answering machine can store up to 59 messages within the maximum recording time of approximately 17 minutes. As well as recording incoming messages, you can record memos for other users of your phone. If the answering machine memory is full, the <📞> icon on the handset will flash, and <FF> will be shown on the base display. Some answering machine functions can be operated from the base, including playing messages, deleting messages, and turning the answering machine on or off. See section 9.3 Base Station with Telephone Answering Machine for further details of button operations.

The following sections give the operating instructions for the answering machine from the handset.

9.1 Turn the Answering Machine On/Off

You can turn the answering machine on or off using the handset menu. When the answering machine is set to ON and is set to answer after the set answer delay and the caller can then leave you a message.

When the answering machine is set to OFF, calls will be answered after 14 rings and the answer only message will be played to your callers. They will not be able to leave you a message.

- Press <Menu> and <UP/DOWN> to scroll to **Answer Machine**.
- Press <Select> and <UP/DOWN> to scroll to **TAM On/Off**.
- Press <Select> and <UP/DOWN> to scroll to **On** or **Off**.
- Press <OK> to confirm.

Note: If the answering machine is set to On, the <📞> icon will be shown on the handset standby display.

- If the answering machine is set to Off, the <📞> icon will not be on the handset display.

9.2 Listen to the Messages in the Answering Machine

When new messages are recorded on the answering machine, the handset display shows "New CallMsg" until all new messages have been played, and the base display flashes the number of new messages.

After a new message is played it is saved as an old message automatically, unless it is deleted. Old messages are played after all new messages have been played.

- Press <Menu> and <UP/DOWN> to select **Answer Machine**.
- Press <Select> and <UP/DOWN> to select **Playback**.
- Press <Select> to start message playback and the screen displays the message number and the date and time information of the message recording.

Note: If there are no messages recorded, the display will briefly show "1 No Messages".

Note: An asterisk is placed in front of the message number to indicate that it is a new message.

After a message has been played, the asterisk will disappear and will not be shown if you listen to this message again.

During message playback, press <UP> or <DOWN> to increase or decrease the message playback volume respectively. For privacy, you can listen via the earpiece by pressing the Speakerphone button <📞> to switch between loudspeaker and earpiece.

4. During message playback, press <Menu> and <UP/DOWN> to select **Stop**, **Next**, **Previous** or **Delete**.

5. Press <Select> to perform the following functions.

Stop: Stop the current message playback and return to the **Answer Machine** menu.

Next: Skip to play the next message. The date and time information of the next message will display if there is next message.

Previous: Skip to repeat playing the current message from the beginning. The date and time information of the current message will display.

Delete: Delete the current message and start playing the next message.

Note: Alternatively, you can use the following shortcut keys on the handset to control different operations during message playback.

Press <Key 5> to stop message playback.

Press <Key 4> once to restart the current message from the beginning. Press twice to skip backward to play the previous message.

Press <Key 6> to skip forward and play the next message.

Press <Key 2> to delete the current message being played.

Keys	Functions
2	While message is not playing
4	Delete the current message playback from the beginning. Press twice to skip backward to play the previous message.
5	Play the message
6	Skip to play the next message
7	Turn on the answering machine
8	Stop the current message playback
9	Turn off the answering machine

9.3 Delete All Messages in the Answering Machine

- Press <Menu> and <UP/DOWN> to select **Answer Machine**.
- Press <Select> and <UP/DOWN> to select **Delete All**.
- Press <Select> to show "7 Delete Confirm".
- Press <OK> to delete all old messages. (Note: New messages will not be deleted).

8 SETTINGS

Your phone comes with a selection of settings that you can change to personalise your phone the way you like it to work.

8.1 Handset Settings

8.1.1 Set the audio volume

To adjust the volume of the sound in the earpiece or loudspeaker.

- Press <MENU> and <UP/DOWN> to select **HS Settings**.
- Press <Select> and <UP/DOWN> to select **Audio Setup**.
- Press <Select> and <UP/DOWN> or <LEFT/RIGHT> to select the volume level from level 1 to level 5.
- Press <OK> to confirm.

8.1.2 Set the internal ringer melody

To set the ringer melody that will sound when an intercom call is received.

- Press <MENU> and <UP/DOWN> to select **HS Settings**.
- Press <Select> and <UP/DOWN> to select **Ring Setup**.
- Press <Select> and <UP/DOWN> to select **Internal Ring**.
- Press <Select> and <UP/DOWN> to select your desired internal ringer melody (10 ringer melodies and 5 standard tones are provided).
- Press <Select> to confirm.

Note: The respective ringer melody will be played while browsing the melody list.

8.1.3 Set the external ringer melody

To set the ringer melody that will sound when an external call is received.

- Press <MENU> and <UP/DOWN> to select **HS Settings**.
- Press <Select> and <UP/DOWN> to select **Ring Setup**.
- Press <Select> and <UP/DOWN> to select **External Ring**.
- Press <Select> and <UP/DOWN> to select your desired external ringer melody (10 ringer melodies and 5 standard tones are provided).
- Press <Select> to confirm.

Note: The respective ringer volume will be played while browsing the melody list.

8.1.4 Adjust the Ringer Volume

- Press <MENU> and <UP/DOWN> to select **HS Settings**.
- Press <Select> and <UP/DOWN> to select **Ring Volume**.
- Press <Select> and <UP/DOWN> or <LEFT/RIGHT> to select your desired ringer volume level from Level 1 to Level 5 or Ringer Off.
- Press <Select> and <UP/DOWN> to select **Ring Volume**.
- Press <Select> to confirm.

Note: The respective ringer volume will be played while changing the levels.

If **Volume Off** is selected, <🔔> icon will display.

5. Press <OK> to confirm.

8.1.5 Set the alert tones

Three different alert tones are set on by default, but can be turned off, if desired.

Key Tone - a single beep is emitted when you press a key.

Low Battery Tone - emitted while you are talking on the phone to alert you that you need to charge the handset battery.

Out of Range Tone - emitted while you are talking on the phone to alert you to move closer to the base station.

- Press <MENU> and <UP/DOWN> to select **HS Settings**.
- Press <Select> and <UP/DOWN> to select **Alert Tones**.
- Press <Select> and <UP/DOWN> to select **Key Tone / Battery Low / Out of Range**.
- Press <Select> and <UP/DOWN> to turn on or off these tones.
- Press <Select> to confirm.

8.1.6 Set the Handset Language

If required, you can change the language used for the handset display.

- Press <Menu> and <UP/DOWN> to select **HS Settings**.
- Press <Select> and <UP/DOWN> to select **Language**.
- Press <Select> and <UP/DOWN> to select the desired language.
- Press <Select> to confirm.

8.1.7 Rename the handset

If required, the handset name shown on the standby screen can be changed from its default of "Handset".

- Press <Menu> and <UP/DOWN> to select **HS Settings**.
- Press <Select> and <UP/DOWN> to select **Rename HS**.
- Press <Select> and then enter your desired handset name. Press <Clear> to delete one character or press and hold <Clear> to delete the whole character string.
- Note: The maximum number of characters for the handset name is 10.
- Press <OK> to confirm.

8.1.8 Select a colour theme

To change the colours used in the handset display:

- Press <Menu> and <UP/DOWN> to select **HS Settings**.
- Press <Select> and <UP/DOWN> to select **Colour Theme**.
- Press <Select> and <UP/DOWN> to select the colour theme you prefer. There are four colour themes, and the display colours will change as you step through the list of options.
- Press <Select> to confirm.

8.1.9 Set the contrast level

To change the contrast level of the handset display:

- Press <Menu> and <UP/DOWN> to select **HS Settings**.
- Press <Select> and <UP/DOWN> to select **Contrast**.
- Press <Select> and <UP/DOWN> to select the contrast level you prefer. There are four contrast levels, and the contrast will change as you step through the list of options.
- Press <Select> to confirm.

8.1.10 Turn on or off the auto answer

When the Auto Answer is turned on, you can answer a call automatically by just lifting the handset off the base or charger, without having to press any key.

- Press <Menu> and <UP/DOWN> to select **HS Settings**.
- Press <Select> and <UP/DOWN> to select **Auto Answer**.
- Press <Select> and <UP/DOWN> to turn on or off the Auto Answer feature.
- Press <Select> to confirm.

8.1.11 Select base station

Your handset can be registered to up to four different base stations, but can only link to one base at a time. To select the base you want to use:

- Press <Menu> and <UP/DOWN> to select **HS Settings**.
- Press <Select> and <UP/DOWN> to select **Select Base**.
- Press <Select> and <UP/DOWN> to select your desired base station.
- Note: The currently selected base is indicated in the list by an asterisk.
- Press <Select> to confirm.
- Press <OK> to show "Confirm".

Note: If the selected base is found successfully, "Saved" will display, otherwise, "Fail" will display.

8.1.12 Reset handset settings to default

You can reset your phone to the default settings. After a reset, all your handset settings will be reset, and your redial and calls lists made empty, but your phonebook entries remain unchanged.

- Press <Menu> and <UP/DOWN> to select **HS Settings**.
- Press <Select> and <UP/DOWN> to select **Reset**.
- Press <Select> and then enter the 4-digit system PIN (Default 4-digit system PIN: 0000)
- Press <OK> to show "Confirm".
- Press <OK> again to confirm the reset.

Note: If the PIN code is entered correctly and confirmed, the handset will chime and the display will return to its standby screen.

If the PIN code is entered incorrectly, "PIN Invalid" will display.

8.2 Base Settings

8.2.1 De-register a Handset

This operation should only be necessary if one of your handsets becomes faulty or lost and needs to be replaced.

You will need to enter the 4-digit system PIN code (default 0000) in order to de-register a handset from the base station. A de-registered handset will have the antenna icon flashing and "1 Unregistered" on the display.

Note: You cannot de-register the handset that you are currently using.

- Press <Menu> and <UP/DOWN> to select **Base Settings**.
- Press <Select> and <UP/DOWN> to select **Delete HS**.
- Press <Select> and you are requested to enter the 4-digit system PIN.
- Enter the 4-digit system PIN.
- Press <OK> and a list of registered handsets is displayed.
- Press <UP/DOWN> to select the handset that you want to de-register.
- Press <Select> to confirm.

Note: If handset de-registration is successfully done, "HS Deleted" will display.

8.2.2 Change the dial mode

You should normally leave the dial mode at its default setting of Tone (also called DTMF), unless the phone is connected to an old exchange that only recognises Pulse dialling.

Note: If Pulse dialling is set, you can press the <-> key to switch to Tone dialling for the rest of that call.

- Press <Menu> and <UP/DOWN> to select **Base Settings**.
- Press <Select> and <UP/DOWN> to select **Dial Mode**.
- Press <Select> and <UP/DOWN> to select **Tone** or **Pulse**.
- Press <Select> to confirm.

8.2.3 Change the Recall (Flash) Time

You may need to change the Recall (Flash) time if your phone is connected to a PBX. The recall time options are Short (the default value of 100ms) Medium (300ms) or Long (600ms).

- Press <Menu> and <UP/DOWN> to select **Base Settings**.
- Press <Select> and <UP/DOWN> to select **Flash Time**.
- Press <Select> and <UP/DOWN> to select your desired Recall (Flash) time (Short, Medium, Long).
- Press <Select> to confirm.

8.2.4 Change the system PIN Code

A 4-digit system PIN code is used for changing the system settings of the base station. It is used to protect your phone against unauthorised use. The default system PIN code is 0000.

- Press <Menu> and <UP/DOWN> to select **Base Settings**.
- Press <Select> and <UP/DOWN> to select **Modify PIN**.
- Press <Select> to show a "Old PIN" with the cursor line flashing after it.
- Enter the current 4-digit system PIN.
- Press <Select> and <UP/DOWN> to select your desired system PIN.
- Press <OK> and enter your new 4-digit system PIN again.
- Press <OK> to confirm.

Note: If the new PIN entered in Step 6 is not the same as the new system PIN entered in Step 5, New PIN Invalid is displayed and you must enter your new remote access PIN again in step 5.

8.2.5 Reset base settings to default

You can reset your phone to the default settings. After a reset, all your base and answering machine settings will be reset, including erasing all answering machine messages, but your phonebook entries remain unchanged.

- Press <Menu> and <UP/DOWN> to select **Base Settings**.
- Press <Select> and <UP/DOWN> to select **BS Default**.
- Press <Select> and then enter the 4-digit system PIN (Default 4-digit system PIN: 0000)
- Press <OK> to show "Confirm".
- Press <OK> again to confirm the reset.

Note: If the PIN code is entered correctly and confirmed, the handset will chime and the display will return to the Base Settings menu. If the PIN code is entered incorrectly, "PIN Invalid" will display.

8.3 Registration

IMPORTANT: When you purchase your Fusion 2025 system, all handsets are already registered to the base, so you do not need to register them. Handset registration is only necessary if you buy extra handsets or if a handset has become faulty. Up to five handsets can be registered to a base station, with each handset's number (1 to 5) shown on its display. A handset can be registered to up to four base stations. To register a new handset to your base:

- Press and hold <PAGE> on the base station for more than five seconds to put the base station into registration mode. It will stay in registration mode for about one minute, so the following handset sequence must be completed within this time.
- Press <Menu> and <UP/DOWN> to select **Registration**.
- Press <Select> and <UP/DOWN> to select the base number you want to register to. (If the handset is already registered to a base, it will be indicated by an asterisk.)
- Press <Select> and then enter the 4-digit system PIN. (Default 0000)
- Press <OK> to confirm and the handset shows "Waiting".

If the handset registration is successful, you will hear a confirmation tone and the display will return to idle screen, with the antenna icon steady on. The handset will automatically be allocated the next available handset number, which is shown in the handset display in standby mode. If the handset registration is unsuccessful, the display will time out and return to the base selection list.

9.5.4.2 Restore to default OGM

- Repeat Steps 1 to 4 in Section 9.5.4.1
- Press <Select> and <UP/DOWN> to select **Default**.
- Press <Select> and <OK> to confirm restoring to default OGM.

9.5.5 Set the Answer Delay

You can set the number of rings before the answering machine answers and starts playing your OGM. You can set the answering machine to answer after two to nine rings or **Time Saver**.

If **Time Saver** is set the answering machine will answer after 4 rings if there are no new messages, or after 2 rings if there is a new message, so if you call in and don't get an answer after 2 or 3 rings, you can hang up and save on call charges.

- Press <Menu> and <UP/DOWN> to select **Answer Machine**.
- Press <Select> and <UP/DOWN> to select **TAM Settings**.
- Press <Select> and <UP/DOWN> to select **Answer Delay**.
- Press <Select> and <UP/DOWN> to select from 2 Rings, 3 Rings, 4 Rings, 5 Rings, 6 Rings, 7 Rings, 8 Rings, 9 Rings or Time Saver.
- Press <Select> to confirm your choice.

9.5.6 Set the Recording Time of Incoming Message

You can set the maximum length of the recording time for each incoming message to be 60, 120 or 180 seconds, or unlimited up to the total recording time remaining on the answer machine.

- Press <Menu> and <UP/DOWN> to select **Answer Machine**.
- Press <Select> and <UP/DOWN> to select **TAM Settings**.
- Press <Select> and <UP/DOWN> to select **Recording Time**.
- Press <Select> and <UP/DOWN> to select from 60 Sec, 120 Sec, 180 Sec or Unlimited.
- Press <Select> to confirm your choice.

9.5.7 Activate Remote Access

Your phone lets you check your messages, or otherwise operate your answering machine, by calling the answering machine when you are away from home by entering a 4-digit remote access PIN on a tone-dialling phone. The 4-digit remote access PIN code is used to prevent other people from unauthorised access of your answering machine. The default remote access PIN is 0000.

9.5.7.1 Change the 4-Digit Remote Access PIN

- Press <Menu> and <UP/DOWN> to select **Answer Machine**.
- Press <Select> and <UP/DOWN> to select **TAM Settings**.
- Press <Select> and <UP/DOWN> to select **Chg Remote PIN**.
- Press <Select> and then enter the Old remote access PIN (Default Remote Access PIN is 0000).

Note: If the Old remote access PIN is incorrect, "Old PIN Invalid" is displayed and then it returns to the **Chg Remote PIN** menu.

- Press <OK> and then enter your new remote access PIN.
- Press <OK> and then enter your new remote access PIN again.
- Press <Select> to confirm.

Note: If the new remote access PIN entered in Step 6 is not the same as the new remote access PIN entered in Step 5, "New PIN Invalid" is displayed and you must enter your new remote access PIN again in step 5.

9.5.7.2 Activate or Deactivate the Remote Access

To allow remote access this option must be turned "On", but you can turn this option "Off" to prevent any remote access at all.

- Press <Menu> and <UP/DOWN> to select **Answer Machine**.
- Press <Select> and <UP/DOWN> to select **TAM Settings**.
- Press <Select> and <UP/DOWN> to select **Remote Access**.
- Press <Select> and <UP/DOWN> to select **On** or **Off** to turn on or off the remote access respectively.
- Press <Select> to confirm.

9.5.4.1 Playback the OGM

- Press <Menu> and <UP/DOWN> to select **Answer Machine**.
- Press <Select> and <UP/DOWN> to select **TAM Settings**.
- Press <Select> and <UP/DOWN> to select **OGM Settings**.
- Press <Select> and <UP/DOWN> to select **Answer & Record** or **Answer Only**.
- Press <Select> and <UP/DOWN> to select **Playback**.
- Press <Select> to playback your current OGM and "Playing" is displayed on the screen.
- Press <Back> to stop the OGM playback and return to the previous menu.

11 PRODUCT GUARANTEE

This product is guaranteed against manufacturing defects for a period of 1 Year. This does not cover the product where the fault is due to misuse, abuse, use in contravention of the instructions, or where the product has been the subject of unauthorised modifications or alterations, or has been the subject of commercial use.

In the event of a problem with the product within the guarantee period please return it to your nearest Argos store. If the item is shown to have had an inherent defect present at the time of sale, the store will provide you with a replacement. Your statutory rights remain unaffected.

Guarantor; Argos Ltd
489 - 499 Avenbury Boulevard
Central Milton Keynes
MK9 2NW

10 TROUBLESHOOTING

If you have difficulty with your phone, please try the suggestions listed below.

Problem	Cause	Solutions
No dialling tone when pressing <TALK> key	a. The connection cord of the base station is not plugged in. b. The adapter cord is not plugged in correctly in the base station. c. Another handset is using the base to make a call. d. Wrong telephone line cord	a. Check the connections. Unplug and plug back in the mains. b. Check the telephone line cord and the 25W plug (remove and plug in). c. Wait until the line is unoccupied. d. Use the original telephone line cord supplied.
When connected to a PBX, no and/or wrong connection after dialling.	Dialling prefix is needed.	Insert the dialling prefix.
"Searching" is displayed.	Base station out of range. Base station not activated or wrong setting.	Reduce the range. Connect base station to mains.
The call does not work.	Service not connected or wrong setting.	Check your Subscription with network or change the dial mode.
No display.	Empty battery.	Recharge battery.
Answering Machine	The call does not record new messages.	The answering machine is turned off. Turn on the answering machine.
The caller cannot leave a message.	a. The answering machine is turned off. b. Message memory is full. c. ANSWER ONLY mode is set.	a. Turn on the answering machine. b. Erase unnecessary messages. c. Change to ANSWER & RECORD mode.
I cannot operate the answering machine remotely.	a. You are entering the wrong remote access code. b. You are pressing the dial keys too quickly. c. You are using a pulse telephone.	a. If you forget the remote access code, reset to the default settings. b. Press each key firmly. c. Try again using a touch tone phone.
While recording an outgoing message or listening to recordings, the unit rings and recording stops.	A call is being received.	Answer the incoming call and try again to record your outgoing message later.

This telephone is not equipped with a grounding function! Therefore some of the functions may be limited when used in PBX systems.

Technical Support

If the fault persists...

Disconnect all other instruments connected to the same line as the Fusion 2025 and try to make a call. Disconnect the base unit from the telephone line and plug a different phone into the master telephone socket. Try making a call. If this works, the line is OK.

If the call does not work and you are using a two-way socket adapter, remove it and plug a telephone directly into the socket. If the call now works, the adapter may be faulty.

If you cannot make a call, the fault may be on the exchange line. Contact your telephone service provider.

If you still cannot identify the cause of the problem, please read out the serial number of this telephone to the Binatone Customer Service Center. The serial number can be found in the battery compartment after removing the batteries. For technical support, call Binatone Customer Service at 0845 345 9677 (UK only).

11 DECLARATION OF CONFORMITY

We the manufacturer / Importer : Binatone Telecom Pte
1 Playway London
NW2 7HF.

Declare under our sole responsibility that the following product
Type of equipment: Digital cordless telephone
Model Name: Binatone Fusion 2025 Series
Country of Origin: China
Brand: Binatone
complies with the essential protection requirements of R&TE Directive 1999/5/EC on the approximation of the laws of the Member States relating to *Radio Spectrum Matters*, the Council Directive 89/336/EEC on the approximation of the laws of the Member States relating to *electromagnetic compatibility (EMC)* and the European Community Directive 2006/95/EC relating to *Electrical Safety*.

The essential requirements of the product with the requirements relating to the essential requirements according to Article 3 R&TE was based on Annex III of the Directive 1999/5/EC and the following standard:
Radio Spectrum: EN 301406; V2.1.1 (2009-07);
EMC: EN 301489 -1; V1.8.1 (2008-04);
EN 301489 - 6; V1.3.1 (2008-08);
Electrical Safety: EN 60950-1:2006 + A11:2009

Manufacturer / Importer 30 Jun 2010
(signature of authorized person) Date Signature

The conformity to the requirements is validated by the symbol.

NOTE: In compliance with Directive 2002/95/EC, when you purchase a product that comes with the symbol shown on the right, you are required to dispose of electrical and electronic equipment by separate waste collection and you cannot dispose of the product as normal waste. This equipment and all its components, subsystems and consumable materials formed an integral part of this product and when you decide to dispose of them you have to take them to the local recycling centres for appropriate waste disposal, in compliance with the current regulations. Details about the location of these centres can be obtained from your local authority.

- 8.2 Base Settings**
- 8.2.1 De-register a Handset**
- This operation should only be necessary if one of your handsets becomes faulty or lost and needs to be replaced.
- You will need to enter the 4-digit system PIN code (default 0000) in order to de-register a handset from the base station. A de-registered handset will have the antenna icon flashing and "1 Unregistered" on the display.
- Note: You cannot de-register the handset that you are currently using.
- Press <Menu> and <UP/DOWN> to select **Base Settings**.
 - Press <Select> and <UP/DOWN> to select **Delete HS**.
 - Press <Select> and you are requested to enter the 4-digit system PIN.
 - Enter the 4-digit system PIN.
 - Press <OK> and a list of registered handsets is displayed.
 - Press <UP/DOWN> to select the handset that you want to de-register.
 - Press <Select> to confirm.
- Note: If handset de-registration is successfully done, "HS Deleted" will display.
- 8.2.2 Change the dial mode**
- You should normally leave the dial mode at its default setting of Tone (also called DTMF), unless the phone is connected to an old exchange that only recognises Pulse dialling.
- Note: If Pulse dialling is set, you can press the <-> key to switch to Tone dialling for the rest of that call.
- Press <Menu> and <UP/DOWN> to select **Base Settings**.
 - Press <Select> and <UP/DOWN> to select **Dial Mode**.
 - Press <Select> and <UP/DOWN> to select **Tone** or **Pulse**.
 - Press <Select> to confirm.
- 8.2.3 Change the Recall (Flash) Time**
- You may need to change the Recall (Flash) time if your phone is connected to a PBX. The recall time options are Short (the default value of 100ms) Medium (300ms) or Long (600ms).
- Press <Menu> and <UP/DOWN> to select **Base Settings**.
 - Press <Select> and <UP/DOWN> to select **Flash Time**.
 - Press <Select> and <UP/DOWN> to select your desired Recall (Flash) time (Short, Medium, Long).
 - Press <Select> to confirm.
- 8.2.4 Change the system PIN Code**
- A 4-digit system PIN code is used for changing the system settings of the base station. It is used to protect your phone against unauthorised use. The default system PIN code is 0000.
- Press <Menu> and <UP/DOWN> to select **Base Settings**.
 - Press <Select> and <UP/DOWN> to select **Modify PIN**.
 - Press <Select> to show a "Old PIN" with the cursor line flashing after it.
 - Enter the current 4-digit system PIN.
 - Press <Select> and <UP/DOWN> to select your desired system PIN.
 - Press <OK> and enter your new 4-digit system PIN again.
 - Press <OK> to confirm.
- Note: If the new PIN entered in Step 6 is not the same as the new system PIN entered in Step 5, New PIN Invalid is displayed and you must enter your new remote access PIN again in step 5.
- 8.2.5 Reset base settings to default**
- You can reset your phone to the default settings. After a reset, all your base and answering machine settings will be reset, including erasing all answering machine messages, but your phonebook entries remain unchanged.
- Press <Menu> and <UP/DOWN> to select **Base Settings**.
 - Press <Select> and <UP/DOWN> to select **BS Default**.
 - Press <Select> and then enter the 4-digit system PIN (Default 4-digit system PIN: 0000)
 - Press <OK> to show "Confirm".
 - Press <OK> again to confirm the reset.
- Note: If the PIN code is entered correctly and confirmed, the handset will chime and the display will return to its standby screen.
- If the PIN code is entered incorrectly, "PIN Invalid" will display.

8.3 Registration

IMPORTANT: When you purchase your Fusion

Free Manuals Download Website

<http://myh66.com>

<http://usermanuals.us>

<http://www.somanuals.com>

<http://www.4manuals.cc>

<http://www.manual-lib.com>

<http://www.404manual.com>

<http://www.luxmanual.com>

<http://aubethermostatmanual.com>

Golf course search by state

<http://golfingnear.com>

Email search by domain

<http://emailbydomain.com>

Auto manuals search

<http://auto.somanuals.com>

TV manuals search

<http://tv.somanuals.com>