

ServSwitch™

ServView 17S KVM Switch Quick Start Guide



 **BLACK BOX**
NETWORK SERVICES

KVT128AE-UK-8-R2
KVT128AE-UK-16-R2

CONTENTS

Chapter 1 **Getting Started**

1.1	Important Safeguards	1
1.2	Regulatory Notice	1-2
1.3	Before Installation	2

Chapter 2 **How to use your CAT5 KVM Switch**

2.1	Password	3
2.2	KVM OSD	4-5
2.3	KVM Hotkey	6-7

1.1 Important Safeguards

Please read all of these instructions carefully before you use the device. Save this manual for future reference.

What the warranty does **NOT** cover

- Any product, on which the serial number has been defaced, modified or removed.
- Damage, deterioration or malfunction resulting from:
 - Accident, misuse, neglect, fire, water, lightning, or other acts of nature, unauthorised product modification, or failure to follow instructions supplied with the product.
 - Repair or attempted repair by anyone not authorised by us.
 - Any damage of the product due to shipment.
 - Removal or installation of the product.
 - Causes external to the product, such as electric power fluctuation or failure.
 - Use of supplies or parts not meeting our specifications.
 - Normal wear and tear.
 - Any other causes which does not relate to a product defect.

1.2 Regulatory Notice

Legal Information

Information in this document has been carefully checked for accuracy; however, no guarantee is given to the correctness of the contents. The information in this document is subject to change without notice. We are not liable for any injury or loss that results from the use of this equipment.

Safety Instructions

- Unplug equipment before cleaning. Don't use liquid or spray detergent; use a moist cloth.
- Keep equipment away from excessive humidity and heat. Preferably, keep it in an air-conditioned environment with temperatures not exceeding 40° Celsius (104° Fahrenheit).
- When installing, place the equipment on a sturdy, level surface to prevent it from accidentally falling and causing damage to other equipment or injury to persons nearby.
- When the drawer is in an open position, do not cover, block or in any way obstruct the gap between it and the power supply. Proper air convection is necessary to keep it from overheating.
- Arrange the equipment's power cord in such a way that others won't trip or fall over it.
- If you are using a power cord that didn't ship with the equipment, ensure that it is rated for the voltage and current labeled on the equipment's electrical ratings label. The voltage rating on the cord should be higher than the one listed on the equipment's ratings label.
- Observe all precautions and warnings attached to the equipment.
- If you don't intend on using the equipment for a long time, disconnect it from the power outlet to prevent being damaged by transient over-voltage.

- Keep all liquids away from the equipment to minimize the risk of accidental spillage. Liquid spilled on to the power supply or on other hardware may cause damage, fire or electrical shock.
- Only qualified service personnel should open the chassis. Opening it yourself could damage the equipment and invalidate its warranty.
- If any part of the equipment becomes damaged or stops functioning, have it checked by qualified service personnel.

Regulatory Notices Federal Communications Commission (FCC)

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. Any changes or modifications made to this equipment may void the user's authority to operate this equipment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Re-position or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

1.3 Before Installation

- It is very important to locate the KVM in a suitable environment.
- The surface for locating and fixing the KVM switch should be stable and level or mounted into a suitable cabinet.
- Make sure the place has good ventilation, is out of direct sunlight and away from sources of excessive dust, dirt, heat, water, moisture and vibration.
- Position LCD Keyboard Drawer with respect to related facilities.

2.1 Password

The password is disabled by default (i.e. There is no password required when you power on the KVM switch for the first time)

■ Enable password.

1. Enter the KVM hotkey **Scroll Lock + Scroll Lock + U**
2. Logout of the KVM switch by entering the hotkey **Scroll Lock + Scroll Lock + P**
3. In SUPERVISOR level, enter "00000000" eight zeros in the user name & password field
(Do not use the "0" on the number pad)
4. In USER level, enter **Space bar + Enter** in the user name & password field
Note: Automatic logout after 10 minutes of inactivity

■ Set your own user name & password.

1. Login to the KVM switch in SUPERVISOR level by entering "00000000" eight zeros in user name & password field.
2. Call the KVM OSD menu by entering the KVM hotkey **Scroll Lock + Scroll Lock + Space Bar**.
3. Enter F1 to view the MAIN MENU.
4. Select "USER SECURITY".
5. Set password in SUPERVISOR & USER level.
 - a. In the top-left row "S" (SUPERVISOR), press **Enter** to set your own user name & password.
 - b. In the row 1 to 8 (USER), press **Enter** to set your own user name & password.
6. Press **Enter** to save the settings or press **Esc** to cancel without saving.
Note:
 - a. Blank has an underscore, while SPACE does not.
 - b. Enter any alphanumeric key to move to next input item. SPACE is treated as a valid character.

■ Change your password.

1. Login to the KVM switch in SUPERVISOR level by entering your own user name & password.
2. Call the KVM OSD menu by entering the KVM hotkey **Scroll Lock + Scroll Lock + Space Bar**.
3. Press **F1** to view the MAIN MENU.
4. Select "USER SECURITY".
5. Change the password in SUPERVISOR & USER level.
 - a. In the top-left row "S" (SUPERVISOR), press **Enter** to change your user name & password.
 - b. In the row 1 to 8 (USER), press **Enter** to change your user name & password.
6. Press **Enter** to save the setting or press **Esc** to cancel without saving.
Note:
 - a. Blank has underscore, while SPACE does not.
 - b. Enter any alphanumeric key to move to next input item. SPACE is treated as a valid character.

■ Enable password.

1. Enter the KVM hotkey **Scroll Lock + Scroll Lock + U**.
2. Logout of the KVM switch by entering the KVM hotkey **Scroll Lock + Scroll Lock + P**.
3. Following this you will not need a user name & password to access the KVM OSD menu.

■ Forget your password.

1. Please contact Black Box for further support.

Note:




- You must enter the KVM hotkey within 2 seconds.
- A beep sound will be heard once you have successfully entered the hotkey.

2.2 KVM OSD

OSD Menu

PORT NAME	
BANK : 1	
01: SYSTEM 01	F1 : MENU
02: SYSTEM 02	F2 : LOGOUT
03: SYSTEM 03	F3 : PREV
04: SYSTEM 04	ESC : QUIT
05: SYSTEM 05	ENTER : COMPLETE
06: SYSTEM 06	↑/↓ : SELECT
07: SYSTEM 07	PgUp/PgDn : BANK SELECT
08: SYSTEM 08	
USER : SUPERVISOR	
SCAN TIME : 10 SEC	
FW1V3	

OSD operation

 next to the system name	The PC is powered on
 next to the system name	The PC is selected
F1	Access F1 MAIN MENU
F2	Logout the OSD menu
F3	Previous menu
Esc	Cancel/Quit
Enter	Complete/Switch to selected port
	Switch to previous or next port
PageUp/PageDown	SWitch to previous bank or next bank
1/2/3/4	Display port 01-08/09-16/17-24/25-32 Note: Display port 17-32 for 32 port model only

F1 Main Menu

MAIN MENU	
SELECT OPTION :	
01	LANGUAGE
02	PORT NAME EDIT
03	PORT SEARCH
04	USER SECURITY
05	ACCESS LIST
06	HOTKEY
07	TIME SETTINGS
08	OSD MOUSE

01	LANGUAGE	OSD language change
02	PORT NAME EDIT	Define port name
03	PORT SEARCH	Quick searching by port name
04	USER SECURITY	Change password
05	ACCESS LIST	Define user access authority
06	HOTKEY	Change hotkey
07	TIME SETTINGS	Modify scan display time interval
08	OSD MOUSE	Modify OSD mouse speed

2.3 KVM Hotkey

Local Console Hotkey

Hotkey	Function
Scroll Lock + Scroll Lock + Space Bar	Calling OSD menu
Right-button mouse + Esc	Calling OSD menu
Scroll Lock + Scroll Lock +	Switch to previous port
Scroll Lock + Scroll Lock +	Switch to next port
Scroll Lock + Scroll Lock + PgUp/PgDown	Switch to previous bank or next bank
Scroll Lock + Scroll Lock + Bank no. + Port no.	Switch to specific port
Scroll Lock + Scroll Lock + B	Turn the buzzer ON and OFF * Default the buzzer is ON
Scroll Lock + Scroll Lock + P	Logout the KVM if password security is ON. Show up the status windows.

Advanced hotkeys (for Supervisor login only)

Scroll Lock + Scroll Lock + S	Activate auto-scan mode for connected servers * Enter any key to exit the auto-scan mode
Scroll Lock + Scroll Lock + R	Reset all the KVM settings to factory default *Except User Security settings
Scroll Lock + Scroll Lock + U	Disable and enable password security * Default security is OFF
Scroll Lock + Scroll Lock + L	To enable/disable the screen saving function and 10 minutes auto-logout

Example:

- **"Scroll Lock + Scroll Lock + Bank no. + Port no."**
 - Bank no. : 1 to 8
 - Port no. : 01 to 16
 - e.g. Bank 1 Port 4: **Scroll Lock + Scroll Lock + 1 + 0 + 4**
 - e.g. Bank 2 Port 16: **Scroll Lock + Scroll Lock + 2 + 1 + 6**
- You must enter the hotkey within 2 seconds.
- A beep sound will be heard once the hotkey had been successfully entered.
- The numerical keypad is not supported by the OSD. The arrow keys, PgUp, PgDn, and Enter keys are supported.

Remote Console Hotkey

Hotkey	Function
Caps Lock + Caps Lock + F1	Calls the Help OSD windows
Caps Lock + Caps Lock + F2	Select Hotkey *Default is Caps Lock
Caps Lock + Caps Lock + C	Toggle the switch between remote & local port
Caps Lock + Caps Lock + Q	Turn the buzzer ON & OFF * By default the buzzer is ON
Caps Lock + Caps Lock + S	Activate auto-scan mode for remote & local port * The scan time interval is 5 seconds
Caps Lock + Caps Lock + A	Auto-adjust the video signal

Free Manuals Download Website

<http://myh66.com>

<http://usermanuals.us>

<http://www.somanuals.com>

<http://www.4manuals.cc>

<http://www.manual-lib.com>

<http://www.404manual.com>

<http://www.luxmanual.com>

<http://aubethermostatmanual.com>

Golf course search by state

<http://golfingnear.com>

Email search by domain

<http://emailbydomain.com>

Auto manuals search

<http://auto.somanuals.com>

TV manuals search

<http://tv.somanuals.com>