

GIGABIT MANAGED ETHERNET SWITCH 16 PoE+ PORTS PLUS TWO SFP PORTS USER MANUAL

Part #ESM316T002R



ESM316T002R

Content

CHAPTER 1 The Introduction	5
Web Browser	5
Logging In	6
CHAPTER 2 System	8
System Information	8
IP Address Setting	8
IPv6 Address Setting	9
User Account	10
Port Setting	10
CHAPTER 3 Configuration	12
Trunk Group Setting	12
Trunk Distribution Algorithm Setting	13
LACP Setting	15
Static VLAN Table Setting	16
VLAN Port Setting	17
VLAN-Stacking Table Setting	18
Vlan Stacking Setting	19
IGMP Multicast Group Information	21
IGMP Snooping	22
IGMP Global Setting	23
IGMP VLAN Setting	24
Spanning Tree	25
Spanning Tree Port Setting	27
Quality of Service (QoS)	29
Port-based Priority Setting	29
DSCP-based Priority Setting	30
Priority to Queue Mapping Setting	31

Packet Scheduling Setting.....	32
LLDP Configurations	33
LLDP Neighbors	34
SNMP Setting.....	35
Trap Receivers Setting	36
Port Mirroring Setting.....	37
Port Security Setting.....	38
Bandwidth Control Setting	40
Jumbo Frame Setting	42
Management Access Filter	43
CHAPTER 4 Security	45
MAC Address Information	45
Static MAC Setting	46
MAC Filtering Setting.....	47
802.1x Setting.....	48
802.1x Port Setting	49
IP Filter Configurations	50
Storm Control settings	52
Port Isolation.....	53
Defence Engine	54
CHAPTER 5 Monitoring.....	55
Port Statistics Information.....	55
CHAPTER 6 Tools.....	56
Http Upgrade	56
Reset Factory Defaults	57
Reboot	58

ABOUT THIS GUIDE

This guide provides information about how to operate and use the management functions of the **Web Management Switch**. The switch features multiple functions as shown below:

Features Overview

- Supports real-time status (link, speed, duplex) of each port
- Supports port setting for enable or disable operation (the 1st port can't be disabled)
- Supports port setting for N-Way or force mode operation
- Supports Broadcast Storm Protection
- Supports Port-bases VLAN
- Supports priority queues for QoS

Revision History


- Several documents prepared beforehand are consulted, this manual is released as the first edition. Date as August 2nd, 2011.

CHAPTER 1 The Introduction

Web Browser

You can log into the Web Management Switch through a Web browser and manage and maintain the switch intuitively by interacting with the built-in Web server. The home page is displayed as shown below. It displays the Main Menu on the left side of the screen and an image of the front panel on the right side. The Main Menu is used to navigate to other menus, and display configuration parameters and statistics.

Figure 1: Home Page



Logging In

Please follow the steps to configure this Web Smart switch. The configure procedure is as follows:

Step 1: Use Ethernet Category 5 cable to connect this switch to your PC.

Step 2: Check that your PC has an IP address on the same subnet as the switch. For example, the PC and the switch are on the same subnet if they both have addresses that start 192.168.1.x. The subnet mask is 255.255.255.0.

Step 3: Open the browser (like Microsoft Internet Explorer) and go to [http:// 192.168.1.1](http://192.168.1.1), which is the switch address, for example. If your PC is properly configured, you will see the login page like below:



Figure 2: Login Popping Up Window

NOTE: If you do not see the login page, check step 1 & 2.

Step 4: Please key in both the default user name “admin” and the password “admin” to pass the authentication. After the authentication procedure, the switch can be used now, as the web home page appears as follows:




Figure 3: Web-Based Management Interface

CHAPTER 2 System

System Information

To lookup System Information in the Web browser, click System, then Information.

Web Smart switch interface

System Information

Device Type	Intelligent Switch
MAC Address	00:03:CE:0A:00:00
IP Address	192.168.1.1
Subnet Mask	255.255.255.0
Gateway	192.168.1.254
IPv6 Address	fe80::203:ceff:fe0a:0/64
IPv6 Router	::
Firmware Version	v1.1.1.6
Firmware Date	Wed Nov 24 18:48:51 CST 2010

Figure 4: System Information

IP Address Setting

To set up static IP address of the switch.

Web Smart switch interface

1. Click System, then IP Setting.
2. Set the Mode to “Static IP”.
3. Specify the IP address, subnet mask, and gateway address.
4. Click Apply.

IP Address Setting

Mode	Static IP <input type="button" value="v"/>
IP Address	<input type="text" value="192.168.1.1"/>
Subnet Mask	<input type="text" value="255.255.255.0"/>
Gateway	<input type="text" value="192.168.1.254"/>

Figure 5: IP Setting

IPv6 Address Setting

IPv6 is an Internet Layer protocol for packet-switched internetworking and provides end-to-end datagram transmission across multiple IP networks. IPv6 includes two distinct address types; link-local unicast and global unicast.

Web Smart switch interface

IPv6 Address Setting

Auto Configuration	Enabled
IPv6 Address	fe80::203:ceff:fe0a:0
Prefix Length	64
Router	::

Apply

Figure 6: IPv6 Address Setting

Hint§

The following parameters are displayed on the IPv6 Address Setting page:

- **Auto Configuration**—Enable stateless auto configuration of IPv6 addresses on the interface and enables IPv6 functionality on the interface.
- **IPv6 Address**—Manually sets up a global unicast address by specifying the full address and network prefix length (in the Prefix field). (Default: *null*)
- **Prefix Length**—Define the prefix length as a decimal value indicating how many contiguous bits (starting at the left) of the address comprise the prefix; that is, the network portion of the address. (Default: 0)
- **Router**—Set up the IPv6 address of the default next hop router. An IPv6 default gateway must be defined if the management station is located in a different IPv6 segment. An IPv6 default gateway can only be successfully set when a network interface that directly connects to the gateway has been configured on the switch.

User Account

To set up the System Password in the Web browser:

Web Smart switch interface

1. Click System, then User Account.
2. Enter the new user name.
3. Enter the new password.
4. Enter the new password again to confirm your input.
5. Click Save.

User Account Setting

New Username	<input type="text"/>
New Password	<input type="password"/>
Retype Password	<input type="password"/>

Figure 7: User Account Setting

Port Setting

To specify options for enabling auto-negotiation or manually setting the speed and duplex mode, or enabling flow control.

To set up port configuration in the Web browser:

1. Click System, Port Setting.
2. Select one or more ports to configure.
3. Make any required changes to the connection settings.
4. Click Apply.

Port Setting

Port	State	Speed/Duplex	Flow Control
Port 1			
Port 2			
Port 3	Enable	Auto	Off
Port 4			
Port 5			
Port 6			

Apply

Port	State	Speed/Duplex		Flow Control	
		Config	Actual	Config	Actual
Port 1	Enabled	Auto	Link Down	On	Link Down
Port 2	Enabled	Auto	Link Down	On	Link Down
Port 3	Enabled	Auto	100 Full	On	Off
Port 4	Enabled	Auto	Link Down	On	Link Down
Port 5	Enabled	Auto	Link Down	On	Link Down
Port 6	Enabled	Auto	Link Down	On	Link Down
Port 7	Enabled	Auto	Link Down	On	Link Down
Port 8	Enabled	Auto	Link Down	On	Link Down
Port 9	Enabled	Auto	Link Down	On	Link Down

Figure 8: Port Setting

Hint§

The following parameters are displayed on the Port Setting configuration:

- **Port**—Set up one or more ports. Hold down the CTRL key and click port numbers to select multiple ports. Hold down the SHIFT key to select a range of ports.
- **State**—Set the link state of port interfaces. (Default: Enabled)
- **Speed/Duplex**—Configure the port speed and duplex mode using auto-negotiation or manual selection. (Default: Auto-negotiation enabled)
 - **Auto** - Enable auto-negotiation. When using auto-negotiation, the optimal settings will be negotiated between the link partners based on their advertised capabilities. Auto must be enabled for all 1 Gbps connections.
 - **100M/Full** - Support 100 Mbps full-duplex operation
 - **100M/Half** - Support 100 Mbps half-duplex operation
 - **10M/Full** - Support 10 Mbps full-duplex operation
 - **10M/Half** - Support 10 Mbps half-duplex operation
- **Flow Control**—Display the following:
 - **Config** – The configured flow control mode of the port.
 - **Actual** – Indicate the link status of the port. When a link is up, indicates the operating flow control mode.

CHAPTER 3 Configuration

Trunk Group Setting

To configure a trunk group.

Web Smart switch interface

1. Click Configuration, Link Aggregation, Trunk Group Setting.
2. Select the trunk group ID to be created or modified.
3. Select the trunk type; Static or LACP.
4. Assign up to four port members to the trunk.
5. Click Add/Modify.




Figure 9: Trunk Group Setting

Trunk Distribution Algorithm Setting

To configure a trunk's load-balancing settings.

Web Smart switch interface

1. Click Configuration, Link Aggregation, Trunk Setting.
2. Select the trunk group ID to be configured or modified.
3. Select the trunk Distribution Algorithm Parameters as required.
4. Click Apply.

Trunk Distribution Algorithm Setting

Group ID	Distribution Algorithm Parameters				
Trunk1	<input type="checkbox"/> Source Port	<input type="checkbox"/> Source MAC	<input type="checkbox"/> Dest. MAC	<input type="checkbox"/> Source IP	<input type="checkbox"/> Dest. IP

Apply

Group ID	Distribution Algorithm Parameters				
Trunk 1	SPA	SMAC	DMAC	SIP	DIP
Trunk 2	SPA	SMAC	DMAC	SIP	DIP
Trunk 3	SPA	SMAC	DMAC	SIP	DIP
Trunk 4	SPA	SMAC	DMAC	SIP	DIP
Trunk 5	SPA	SMAC	DMAC	SIP	DIP
Trunk 6	SPA	SMAC	DMAC	SIP	DIP
Trunk 7	SPA	SMAC	DMAC	SIP	DIP
Trunk 8	SPA	SMAC	DMAC	SIP	DIP

Figure 10: Trunk Distribution Algorithm Setting

Hint§

The switch provides five load-balancing methods to distribute a balanced load across all links in a trunk. The following parameters are displayed on the Trunk Distribution Algorithm Setting:

■ **Distribution Algorithm Parameters**—To ensure the switch traffic load is distributed evenly across all links in a trunk, the hash methods used in the load-balance calculation can be selected to provide the best result for trunk connections. The following options are supported:

■ **Source Port** - All traffic with the same source and destination TCP/UDP port number is output on the same link in a trunk. Avoid using this mode as a lone option. It may overload a single port member of the trunk for application traffic of a specific type, such as web browsing. However, it can be used effectively in combination with the IP Address option.

■ **Source MAC** - All traffic with the same source MAC address is output on the same link in a trunk. This mode works best for switch-to-switch trunk links where traffic through the switch is received from many different hosts.

▪ **Destination MAC** - All traffic with the same destination MAC address is output on the same link in a trunk. This mode works best for switch-to-switch trunk links where traffic through the switch is destined for many different hosts. Do not use this mode for switch-to-router trunk links where the destination MAC address is the same for all traffic.

▪ **Source IP** - All traffic with the same source and destination IP address is output on the same link in a trunk. This mode works best for switch-to-router trunk links where traffic through the switch is destined for many different hosts. Do not use this mode for switch-to-server trunk links where the destination IP address is the same for all traffic.

▪ **Destination IP** - All traffic with the same source and destination IP address is output on the same link in a trunk. This mode works best for switch-to-router trunk links where traffic through the switch is destined for many different hosts. Do not use this mode for switch-to-server trunk links where the destination IP address is the same for all traffic.

LACP Setting

The LACP (link aggregation control protocol) dynamically aggregates ports and removes aggregations. LACP interacts with its peer by sending LACPDU (link aggregation control protocol data units).

Web Smart switch interface

To arrange LACP settings,

1. Click Configuration, Link Aggregation, LACP Setting.
2. Enable LACP on the switch.
3. Specify the LACP System Priority to identify LAGs (link aggregation group) on the switch.
4. Click Apply.

LACP Setting

LACP Status:

System Priority: (0~65535)

Port	LACP	Aggregated
Port1	Disabled	-
Port2	Disabled	-
Port3	Disabled	-
Port4	Disabled	-
Port5	Disabled	-
Port6	Disabled	-
Port7	Disabled	-
Port8	Disabled	-
Port9	Disabled	-
Port10	Disabled	-
Port11	Disabled	-
Port12	Disabled	-

Figure 11: LACP Setting

Hint§

The following parameters are shown on the LACP Setting:

- **LACP Status** – Specify whether LACP is enabled on this switch. LACP will aggregate two or more ports if they belong to the same group. LACP can form up to 8 trunks per switch.
- **System Priority** – LACP system priority is used to identify LAGs membership of this switch to other switches during LAG negotiations. (Range: 0-65535, Default: 32768)

Static VLAN Table Setting

The VLAN (virtual local area network) technology is developed for switches to control broadcast operations in LANs. By creating VLANs in a physical LAN, you can divide the LAN into multiple logical LANs, each of which has a broadcast domain of its own. Hosts in the same VLAN communicate with each other as if they are in a LAN. However, hosts in different VLANs cannot communicate with each other directly. In this way, broadcast packets are confined within a VLAN.

Web Smart switch interface

To manage VLAN groups,

1. Click Configuration, VLAN, Static VLAN.
2. Select a VLAN ID number.
3. Define a name to identify the VLAN.
4. Mark the ports to be assigned to the new VLAN as tagged or untagged members.
5. Click Add/Modify.

Static VLAN Table Setting

VLAN ID	<input type="text" value=""/>	(1-4094)	VLAN Name	<input type="text" value=""/>											
Port	Select All	1	2	3	4	5	6	7	8	9	10	11	12	13	14
Untagged	<input type="button" value="All"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>
Tagged	<input type="button" value="All"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>
Not Member	<input type="button" value="All"/>	<input checked="" type="radio"/>	<input checked="" type="radio"/>	<input checked="" type="radio"/>	<input checked="" type="radio"/>	<input checked="" type="radio"/>	<input checked="" type="radio"/>	<input checked="" type="radio"/>	<input checked="" type="radio"/>	<input checked="" type="radio"/>	<input checked="" type="radio"/>	<input checked="" type="radio"/>	<input checked="" type="radio"/>	<input checked="" type="radio"/>	<input checked="" type="radio"/>
Port	Select All	15	16	17	18										
Untagged	<input type="button" value="All"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>										
Tagged	<input type="button" value="All"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>										
Not Member	<input type="button" value="All"/>	<input checked="" type="radio"/>	<input checked="" type="radio"/>	<input checked="" type="radio"/>	<input checked="" type="radio"/>										

VLAN ID	VLAN Name	Member Ports	Tagged Ports	Untagged Ports	Delete
<u>1</u>	default	1-18	-	1-18	<input type="checkbox"/>

Figure 12: Static VLAN Table Setting

Hint§

The following parameters are shown on the Static VLAN Table Setting:

- **Port** – Select VLAN membership for each interface by marking the appropriate radio button for a port or trunk as **Untagged**, **Tagged**, or **Not Member**
- **VLAN ID** – VLAN Identifier. (Range: 1-4094)

- **VLAN Name** – Name of the VLAN (1-100 characters)

VLAN Port Setting


Arranging VLAN attributes for specific interfaces, including the default Port VLAN identifier (PVID).

Web Smart switch interface

To specify attributes for VLAN port members,

1. Click Configuration, VLAN, VLAN Setting.
2. Select one or more ports or trunks to configure.
3. Configure the required PVID setting.
4. Click Apply.

VLAN Port Setting



Port	PVID
Port 1	
Port 2	
Port 3	
Port 4	
Port 5	
Port 6	

Apply

Port	PVID
Port 1	1
Port 2	1
Port 3	1
Port 4	1
Port 5	1
Port 6	1
Port 7	1
Port 8	1
Port 9	1
Port 10	1

Figure 13: VLAN Port Setting

Hint§

The following parameters are shown on the Static VLAN Table Setting:

- **Port** –Select one or more ports to configure. Hold down the CTRL key and click port numbers to select multiple ports. Hold down the SHIFT key to select a range of ports.
- **PVID** - The VLAN ID assigned to untagged frames received on the interface. (Range: 1-4095, Default: 1) Ports must be a member of the same VLAN as the Port VLAN ID.

VLAN-Stacking Table Setting

Set the stacking VLAN membership for selected interfaces to be part of the Service Provider VLAN (S-VLAN), that is uplink ports for a 802.1Q Tunnel. This stacking VLAN is used to segregate and preserve customer VLAN IDs for traffic crossing the service provider network. The switch supports up to 64 S-VLAN IDs.

Web Smart switch interface

To manage stacking VLAN port members,

1. Click Configuration, VLAN Stacking, S-VLAN Table.
2. Specify the S-VLAN ID number.
3. Mark the ports to be included as stacking VLAN port members for specified S-VLAN.
4. Click Add.

Port	PVID	Provider Network Port
Port 1	1	Disabled
Port 2	1	Disabled
Port 3	1	Disabled
Port 4	1	Disabled
Port 5	1	Disabled
Port 6	1	Disabled
Port 7	1	Disabled
Port 8	1	Disabled
Port 9	1	Disabled
Port 10	1	Disabled
Port 11	1	Disabled
Port 12	1	Disabled
Port 13	1	Disabled
Port 14	1	Disabled
Port 15	1	Disabled
Port 16	1	Disabled
Port 17	1	Disabled
Port 18	1	Disabled

Figure 14: VLAN-Stacking Table Setting

Hint§

The following parameters are shown on the VLAN-Stacking Table Setting:

- **S-VLAN ID** - The VLAN identifier of a stacking VLAN. (Range: 1-4094)
- **Member Ports** - Switch ports that are members of the stacking VLAN. That is, ports that will double tag ingress and egress packets.

Vlan Stacking Setting

After configuring port members for stacking VLANs on the switch, the ports connected to a service provider network need to be enabled as doubled tagged ports. Also the Tag Protocol Identifier (TPID) value must be set for the doubled-tagged ports to identify 802.1Q tagged frames.

Web Smart switch interface

To manage stacking VLAN port settings,

1. Click Configuration, VLAN Stacking, S-VLAN Setting.
2. Specify the Tag Protocol ID number.
3. Set the stacking PVID for service provider ports and configure them as “Enabled.”
4. Click Apply.

Tag Protocol ID

Tag Protocol ID

(0x0000~0xffff)

S-VLAN Port Configuration

Port	PVID	Provider Network Port
Port 1		Disable
Port 2		
Port 3		
Port 4		
Port 5		
Port 6		

Port	PVID	Provider Network Port
Port 1	1	Disabled
Port 2	1	Disabled
Port 3	1	Disabled
Port 4	1	Disabled
Port 5	1	Disabled
Port 6	1	Disabled
Port 7	1	Disabled
Port 8	1	Disabled
Port 9	1	Disabled
Port 10	1	Disabled
Port 11	1	Disabled
Port 12	1	Disabled
Port 13	1	Disabled
Port 14	1	Disabled
Port 15	1	Disabled
Port 16	1	Disabled
Port 17	1	Disabled
Port 18	1	Disabled
Port 19	1	Disabled
Port 20	1	Disabled
Port 21	1	Disabled

Figure 15: VLAN Stacking Setting

Hint§

The following parameters are shown on the VLAN-Stacking Table Setting:

- **Tag Protocol ID** - Tag Protocol Identifier specifies the Ether type of incoming packets on a tunnel port. (Range: 0x0600~0xFFFF hexadecimal, Default: 0x88a8)
- **PVID** - The stacking VLAN Port VLAN Identifier. The PVID determines the stacking VLAN tag for single-tagged packets forwarded to an enabled S-VLAN port.
- **Provider Network Port** - Set the S-VLAN membership mode for the selected interface. This mode is used to segregate and preserve customer VLAN IDs for traffic crossing the service provider network.(Default: Disable)
 - **Enable** - Indicate a port linked to a service provider (an 802.1Q Tunnel port).
 - **Disable** - Indicate a port linked to a customer.

IGMP Multicast Group Information

To display multicast group and router port information, click Configuration, IGMP Snooping, Multicast Entry Table.

The IGMP Multicast Router Information table displays the current multicast groups learned through IGMP Snooping. Multicast routers that are attached to ports on the switch use information obtained from IGMP, along with a multicast routing protocol such as DVMRP or PIM, to support IP multicasting across the Internet. You can use the IGMP Multicast Router Information table to see which ports on the switch are attached to a neighboring multicast router.

IGMP Multicast Group Information				
VID	VLAN Name	Source IP	Group Address	Member Port

IGMP Multicast Router Information		
VID	VLAN Name	Dynamic Router Port

Figure 16: Multicast Entry Table

Hint§

The following parameters are shown on the Multicast Entry Table page:

- **VID** - A VLAN on the switch that is forwarding multicast traffic to downstream ports for the specified multicast group address.
- **VLAN Name** – The name of the VLAN on the switch that is forwarding multicast traffic.
- **Source IP** - The IP address of one of the multicast servers transmitting traffic to the specified group.
- **Group Address** – IP multicast group address with subscribers directly attached or downstream from the switch, or a static multicast group assigned to this interface.
- **Member Port** – An downstream port that is receiving traffic for the specified multicast group.
- **Dynamic Router Port** – The port interfaces dynamically discovered by the switch to be attached to Multicast routers.

IGMP Snooping

IGMP Snooping (Internet Group Management Protocol Snooping) is a multicast constraining mechanism that runs on Layer 2 switch to manage and control multicast groups.

IGMP Global Setting

IGMP Snooping	Disabled	▼
IGMP Fast-Leave	Disabled	▼
Unknown Multicast	Drop	▼
Query Interval	125	(60-600 Sec)
Response Time	10	(10-25 Sec)
Router Timeout	125	(60-600 Sec)
Last Member Query Interval	1	(1-25 Sec)
Robustness Variable	2	(1-255)
Host Timeout	260 Sec	
Querier Election Time	255 Sec	

IGMP VLAN Setting

VLAN ID	Snooping State	Querier State
1	Disable	Disable

VLAN ID	VLAN Name	Snooping State	Querier State
1	default	Enabled	Disabled

Figure 17: IGMP Snooping

IGMP Global Setting

Web Smart switch interface

To manage IGMP Snooping global settings,

1. Click Configuration, IGMP Snooping, IGMP Snooping Setting.
2. Enable IGMP Snooping on the switch.
3. Modify other IGMP global settings as required.
4. Click Update.

Hint§

The following parameters are shown on the IGMP Snooping global settings page:

- **IGMP Snooping** - When enabled, the switch will monitor network traffic to determine which hosts want to receive multicast traffic. (Default: Disabled) This switch can passively snoop on IGMP Query and Report packets transferred between IP multicast routers/switches and IP multicast host groups to identify the IP multicast group members. The switch monitors the IGMP packets passing through it, picks out the group registration information, and configures the multicast filters accordingly.
- **IGMP Fast-Leave** - Immediately deletes a member port of a multicast service if a leave packet is received on that port. Fast Leave can improve bandwidth usage for a network which frequently experiences many IGMP host add and leave requests. (Default: Disabled)
- **Unknown Multicast** - When the table used to store multicast entries for IGMP snooping is filled, no new entries are learned. If no router port is configured in the attached VLAN, any subsequent multicast traffic not found in the table is either dropped or flooded throughout the VLAN. (Default: Drop)
- **Query Interval** - Sets the frequency at which the switch sends IGMP host-query messages. (Range: 60-600 seconds, Default: 125)
- **Response Time** - Set the time between receiving an IGMP Report for an IP multicast address on a port before the switch sends an IGMP Query out of that port and removes the entry from its list. (Range: 10-25 seconds, Default: 10)
- **Router Timeout** - On a multicast network running IGMP, a Layer 3 multicast switch may exist that serves as an IGMP querier responsible for sending IGMP query messages. The time the switch waits after the previous querier stops before it considers it to have expired. (Range: 60-600 seconds, Default: 125)
- **Last Member Query Interval** - The interval to wait for a response to a group-specific or group-and-source-specific query message. (Range: 1-25 seconds, Default: 1 second)
- **Robustness Variable** - Specify the robustness or expected packet loss for interfaces. The robustness value is used in calculating the appropriate range for other IGMP variables. (Range: 1-255, Default: 2)
- **Host Timeout** - The time the switch waits for an IGMP report from a host for a multicast group. When IGMP reports are not received, host ports are removed from the member list of that multicast group.
- **Querier Election Time** - The time the switch waits to receive IGMP queries from other routers. If no queries are received, the switch itself will become the querier (when enabled).

IGMP VLAN Setting

Web Smart switch interface

To manage IGMP Snooping settings,

1. Click Configuration, IGMP Snooping, IGMP Snooping Setting.
2. Specify the VLAN ID.
3. Enable IGMP Snooping on the VLAN.
4. Enable IGMP Querier on the VLAN if you want this switch to be elected as querier.
5. Click Apply.

Hint§

The following parameters are shown on the IGMP Snooping VLAN settings page:

- **VLAN ID** - Specify the ID of a configured VLAN on the switch. (Range: 1-4094)
- **VLAN Name** - Display the name of the VLAN.
- **Snooping State** - Enable IGMP snooping on the VLAN. (Default: Disabled)
- **Querier State** - Enable IGMP querier on the VLAN. (Default: Disabled)

Spanning Tree

The spanning tree protocol is used to eliminate loops in a local area network. A switch running this protocol detects any loop in the network by exchanging information with one another and eliminates the possible loop by blocking certain ports until the loop network is pruned into a loop-free tree, thereby avoiding infinite recycling of packets in a loop network.

Web Smart switch interface

To manage global settings for Spanning Tree,

1. Click Configuration, Spanning Tree, STP Global Setting.
2. Set the Spanning Tree Status to enabled.
3. Modify other required parameters.
4. Click Apply.

Spanning Tree Setting

Spanning Tree Status	Disabled
Force Version	RSTP
Priority	32768
Maximum Age	20 (6~40 Sec)
Hello Time	2 (1~10 Sec)
Forward Delay	15 (4~30 Sec)
Root Priority	32768
Root MAC Address	00:03:CE:0A:00:01
Root Path Cost	0
Root Port	None
Root Maximum Age	20 Sec
Root Hello Time	2 Sec
Root Forward Delay	15 Sec
Topology Changes	0 Times
Last Topology Change Time	0 Sec

Apply

Figure 18: spanning tree settings

Hint§

The following parameters are shown on the Spanning Tree settings page:

- **Spanning Tree Status** - Enable Spanning Tree on the switch. (Default: Disabled)
- **Force Version** - Select the type of spanning tree used on this switch. Options: RSTP or STP, Default: RSTP
- **Priority** - Bridge priority is used in selecting the root switch, root port, and designated port. The switch with the highest priority becomes the STP root switch. However, if all switches have the same priority, the switch with the lowest MAC address will then become the root switch. Note that lower numeric values indicate higher priority. (Options: 0-61440, in steps of 4096; Default: 32768)
 - **Maximum Age** - The maximum time (in seconds) a switch can wait without receiving a configuration message before attempting to reconfigure. All switch ports (except for designated ports) should receive

configuration messages at regular intervals. Any port that ages out STP information (provided in the last configuration message) becomes the designated port for the attached LAN. If it is a root port, a new root port is selected from among the switch ports attached to the network. (Note that references to “ports” in this section mean “interfaces,” which includes both ports and trunks.)

Minimum: The higher of 6 or $[2 \times (\text{Hello Time} + 1)]$

Maximum: The lower of 40 or $[2 \times (\text{Forward Delay} - 1)]$

Default: 20

■ **Hello Time** - The interval (in seconds) at which the root switch transmits a configuration message.

Default: 2

Minimum: 1

Maximum: The lower of 10 or $[(\text{Max. Message Age} / 2) - 1]$

■ **Forward Delay** - The maximum time (in seconds) this switch will wait before changing states (i.e., discarding to learning to forwarding). This delay is required because every switch must receive information about topology changes before it starts to forward frames. In addition, each port needs time to listen for conflicting information that would make it return to a discarding state; otherwise, temporary data loops might result.

Minimum: The higher of 4 or $[(\text{Max. Message Age} / 2) + 1]$

Maximum: 30

Default: 15

■ **Root Priority** - The priority of the switch in the Spanning Tree that this switch has accepted as the root switch.

■ **Root MAC Address** - The MAC address of the switch in the Spanning Tree that this switch has accepted as the root switch.

■ **Root Path Cost** - The path cost from the root port on this switch to the root switch.

■ **Root Port** - The number of the port on this switch that is closest to the root. This switch communicates with the root switch through this port. If there is no root port, then this switch has been accepted as the root switch of the Spanning Tree network.

■ **Root Maximum Age** - The maximum time (in seconds) this switch can wait without receiving a configuration message before attempting to reconfigure. All switch ports (except for designated ports) should receive configuration messages at regular intervals. If the root port ages out STA information (provided in the last configuration message), a new root port is selected from among the switch ports attached to the network. (References to “ports” in this section means “interfaces,” which includes both ports and trunks.)

■ **Root Hello Time** - The interval (in seconds) at which this switch transmits a configuration message.

■ **Root Forward Delay** - The maximum time (in seconds) this switch will wait before changing states (i.e., discarding to learning to forwarding). This delay is required because every switch must receive information about topology changes before it starts to forward frames. In addition, each port needs time to listen for conflicting information that would make it return to a discarding state; otherwise, temporary data loops might result.

■ **Topology Changes** — The number of times the Spanning Tree has been reconfigured.

■ **Last Topology Change Time** - The time since the Spanning Tree was last reconfigured.

Spanning Tree Port Setting

Use the STP Port Setting page to configure Spanning Tree attributes for specific interfaces, including path cost, port priority, edge port (for fast forwarding), automatic detection of an edge port, and point-to-point link type.

Web Smart switch interface

To configure port settings for Spanning Tree,

1. Click Configuration, Spanning Tree, STP Port Setting.
2. Modify the required attributes for one or a group of ports.
3. Click Apply.

Spanning Tree Port Setting

Port	Path Cost	Priority	P2P	Edge
<div style="border: 1px solid #ccc; padding: 2px;"> Port 1 Port 2 Port 3 Port 4 Port 5 Port 6 </div>	<input style="width: 80%;" type="text" value="0"/> (1~200000000), 0 = Auto	128	Auto	False

Port	State	Role	Path Cost		Priority	P2P		Edge	
			Config	Actual		Config	Actual	Config	Actual
Port 1	Disabled	-	Auto	-	128	Auto	-	False	-
Port 2	Disabled	-	Auto	-	128	Auto	-	False	-
Port 3	Disabled	-	Auto	-	128	Auto	-	False	-
Port 4	Disabled	-	Auto	-	128	Auto	-	False	-
Port 5	Disabled	-	Auto	-	128	Auto	-	False	-
Port 6	Disabled	-	Auto	-	128	Auto	-	False	-
Port 7	Disabled	-	Auto	-	128	Auto	-	False	-
Port 8	Disabled	-	Auto	-	128	Auto	-	False	-
Port 9	Disabled	-	Auto	-	128	Auto	-	False	-

Figure 19: spanning tree port settings

Hint§

The following parameters are shown on the Spanning Tree Port settings page:

- **Path Cost** — This parameter is used by the STP to determine the best path between devices. Therefore, lower values should be assigned to ports attached to faster media, and higher values assigned to ports with slower media. (Path cost takes precedence over port priority.)
- **Priority** — Specify the priority used for this port in the Spanning Tree Protocol. If the path cost for all ports on a switch are the same, the port with the highest priority (i.e., lowest value) will be configured as an active link in the Spanning Tree. This makes a port with higher priority less likely to be blocked if the Spanning Tree Protocol

is detecting network loops. Where more than one port is assigned the highest priority, the port with lowest numeric identifier will be enabled. (Range: 0-240, in steps of 16; Default: 128)

■ **P2P** - The link type attached to an interface can be set to automatically detect the link type, or manually configured as point-to-point or shared medium. Transition to the forwarding state is faster for point-to-point links than for shared media. These options are described below:

- **Auto** - The switch automatically determines if the interface is attached to a point-to-point link or to shared medium. (This is the default setting.)

- **True** - A point-to-point connection to exactly one other bridge.

- **False** - A shared connection to two or more bridges.

■ **Edge (Fast Forwarding)** — You can enable this option if an interface is attached to a LAN segment that is at the end of a bridged LAN or to an end node. Since end nodes cannot cause forwarding loops, they can pass directly through to the spanning tree forwarding state. Specifying edge ports provides quicker convergence for devices such as workstations or servers, retains the current forwarding database to reduce the amount of frame flooding required to rebuild address tables during reconfiguration events, does not cause the spanning tree to initiate reconfiguration when the interface changes state, and also overcomes other STP-related timeout problems. However, remember that this feature should only be enabled for ports connected to an endnode device. (Default: False)

■ **State** - Displays current state of this port within the Spanning Tree.

- **Disabled** - There is no connection on the port.

- **Discarding** - Port receives STP configuration messages, but does not forward packets.

- **Learning** - Port has transmitted configuration messages for an interval set by the Forward Delay parameter without receiving contradictory information. Port address table is cleared, and the port begins learning addresses.

- **Forwarding** - Port forwards packets, and continues learning addresses.

■ **Role** - Roles are assigned according to whether the port is part of the active topology connecting the bridge to the root bridge (that is, **root** port), connecting a LAN through the bridge to the root bridge (that is, **designated** port), or is an **alternate** or **backup** port that may provide connectivity if other bridges, bridge ports, or LANs fail or are removed. The role is set to disabled (that is, **disabled** port) if a port has no role within the spanning tree.

■ **Path Cost** - The path cost setting for the port,

- **Config** - The administrator configured path cost setting.

- **Actual** - The contribution of this port to the path cost of paths towards the spanning tree root which include this port.

■ **P2P** - The point-to-point setting for the port,

- **Config** - The administrator configured P2P setting.

- **Actual** - The operational point-to-point status of the LAN segment attached to this interface. This parameter is determined by manual configuration or by auto-detection.

■ **Edge** — The Edge setting for the port,

- **Config** — The administrator configured Edge setting.

- **Actual** — This parameter is initialized to the port setting for Edge (that is, True or False), but will be set to false if a BPDU is received, indicating that another bridge is attached to this port.

Quality of Service (QoS)

QoS is the evaluation on the service ability of network delivery or on the capacity of dealing with situations such as delay, delay jitter and packet loss rate in packet delivery.

Port-based Priority Setting


Management of the default port priority for each port on the switch.

Web Smart switch interface

To configure global settings for Spanning Tree:

1. Click Configuration, QoS, Port-based Priority.
2. For one or a group of ports, set the default priority value.
3. Click Apply.

Port-based Priority Setting



Port	Priority
Port 1	0
Port 2	0
Port 3	0
Port 4	0
Port 5	0
Port 6	0
Port 7	0
Port 8	0
Port 9	0
Port 10	0

Figure 20: Port-based Priority Setting

Hint§

The following parameters are shown on the Port-based Priority Setting page:

- **Priority** - The default priority used when adding a tag to untagged frames. (Range: 0-7; Default: 0)

DSCP-based Priority Setting


The Differentiated Services Code Point (DSCP) is a six-bit field in the IP header, allowing coding for up to 64 different forwarding behaviors. The DSCP replaces the ToS bits, but it retains backward compatibility with the three precedence bits so that non-DSCP compliant, ToS-enabled devices, will not conflict with the DSCP mapping. Based on network policies, different kinds of traffic can be marked for different kinds of forwarding. Note that all the DSCP values that are not specified are mapped to priority value 0.

Web Smart switch interface

To configure port-level DSCP remarking,

1. Click Configuration, QoS, DSCP-based Priority.
2. Map one or more DSCP values to a priority value.
3. Click Apply.

DSCP-based Priority Setting



DSCP	Priority
0	0
1	0
2	0
3	0
4	0
5	0
6	0
7	0
8	0
9	0

Figure 21: DSCP-based Priority Setting

Hint§

The following parameters are shown on the DSCP-based Priority Setting page:

- **DSCP** - List the DSCP values. (Range: 0-63)
- **Priority** — Map a priority value to the selected DSCP Priority value.

Note that “0” represents low priority and “7” represent high priority.

- **DSCP Priority Table** — Show the DSCP to Priority map.

Priority to Queue Mapping Setting

The QoS technique known as class of service (CoS), is a 3-bit field within an Ethernet frame header when using tagged frames on an 802.1 network. So up to eight separate traffic priorities are defined in IEEE 802.1p. Always can map the priority levels to the switch's output queues in any way that benefits application traffic for our own network.

Web Smart switch interface

To configure port-level DSCP remarking,

1. Click Configuration, QoS, Priority to Queue Mapping.
2. Map one or more priority values to a queue ID.
3. Click Apply.

Priority to Queue Mapping Setting

Priority	Queue ID
0	
1	
2	
3	
4	1(lowest)
5	
6	
7	

Apply

Priority	Queue ID
0	1
1	2
2	3
3	4
4	5
5	6
6	7
7	8

Figure 22: Priority to Queue Mapping Setting

Hint§

The following parameters are shown on the DSCP-based Priority Setting page:

- Priority - CoS value. (Range: 0-7, where 7 is the highest priority)
- Queue ID - Output queue buffer. (Range: 1-8, where 8 is the highest priority queue)

Packet Scheduling Setting

You can set the switch to service the queues based on a strict rule that requires all traffic in a higher priority queue to be processed before lower priority queues are serviced, Weighted Fair Queuing (WFQ), or Weighted Round-Robin (WRR) queuing that specifies a relative weight of each queue. The traffic classes are mapped to one of the eight egress queues provided for each port. You can assign a weight to each of these queues (and thereby to the corresponding traffic priorities). This weight sets the frequency at which each queue will be polled for service, and subsequently affects the response time for software applications assigned a specific priority value.

Web Smart switch interface

To configure port-level DSCP remarking,

1. Click Configuration, QoS, Packet Scheduling.
2. Select the scheduling algorithm, WFQ or WRR.
3. Map scheduling weights to a queue ID, or select "Strict."
4. Click Apply.

Packet Scheduling Setting

Scheduling Algorithm
Weight-fair-queue

Apply

Queue ID	Weight
1	Strict priority
2	
3	
4	
5	
6	
7	
8	

Apply

Queue ID	Scheduling Algorithm	Weight
1	Weight-fair-queue	1
2	Weight-fair-queue	2
3	Weight-fair-queue	3
4	Weight-fair-queue	4
5	Weight-fair-queue	5
6	Weight-fair-queue	6
7	Weight-fair-queue	7
8	Weight-fair-queue	8

Figure 23: Packet Scheduling Setting

Hint§

The following parameters are shown on the DSCP-based Priority Setting page:

- **Scheduling Algorithm** - Select the service method used for port egress queues.
 - **Weight-fair-queue** - Service the egress queues containing data based on the weight of the queue compared

to the sum of the weights of all queues. (This is the default selection.)

- **Weight-round-robin** - Share bandwidth at the egress ports by using the scheduling weights for queues 1 through 8 respectively. WRR specifies a relative weight for each queue that determines the percentage of service time the switch services each queue before moving on to the next queue.
- **Queue ID** - Output queue buffer. (Range: 1-8, where 8 is the highest priority queue)
- **Weight** - Set a new weight for the selected traffic class. (Range: Strict or 1-15)

Use queue weights 1-15 for queues to allocate service time based on WFQ or WRR. Queue weights must be configured in ascendant manner, assigning more weight to each higher numbered queue.

Strict priority requires all traffic in the queue to be processed before lower priority queues are serviced.

LLDP Configurations

LLDP is a Layer 2 protocol that uses periodic broadcasts to advertise information about the sending device.

Web Smart switch interface

To configure global and port settings for LLDP:

1. Click Configuration, LLDP, LLDP Settings.
2. Enable LLDP for the switch.
3. If required, modified other LLDP parameters.
4. For one or a group of ports, set the LLDP mode.
5. Click Apply.

LLDP Configurations

LLDP Status	Disable
Transmission Interval	30 (5~32768)
Hold Time Multiplier	4 (2~10)

Apply

Port	State
Port 1	
Port 2	
Port 3	Disable
Port 4	
Port 5	
Port 6	

Apply

LLDP Port State

Port	State
Port 1	TX and RX
Port 2	TX and RX
Port 3	TX and RX
Port 4	TX and RX
Port 5	TX and RX
Port 6	TX and RX
Port 7	TX and RX

Figure 24: LLDP Settings

Hint§

The following parameters are shown on the LLDP Settings.

- **LLDP Status** - Enable LLDP on the switch. (Default: Disabled)
- **Transmission Interval** - Configure the periodic transmit interval for LLDP advertisements. (Range: 5-32768 seconds; Default: 30 seconds)
This attribute must comply with the following rule: $(\text{Transmission Interval} * \text{Transmission Hold Time}) \leq 65536$, and $\text{Transmission Interval} \geq (4 * \text{Transmission Delay})$
- **Hold Time Multiplier** - Configure the time-to-live (TTL) value sent in LLDP advertisements as shown in the formula below. (Range: 2-10; Default: 3)
The time-to-live tells the receiving LLDP agent how long to retain all information pertaining to the sending LLDP agent if it does not transmit updates in a timely manner. TTL in seconds is based on the following rule: $(\text{Transmission Interval} * \text{Transmission Hold Time}) \leq 65536$. Therefore, the default TTL is $30 * 3 = 90$ seconds.
- **Port** - Port identifier. (Range: 1-18)
- **State** - Enable LLDP message transmit and receive modes for LLDP Protocol Data Units. (Options: Disabled, Tx/Rx, Rx only, Tx only; Default: Disabled)

LLDP Neighbors

To display information about devices connected directly to the switch's ports which are advertising information through LLDP.

Web Smart switch interface

To display LLDP neighbors, click Configuration, LLDP, LLDP Neighbors.

Click the Refresh button to update the LLDP information.




Figure 25: LLDP Neighbors

Hint§

The following parameters are shown on the LLDP Neighbors page.

- **Local Port** - The local port to which a remote LLDP-capable device is attached.
- **Chassis ID** - An octet string indicating the specific identifier for the particular chassis in this system.
- **TTL** - Indicate the time (in seconds) the remote device's information should be treated as valid.
- **LLDP Entry Number** - The number of the LLDP table entry.

SNMP Setting

SNMP (Simple Network Management Protocol) monitor network switches through TCP/IP protocol suite. It offers automatic network management and avoids the physical differences between various switches, and thus provides automatic management of products from different manufacturers.

Web Smart switch interface

To specify SNMP system settings:

1. Click Configuration, SNMP Setting.
2. Enable SNMP for the switch.
3. Configure the Name, Location, and Contact information.
4. Define at least one new community string with read-write access.
5. Delete the default “private” string for security reasons.
6. Click Apply.

SNMP Setting

SNMP Status	Disabled
System Name	Layer 2 Switch
System Location	No Location
System Contact	No Contact

Apply

Community Strings Setting

String	Type
	read-only

Apply

String	Type	Select
public	read-only	<input type="checkbox"/>
private	read-write	<input type="checkbox"/>

Delete

Trap Receivers Setting

IP Address	Community String

Apply

IP Address	Community String	Select

Delete

Figure 26: SNMP Setting, Community Strings Setting, Trap Receivers Setting

Hint§

The following parameters are shown on the SNMP Setting, Community Strings Setting.

- **SNMP Status** - Enable or disable SNMP service. (Default: Disabled)
- **System Name** - A name assigned to the switch system.
- **System Location** - Specify the system location.
- **System Contact** - An administrator responsible for the system.
- **String** – A community string that acts like a password and permits access to the SNMP protocol.

Default strings: “public” (read-only access), “private” (read-write access) Range: 1-32 characters, case sensitive

- **Type** - Specifies the access rights for the community string:
 - **Read-Only** - Authorized management stations are only able to retrieve MIB objects.
 - **Read-Write** - Authorized management stations are able to both retrieve and modify MIB objects.

Trap Receivers Setting

Traps indicating status changes are issued by the switch to specified trap managers. You must specify trap managers so that key events are reported by this switch to your management station (using network management software).

Web Smart switch interface

To configure SNMP system settings:

1. Click Configuration, SNMP Setting.
2. Specify the IP address of management station that will receive SNMP trap messages.
3. Specify a configured community string for the trap receiver.
4. Click Apply.

Hint§

The following parameters are shown on the Trap Receivers Setting.

- **IP Address** - IP address of a new management station to receive notification messages.
- **Community String** – Specify a valid community string for the new trap manager entry. The string must already be defined in the Community String Setting section. (Range: 1-32 characters, case sensitive)

Port Mirroring Setting

Port mirroring includes local mirroring groups, remote source mirroring groups and remote destination mirroring groups.

Web Smart switch interface

To configure port mirroring:

1. Click Configuration, Port Mirroring.
2. Select the Mirror Set Index.
3. Select the Mirror Direction.
4. Select the Mirroring (target) port.
5. Select the one or more mirrored (source) ports.
6. Click Apply.

Port Mirroring Setting

Mirror Set Index	Mirror Direction	Mirroring Port	Mirrored Port List
1	RX	Port 1	<div style="border: 1px solid #ccc; padding: 2px;"> Port 1 Port 2 Port 3 Port 4 Port 5 Port 6 </div>

Mirror Set Index	Mirror Direction	Mirroring Port	Mirrored Port List	Select
1	Disabled	-	-	<input type="checkbox"/>
2	Disabled	-	-	<input type="checkbox"/>

Figure 27: Port mirroring

Hint§

The following parameters are shown on the LLDP Neighbors page.

- **Mirror Set Index** — Display a list of current mirror sessions.
- **Mirror Direction** — Allow you to select which traffic to mirror to the target port, Rx (receive) or Tx (transmit). (Default: Rx)
- **Mirrored Port List** — One or more source ports whose traffic will be monitored. (Range: 1-18 and configured trunks)
- **Mirroring Port** — The target port that will mirror the traffic on the source ports. (Range: 1-18)

Port Security Setting

Port security is a feature that allows you to configure a switch port with a maximum number of MAC addresses that are authorized to access the network through that port. When port security is enabled on a port, the switch stops learning new MAC addresses on the specified port when it has reached a configured maximum number. Only incoming traffic with source addresses already stored in the dynamic or static address table will be accepted as authorized to access the network through that port. If a device with an unauthorized MAC address attempts to use the switch port, the intrusion will be detected and the switch can automatically take a specified action.

Web Smart switch interface

To configure port security:

1. Click Configuration, Port Security.
2. Select the ports to configure.
3. Set Security to Enable.
4. Configure the maximum number of MAC addresses allowed on the port.
5. Set an action for port security violations.
6. Click Apply.

Port Security Setting

Port	Security	Maximum L2 Entry	Action
Port 1			
Port 2			
Port 3			
Port 4	Disable	Un limited (0-16447)	Trap to CPU
Port 5			
Port 6			

Apply

Port	Security	Maximum L2 Entry	Action
Port 1	Disabled	-	-
Port 2	Disabled	-	-
Port 3	Disabled	-	-
Port 4	Disabled	-	-
Port 5	Disabled	-	-
Port 6	Disabled	-	-
Port 7	Disabled	-	-
Port 8	Disabled	-	-
Port 9	Disabled	-	-
Port 10	Disabled	-	-

Figure 28: Port security

Hint§

The following parameters are shown on the Port security page.

- **Port** - Port number.
- **Security** — Enable or disable port security for the selected ports. (Default: Disabled)

- **Maximum L2 Entry** — The maximum number of MAC addresses that can be learned on a port. (Range: 0 - 16447, where 0 means disabled)
- **Action** — Indicate the action to be taken when a port security violation is detected:
 - **Trap to CPU**: Send an SNMP trap message. (This is the default.)
 - **Drop**: Drop other traffic from the port.
 - **Forward**: No action is taken. Traffic is forwarded as normal.

Bandwidth Control Setting

This function allows the network manager to control the maximum rate for traffic received on a port or transmitted from a port. Rate limiting is configured on ports at the edge of a network to limit traffic into or out of the switch. Packets that exceed the acceptable amount of traffic are dropped.

Rate limiting can be applied to individual ports or trunks. When an interface is configured with this feature, the traffic rate will be monitored by the hardware to verify conformity. Non-conforming traffic is dropped, conforming traffic is forwarded without any changes. Input and output rate limits can be enabled or disabled for individual interfaces.

Web Smart switch interface

To configure bandwidth control:

1. Click Configuration, Bandwidth Control.
2. Select the ports to configure.
3. Set Type to Ingress or Egress .
4. Set State to Enable.
5. Configure the maximum rate allowed on the ports.
6. Click Apply.

Bandwidth Control Setting

Port	Type	State	Rate(Kbit/sec)
Port 1			
Port 2			
Port 3	Ingress	Disable	Un limited (0-1048544, must be a multiple of 16)
Port 4			
Port 5			
Port 6			

Port	Ingress Rate (Kbit/sec)	Egress Rate (Kbit/sec)
Port 1	Un limited	Un limited
Port 2	Un limited	Un limited
Port 3	Un limited	Un limited
Port 4	Un limited	Un limited
Port 5	Un limited	Un limited
Port 6	Un limited	Un limited
Port 7	Un limited	Un limited
Port 8	Un limited	Un limited
Port 9	Un limited	Un limited
Port 10	Un limited	Un limited

Figure 29: bandwidth control

Hint§

The following parameters are shown on the LLDP Neighbors page.

- **Port** - Display the port/trunk number.

- **Type** - Specify ingress or egress traffic. (Default: Ingress)
- **State** - Enable or disable the rate limit. (Default: Disabled)
- **Rate (Kbit/sec)** - Set the rate limit level. (Range: 0 - 1048544 Kbps in steps of 16)

Jumbo Frame Setting

The switch provides more efficient throughput for large sequential data transfers by supporting jumbo frames up to 9216 bytes.

Web Smart switch interface

To configure Jumbo Frames:

1. Click Configuration, Jumbo Frame.
2. Select the frame size to configure.
3. Click Apply.




Figure 30: Jumbo Frame Setting

Hint§

The following parameters are shown on the LLDP Neighbors page.

- **Jumbo Frame (Bytes)** - Configure support for jumbo frames. (Options: 9216, 1522, 1536, 1552 Bytes; Default: 9216 bytes)

Management Access Filter

To create up to eight IP addresses or IP address groups that are allowed access to the switch through the Web browser.

Web Smart switch interface

1. Click Configuration, Management Access Filter.
2. Enter an IP address
3. Specify a netmask to define a single IP address, or an address range.
4. Select the table entry to activate the filter.
5. Click Apply.

Management Access Filter

Select	IP Address	IP Netmask
<input type="checkbox"/>	0.0.0.0	255.255.255.255
<input type="checkbox"/>	0.0.0.0	255.255.255.255
<input type="checkbox"/>	0.0.0.0	255.255.255.255
<input type="checkbox"/>	0.0.0.0	255.255.255.255
<input type="checkbox"/>	0.0.0.0	255.255.255.255
<input type="checkbox"/>	0.0.0.0	255.255.255.255
<input type="checkbox"/>	0.0.0.0	255.255.255.255
<input type="checkbox"/>	0.0.0.0	255.255.255.255
<input type="checkbox"/>	0.0.0.0	255.255.255.255

Figure 31: Management Access Filter

Hint§

The following parameters are shown on the LLDP Neighbors page.

- **IP Address** - An IP address specifies a range, that is allowed management access to the switch.
- **IP Netmask** - A mask that specifies a single IP address, or a range of IP addresses. (Default: 255.255.255.255 for a single IP address)


Power over Ethernet Setting

Power over Ethernet (PoE) means that power sourcing equipment (PSE) supplies power to powered devices (PD) such as IP telephone, wireless LAN access point, and web camera from Ethernet interfaces through twisted pair cables.

Web Smart switch interface

1. Click Configuration, Power over Ethernet.
2. Select the port number of the connected PD.
3. Specify the PD on.
4. Click Apply.

Power Over Ethernet Setting



Port	PD	Class	Consumption Power (W)
Port 1	Off	-	0.0
Port 2	Off	-	0.0
Port 3	Off	-	0.0
Port 4	Off	-	0.0
Port 5	On	Class 3	0.800
Port 6	Off	-	0.0
Port 7	Off	-	0.0
Port 8	Off	-	0.0

Figure 32: Power over Ethernet

Hint§

The following parameters are shown on the Power over Ethernet page.

- **PD** - Enable the powered devices. The consumption power in watt will be shown in the table below.
- **Class** – Indicate the PD classification.
- **Consumption Power (W)** – Indicate the PD power consumption.

Once the PSE has detected the PD's power class, the PSE can manage the power allocation by subtracting the PD's class maximum value from overall power budget. This allows for control and management of power allocation when there is not enough power available from the PSE to supply maximum power to all ports.

CHAPTER 4 Security

MAC Address Information

To display the MAC address forwarding table.

Web Smart switch interface

1. Click Configuration.
2. Then click Security, MAC Address, MAC Forwarding Table.

MAC Address Information

No.	MAC Address	VLAN ID	Type	Port
1	00:0C:8E:DC:C5:F5	1	Dynamic Unicast	3

Figure 33: MAC Address Information

Hint§

The following parameters are shown on the MAC Address Information page.

- **No.** - The number of the address entry in the forwarding table.
- **MAC Address** - Physical address associated with this interface.
- **VLAN ID** - The ID of a configured VLAN (1-4094).
- **Type** - Indicate if the MAC address has been dynamically learned or configured as a static entry.
- **Port** - Indicate the port.
- **Clear Dynamic Entries** — Remove all dynamically learned addresses from the forwarding table.

Static MAC Setting

A static address can be assigned to a specific interface on the switch. Static addresses are bound to the assigned interface and will not be moved.

Web Smart switch interface

To configure static MAC addresses:

1. Click Security, MAC Address, Static MAC.
2. Specify the MAC address to be statically assigned.
3. Specify the VLAN ID.
4. Select the port or trunk interface for the static assignment.
5. Click Add.

Static MAC Setting

MAC Address	VLAN ID	Port
<input type="text" value="00:00:00:00:00:00"/>	<input type="text" value=""/> (1~4094)	<input type="text" value="Port 1"/> ▼

No.	MAC Address	VLAN ID	Port	Select
-----	-------------	---------	------	--------

Figure 34: Static MAC Setting

Hint§

The following parameters are shown on the Static MAC Setting page.

- **MAC Address** - Physical address of a device mapped to an interface.
- **VLAN ID** - The ID of a configured VLAN (1-4094).
- **Port** - Port or trunk associated with the device that is assigned as a static address.

MAC Filtering Setting

The MAC Filtering pages are used to filter service to clients attempting to access the Internet based on protocol type, destination/source MAC address, and the direction of traffic for each packet.

Web Smart switch interface

To configure MAC Address Filtering:

1. Click Security, MAC Address, MAC Address Filtering.
2. Specify the MAC address to be filtered.
3. Specify the VLAN ID.
4. Select to filter the MAC address as the source, destination, or both.
5. Set a name to describe the filter.
6. Click Add.

MAC Filtering Setting

MAC Address	VLAN ID	Filter	Name
00:00:00:00:00:00	(1~4094)	Source MAC	

Add

No.	MAC Address	VLAN ID	Filter	Name	Select
-----	-------------	---------	--------	------	--------

Delete

Figure 35: MAC Filtering Setting

Hint§

The following parameters are shown on the LLDP Neighbors page.

- **MAC Address** - Physical address of a device.
- **VLAN ID** - The ID of a configured VLAN (1-4094).
- **Filter** - Filter traffic matching the MAC address in packets. (Options: Source MAC, Destination MAC, Both; Default: Source MAC)
 - **Destination MAC** - Filter packets with a matching destination MAC address.
 - **Source MAC** - Filter packets with a matching source MAC address.
 - **Both** - Filter packets with a matching the source or destination MAC address.
- **Name** – A descriptive name for the MAC address filter.

802.1x Setting

The 802.1X protocol provides port authentication. The 802.1X protocol must be enabled globally for the switch system before port settings are active.

Web Smart switch interface

To configure 802.1X global settings:

1. Click Security, 802.1X, 802.1X Setting.
2. Set 802.1X to Enabled.
3. Specify the RADIUS server IP address.
4. Specify the RADIUS server shared key.
5. Modified other parameters as required.
6. Click Apply.

802.1x Setting

802.1X	Disabled
Radius Server IP	192.168.1.99
Server Port (1024-65535)	1812
Shared Key (max. 30 characters)	
Retype Shared Key	
ReauthEnabled	Enabled
Reauth Period (30~65535 sec)	3600

Apply

Figure 36: 802.1x Setting

Hint

The following parameters are shown on the LLDP Neighbors page.

- **802.1X** — Sets the global setting for 802.1X. (Default: Disabled)
- **RADIUS Server IP** — Address of the authentication server.
- **Server Port** — Network (UDP) port of RADIUS server used for authentication messages. (Range: 1024-65535; Default: 1812)
- **Shared Key** — Encryption key used for RADIUS server messages. Do not use blank spaces in the string. (Maximum length: 30 characters)
- **Retype Shared Key** — Re-type the string entered in the previous field to ensure no errors were made. The switch will not change the encryption key if these two fields do not match.
- **ReauthEnabled** — Set clients to be re-authenticated after the interval specified by the Reauth Period. Re-authentication can be used to detect if a new device is plugged into a switch port. (Default: Enabled)
- **Reauth Period** — Set the time period after which a connected client must be re-authenticated. (Range: 30-65535 seconds; Default: 3600 seconds)


802.1x Port Setting

When 802.1X is enabled, you need to configure the parameters for the authentication process that runs between the client and the switch (that is, authenticator), as well as the client identity lookup process that runs between the switch and authentication server.

Web Smart switch interface

1. Click Security, 802.1X, 802.1X Port Setting.
2. Select one or more ports to configure.
3. Set the 802.1X Mode to “Authentication.”
4. Click Apply.

802.1x Port Setting



Port	Mode
Port 1	Force Unauthorized
Port 2	
Port 3	
Port 4	
Port 5	
Port 6	

Apply

Port	Mode	State
Port 1	No Authentication	Initialize
Port 2	No Authentication	Initialize
Port 3	No Authentication	Initialize
Port 4	No Authentication	Initialize
Port 5	No Authentication	Initialize
Port 6	No Authentication	Initialize
Port 7	No Authentication	Initialize
Port 8	No Authentication	Initialize
Port 9	No Authentication	Initialize
Port 10	No Authentication	Initialize

Figure 37: 802.1x Port Setting

Hint§

The following parameters are shown on the 802.1X Port Setting page.

- **Mode** - Sets the authentication mode to one of the following options:
 - **Force-Authorized** - Force the port to grant access to all clients, either dot1x-aware or otherwise.
 - **Force-Unauthenticated** - Force the port to deny access to all clients, either dot1x-aware or otherwise.
 - **Authentication** - Require a dot1x-aware client to be authorized by the authentication server. Clients that are not dot1x-aware will be denied access.
 - **No Authentication** - Disable 802.1X authentication on the port. (This is the default setting.)
- **State** - Show the current status of the 802.1X authentication process.

IP Filter Configurations

IP Filter Security is a feature that filters IP traffic on port interfaces based on manually configured entries in the IP Filter table, or allowed IP address assignment through DHCP. IP Filter Security can be used to prevent traffic attacks caused when a host tries to use the IP address of a neighbor to access the network.

Web Smart switch interface

To configure IP Filter settings:

1. Click Security, IP Filter Setting.
2. Select one or more ports to configure.
3. Select the mode Static and set an IP address, or select DHCP.
4. Select ports on which to allow traffic to DHCP servers.
5. Click Apply.

IP Filter Configurations

Port	Mode	IP Address	IP Netmask
Port 1			
Port 2			
Port 3	IP Filter Disable	0.0.0.0	255.255.255.0
Port 4			
Port 5			
Port 6			

Apply

Port	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18
DHCP Server Allowed	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>

Apply

Port	Mode	IP	IP Netmask
Port 1	IP Filter Disable	-	-
Port 2	IP Filter Disable	-	-
Port 3	IP Filter Disable	-	-
Port 4	IP Filter Disable	-	-
Port 5	IP Filter Disable	-	-
Port 6	IP Filter Disable	-	-

Figure 38: IP Filter Configurations

Hint§

The following parameters are shown on the IP Filter Configurations page.

- **Mode** – Configure the switch to filter traffic based on IP addresses. (Default: IP Filter Disable)
 - **IP Filter Disable** – Disable IP filtering on the port.
 - **Static** – Enable traffic filtering based on IP addresses configured in the table.
 - **DHCP** – Enable traffic filtering based on IP addresses assigned through DHCP.

- **IP Address** — An IP address, or an address specifying a range, that is allowed access through the switch.
- **IP Netmask** — A mask that specifies a single IP address, or defines a range of IP addresses. (Default: 255.255.255.0)
- **DHCP Server Allowed** — Permit traffic from a DHCP server through the specified ports. (Default: All ports allowed)

Storm Control settings

Broadcast storms may occur when a device on your network is malfunctioning, or if application programs are not well designed or properly configured. If there is too much broadcast traffic on your network, performance can be severely degraded or everything can come to complete halt.

You can protect your network from broadcast storms by setting a threshold for broadcast traffic. Any broadcast packets exceeding the specified threshold will then be dropped.

Web Smart switch interface

To configure Storm Control settings:

1. Click Security, Storm Control.
2. Select the Storm Control type.
3. Select one or more ports to configure.
4. Set the State to “On” and set the threshold rate.
5. Click Apply.

Storm Control Setting

Storm Type	Port	State	Rate (pps)
Broadcast	Port 1 Port 2 Port 3 Port 4 Port 5 Port 6	Off	(0-1000000)

Apply

Port	Broadcast (pps)	Multicast (pps)	Unknown Unicast (pps)	Unknown Multicast (pps)
Port 1	Off	Off	Off	Off
Port 2	Off	Off	Off	Off
Port 3	Off	Off	Off	Off
Port 4	Off	Off	Off	Off
Port 5	Off	Off	Off	Off
Port 6	Off	Off	Off	Off
Port 7	Off	Off	Off	Off
Port 8	Off	Off	Off	Off
Port 9	Off	Off	Off	Off
Port 10	Off	Off	Off	Off

Figure 39: Storm Control settings

Hint§

The following parameters are shown on the LLDP Neighbors page.

- **Storm Type** — Select the storm control type. (Broadcast, Multicast, Unknown Unicast, Unknown Multicast)
- **Port** — Select port and trunk interfaces. (Port Range: 1-18)
- **State** — Enable or disable storm control. (Default: Off)
- **Rate** — Threshold as packets per second (pps). (Range: 0-1000000)

Port Isolation


The feature provides port-based security and isolation of local ports. The switch isolates port traffic by specifying those ports to which it can forward or receive traffic.

Web Smart switch interface

To configure Port Isolation settings:

1. Click Security, Port Isolation.
2. Select one or more ports to configure.
3. Select one or more ports to which traffic can be forwarded and received.
4. Click Apply.

Port Isolation Setting



Port	Port Isolation List
Port 1	Port 1
Port 2	Port 2
Port 3	Port 3
Port 4	Port 4
Port 5	Port 5
Port 6	Port 6

Apply

Port	Port Isolation List
Port 1	1-18
Port 2	1-18
Port 3	1-18
Port 4	1-18
Port 5	1-18
Port 6	1-18
Port 7	1-18
Port 8	1-18
Port 9	1-18
Port 10	1-18

Figure 40: Port Isolation

Hint§

The following parameters are shown on the Port Isolation page.

- **Port** — Select port and trunk interfaces. (Port Range: 1-18)
- **Port Isolation List** — Select port and trunk interfaces to which traffic can be forwarded and received. (Port Range: 1-18; Default: All ports and trunks)

Defence Engine

Defence Engine is an advanced feature that can prevent a switch's CPU from being overwhelmed by flooded packets, such as unknown unicast, unknown multicast, or broadcast packets. This function can be used to prevent malicious viruses or worm attacks.

Web Smart switch interface

To configure Defence Engine settings:

1. Click Security, Defence Engine.
2. Set Defence Engine status to Enabled.
3. Click Apply.




Figure 41: Defence Engine

Hint§

The following parameters are shown on the LLDP Neighbors page.

- **Defence Engine** — Enable or disable the feature. (Default: Enabled)

CHAPTER 5 Monitoring

Port Statistics Information

You can display standard statistics on network traffic passing through each port. This information can be used to identify potential problems with the switch, such as a faulty port or unusually heavy loading. All values displayed have been accumulated since the last system reboot.

Web Smart switch interface

To click Monitoring, Port Statistics to display port statistics.

Port Statistics Information

Port	State	Link Status	TxGoodPkt	TxBadPkt	RxGoodPkt	RxBadPkt
Port 1	Enabled	Link Down	0	0	0	0
Port 2	Enabled	Link Down	0	0	0	0
Port 3	Enabled	Link Up	1854	0	1876	0
Port 4	Enabled	Link Down	0	0	0	0
Port 5	Enabled	Link Down	0	0	0	0
Port 6	Enabled	Link Down	0	0	0	0
Port 7	Enabled	Link Down	0	0	0	0
Port 8	Enabled	Link Down	0	0	0	0
Port 9	Enabled	Link Down	0	0	0	0
Port 10	Enabled	Link Down	0	0	0	0
Port 11	Enabled	Link Down	0	0	0	0
Port 12	Enabled	Link Down	0	0	0	0
Port 13	Enabled	Link Down	0	0	0	0
Port 14	Enabled	Link Down	0	0	0	0
Port 15	Enabled	Link Down	0	0	0	0
Port 16	Enabled	Link Down	0	0	0	0
Port 17	Enabled	Link Down	0	0	0	0
Port 18	Enabled	Link Down	0	0	0	0

Clear

Figure 42: Port Statistics Information

Hint§

The following parameters are shown on the Port Statistics Information page.

- **Port** - The port number.
- **State** - Display the link state of port interfaces (Enabled or Disabled).
- **Link Status** - Display the link state of the port interface (Link Up or Link Down).
- **TxGoodPkt** - The total number of packets transmitted out of the interface.
- **TxBadPkt** - The total number of outbound packets that could not be transmitted because of errors.
- **RxGoodPkt** - The total number of packets received on the interface.
- **RxBadPkt** - The total number of inbound packets that contained errors preventing them from being deliverable.
- **Clear** - Click the button to reset all counters.

CHAPTER 6 Tools

Http Upgrade

Use the HTTP Upgrade page to upgrade the switch's system firmware by specifying a new software file. You can also use the HTTP Upgrade page to save the current configuration to a file on your computer, or to restore previously saved configuration settings to the switch.

Web Smart switch interface

To upgrade switch software:

1. Click Tools, HTTP Upgrade.
2. Click the Browse button, and select the firmware file.
3. Click the Upgrade button to upgrade the switch's firmware.

After the software file is uploaded, the switch prompts for a reboot.

The screenshot shows three distinct sections of a web interface, each enclosed in a rounded rectangular box. The first section is titled 'HTTP Configuration Backup' and contains a single 'Backup' button. The second section is titled 'HTTP Configuration Restore' and features a text input field, a 'Browse...' button with a folder icon, and a 'Restore' button. The third section is titled 'HTTP Firmware Upgrade' and features a text input field, a 'Browse...' button with a folder icon, and an 'Upgrade' button.

Figure 43: Http Upgrade

Hint§

The following parameters are shown on the Http Upgrade page.

- **HTTP Configuration Backup** - Click the Backup button to save the current configuration settings to a file on the local web management station.
- **HTTP Configuration Restore** - Restore previously saved configuration settings to the switch from a file on the local web management station. Use the Browse button to locate the configuration file, then click Restore.
- **HTTP Firmware Upgrade** - Upgrade the switch software from a file on the local web management station. Use the Browse button to locate the software file, then click Upgrade.

Reset Factory Defaults

To restore factory defaults.

Web Smart switch interface

To click Tools, Reset, then click the Reset button. The reset will be complete when the Web browser displays the login page.



Figure 44: Reset

Reboot

To restart the switch.

Web Smart switch interface

To click Tools, Reboot, then click the Reboot button. The reboot will be complete when the web interface displays the login page.




Figure 45: Reboot

SPECIFICATIONS

Standards

- IEEE 802.1d (Spanning Tree Protocol)
- IEEE 802.1p (Traffic Prioritization)
- IEEE 802.1q (VLAN Tagging)
- IEEE 802.1w (Rapid Spanning Tree Protocol)
- IEEE 802.3ad (Link Aggregation)
- IEEE 802.3 (10Base-T Ethernet)
- IEEE 802.3ab (Twisted Pair Gigabit Ethernet)
- IEEE 802.3ad (Link Aggregation Control Protocol LACP)
- IEEE 802.3af (Power over Ethernet 802.3at Type 1)
- IEEE 802.3at (Power over Ethernet 802.3at Type 2)
- IEEE 802.3u (100Base-TX Fast Ethernet)
- IEEE 802.3x (flow control, for full duplex mode)

General

- Media support:
 - 10Base-T Cat3, 4, 5 UTP/STP RJ45
 - 100Base-TX Cat5 UTP/STP RJ45
 - 1000Base-T Cat5e UTP/STP RJ45
- Packet filter/forwarding rate:
 - 1,488,000 pps (1000 Mbps)
 - 148,800 pps (100 Mbps)
 - 14,880 pps (10 Mbps)
- MAC address table: 16K

- Backplane speed: 36 Gbps
- Switch architecture: store and forward
- Configuration options:
 - Port link speed: 10 Mbps, 100 Mbps, 1000 Mbps or auto-negotiation
 - PoE on/off per port
 - Flow control on/off per port
 - VLAN
 - Rate limiting (ingress rate and egress rate)
 - Port Mirroring
 - Port Aggregation/LACP: 8 groups
 - Broadcast Storm configuration with broadcast rate, multicast rate, and flooded unicast rate
 - IGMP Snooping
 - Quality of Service (QoS): port-based or DSCP
- Integrated ICMP Ping client sends ping requests to other network nodes
- SNMPv1/v2c (Simple Network Management Protocol)
- LAN settings (IP address, Gateway, etc.)
- Certifications: FCC Class A, CE

LEDs

- PoE
- Power
- Link/activity

Power

- Input: 90 – 260 V AC, 50 – 60 Hz
- Power consumption: 180 Watts (maximum)

Environmental

- Metal housing
- Dimensions: 440 (W) x 220 (L) x 44 (H) mm (17.3 x 8.7 x 1.7 in.)
- Weight: 3 kg (6.6 lbs.)
- Operating temperature: 0 – 45°C (32 – 113°F)
- Operating humidity: 10 – 90% RH, non-condensing
- Storage temperature: -20 – 90°C (-4 – 194°F)



Free Manuals Download Website

<http://myh66.com>

<http://usermanuals.us>

<http://www.somanuals.com>

<http://www.4manuals.cc>

<http://www.manual-lib.com>

<http://www.404manual.com>

<http://www.luxmanual.com>

<http://aubethermostatmanual.com>

Golf course search by state

<http://golfingnear.com>

Email search by domain

<http://emailbydomain.com>

Auto manuals search

<http://auto.somanuals.com>

TV manuals search

<http://tv.somanuals.com>