



**INTRODUCTION**

Your Caller ID phone stores and displays specific information, provided by your local telephone company, to subscribers of Caller ID or similar caller identification services. You must subscribe to one of these services in order to use this unit.


Your Caller ID phone enables you to:

- Identify callers before you answer the phone.
- View the time and date of each incoming call.
- Handset records 40 Caller ID records sequentially.
- Know who called while you were away.

To get the most from your new phone, we suggest that you take a few minutes right now to read through this user's guide.

**IMPORTANT:** In order to use this unit, you must subscribe to either the standard Name/Number Caller ID Service or Caller ID with Call Waiting Service. To know who is calling while you are on the phone, you must subscribe to Caller ID with Call Waiting Service.

**IMPORTANT:** Because cordless phones operate on electricity, you should have at least one phone in your home that isn't cordless, in case the power in your home goes out.




**WARNING:** TO PREVENT FIRE OR ELECTRICAL SHOCK HAZARD, DO NOT EXPOSE THIS PRODUCT TO RAIN OR MOISTURE.

**BEFORE YOU BEGIN**

**PARTS CHECKLIST**

Make sure your package includes the items shown here.



**MODULAR JACK REQUIREMENTS**

You need an RJ11 type modular jack, which is the most common type of phone jack and might look like the one pictured here. If you don't have a modular jack, call your local phone company to find out how to get one installed.

**INSTALLATION NOTE:** Some cordless telephones operate at frequencies that may cause interference to nearby TVs and VCRs. To minimize or prevent such interference, the base of the cordless telephone should not be placed near or on top of a TV or VCR. If such interference continues, move the cordless telephone farther away from the TV or VCR.

**DIGITAL SECURITY SYSTEM**


Your cordless phone uses a digital security system to provide protection against false ringing, unauthorized access, and charges to your phone line.

When you place the handset in the base, the unit verifies its security code. After a power outage or battery replacement, you should place the handset in the base for about 20 seconds to reset the code.

**INSTALLATION**

**DESKTOP INSTALLATION**

**NOTE:** For desktop charging **only**, the handset is able to charge facing up or down.




1. Place the handset in the base.
2. Raise the base antenna.
3. Plug the power supply cord into an AC outlet. The CHARGE/IN USE indicator comes on indicating that the battery is charging.
4. After charging, connect the telephone line cord to the wall jack.
5. Set the RINGER switch on the handset to ON.

**NOTE:** The phone automatically defaults to touch-tone dialing. To change to pulse (rotary) dialing, see "Tone/Pulse Dialing". If you don't know which type of service you have, check with the phone company.

**WALL MOUNT INSTALLATION**

Because it is necessary to charge the handset for 12 hours prior to connecting the phone for use the first time, it is better to leave the unit on a flat surface during initial charge before attempting to hang it on the wall.

1. Remove the handset hook; turn it upside down, and put it back in the slot. You need to do this so the handset doesn't fall out of the base when it is on the wall.
2. Set the RINGER switch on the handset to ON.
3. Place the handset in the base.
4. Plug the power supply into the base and then into an AC outlet.




The CHARGE/IN USE indicator comes on indicating that the battery is charging.

**Allow the phone to charge for 12 hours before using the first time. If you don't charge the phone properly (for 12 hours) when you first set up the phone, performance of the battery will be compromised.**

5. After charging, plug telephone line cord into the wall jack and store excess phone cord in wall mount bracket.
6. Attach the wall mount bracket by inserting the two tabs at the top and then snapping the tab at the bottom into place.
7. Slip the mounting holes over the wall plate posts and slide the unit down firmly into place. (Wall plate not included.)
8. Raise the base antenna.

**NOTE:** The phone automatically defaults to touch-tone dialing. To change to pulse (rotary) dialing, see "Tone/Pulse Dialing". If you don't know which type of service you have, check with the phone company.

**CALLER ID BOX INSTALLATION**



Required Equipment: Drill, 3/16" Drill Bit, Phillips Head Screw Driver, Level (optional)

1. Determine a suitable location for the unit which is visible from various locations. Be sure the unit is close to an AC outlet, unless you intend to operate the unit with batteries.
2. Locate the mounting template. A guide for the size of the remote unit is included.
3. Fold the template along the horizontal dashed line.
4. Place the template on the wall, and make sure the horizontal dashed line (folded line) is level. You might want to do this visually only, but a level will work best.
5. On the wall, mark the locations shown on the template for holes and drill a 3/16" diameter hole, at least one inch deep.
6. Press one of the plastic anchors into each of the holes and place one screw in each of the anchors. Turn the screw until the head of the screw is 1/8" above the surface of the wall.
7. Slip the mounting holes on the remote unit over the screw heads, and slide the unit firmly into place.


**POWERING THE UNIT**

Your Caller ID box uses an AC power supply or 8 C-size alkaline batteries for receiving caller ID records.

**IMPORTANT:** You will have a limited amount of time to replace the batteries before the memories are lost. Please read the instructions before replacing the batteries and have the batteries ready to be inserted beforehand.

To use the power supply, plug one end of the power supply into the power jack on the back of the Caller ID box and the other end into an AC outlet.

**BATTERY INSTALL**




1. Remove the screw on the bottom of the Caller ID unit and open the battery door.
2. Insert 8 C-size batteries as shown on the diagram.
3. Replace the battery compartment door securely and replace the screw.

**NOTE:** If the low battery icon appears in the display, you need to replace the batteries. It is important that you replace the batteries as soon as possible to maintain Caller ID operation.

**IMPORTANT:** If you are not going to use the telephone for more than 30 days, remove the batteries because they may leak and damage the unit.

**CAUTION:** Use only the ATLINKS USA 5-2497 power supply that came with this unit. Using other power supplies may damage the unit.

**CORDLESS PHONE BASICS**



**RECEIVING A CALL**

1. Check the display to see who is calling.
2. Press the TALK button.

**MAKING A CALL**

To make a call, press the TALK button before you dial and back on.

**REDIAL**

While the phone is on, press the REDIAL button to redial the last number you dialed (up to 32 digits). If you get a busy signal, and want to keep dialing the number, just press REDIAL again (you don't have to turn the phone off and back on).

**FLASH**

Use the FLASH button to activate custom calling services such as call waiting or call transfer, which are available through your local phone company.

**TIP:** Don't use the TALK button to activate custom calling services such as call waiting, or you'll hang up the phone.

**CHANNEL BUTTON**

While talking, you might need to manually change the channel in order to get rid of static. Press and release the CHANNEL button to advance to the next clear channel.

**TEMPORARY TONE**

This feature enables Pulse (rotary) service phone users to access touch-tone services offered by banks, credit card companies, etc., by pressing the TONE button to temporarily make the phone touch-tone compatible. To get information about your bank account, for example, you would:

1. Call the bank's information line.
2. Press the TONE button (\*) after your call is answered.
3. Follow the voice instructions to complete your transaction.
4. Hang up when finished. The phone returns to Pulse (rotary) service.

**FINDING THE HANDSET**

This feature helps to locate a misplaced handset.

Press the PAGE button on the base. The handset beeps continuously for about 2 minutes or until you press any button on the handset. You can also press PAGE again to cancel.

**NOTE:** The ringer does not have to be on for this feature to work.

**RINGER SWITCH**

The RINGER switch must be ON for the handset to ring during incoming calls.

**TONE/PULSE DIALING**

This adjustment allows you to select tone (touch-tone) or pulse (rotary) mode dialing. The phone is automatically set for touch-tone use.

**TONE**

1. Make sure the phone is OFF.
2. Press and hold the CHANNEL button for 2 seconds until the phone beeps.
3. Press TONE\*

**PULSE**


1. Make sure the phone is OFF.
2. Press and hold the CHANNEL button for 2 seconds until the phone beeps.
3. Press #.

**VOLUME**

The VOLUME buttons control the volume of the handset's earpiece.


**VOICE MESSAGING**

Provided your phone company offers voice messaging service and you subscribe to it, the CHARGE/IN USE indicator on the base flashes when the phone is not in use to indicate there is a message waiting. It stops flashing after the message has been reviewed.



**CALLER ID FEATURES**

This unit receives and displays information transmitted by your local phone company. This information can include the phone number, date, and time; or the name, phone number, date, and time. The unit can store up to 40 calls for later review.



**CALLER ID WITH CALL WAITING**

Provided you subscribe to Caller ID with Call Waiting service from your phone company, you are able to see who is calling when you hear the call waiting beep. The caller identification information appears in the display after you hear the tone.

- Press the FLASH button to put the current person on hold so that you can answer the incoming call.

**IMPORTANT:** In order to use this unit, you must subscribe to either the standard Name/Number Caller ID Service or Caller ID with Call Waiting Service. To know who is calling while you are on the phone, you must subscribe to Caller ID with Call Waiting Service.

**RECEIVING AND STORING CALLS**

When you receive a call, the information is transmitted by the phone company to your Caller ID telephone between the first and second ring.

When the memory is full, a new call automatically replaces the oldest call in memory. NEW appears in the display for calls received that have not been reviewed.

**NOTE:** Check with your local phone company regarding name service availability.

**REVIEWING RECORDS**

As calls are received and stored, the display is updated to let you know how many calls have been received.

- Press the arrow down button to scroll through the call records from the most recent to the oldest.
- Press the arrow up button to scroll through the call records from the oldest to the newest.
- To display the last Caller ID record reviewed, make sure the phone is OFF. Then press REDIAL. To dial the number, press REDIAL again. The number dials automatically.

**DELETING RECORDS**

Use the DELETE button to erase the record currently shown in the display or all records.

**DELETING THE CURRENT RECORD**

1. Make sure the phone is OFF.
2. Use the arrow buttons to display the desired Caller ID record.
3. Press DELETE. The display shows ERASE CALL ID?
4. Press DELETE again to erase the record.

**DELETING ALL RECORDS**

1. Make sure the phone is OFF.
2. Use the arrow buttons to display the desired Caller ID record.
3. Press and hold DELETE. The display shows ERASE ALL?
4. Press DELETE again to erase all records.

**DIALING A CALLER ID NUMBER**

1. Make sure the phone is OFF.
2. Use the arrow buttons to display the desired Caller ID record.
3. Press CALL BACK. The number dials automatically.

**CHANGING THE NUMBER FORMAT**

The FORMAT button lets you change the format of the displayed number. The available formats are as follows.

- 7-digit** 7-digit telephone number.
- 10-digit** 3-digit area code + 7-digit telephone number.
- 11-digit** long distance code "1" + 3-digit area code + 7-digit telephone number.

1. Use the arrow buttons to scroll to the number you want to call back.
2. If the number will not dial as shown, press the FORMAT button. Repeat if necessary, until the correct number of digits are shown.
3. Press CALL BACK. The number dials automatically.

**NOTE:** To clear the local area code, press and hold CHANNEL until AREA CODE appears. Then enter "000".

**MEMORY**

Store up to ten 24-digit numbers in memory for quick dialing. This memory feature is in addition to the 40 Caller ID records that can be stored in the Caller ID memory log.

**STORING A NUMBER IN MEMORY**

1. Make sure the phone is OFF.
  2. Press the MEMORY button.
  3. Press the memory location number (0-9).
  4. Press MEMORY again. The display shows ENTER NAME.
- NOTE:** If you don't want to enter the name, skip step 5.
5. Use the keypad to store a name (up to 15 characters). More than one letter or character is stored in each of the number keys. For example, to enter Joe Smith, press 5 for J; press 6 three times for O; press 3 two times for E; press 1 to enter a space before you start entering the last name; press 7 four times for S; press 6 for M; press 4 three times for I; and 2 two times for H.
- If you're using two letters consecutively that are stored in the same number key, you must press FORMAT between the letters. For example, if you enter Barb, press 2 two times for B; press FORMAT; press 2 for A; 7 three times for R; and 2 two times for B. You need to press FORMAT between the B and the A since they are stored within the same number key.
6. Press MEMORY. The display shows ENTER TEL NUMBR.
  7. Use the keypad to enter the number you want to store (up to 24 digits). To add a pause, See "Inserting a Pause in the Dialing Sequence".
  8. Press MEMORY again to store the number.
  9. Record whose number is stored in the location on the memory label provided. You will also be able to view the name and number in the display.

**CHANGING A STORED NUMBER**

Use the same procedure to change a stored number as you do to store a number—you're just replacing the phone number with a different one.

**DIALING A STORED NUMBER**

1. Make sure the phone is ON by pressing the TALK button.
  2. Press MEMORY.
  3. Press the number (0-9) for the desired memory location. The number dials automatically.
- OR -
1. Make sure the phone is OFF.
  2. Press MEMORY.
  3. Use the arrow buttons to scroll through the numbers stored in memory until the desired number is shown.
  4. Press CALL BACK. The numbers dials automatically.

**IMPORTANT:** If you make test calls to emergency numbers stored in memory, remain on the line and briefly explain the reason for the call to the dispatcher. Also, it's a good idea to make these calls in off-peak hours, such as early morning or late evening.

**INSERTING A PAUSE IN THE DIALING SEQUENCE**

Press the REDIAL button to insert a delay in the dialing sequence of a stored telephone number when a pause is needed to wait for a dial tone (for example after you dial 9 for an outside line, or to wait for a computer access tone). Each pause counts as 1 digit in the dialing sequence.





## Free Manuals Download Website

<http://myh66.com>

<http://usermanuals.us>

<http://www.somanuals.com>

<http://www.4manuals.cc>

<http://www.manual-lib.com>

<http://www.404manual.com>

<http://www.luxmanual.com>

<http://aubethermostatmanual.com>

Golf course search by state

<http://golfingnear.com>

Email search by domain

<http://emailbydomain.com>

Auto manuals search

<http://auto.somanuals.com>

TV manuals search

<http://tv.somanuals.com>