

KEYS 8800, 8800 LI and 8500 TREADMILL

MODEL NO._____

SERIAL NO.

The Model and Serial numbers are located on frame just below the motor hood cover. Please write down these numbers in the spaces provided above for future reference.


OUESTIONS?

DO NOT RETURN this product to the store where purchased. CALL OUR TOLL FREE HELPLINE

USA: 1-888-340-0482 Canada: 1-800-897-6025

CAUTION!

Please read the precautions and instructions in this manual before using this equipment. Please save this manual for future reference.



OWNER'S MANUAL

KEYS FITNESS PRODUCTS, L.P. P.O. Box 551239
Dallas, Texas 75238-1239

MADE IN U.S.A.

KEYS FITNESS PRODUCTS, LP - LIMITED WARRANTY

PLEASE CONSULT YOUR PHYSICIAN BEFORE USING THIS PRODUCT.

This Limited Warranty applies in the United States, Canada, and Mecioe to products manufactured or distributed by Keys Riness Products. LiP (Keys) ") under the Keys Inraed name. The warranty period to the original purchaser for the model 800 is distincting on the trans, (a) years on the model. (b) years not the model and the model of the model 100 is distincted on the trans, (b) years on the model. (b) years not the model and the warranty period to the original purchaser for the model along light instinctions is (elithine) on the frame, (b) years on the model. (b) years not period to the product (the 100) year have purchased for non-commercial, personal, hinty, or bioscaled or or on an authorized Keys results is fee from one of the feet of the model of the 100 years and the model of the model of the 100 years are the model of the 100 years are the product (the 100 years are the period of the 100 years are the 1

Keys warrant that the Freduct (the 1900) you have purchased for non-commercial, personal, family, or household use from Keys of 1900 an intenders every resulter is tree from refects in materials or workmarship under commission within the warranty personal. Keys warrants that the Product the video commercial use from Keys or from an authorized Keys resider is kee from defects in materials or workmarship under normal use during the warranty person. Seeks receipt, showing the date of purchases of the Product from you. It is also receipt, showing the date of purchases of the Product from you. It excludes separable parts. This warranty may vertend to you, the Vertendant to you will be transferable to anyone who subsequently purchases the Product from you. It excludes separable parts. This warranty may remark to you be readed to the product from you. It excludes separable parts from the Vertendant to the Vertendant to the Vertendant to the Vertendant to the Vertendant of the Vertendant to Mercy Fineses authorized descendant to Mercy Fineses and the Vertendant to Mercy Fineses authorized

assumpostination by a Keys Tainest authorized maintechnician unities otherwise authorized by Keys Thiests in writing (If anyous other than it Keys Thiests authorized dealurischnician seemblest a Keys Thiests Seadmill the water and the season of the seaso

be contrally existing womenty.

To obtain warranty service, you must contact a Keya authorized service technician or Keys Filmess at our plane numbers located in this menual. Any parts
determined to be defective must be returned to Keys to Ostain warranty service.

The obtaining the contractive of the contractive of

loss during singment. You must precent style with protect-projections during singment. You must precent style with protection provided documents will be cares in with the Lamber of the protection of the protect

Experience for payment.

Light-institutional settings, as defined there include hotel, motel, hospital or rehabilitation centers, multi-family devellings (condominium or aparament complexes), police departments, for departments, for departments, for departments, for departments, for departments, for any other settings, whereas the Product will carry no warranty, Health clubs, fitness centers, pass, and the like that have a memberably fer are accluded as light-institutional settings, whereas the Product will carry no warranty in these settings. Written authorization from Keys Friences was to obtained regarding any other Fight-institutional settings.

SCORT AS EXPRESSLY EST PORTH IN THIS MARSHALL (EST MAKES NO OTHER WARRANTER, CERRESSO ON IMPLICE INCLUDING ANY IMPLICE WARRANTIES OF MEMORIAN CHARLES AND INCLUDING ON PARTICULAR PRINCES. MYSE SERVICES OF CONTROL AND INCLUDING ON PARTICULAR PRINCES. MYSE SERVICES OF CONTROL AND INTEREST ON THIS LIMITED ON THE SERVICE OF CONTROL AND INTEREST ON THE SERVICE OF CONTROL AND INTEREST ON THE SERVICE OF CONTROL AND INTEREST ON THE SERVICE OF CONTROL ON THE SERVICE ON THE SERVICE OF CONTROL ON THE SERVICE OF CONTROL ON THE SERVING ON THE SERVICE OF CONTROL ON THE SERVICE OF CONTROL ON THE SER

PLEASE SEND IN THE ATTACHED WARRANTY CARD WITHIN TEN (16) DAYS OF PURCHASE TO REGISTER YOUR TREADMILL WITH KEYS FITNESS PRODUCTS, LP.

| | WARRANTY REGISTRATION | |
|--|--|---|
| A, FIRST NAME INITIAL ITREET | LAST NAME APT NO. STATE ZIP | NOTE The model number is found on the food of the Courter Manual MODEL NO. SERIAL NO. NOTE The senial number is found on the E' sticke located on the Form of the treadmal DATE OF PURCHASE |
| B. What store or catalog did you purchase this product? | How did you learn of this product? TV Friend Radio Print ad/liyer Internet Salesperson | I. How important are each of the following features: Least Most Speed Downstern Downster |
| C. How do you plan to use this product? | G. Why did you buy a treadmill? Dr.'s Orders Improve cardiovascular Lose weight fitness | Price DDDD |
| D Sex of purchaser: Mate □ Fernale | ☐ Firm up ☐ In home convenience/ safety ☐ Other | Other comments or suggestions: |
| E. Age of purchaser: Under 14 115-24 125-34 135-44 45-54 155-045 Over 155 over 15 | H. Why did you choose our product? Speed Range Look/Design Horsepower Salety Warranty Brand DAMESCOM. AIT WARRINGS Sea | arch And Download |

KEYS 8800, 8800 LI and 8500 OWNER'S MANUAL



TABLE OF CONTENTS

PAGE

| Warranty card | 2-3 |
|---|------------|
| Important safety information | 4-5 |
| Before you start | 5 |
| Assembly instructions | 6-7-8 |
| How to plug in the power cord | 9 |
| Console functions | 10 |
| Console descriptions | 11 |
| Program profiles | 12 |
| Operating instructions | 13 |
| Heart rate control operating instructions | 14 |
| Maintenance instructions | 14 |
| Belt adjustments and tension | 15 |
| Troubleshooting guide | 16 |
| Exploded view and parts list | 17 |
| Exercise guide | 18 |
| Contacting customer service (back cover) | Back Cover |

Download from Www.Somanuals.com. All Manuals Search And Download.

Important Safety Information

WARNING!

- 4) Before using this treadmill or starting any exercise program, consult your physician. This is especially important for persons over the age of 35 and/or persons with pre-existing health problems. Keys Fitness Products LP assumes no responsibility for personal injury or property damage sustained by or through the use of this product.
- 2) To reduce the risk of electrical shock, burns, fire, or other possible injuries to the user, it is important to review this manual and the following precautions before operation.

SAFETY PRECAUTIONS AND TIPS


- It is the owner's responsibility to ensure that all users of this treadmill have read the Owner' Manual and are familiar with warnings and safety precautions.
- This treadmill has a user capacity of 300 pounds maximum user weight.
- The treadmill should only be used on a level surface and is intended for indoor use only. The treadmill should not be placed in a garage, patio, or near water and should never be used while you are wet. Keys recommends a treadmill mat be placed under the treadmill to material floor or careet and for easier cleaning.
- Follow safety information in regards to plugging in your treadmill. Keep the power cord away from the incline wheels and do not run the power cord underneath your treadmill. Do not operate the treadmill with a damaged or frayed power cord.
- Wear comfortable, good-qualify walking or running shoes and appropriate clothing. Do not use the treadmill with bare feet, sandals, socks or stockings!
- Always straddle the belt and allow it to start moving before stepping onto the belt.
- Hold on to handrails when adjusting speed, incline, or other controls.
- Always examine your treadmill before using to ensure all parts are in working order.
- Allow the belt to fully stop before dismounting.
- Pets should be never be allowed near or on the treadmill.
- Do not leave children unsupervised near or on the treadmill.
- Never operate the treadmill where oxygen is being administered, or where aerosol products are being used.
- Never insert any object or body parts into any opening.

- Always unplug the treadmill before cleaning and/or servicing. Service to your treadmill should only be performed by an authorized service representative, unless authorized and/or instructed by a Keys treadmill technician. Failure to follow these instructions will void the treadmill warranty.
- Never leave the treadmill unattended while it is running.

Before You Start

Thank you for purchasing a Keys treadmill! This quality product you have chosen was designed to meets your needs for cardiovascular exercise.

- Before you start, please read the Owner's Manual and become familiar with the operation of your new treadmill.
- . Do not stand on the walking belt wile pressing the Power button or Start/Stop button.
- Always adjust the speed of the treadmill in small increments as this treadmill is capable of high speeds.
- If you are taking medication, consult your physician to see if the medication will affect your exercise heart rate.
- If you have heart problems, you are not active, and/or are over the age of 50 years, do not use
 the pre-set treadmill programs or start an exercise program without first contacting a getting
 approval from your physician.
- To avoid the risk of electrical shock, always keep the console dry. Do not spill liquids on the console. Keys recommends a sealed water bottle for beverages consumed while using the treadmill.




Assembly Instructions

Keys treadmills are shipped in two pieces; the console assembly and the base. The following steps should be followed for assembling the treadmill:

Remove any packing materials from the treadmill. Do not throw away any packing materials until assembly is completed.

Place the base on a clean, level surface. Make sure the electrical cord will easily reach an electrical outlet

- 1. Raise the console into an upright position and install 3.5" x 5/16" bolts (2) with washers and secure using 5/16" nyloc nuts (2) (Diagram 1).
- 2. Find the wire harness exiting from the left upright. Plug wire harness into motor controller circuit board. Tie off excess wire with the attached plastic tie (Diagram 1).
- 3. Install motor hood cover using 5/8" phillips head screws (8 screws) (Diagram 1).
- 4. Handlebar installation, Handlebars include toggle switches for speed and incline. Incline toggle switch is on the left (as you stand on the treadmill). Plug in wire harnesses for each side and push excess wire into holes (Diagram 2).
- Attach left and right handlebars with 5" all thread bolts, Loosely tighten (Diagram 3).
- Loosely attach bottom side of handrails to uprights with 1" button head screws (Diagram 3).
- Install cross handlebar with 2 ½ button screws (Diagram 3).
- 8. Securely tighten all handrail bolts and screws.
- 9. Be sure that the treadmill is level to the floor. The rear feet can be adjusted to level the treadmill. Assembly is complete!



How to Plug in the Power Cord

WARNING!

IMPROPER CONNECTION OF THE EQUIPMENT GROUNDING CONNECTOR CAN RESULT IN A RISK OF AN ELECTRIC SHOCK. CHECK WITH A QUALIFIED ELECTRICIAN OR SERVICE MAN IF YOU ARE IN DOUBT AS TO WHETHER THE PRODUCT IS PROPERLY GROUNDED. DO NOT MODIFY THE PLUG PROVIDED WITH THE PRODUCT, IF IT WILL NOT FIT THE OUTLET, HAVE A PROPER OUTLIFFT INSTALLED BY A QUALIFIED ELECTRICIAN.


This treadmill can be seriously damaged by sudden voltage changes in your home's electrical power. Voltage spikes, surges, and noise interference can result from weather conditions or from other appliances being turned on or off. To reduce the possibility of treadmill damage, always use a surge protector (not included) with your treadmill.

Surge protectors can be purchased at most hardware stores. Keys recommends a single outlet surge protector with a UL 1449 rating as a Transient Voltage Surge Suppressor (TVSS) with a UL suppressed voltage rating of 400V or less and an electrical rating of 120VAC 15 amost.

This treadmill must be grounded to reduce the risk of electrical shock. Grounding provides a path of least resistance for electric current, should the treadmill mailfunction. The Keys treadmill comes with an electrical cord having an equipment-grounding conductor and a grounding plug. Always plug the power cord into a surge protector, and plug the surge protector into an appropriate outlet that is properly installed and grounded in accordance with all local codes and ordinances.

This product is for use on a nominal 120-volt circuit, and has a grounding plug that looks like the plug illustrated in the drawing (1) below. A temporary adapter shown below (2) can be used to connect the surge protector to a 2-pole receptacle if a property grounded outlet is not available. This temporary adapter should only be used until a property grounded outlet (3-pole) receptacle can be installed by a qualified electrician.

The green colored lug or equivalent extending from the adapter must be connected to a permanent ground such as a property grounded outlet box cover. Whenever the adapter is used, it must be held in place by a metal screw. Some 2-pole receptable outlet box covers are not grounded. Contact a qualified electrician to insure the outlet box cover is grounded before using an adapter.



.

Console Functions

There are five display windows on the control panel to provide you with vital feedback information.

TIME WINDOW

- TIME: Indicates elapsed time after pressing start in minutes and seconds (0-99 minutes, 0-59 seconds)
- INTERVAL TIME: Indicates countdown in seconds to the next interval starting at 5 seconds and counting to 0 seconds.

SPEED WINDOW

. SPEED: Indicates MPH (miles per hour) or KMH (kilometer per hour) in .1 increments

DISTANCE / CALORIES WINDOW

- DISTANCE: Indicates Miles or Kilometers traveled in .01 increments up to 9.99 and .1 increments starting at 10.0
- . CALORIES: Indicates estimated calories used based on 150 lb person at the indicated speed, incline, and time

INCLINE WINDOW

- INCLINE: Indicates incline in percent of grade 0-15% in .5 increments
- PULSE (8800 Model Only): Indicates current heart rate
- HEART "*" (8800 Model Only): Indicates control panel is receiving a signal from heart rate transmitter. Heart will blink on and off if receiving signal from Heart Rate Transmitter chest strap.

CENTER BRICKYARD


 Displays quarter mile track in Manual mode. Indicates position on track by a blink. In program mode, shows the change in speed profile across the interval range (1-10) and shows position with a blinking action.

SPEED BAR


The Speed Bar allows the user to adjust speed quickly. The Speed Bar works in all manual and program
modes. To use the Speed Bar, the bett must already be moving. Press the desired speed (2 through 8), and
the treadmill will slowly reach the speed selected. In program mode, the change in speed with the Speed Bar
will only work in the current interval. Once the program switches to another interval, the speed will revert back
to the programmed speed.


TOGGLE SWITCHES IN HANDLEBARS FOR SPEED AND INCLINE

Your treadmill is equipped with toggle switches to conveniently change the indine and speed without reaching
up to the conside, in program mode, the change in speed and/or incline with the toggle switches will only work
in the current interval. Once the program switches to another interval, the speed and incline will revert back to
the programmed speed and incline.



Program Profiles






FAT BURN PROGRAM

Constant Speed throughout program, with Incline changes on alternating intervals.



CARDIO PROGRAM

Constant Incline throughout program, with Speed changes on alternating intervals.



INTERVAL

Gradual Speed and Incline increase to plateau, ending with gradual decrease in Speed and Incline.

CROSS TRAINING PROGRAM Variable Speed and Incline changes from full Incline and half Speed to zero Incline and full Speed, changing on each interval.

Operating Instructions

QUICK START / MANUAL MODE

- Plug into a standard wall outlet (110 Volt AC, 15 amp circuit)
- · Stand on the treadmill and straddle belt.
- Press POWER button. There will be an eight (8) second delay after pressing the POWER button before data can be entered. The TIME window will flash.
- Press START/STOP button. Belt will begin to move after 4 seconds. Slep on belt slowly after the belt starts moving. Speed or incline may be adjusted by using the appropriate + (increase) or -- (decrease) buttons.
- To end your workout, press START/STOP button.
 Belt will gradually slow to zero.
- To pause your workout, press PAUSE.
- To re-start after pausing: Press the PAUSE button.
 WARNING: The treadmill belt will resume at the speed the treadmill was moving prior to pausing.
- Countdown Time, Preset Speed and/or Incline:
 Time, Speed, and Incline may be preset prior to getting
 started. After pressing the POWER button, the time
 window will blink. Use the SPEED/TIME + or arrows
 to select your workout time, then press the ENTER
 PROGRAM button. The SPEED/TIME window will now
 be flashing. Using the same + or arrows, select the
 speed for your workout, then press ENTER
 PROGRAM. Not the INCLINE window will be flashing.
 Use the INCLINE + or arrows to set your workout
 incline, then press ENTER PROGRAM. To start, press
 the START/STOP button.

PROGRAM MODE

- Plug into a standard wall outlet (110 Volt AC, 15 amp circuit)
- Stand on the treadmill and straddle belt.
- Press POWER button. There will be an eight (8) second delay after pressing the POWER button before data can be entered. The TIME window will flash.

- There are four (4) preset programs to choose from: Fat Burn, Cardio, Warm Up, and Cross Training (see the program profiles later in this manual). Select the program by pressing the appropriate button.
- Press START/STOP button. Belt will begin to move after 4 seconds. Step on belt slowly after the belt starts moving.
- Customizing programs in P1 and P2 Mode: Each pre-set program can be customized in the P1 or P2 mode. After making the program selection, the top right window (CALORIES / DISTANCE) will read "OP." "OP" refers to "original program" and is preset. Press the same program button once more, and the CALORIE / DISTANCE window will read P1. The "P1" mode is now accessed. You can now program the Time. Speed, and Indine in P1 mode, which will save your entered information for future use, the time window will blink. Use the SPEED/TIME + or - arrows to select your workout time, then press the ENTER PROGRAM button. The SPEED/TIME window will now be flashing. Using the same + or - arrows, select the speed for your workout, then press ENTER PROGRAM. Now the INCLINE window will be flashing. Use the INCLINE + or - arrows to set your workout incline, then press ENTER PROGRAM. To start, press the START/STOP button. To access P2 mode, press the selected program button three times (once for OP, twice for P1, three times for P2). Follow the above procedure to customize. PLEASE NOTE: Once you have programmed the P1 or P2 modes, you will need to use the PAUSE button to change the program you previously entered.
- USER PROGRAMS There are two (2) user programs that allow the user to customize speed and incline for each of the ten (10) intervals. Press the User Program button once for U1 or twice for U2. The top right window (CALORIES/DISTANCE) will read U1. The TIME window should flash, but if it is not, press the PAUSE button. Use the SPEED/TIME + or buttons to set your workout time, then press the ENTER PROGRAM button. The SPEED/TIME window will now be flashing. Using the same or arrows, select the speed for the first interval, then press ENTER PROGRAM. Now the INCLINE window will be flashing. Use the INCLINE+ or arrows to set the incline for the first interval, then press ENTER PROGRAM. Continue these steps for all ten intervals.

Heart Rate Control Operating Instructions (8800 Only)

HEART RATE PROGRAM MODE

- Plug into a standard wall outlet (110 Volt AC, 15 amp circuit)
- Place the Heart Rate transmitter strap across chest against the skin. Stand on the treadmill and straddle belt.
- Press POWER button. There will be an eight (8) second delay after pressing the POWER button before data can be
 entered. The TIME window will flash. The "Heart" shape on the treadmill will be flashing if the Heart Rate Transmitter is
 transmitting. Adjust the strap on the chest until the console is picking up a signal.
- For Ouick Start, press START/STOP button. Belt will begin to move after 4 seconds. Step on belt stowly after the belt starts
 moving. Speed or incline may be adjusted by using the appropriate + (increase) or (decrease) buttons. Heart rate will read
 out in the Incline window.
- To select the Heart Rate Control program, press the "Heart Rate Control" button.
- You can now program the Time, Speed, and Heart Rate. The time window will blink. Use the SPEED/TIME + or arrows to select your workout time, then press the ENTER PROGRAM button. The SPEED/TIME window will now
 be flashing. Using the same + or arrows, select the maximum speed for your workout, then press ENTER
 PROGRAM. Now the INCLINE window will be flashing. Use the TARGET + or arrows to set your target heart rate,
 then press ENTER PROGRAM. To start, press the START/STOP button.

Maintenance Instructions

The Keys treadmills are equipped with MAINTENCANCE-FREE DECKS. LUBRICATION IS NOT REQUIRED!

The treadmill deck is a specialized waxed surfacellaminate material that is maintenance free. There are no re-wax products available and the deck cannot be re-waxed. Any attempt to lubricate the treadmill deck will void the warranty.

CLEANING.

Routine cleaning of your Keys treadmill will extend the life of your treadmill. WARNING! To prevent electrical shock, be sure the power to the treadmill is OFF and the unit unplugged from the wall electrical outlet before attempting any cleaning or maintenance.

AFTER EACH WORKOUT: Wipe off the console and other treadmill surfaces with a clean, water dampened soft cloth to remove excess perspiration. USE NO CHEMICALS.

WEEKLY: Use of a treadmill mat is recommended for ease of cleaning. Dirt from your shoes contacts the belt and eventually makes it to underneath the treadmill. Vacuum underneath treadmill once a week,

DO NOT CLEAN OR WIPE UNDERNEATH THE BELT! As mentioned above, the deck is lubricated

Belt Adjustment and Tension

Belt adjustment and tension performs two functions: adjustment for tension and centering. Your new treadmill comes pre-adjusted from the factory for tension and centering. Please follow the procedures below if the belt shifts left or right or if the belt slips while walking:

WALKING BELT HAS SHIFTING TO THE LEFT (Diagram 1)

First, unplug the power cord from the surge protector. Using the hex key provided, turn the left rear roller adjustment bolt ¼ turn in the clockwise direction. Plug the power cord back into the surge protector and run the treadmill at 2.5 mph. You should see the belt start to correct itself, moving back towards the center. Repeat the above procedure until the walking belt is centered. It may be necessary to set walking belt tension once you have completed this procedure if the belt feels like it is slipping while walking. Refer to below to the "Walking Belt Slipping" instructions.

WALKING BELT HAS SHIFTING TO THE RIGHT (Diagram 2)

First, unplug the power cord from the surge protector. Using the hex key provided, turn the right rear roller adjustment bolt ¼ turn in the clockwise direction. Plug the power cord back into the surge protector and run the treadmill at 2.5 mpt. You should see the belt start to correct itself, moving back towards the center. Repeat the above procedure until the walking belt is centered. It may be necessary to set walking belt tension once you have completed this procedure if the belt feels like it is slipping while walking. Refer to below to the "Walking Belt Slipping" instructions.

WALKING BELT IS SLIPPING DURING USE (Diagram 3)

First, unplug the power cord from the surge protector. Using the hex key provided, turn both left and right rear roller adjustment botts the same distance, usually a ¼ turn in the clockwise direction. Plug the power cord back into the surge protector and run the treadmill at 2.5 mph. You should now walk on the belt to determine if the belt is still slipping. Repeat the above procedure until the walking belt is not slipping. The tension should be just tight enough not to slip.

WARNING: Incorrect tension adjustment (too tight) may cause pre-mature roller failure. Do not over tighten.



Troubleshooting Guide

Treadmill will not start.

- Make sure the power cord is plugged into a surge protector, the surge protector is plugged into a properly
 grounded cuttlet, and the surge protector is turned on. (Refer to "How to Pluo in the Power Cord)
- Check the circuit breaker located on the front of the treadmill. If the switches protrudes, it has tripped. Wait five minutes and then press the switch back in.
- 3) Check the house electrical breaker box and the circuit breaker for the room the treadmill is located in. If it has tripped, reset or have an electrician replace the breaker in home.
- 4) Have an electrician check for inadequate voltage at the outlet.

Treadmill looses power during use.

- Check the circuit breaker located on the front of the treadmill. If the switches protrudes, it has tripped. Walt five minutes and then press the switch back in.
- 2) Check the house electrical breaker box and the circuit breaker for the room the treadmill is located in. If it has tripped, reset or have an electrician replace the breaker in home.
- 3) If treadmill still will not operate, please call our toll-free HELPLINE, (888) 340-0482.

Treadmill walking belt slows during use.

- Check to make sure the treadmill is securely plugged into a UL-listed surge protector, rated at 15 amps, with a 14-quage cord of five feet or less and the surge protector is securely plugged into the outlet.
- 2) If treadmill still will not operate, please call our toll-free HELPLINE, (888) 340-0482.

Treadmill walking belt slips or is not centered on rear roller.


- 1) Refer to "Belt Adjustment and Tension" section.
- Need help? Call our toll-free HELPLINE, (888) 340-0482.

Treadmill Error Messages.

Your treadmill is equipped with a software package that enables error messages to be displayed when there is a problem. To avoid possible damage to the treadmill and the possibility of injury, do not operate the treadmill until the problem is corrected.

Call our toll-free HELPLINE, (888) 340-0482 for recalibration procedures and self check information.

Error Codes include: E11, E22, E33, SI-1, SI-2



Exercise Guide

WARNING!

Before using this treadmill or starting any exercise program, consult your physician. This is especially important for persons over the age of 35 and/or persons with pre-existing health problems. Keys Fitness Products LP assumes no responsibility for personal injury or property damage sustained by or though the use of this product.

WARM LIP

Warming up prepares the body for exercise by increasing circulation, supplying more oxygen to the muscles and raising body temperature. Begin each workout with 5 to 10 minutes of stretching and light exercise to warm up. The drawings on this page show several forms of basic stretching you may perfore before your workouts. Again, consult a physician before starting this or any other exercise program!

- Toe Touch Stretch (Repeat 3 times). Stand bending your knees slightly and slowly bend forward from your hips. Allow your back and shoulders to relax as your each down toward your toes as far as possible. Hold for 15 counts, then relax. This will stretch your harnstrings, back of knees, and back.
- Hamstring Stretch (Repeat 3 times). Sit with one leg extended. Bring the sole of the opposite foot toward you and rest it against the inner thigh of your extended leg. Reach toward your toes as far as possible. Hold for 15 counts, then relax. Repeat with the other leg. This will stretch your hantings, lower back, and proin.
- 3) Calf-Achilles Stretch (Repeat 3 times). With one leg in front of the other, reach forward and place your hands against a wall. Keep your back leg straight and your back foot flat on the floor. Bend your front leg, lean forward and move your hips toward the wall. Hold for 15 courts, then relax. To cause further stretching of the achilles tendors, bend your back leg as well. Repeat with the other leg. This will stretch your calves, achilles tendors, and ankies.
- 4) Quadriceps Stretch (Repeat 3 times). With one hand against a wall for balance, reach back and grasp one foot with your other hand. Bring your heel as dose to your buttocks as possible. Hold for 15 counts, then relax. Repeat with the other leg., This will stretch your quadriceps and hip muscles.
- 5) Inner Thigh Stretch (Repeat 3 times). Sit with the soles of your feet together and your knees outward. Pull your feet toward your groin area as far as possible. Hold for 15 counts, then relax. This will stretch your quadriceps and hip muscles.





KEYS 8800, 8800 LI and 8500 TREADMILL

QUESTIONS?

CALL OUR TOLL FREE HELPLINE

USA: (888) 340-0482 or (214) 340-8888

Canada: (800) 897-6025

CAUTION!

Please read the precautions and instructions in this manual before using this equipment. Please save this manual for future reference.

Dear Keys' Treadmill Customer!

Thank you for purchasing a keys' treadmility you have now invested in a superior quality product and a fitness lifestyle. We have at Keys Fitness Products have produced what we believe is the finest treadmill with exceptional value. A dedicated team of employees manufactures all Keys treadmills at our plant in Tyler, Texas.

Should you ever have a question concerning your treadmill, please feel free to give us a call at 1-888-340-0482. We will be glad to be at your sanice!

Sincerely yours in fitness!

Keys Fitness Products, LP

OWNER'S MANUAL

KEYS FITNESS PRODUCTS, L.P. P.O. Box 551239 Dallas, Texas 75238-1239

MADE IN U.S.A.

Download from Www.Somanuals.com. All Manuals Search And Download.

Free Manuals Download Website

http://myh66.com

http://usermanuals.us

http://www.somanuals.com

http://www.4manuals.cc

http://www.manual-lib.com

http://www.404manual.com

http://www.luxmanual.com

http://aubethermostatmanual.com

Golf course search by state

http://golfingnear.com

Email search by domain

http://emailbydomain.com

Auto manuals search

http://auto.somanuals.com

TV manuals search

http://tv.somanuals.com