

# ACCUSPLIT® AX740SBL

## OPERATING INSTRUCTIONS

### BASIC STOPWATCH OPERATIONS

**Twin Button Feature:** The Left and Right buttons on new ACCUSPLIT stopwatches operate interchangeably, so both are labeled “A” for these instructions.

#### Backlight

LED Backlight comes on for 10 minutes after each button push (light cannot be turned off).

#### Event

A – Start

A – Stop (Display shows “SPLIT”)

A (2sec) – Reset

#### Dual Split Memory with Split Counter

A – Start (Shows Running DUAL Time)

A – Split\* (Top shows CUM 1, Bottom shows LAP 1)

A – Split\* (shows CUM 2, Bottom shows LAP 2)

A – Split\* (Top shows CUM 3, Bottom shows LAP 3)

A – Split\* (Top shows CUM 4, Bottom shows LAP 4)

A (2sec) – Reset

\*Split Counter always shows Current Split

Push C to return to Running Time

#### Memory Review (before Resetting)

C (2sec) – Review\* (Bottom shows AVE LAP Split, Top shows TOTAL ELAPSED TIME)

C – Review (Shows last DUAL Split)

C – Review (Shows next DUAL Split, in reverse order)

\*Reviews at any time in reverse numerical order. Hold down for Rapid Review.

### RECHARGING

To recharge the stopwatch battery, use SBLCHARGER kit (included with each watch). SBLCHARGER includes provision for charging watch from normal 120 Volt electrical outlet, from cigarette lighter in car, or from USB port on a computer.

With continuous use of the backlight, the watch will last at least 10 hours before needing a recharge. If the backlight is never used, a single charge will last approximately six months (up to one year if stopwatch is used sparingly).

### SERVICE

If service is needed, please return the watch to ACCUSPLIT. Please do not open the case, as the watch is not designed for service by the consumer.

**WARNING** —This watch uses a rechargeable battery—replacement of the battery with a non-rechargeable battery is unsafe and will result in damage to the watch, and could cause personal injury.



#### NO-PROOF-OF-PURCHASE LIMITED WARRANTY

See label on back of unit for details, or check

<http://support.ACCUSPLIT.com>

ACCUSPLIT, Inc. • 3090 Independence Drive, Suite 148 • Livermore, CA 94551 USA

800-935-1996 • 925-290-1900 • FAX 925-290-1930

[www.ACCUSPLIT.com](http://www.ACCUSPLIT.com) • [support@ACCUSPLIT.com](mailto:support@ACCUSPLIT.com)

## Free Manuals Download Website

<http://myh66.com>

<http://usermanuals.us>

<http://www.somanuals.com>

<http://www.4manuals.cc>

<http://www.manual-lib.com>

<http://www.404manual.com>

<http://www.luxmanual.com>

<http://aubethermostatmanual.com>

Golf course search by state

<http://golfingnear.com>

Email search by domain

<http://emailbydomain.com>

Auto manuals search

<http://auto.somanuals.com>

TV manuals search

<http://tv.somanuals.com>