


LASER

User Manual



Note: In order to charge 3 devices simultaneously, use the Quick charge feature, and to use the device safely, please only use the supplied Wall Adapter and USB-C cable. Failure to do so may result in some features not working properly or cause a safety risk.

3-IN-1 Wireless Charging Station

PW-3IN1SS-C

WHAT'S IN THE BOX:

- 1 x 3-IN-1 Wireless Charging Station
- 1 x Wall Charger
- 1 x USB-C Cable
- 1 x User Manual

SPECIFICATIONS:

Wall Charger Input:	9V/2A, 9V/2.7A or 12V/2A
Wall Charger Output:	9V/2A, 12V/1.5A
Phone Output:	15W/10W/7.5W/5W
Watch Output:	2.5W (Only compatible with Samsung Galaxy Watch 1/3/3 LTE/4, Watch Active 2/2 LTE/Active 1 Sport).
Earphone Output:	3.0W (Compatible with Galaxy buds, buds+, and other Qi-compatible TWS Earphones with wireless charging case).
Input socket:	Type-C
Conversion Rate (Phone):	≥ 73%
Product Size:	174 x 113 x 100mm

FEATURES:



- Compact design charges up to 3 devices at the same time
- Certified for safety and quality
- Supports fast charging
- Power light indicator

PRODUCT DIAGRAM:



1. Samsung Watch Charging Area
2. Phone Charging Area
3. LED Light Switch
4. Earbuds Charging Area
5. LED Light
6. Anti-slip silicone for phone
7. USB Type-C Port
8. Anti-slip silicone base
9. Cooling Vent
10. Product Information

GETTING STARTED:



Touch ON/OFF the light

1. Connect the Wireless Charger to the USB-C cable.
2. Plug the other end of the USB-C cable to the Wall Adapter.
3. Plug the wall adapter into a power socket.
4. The charging station is now ready to be used.

Note: When charging your Samsung Galaxy Watch roll up the band for a more stable and unobtrusive placement.


LED Light Behaviour

- Green Light – Standby mode or not charging
- Coloured Animated Light – Wireless Charging the phone
- Red Light – Incompatible device detected or device is misaligned with the charging pad.

CHARGING DIAGRAM:



Charging 3 Samsung devices simultaneously



Compatible Devices:

Smart Phone:

Apple: iPhone 12, 12 Pro, 12 Pro Max, 12 mini, SE, 11, 11 Pro, 11 Pro Max, Xs, Xs Max, XR, X, 8, 8 Plus.

Samsung: Galaxy S: 21 5G, 21+ 5G, 21 Ultra 5G, FE 5G, 20 5G, 20+ 5G, 20 Ultra 5G, 10, 10+, 10e, 9, 9+, 8, 8+, 7, 7 edge, 6, 6 edge, 6 edge+, 6 G9209, 6 Active.

Galaxy Note: 10, 10e, 10+, 9, 8, 7, 6, 5

LG: G2 (VS980, Verizon version), G3, G6, G6+, G7, G7 ThinQ, G7+ ThinQ, G8, G8 ThinQ, V30, V30+, V35, V40 ThinQ, V50, V50 ThinQ, LG Lucid2 (VS870), LG Optimus LTE 2, etc.

Motorola: Droid Turbo, Droid Turbo2, Droid 5, Moto Maxx, Ultra M, Moto X Force

Huawei: P30 Pro, P40, P40 Pro, P40 Pro+. Mate: 40E, 40 RS, 40 Pro+, 40 Pro, 40, 30E Pro, 30 5G, 30 Pro, 5G, 30, 30 Pro, 30 RS, 20 Pro, 20 RS, RS.

Xiaomi: 10, 10 Pro, 9, 9 Pro, Mix 3, Mix 2s.

Also includes any other phone which supports Qi Wireless Charging.

TROUBLESHOOTING:

Slow or interrupted Charging:

- A. Phone case thickness must not exceed 5mm.
- B. The back of your phone should be free from any obstructions including credit cards, metal objects etc.
- C. Place your phone directly on the centre of the charging pad. This allows the charging coil on your phone to line up with the coil on the charger.
- D. The wireless charging coil on some phones (e.g Sony) is located just below the centre.
- E. Try swapping the Vertical and Horizontal placement of your phone.

If failing to charge your device:

- A. Try powering your phone/watch/earbuds OFF then ON again.
- B. Check the LED indicator Light for charging status.
- C. Check you are using only the Cable and Adapter supplied with this device,
- D. Phone/Watch/Earbud case thickness must not exceed 5mm.
- E. The back of your phone should be free from any obstructions including credit cards, metal objects etc.

SAFETY TIPS:

- Please keep the charger away from water or other liquids.
- If you need to clean the charger, unplug from power source, and remove any connected devices.
- Ideal operating temperature = 0 - 45°C
- Phone Temperature = $\leq 55^{\circ}\text{C}$ or $\leq 131^{\circ}\text{F}$

WARRANTY AGAINST DEFECTS

Laser warrants your new product to be free from defects in materials and workmanship for 12 months, from the date of purchase, provided that the product is used in accordance with accompanying recommendations or instructions where provided. The benefit of this warranty is in addition to your rights under the Australian Consumer Law and to other rights and remedies of the consumer under a law in relation to the goods or services to which the warranty relates.

Through a network of retailers and resellers, Laser will provide you with your choice of a refund, repair, or exchange (where possible) for this product if it becomes defective within the warranty period. This warranty will no longer apply where the defect is a result of alteration, accident, misuse, abuse, normal wear and tear, neglect, or improper storage. **Please retain your receipt as proof of purchase**

How to make a product warranty claim:

1. Find your receipt with date of purchase. If this is not available, Laser will make an assessment based on the date of manufacture, condition of the product and type of defect.
2. Please contact your original place of purchase. They will assess the nature of the fault and refund or replace the product as per their store refund or warranty policy.
3. If your original place of purchase cannot be contacted, please contact Laser with a description of the fault. To assist our team in providing you with a quick resolution, please include any photos and/or a short video demonstrating the fault with your product.
 - Phone: (02) 9870 3355
 - Email: support@laserco.com.au
 - Online: www.laserco.net/support/warranty and follow the website instructions
 - Business Address: U1 6-8 Byfield Street, Macquarie Park, 2113, NSW, Australia
4. Laser will review your claim and in the first instance, attempt to troubleshoot and resolve the issue for you without the need to return the product.
5. If it is determined via troubleshooting that your product may be faulty, our team will provide instructions to have the product returned for assessment. If the product does need to be returned within the warranty period, Laser will arrange return shipping at no cost to you.
6. Once we receive the product, our experienced technicians will assess it and determine how best to resolve the issue.

Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.

For more
helpful guides
visit us at



LASER
www.youtube.com/LasercoAu



SCAN ME

Free Manuals Download Website

<http://myh66.com>

<http://usermanuals.us>

<http://www.somanuals.com>

<http://www.4manuals.cc>

<http://www.manual-lib.com>

<http://www.404manual.com>

<http://www.luxmanual.com>

<http://aubethermostatmanual.com>

Golf course search by state

<http://golfingnear.com>

Email search by domain

<http://emailbydomain.com>

Auto manuals search

<http://auto.somanuals.com>

TV manuals search

<http://tv.somanuals.com>