




**CAUTION:** Although this device enables drivers to conduct handsfree conversations, it is still safer to pull over before using a mobile phone. **Always keep your full attention on your driving.**

Driving while talking on your mobile phone is dangerous, and illegal in many states.

Check local laws regarding the use of a mobile handset and wireless headset while driving. If you use the **Bluetooth Headset** while driving, ensure your attention and focus remains on your driving.

**Please use your mobile phone, and our product responsibly while driving!**

### Location of controls



## Bluetooth® Wireless Headset


Model: EM129

### In the box

### Charging the Bluetooth Headset


1. Connect the charging pin of the Micro USB cable to the Micro USB jack of the headset.
2. Connect the other end of the Micro USB cable to your computer's USB port.
3. The **RED LED** indicator light turns on.
4. When the headset is fully charged (approximately 2-3 hours), the **BLUE LED** indicator light turns on.

**NOTE:** When the battery is running low, the **RED LED** indicator light starts to flash.



**NOTE:** Charge your headset for at least **8 hours** before using it for the first time.

1. Make sure the EM129 is turned off.
2. Keep your EM129 and Bluetooth enabled device within 3 feet of each other during the pairing process.
3. Set your mobile phone or other Bluetooth enabled device to search for Bluetooth devices.



#### On an iPhone

- Go to SETTINGS > GENERAL > BLUETOOTH (Make sure Bluetooth is turned ON)



#### On a BlackBerry

- Go to SETTINGS/OPTIONS > BLUETOOTH
- Enable BLUETOOTH




#### On an Android Phone

- Go to SETTINGS > BLUETOOTH > MENU > Search for devices (Make sure Bluetooth is turned ON)



#### On other Cell Phones/Devices

Review the instruction manual that came with your phone/device.



**NOTE:** The illustrations above are typical of many Bluetooth enabled phones in the market today, and are used to assist in the explanation of the pairing process. Your mobile phone's interface and interaction with the headphones may be

4. Press and hold the **[Power]** button on the EM129 until the LED Indicator Light flashes RED and BLUE alternately (approximately 8 seconds). The LED Indicator Light will turn BLUE after 5 seconds, but keep holding until the light flashes BLUE and RED.
5. When the Bluetooth enabled device finds the EM129, confirm by selecting EM129 from the list. If asked for a passcode, enter "0000" (four zeroes).
6. After a successful registration, the LED Indicator Light will blink BLUE every 8 seconds.

### Pairing the Bluetooth Headset with a Sony PlayStation 3

#### <SET ACCESSORY to BLUETOOTH on PS3>

1. Go to the PS3 main menu, scroll to and select "Settings".
2. Scroll to and select "Accessory Settings".
3. Scroll to and select "Manage Bluetooth Devices".
4. The menu will ask: "The Bluetooth device has not been registered. Do you want to register it?", then select "YES"

#### <REGISTER EM129 to PS3>

Put your Bluetooth Headset into pairing mode. (See "Pairing the headset with a Bluetooth enabled device")

1. Select "Start Scanning" from the PS3 menu.
2. Once the PS3 has discovered the Headset, the screen will read "Select the Bluetooth device to register", then select "EM129"
3. The PS3 will ask for a passkey. Enter [0000] then select "OK". Now press [O] (the PS3 circle button) to get back to the previous menu.
4. Scroll to and select "Audio Device Settings" to change the "Input Device" to "EM129".

**NOTE:** "Input Device" is the microphone, and determines the method of how others will hear you speak. By default, the "Output Device" will now switch to "EM129" "Output Device" is the audio, and determines how you will hear the PS3 audio and others speaking.

To test the connection, speak into the headset and you will see the bars above the "Microphone Level" moving, if not, repeat the pairing process.


Press "OK" to confirm the new settings. You are now ready to use the Bluetooth Headset with your PS3 Entertainment System. If you would like to hear the PS3 audio through your TV or Audio System, scroll to "Output Device" and switch to "System Default Device".

For further assistance with Bluetooth settings on your PS3 please refer to your PS3 instruction manual.

### Using your Bluetooth Headset

#### Powering ON/OFF


- To turn **ON**, press and hold the **[POWER]** button until the **BLUE LED** indicator light flashes three times. When powered on, the **BLUE LED** indicator light will quickly flash.
- To turn **OFF**, press and hold the **[POWER]** button until the **LED** indicator light flashes **SOLID RED** and then shuts off.



**Note:** If you hold the power button too long when turning the headset on, the light will flash **RED and BLUE** and the phone will be in pairing mode. If this happens, turn the headset off, then turn it on again.

#### Answering/Ending a call

- To answer a call, press and release the **[POWER]** button.
- To end a call, press and release the **[POWER]** button.



### Using your Bluetooth Headset (Continued)

#### To make a call


Dial the number and press the send button on your mobile phone, the call is automatically transferred to the headset.

**Redialing the last number called (Dependent on your phone supporting this feature)**  
Quickpress the **[Power]** button twice. The last number called will be redialed.



#### Adjusting the volume

Press the **[+]** or **[-]** buttons to adjust the volume.  
Note: You may also adjust the volume from your mobile phone's volume control.



### Troubleshooting tips

#### I cannot get the Bluetooth Headset into Pairing Mode

- Make sure the **Bluetooth Headset** is turned off before beginning the pairing process.
- Press and hold the **[Power]** button on the EM129 until the LED Indicator Light flashes RED and BLUE alternately (approximately 8 seconds). The LED Indicator Light will turn BLUE after 5 seconds, but keep holding until the light flashes BLUE and RED.

#### My mobile phone is not able to pair with the Bluetooth Headset

- Make sure that you fully charged the headset before pairing.
- Keep your **Bluetooth Headset** and mobile phone within 3 feet of each other during the pairing process.
- Check that your phone's Bluetooth feature is turned **ON**.
- Try repeating the pairing process, see "Pairing the EM129."

#### After successfully pairing my mobile phone and Bluetooth Headset, when I shut my phone and turn it on again, my headset did not automatically connect

- Try turning the headset **OFF**, and then turning it **ON** again.
- Many mobile phones have an auto reconnect option when first attempting to reconnect to a newly paired Bluetooth device. Make sure you accept this option, so that your **Bluetooth Headset** automatically reconnects to your mobile phone; check the user guide of your mobile phone for more information regarding this option.
- Try unpairing the headset from your phone, and repeat the pairing procedure.

#### I hear distortion, and the sound quality is poor

- For the best audio quality, always wear your **Bluetooth Headset** on the same side of the body as your mobile phone.
- Check that the battery is charged enough.

#### The sound is very low

- Press the **[+]** and **[-]** buttons to adjust the volume.

### FCC and telephone company information

#### FCC Part 15

This equipment has been tested and found to comply with the requirements for a Class B digital device under Part 15 of the Federal Communications Commission (FCC) rules. These requirements are intended to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Re-orient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

#### Do not attempt to repair or modify this equipment.

**Warning:** Changes or modifications to this equipment not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

### Industry Canada

Operation is subject to the following two conditions: (1) This device may not cause interference and (2) This device must accept any interference, including interference that may cause undesired operation of the device.

The term "IC:" before the certification/registration number only signifies that registration was performed based on a Declaration of Conformity indicating that Industry Canada technical specifications were met. It does not imply that Industry Canada approved the equipment.

### Warranty information

#### Limited Warranty

In the unlikely event that this product is defective, or does not perform properly, you may within 90 days from your original date of purchase return it to the authorized service center for repair or exchange.

#### TO OBTAIN WARRANTY SERVICE:

- Provide proof of the date of purchase within the package (Dated bill of sale).
- Prepay all shipping costs to the authorized service center, and remember to insure your return.
- Include a return shipping address (no P.O. Boxes), a telephone contact number, and the defective unit within the package.
- Describe the defect or reason you are returning the product.

Your product will be repaired or replaced, at our option, for the same or similar model of equal value if examination by the service center determines this product is defective. Products received damaged as a result of shipping will require you to file a claim with the carrier.

The shipping address of the authorized service center is:

**Southern Telecom, Inc.**  
ATTN: Customer Service (2nd Floor)  
14-C 53rd Street  
Brooklyn, NY 11232

Should you have any questions or problems concerning this product, please contact our customer service department at:

**1-877-768-8483 (Toll Free)**  
**Monday - Friday: 8AM - 10PM (EST)**  
or  
via e-mail at  
**cs@southern telecom.com**

### Warranty service not provided

This warranty does not cover damage resulting from accident, misuse, abuse, improper installation or operation, lack of reasonable care, and unauthorized modification. This warranty is voided in the event any unauthorized person opens, alters or repairs this product. All products being returned to the authorized service center for repair must be suitably packaged.

#### Limitation of Warranty:

THE WARRANTY STATED ABOVE IS THE ONLY WARRANTY APPLICABLE TO THIS PRODUCT. ALL OTHER WARRANTIES, EXPRESS OR IMPLIED (INCLUDING ALL IMPLIED WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE) ARE HEREBY DISCLAIMED. NO VERBAL OR WRITTEN INFORMATION GIVEN BY SOUTHERN TELECOM INC.'S AGENTS, OR EMPLOYEES SHALL CREATE A GUARANTEE OR IN ANY WAY INCREASE THE SCOPE OF THIS WARRANTY.

REPAIR OR REPLACEMENT AS PROVIDED UNDER THIS WARRANTY IS THE EXCLUSIVE REMEDY OF THE CONSUMER. SOUTHERN TELECOM INC. SHALL NOT BE LIABLE FOR INCIDENTAL OR CONSEQUENTIAL DAMAGES RESULTING FROM THE USE OF THIS PRODUCT OR ARISING OUT OF ANY BREACH OF ANY EXPRESS OR IMPLIED WARRANTY ON THIS PRODUCT. THIS DISCLAIMER OF WARRANTIES AND LIMITED WARRANTY ARE GOVERNED BY THE LAWS OF THE STATE OF NEW YORK. EXCEPT TO THE EXTENT PROHIBITED BY APPLICABLE LAW, ANY IMPLIED WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE ON THIS PRODUCT IS LIMITED TO THE APPLICABLE WARRANTY PERIOD SET FORTH ABOVE.

Some states do not allow the exclusion nor limitation of incidental or consequential damages, or limitations on how long an implied warranty lasts so the above limitations or exclusions may not apply to you. This warranty gives you specific legal rights, and you also may have other rights that vary from state to state.

#### www.emersonphones.com

Distributed by Southern Telecom Inc. Brooklyn, NY 11232  
© 2013 Southern Telecom Inc. All rights reserved.  
Emerson and the G-Clef logo are registered trademarks of Emerson Radio Corp. Parsippany, New Jersey USA.  
The Bluetooth® word mark and logos are owned by the Bluetooth SIG, Inc. SONY PlayStation® & PS3™ are either trademarks or registered trademarks of SONY.  
All other trademarks are trademarks of their respective owners.



## Free Manuals Download Website

<http://myh66.com>

<http://usermanuals.us>

<http://www.somanuals.com>

<http://www.4manuals.cc>

<http://www.manual-lib.com>

<http://www.404manual.com>

<http://www.luxmanual.com>

<http://aubethermostatmanual.com>

Golf course search by state

<http://golfingnear.com>

Email search by domain

<http://emailbydomain.com>

Auto manuals search

<http://auto.somanuals.com>

TV manuals search

<http://tv.somanuals.com>