


General information:


EXD-HP1/2 are stand-alone superheat and or economizer controllers. EXD-HP1 is intended for operation of one EXM/EXL or EXN valve whereas EXD-HP2 is designed for operation of two independent EXM/EXL or two EXN valves.

Note: It is possible to use only circuit 1 from EXD-HP2. In this case, the circuit 2 must be disabled (C2 parameter) and the sensors and the valve for the second circuit are not needed.

ModBus communication is described in a Technical Bulletin and it is not covered by this document.

Technical Data:

Power supply	24VAC/DC ±10%; 1A
Power consumption	EXD-HP1: 15VA EXD-HP2: 20VA
Plug-in connector	Removable screw terminals wire size 0.14...1.5 mm ²
Protection class	IP20
Digital Inputs	Potential free contacts (free from voltage)
Temperature sensors	ECP-P30
Pressure sensors	PT5N
Operating/surrounding temp.	0...+55°C
Output alarm relay	SPDT contact 24V AC 1 Amp inductive load; 24V AC/DC 4 Amp resistive load
Activated/energized:	During normal operation (no alarm condition)
Deactivated/de-energized:	During alarm condition or power supply is OFF
Stepper motor output	Coil: EXM-125/EXL-125 or EXN-125 Valves: EXM/EXL-... or EXN-...
Type of action	1B
Rated impulse voltage	0.5kV
Pollution Degree	2
Mounting:	For standard DIN rail
Marking	 



Warning -Flammable refrigerants:

EXD-HP1/2 has a potential ignition source and does not comply with ATEX requirements. Installation only in non-explosive environment. For flammable refrigerants only use valves and accessories approved for it!

Safety instructions:

- Read operating instructions thoroughly. Failure to comply can result in device failure, system damage or personal injury.
- It is intended for use by persons having the appropriate knowledge and skill.
- Before installation or service disconnect all voltages from system and device.
- Do not operate system before all cable connections are completed.
- Do not apply voltage to the controller before completion of wiring.
- Entire electrical connections have to comply with local regulations.
- Inputs are not isolated, potential free contacts needed to be used.
- Disposal: Electrical and electronic waste must NOT be disposed of with other commercial waste. Instead, it is the user responsibility to pass it to a designated collection point for the safe recycling of Waste Electrical and Electronic Equipment (WEEE directive 2019/19/EU). For further information, contact your local environmental recycling center.

Electrical connection and wiring:

- Refer to the electrical wiring diagram for electrical connections.
- **Note:** Keep controller and sensor wiring well separated from supply power cables. Minimum recommended distance 30mm.
- EXM-125, EXL-125 or EXN-125 coils are supplied with fix cable and JST terminal block at cable end. Cut the wires close to terminal block. Remove the wire insulation approximately 7 mm at the end. It is recommended that the wires end to

be equipped with core cable ends or metallic protective sleeve. When connecting the wires of EXM/EXL or EXN, consider the color coding as follows:


EXD	Terminal	EXM/L-125 wire color	EXN-125 wire color
EXD-HP1	6	Brown	Red
	7	Blue	Blue
	8	Orange	Orange
	9	Yellow	Yellow
	10	White	White
EXD-HP2	30	Brown	Red
	31	Blue	Blue
	32	Orange	Orange
	33	Yellow	Yellow
	34	White	White

- The digital input DI1 (EXD-HP1) and DI1/D12 (EXD-HP1/2) are the interfaces between EXD-HP1/2 and upper level system controller if the Modbus communication has not been used. The external digital shall be operated in function system's compressor/demand.
- If the output relays are not utilized, the user must ensure appropriate safety precautions are in place to protect the system.

Operating condition	Digital input status
Compressor starts/run	closed (Start)
Compressor stops	open (Stop)

Note: Connecting any EXD-HP1/2 inputs to the supply voltage will permanently damage the EXD-HP1/2.

Wiring base board (EXD-HP1/2):




Note:

- Base board is for function of superheat control or Economizer control.
- Alarm relay, dry contact. Relay coil is not energized during alarm condition or power off.
- Hot gas discharge sensor input is mandatory only for economizer control function.

⚠ Warning: Use a class II category transformer for 24VAC power supply. Do not ground the 24VAC lines. We recommend using individual transformers for EXD-HP1/2 controller and for third party controllers to avoid possible interference or grounding problems in the power supply.

Wiring: Upper board (EXD-HP2):



Note:

- Upper board is only for function of superheat control.
- Upper board does not need to be wired if the circuit 2 is disabled.

Preparation for Start-up:


- Vacuum the entire refrigeration circuit.
- **⚠ Warning: Electrical Control Valves EXM/EXL or EXN are delivered partially open position. Do not charge system with refrigerant before closure of valve.**
- Apply supply voltage 24V to EXD-HP1/2 while the digital input (DI1/DI2) is OFF(open). The valve will be driven to close position.
- After closure of valve, start to charge the system with refrigerant.

Setup of parameters:

(need to be checked/modified before start-up)

- Make sure that digital input (DI1/DI2) is off (open). Turn the power supply ON.
- Four main parameters Password (H5), type of function (1uE), refrigerant type (1u0/2u0) and pressure sensor type (1uP/2uP) can be set only when digital input DI1/DI2 is off (open) while the power supply is ON (24V). This feature is for added safety to prevent accidental damage of compressors and other system components.
- Once the main parameters have been selected/saved the EXD-HP1/2 is ready for startup. All other parameters can be modified at any time during operation or standby if it is necessary.

Display/keypad unit (LEDs and button functions):



Procedure for parameter modification:

The parameters can be accessed via the 4-button keypad. The configuration parameters are protected by a numerical password. The default password is "12". To select the parameter configuration:

- Press the **PRG** button for more than 5 seconds, A flashing "0" is displayed
- Press **▲** until "12" is displayed; (password)
- Press **SEL** to confirm password
- Press **▲** or **▼** to show the code of the parameter that has to be changed
- Press **SEL** to display the selected parameter value
- Press **▲** or **▼** to increase or decrease the value
- Press **SEL** to temporarily confirm the new value and display its code
- Repeat the procedure from the beginning "press **▲** or **▼** to show..."

To exit and save the new settings:

- Press **PRG** to confirm the new values and exit the parameters modification procedure.

To exit without modifying/saving any parameters:

- Do not press any button for at least 60 seconds (TIME OUT).

Reset all parameters to factory setting:

- Make sure that digital input (DI1/DI2) is Off (open).
- Press **▲** and **▼** together for more than 5 seconds.
- A flashing "0" is displayed.
- Press **▲** or **▼** until the password is displayed (Factory setting = 12).
- If password was changed, select the new password.

Note: In standard mode the actual superheat is shown at the display. In case of liquid injection and economizer function this change to discharge temperature.

- To display other data of circuit 1 of EXD-HP1/2 or 2 of EXD-HP2:

- Press **SEL** and **▼** together for 3 seconds to show data of circuit 1
- Press **SEL** and **▲** together for 3 seconds to show data of circuit 2
- To display data of each circuit: Press the **SEL** button for 1 second until index number according to the below table appears. Release the **SEL** button and the next variable data will appear. By repeating above procedure, variable data can be displayed in a sequence as Measured superheat (K) → Measured suction pressure (bar) → Valve position (%) → Measured suction gas temperature (°C) → Calculated saturated temperature (°C) → Measured discharge temperature (°C) (if economizer function is selected) → REPEATING....

Variable data	Circuit 1 (EXD-HP1/2)		Circuit 2 (EXD-HP2)	
Default Superheat K	1	0	2	0
Suction pressure bar	1	1	2	1
Valve position %	1	2	2	2
Suction gas temp °C.	1	3	2	3
Saturation temp. °C	1	4	2	4
Discharge temp. °C	1	5	-	-

Note 1: Discharge temp. is available only if economizer function is selected.

Note 2: After 30 minutes, display reverts to index 0.



**Operating instruction
EXD-HP1/2 Controller with ModBus
communication capability**

EN

Manual alarm reset/clearing functional alarms (except hardware errors):

Press **PRG** and **SEL** together for 5 seconds. When the clearing is done, “CL” message appears for 2 seconds.

Manual mode operation

Press **PRG** and **▼** together for 5 seconds to access to manual mode operation.

List of parameters in scrolling sequence by pressing **▼** button

Code	Parameter description and choices	Min	Max	Factory setting	Field setting
1Ho	Manual mode operation; circuit 1 0 = off; 1 = on	0	1	0	
1HP	Valve opening (%)	0	100	0	
2Ho	Manual mode operation; circuit 2 0 = off 1 = on	0	1	0	
2HP	Valve opening (%)	0	100	0	

Note: During manual operation, functional alarms such as low superheat are disabled. It is recommended to monitor the system operation when the controller is operated manually. Manual operation is intended for service or temporary operation of valve at a specific condition. After achieving the required operation, set the parameter 1Ho and 2Ho at 0 so the controller automatically operates the valve(s) according to its setpoint(s).

List of parameters in scrolling sequence by pressing **▼ button:**

Code	Parameter description and choices	Min	Max	Factory setting
H5	Password	1	1999	12
Adr	ModBus address	1	127	1
br	Modbus baudrate	0	1	1
PAr	Modbus parity	0	1	0
-C2	Circuit 2 of EXD-HP2 enabled 0 = Enabled; 1 = Disabled	0	1	0
-uC	Units conversion 0 = °C, K, bar; 1 = F, psig This Parameter effects only the display. Internally the units are allways SI-based.	0	1	0
HP-	Display mode 0 = No display 1 = Circuit 1 2 = Circuit 2 (only EXD-HP2)	0	2	1


Parameters Circuit 1

1uE	Function 0 = Superheat control 1 = Economizer control (Only for R410A/R407C/R32)	0	1	1
1u4	Superheat control mode 0 = Standard control coil heat exchanger 1 = Slow control coil heat exchanger 2 = fixed PID 3 = fast control plate heat exchanger (not for 1uE = 1) 4 = Standard plate heat exchanger (not for 1uE = 1)	0	4	0
1u0	Refrigerant 0 = R22 1 = R134a 2 = R410A 3 = R32 4 = R407C 5 = R290* 6 = R448A 7 = R449A 8 = R452A 9 = R454A* 10 = R454B* 11 = R454C* 12 = R513A 13 = R452B* 14 = R1234ze* 15 = R1234yf* *) EXN not permitted *) ⚠ Warning -Flammable refrigerants: EXD-HP1/2 has a potential ignition source and does not comply with ATEX requirements. Installation only in non-explosive environment. For flammable refrigerants only use valves and accessories approved for it!	0	15	2
1uP	Installed pressure sensor type 0 = PT5N-07... 1 = PT5N-18... 2 = PT5N-30... 3 = PT5N-10P-FLR	0	3	2
1uu	Start valve opening (%)	10	100	20
1u9	Start opening duration (second)	1	30	5
1uL	Low superheat alarm function 0 = disable (for flooded evaporator) 1 = enable auto reset 2 = enable manual reset	0	2	1
1u5	Superheat set-point (K) If 1uL = 1 or 2 (enabled auto or manual reset) If 1uL = 0 (disabled)	3 0.5	30 30	6 6
1u2	MOP function 0 = disable 1 = enable	0	1	1
1u3	MOP set-point (°C) saturation temperature Factory setting according to selected refrigerant (1u0). The default value can be changed	see MOP table		

Code	Parameter description and choices	Min	Max	Factory setting
1P9	Low pressure alarm mode circuit 1 0 = disabled 1 = enabled auto reset 2 = enabled manual reset	0	2	0
1PA	Low pressure alarm cut-out circuit 1	-0.8	17.7	0
1Pb	Low pressure alarm delay circuit 1	5	199	5
1Pd	Low pressure alarm cut-in circuit 1	0.5	18	0.5
1P4	Freeze protection alarm function 0 = disabled, 1 = enabled auto-reset, 2 = enabled manual reset	0	2	0
1P2	Freeze alarm cut-out circuit 1	-20	5	0
1P5	Freeze protection alarm delay, sec.	5	199	30
1P-	Superheat control circuit 1 fixed PID (Kp factor) Display 1/10K	0.1	10	1.0
1i-	Superheat control circuit 1 fixed PID (Ti factor)	1	350	100
1d-	Superheat control circuit 1 fixed PID (Td factor) Display 1/10K	0.1	30	3.0
1EC	Hotgas temperature sensor source 0 = ECP-P30 1 = Via Modbus input	0	1	0
1PE	Economizer control circuit 1 fixed PID (Kp factor) Display 1/10K	0.1	10	2.0
1iE	Economizer control circuit 1 fixed PID (Ti factor)	1	350	100
1dE	Economizer control circuit 1 fixed PID (Td factor) Display 1/10K	0.1	30	1.0
1uH	High superheat alarm mode circuit 1 0 = disabled 1 = enabled auto-reset	0	1	0
1uA	High superheat alarm setpoint circuit 1	16	40	30
1ud	High superheat alarm delay circuit 1	1	15	3
1E2	Positive correction of measured Hotgas temperature.	0	10	0
Parameters Circuit 2 (only EXD-HP2)				
Code	Parameter description and choices	Min	Max	Factory setting
2u4	Superheat control mode 0 = Standard control coil heat exchanger 1 = Slow control coil heat exchanger 2 = fixed PID 3 = fast control plate heat exchanger 4 = Standard plate heat exchanger	0	4	0
2u0	System Refrigerant 0 = R22 1 = R134a 2 = R410A 3 = R32 4 = R407C 5 = R290* 6 = R448A 7 = R449A 8 = R452A 9 = R454A* 10 = R454B* 11 = R454C* 12 = R513A 13 = R452B* 14 = R1234ze* 15 = R1234yf* *) EXN not permitted *) ⚠ Warning -Flammable refrigerants: EXD-HP1/2 has a potential ignition source and does not comply with ATEX requirements. Installation only in non-explosive environment. For flammable refrigerants only use valves and accessories approved for it!	0	5	2
2uP	Installed pressure sensor type (When D12 is off) 0 = PT5N-07... 1 = PT5N-18... 2 = PT5N-30... 3 = PT5N-10P-FLR	0	3	1
2uu	Start valve opening (%)	10	100	20
2u9	Start opening duration (second)	1	30	5
2uL	Low superheat alarm function 0 = disable (for flooded evaporator) 1 = enable auto reset 2 = enable manual reset	0	2	1
2u5	Superheat set-point (K) If 2uL = 1 or 2 (enabled auto or manual reset) If 2uL = 0 (disabled)	3 0.5	30 30	6 6
2u2	MOP function 0 = disable 1 = enable	0	1	1
2u3	MOP set-point (°C) saturation temperature Factory setting according to selected refrigerant (2u0). The default value can be changed	see MOP table		
2P9	Low pressure alarm mode circuit 2 0 = disabled 1 = enabled auto reset 2 = enabled manual reset	0	2	0
2PA	Low pressure alarm cut-out (bar) circuit 2	-0.8	17.7	0
2Pb	Low pressure alarm delay (sec) circuit 2	5	199	5
2Pd	Low pressure alarm cut-in (bar) circuit 2	0.5	18	0.5
2P4	Freeze protection alarm function 0 = disable, 1 = enable auto-reset, 2 = enable manual reset	0	2	0

Code	Parameter description and choices	Min	Max	Factory setting
2P2	Freeze alarm cut-out circuit 2	-20	5	0
2P5	Freeze protection alarm delay, sec.	5	199	30
2P-	Superheat control circuit 2 (Kp factor), fixed PID Display 1/10K	0.1	10	1.0
2i-	Superheat control circuit 2 (Ti factor), fixed PID	1	350	100
2d-	Superheat control circuit 2 (Td factor), fixed PID - Display 1/10K	0.1	30	3.0
2uH	High superheat alarm mode circuit 2 0 = disabled 1 = enabled auto-reset	0	1	0
2uA	High superheat alarm setpoint (K) circuit 2	16	40	30
2ud	High superheat alarm delay (Min) circuit 2	1	15	3

**Control (valve) start-up behavior:
(Parameter 1uu/2uu and 1u9/2u9)**



Upload/download Key: Function

- For serial production of systems/units, upload/download key allows the transmission of configured parameters among range of identical systems.

Uploading procedure:

(storing configured parameters in key)

- Insert the key while the first (reference) controller is ON and press button; the "uPL" message appears followed by "End" message for 5 seconds.
- Note: If the "Err" message is displayed for failed programming, repeat the above procedure.

Downloading procedure:

(configured parameters from key to other controllers)

- Turn off power to new controller
- Insert a loaded Key (with stored data from reference controller) into new controller and turn on the power supply.
- The stored parameters of the key will be downloaded automatically into the new controller memory; The "dOL" message appears followed by a "End" message for 5 seconds.
- The new controller with new loaded parameters setting will start to operate after "End" message disappears.
- Remove the key.
- Note: If the "Err" message is displayed for failed programming, repeat the above procedure.



Selection for both circuits and discharge temperature control

Code	Parameter description and choices	Min	Max	Factory setting
Et	Valve type 0 = EXM / EXL 1 = EXN Note: EXD-HP2 can drive two similar valves i.e. both valves must be either EXM/EXL or EXN.	0	1	0
1E3	Discharge Temperature Setpoint Start Setpoint	70	140	85
1E4	Discharge Temperature Control band	2	25	20
1E5	Discharge Temperature limit	100	150	120

MOP table (°C)

Refrigerant	Min.	Max.	Factory setting	Refrigerant	Min.	Max.	Factory setting
R22	-40	+50	+15	R452A	-45	+66	+15
R134a	-40	+66	+15	R454A	-57	+66	+10
R410A	-40	+45	+15	R454B	-40	+45	+18
R32	-40	+30	+15	R454C	-66	+48	+17
R407C	-40	+48/	+15	R513A	-57	+66	+13
R290	-40	+50	+15	R452B	-45	+66	+25
R448A	-57	+66	+12	R1234ze	-57	+66	+24
R449A	-57	+66	+12	R1234yf	-52	+66	+15

Error/Alarm handling

Alarm code	Description	Related parameter	Alarm relay	Valve	What to do?	Requires manual reset after resolving alarm
1E0/2E0	Pressure sensor 1/2 error	-	Triggered	Fully close	Check wiring connection and measure the signal 4 to 20 mA	No
1E1/2E0	Temperature sensor 1/2 error	-	Triggered	Fully close	Check wiring connection and measure the resistance of sensor	No
1Ed	Discharge hot gas temperature sensor 3 error	-	Triggered	Operating	Check wiring connection and measure the resistance of sensor	No
1T-2T-	EXM/EXL or EXN electrical connection error	-	Triggered	-	Check wiring connection and measure the resistance of winding	No
1Ad	Discharge hot gas temperature above limit		Triggered	Operating	Check valve opening/ check liquid flow for flash gas free/check discharge hot gas temperature sensor	No
1AF/2AF	Freeze protection	1P4/2P4: 1	Triggered	Fully close	Check the system for cause of low pressure such as insufficient load on evaporator	No
1AF/2AF blinking		1P4/2P4: 2	Triggered	Fully close		Yes
1AL/2AL	Low superheat (<0,5K)	1uL/2uL: 1	Triggered	Fully close	Check wiring connection and operation of valve	No
1AL/2AL blinking		1uL/2uL: 2	Triggered	Fully close		Yes
1AH/2AH	High superheat	1uH/2uH: 1	Triggered	Operating	Check the system	No
1AP/2AP	Low pressure	1P9/2P9: 1	Triggered	Operating	Check the system for cause of low pressure such as refrigerant loss	No
1AP/2AP blinking		1P9/2P9: 2	Triggered	Operating		Yes
Err	Failed uploading/downloading	-	-	-	Repeat again the procedure for uploading/downloading	No

Note: When multiple alarms occur, the highest priority alarm is displayed until being cleared, then the next highest alarm is displayed until all alarms are cleared. Only then will parameters be shown again.

Beschreibung:


EXD-HP1/2 sind autonome, universell einsetzbare Überhitzungs- und oder Economiser-Regler. EXD-HP1 besitzt einen Regelkreis für ein Ventil der Baureihe EXM/EXL oder EXN, während EXD-HP2 Regelkreise für zwei Ventile EXM/EXL oder zwei EXN besitzt.

Hinweis: Es ist möglich nur den Kreislauf 1 vom EXD-HP2 zu verwenden. In diesem Falle muss der Kreislauf 2 über den Parameter C2 abgeschaltet werden; Ventil und Sensoren brauchen nicht angeschlossen werden.

Die ModBus Kommunikation ist im Technical Bulletin beschrieben und nicht Teil dieses Dokuments.

Technical Data:

Versorgungsspannung:	24VAC/DC ±10%; 1A
Leistungsaufnahme:	EXD-HP1: 15VA EXD-HP2: 20VA
Steckerverbindung:	Steckbare Schraubklemmen für Adern mit max. 0,14...1,5 mm ² Querschnitt
Schutzart:	IP20
Digitaleingang:	Potenzialfreie Kontakte (siehe Verdrahtungsschema)
Temperaturfühler:	ECP-P30
Drucktransmitter:	PT5N
Betriebsumgebungstemp.	0...+55°C
Ausgang Alarmrelais	Wechsler (für 24V AC/DC), Induktive Last: 1A 24V AC/DC 4 Amp Ohm'sche Last
aktiviert:	bei Normalbetrieb (kein Alarmzustand)
inaktiv/stromlos:	im Alarmzustand oder bei abgeschalteter Spannung
Schrittmotorausgang	Spule: EXM-125 / EXL-125 oder EXN-125 Ventile: EXM-.../EXL-... oder EXN-...
Type of action	1B
Rated impulse voltage	0.5kV
Pollution Degree	2
Montage:	Standard Schienenmontage
Kennzeichnung	

Abmessungen (mm)

⚠ Warnung – Brennbare Kältemittel

EXD-HP1/2 hat eine potentielle Zündquelle und entspricht nicht den ATEX Bestimmungen. Installation nur in nicht explosionsgefährdeten Umgebungen. Für brennbare Kältemittel nur Ventile und Zubehörteile, die dafür zugelassen sind, verwenden!

⚠ Sicherheitshinweise:

- Lesen Sie die Betriebsanleitung gründlich. Nichtbeachtung kann zum Versagen oder zur Zerstörung des Gerätes und zu Verletzungen führen.
- Der Einbau darf nur von Fachkräften vorgenommen werden.
- Der Kältekreislauf darf nur in drucklosem Zustand geöffnet werden.
- Die Anlage erst in Betrieb nehmen, wenn alle Kabelverbindungen vollständig sind.
- Die Anlage darf erst dann in Betrieb genommen werden, wenn alle Verbindungen hergestellt sind.
- Für den gesamten elektrischen Anschluss sind die länderspezifischen Vorschriften einzuhalten.
- Digitaleingänge sind spannungsbehaftet; nur potentialfreie Schaltkontakte verwenden.
- Entsorgung:** Elektro- und Elektronik-Altgeräte dürfen nicht mit anderem Gewerbemüll entsorgt werden. Stattdessen ist es in der Verantwortung Benutzer es zu einem Sammelpunkt für die sichere Entsorgung von Elektro- und Elektronik-Altgeräte (Richtlinie 2019/19/EU) zu übergeben. Für weitere Informationen kontaktieren Sie bitte Ihren örtlichen Recyclinghof.

Elektrischer Anschluss und Verdrahtung::


- Den elektrischen Anschluss gemäß Verdrahtungsschema durchführen!
- Hinweis:** Signalleitungen und Leitungen mit Netzspannung in getrennten Kabelschächten verlegen, Mindestabstand 30mm.
- EXM-125, EXL-125 oder EXN-125 Spulen werden mit Kabel und JST Klemme geliefert. Klemme abschneiden. Offene Aderenden ca. 7 mm abisolieren. Aderendhülsen verwenden. Bei Anschluss von EXM/L und EXN(Ventilstecker) muss die Farbe der Adern wie folgt berücksichtigt werden:

EXD	Terminal	EXM/L Adernfarbe	EXN Adernfarbe
EXD-HP1	6	BR	Rot
	7	BL	Blau
	8	OR	Orange
	9	YE	Gelb
	10	WH	Weiß
EXD	Terminal	EXM/L Adernfarbe	EXN Adernfarbe
EXD-HP2	30	BR	Rot
	31	BL	Blau
	32	OR	Orange
	33	YE	Gelb
	34	WH	Weiss

- Die Digitaleingänge DI1 (EXD-SH1/SH2) und DI2 (EXD-SH2) sind die Schnittstellen zwischen EXD-SH1/2 und dem übergeordnetem Systemregler, wenn keine Modbus Kommunikation eingesetzt wird. Die externen Schaltkontakte müssen entsprechend der Systemanforderung angesteuert werden.
- Werden die Relaisausgänge nicht verwendet, muss das System auf andere Weise gegen Ausfälle geschützt werden

Betriebszustand	Status Digitaleingang
Verdichter startet/läuft	Externe Schaltkontakte schließen (Start)
Kompressor stoppt	Externe Schaltkontakte öffnen (Stop)


Hinweis: Das Aufschalten von externer Spannung auf die Digitaleingänge führt zur dauerhaften Beschädigung des EXD-SH1/2

Verdrahtungsschema Grundplatine (EXD-HP1/2):

Hinweis:

- Die Grundplatine erlaubt Überhitzungs- oder Economiser-Regelung
- Alarmrelais, potentialfrei. Bei Alarm oder Stromausfall ist die Relaisspule nicht bestromt.
- Der Heißgastemperaturfühler wird nur für die Economiser-Regelung benötigt.

Achtung: Für die 24V Stromversorgung sind ausschließlich Transformatoren der Klasse II zu verwenden. Die 24V Leitungen dürfen nicht geerdet werden. Wir empfehlen die Verwendung jeweils separater EMERSON Transformatoren für EXD-HP1/2 Regler und die Regler anderer Hersteller, weil unter Umständen über die Erdleitungen Kurzschlüsse entstehen können.

Verdrahtungsschema obere Platine (EXD-HP2):



Hinweis:

- Die obere Platine ist nur zur Überhitzungsregelung geeignet.
- Wird der Regelkreis 2 nicht benötigt, ist die Verdrahtung dieser Platine nicht erforderlich.

Vorbereitungen für die Inbetriebnahme:

- Den gesamten Kältekreislauf evakuieren.
- Achtung:** Die Elektrischen Regelventile EXM/EXL und EXN werden halb geöffnet ausgeliefert. Den Kältekreislauf nur bei geschlossenem Ventil mit Kältemittel füllen.
- Die 24V Versorgungsspannung des EXD-HP1/2 einschalten, während die Digitaleingänge (DI1/DI2) offen sind. Das Ventil wird schließen.
- Bei geschlossenem Ventil System mit Kältemittel füllen.


Parameter einstellung:

(müssen vor dem Starten geprüft und bei Bedarf angepasst werden)

- Digitaleingang öffnen (DI1/DI2). Versorgungsspannung einschalten.

- Vier Hauptparameter lassen sich nur bei offenem Digitaleingang DI1/DI2 mit eingeschalteter Stromversorgung (24V) einstellen: Passwort (H5), Funktionsart (1uE), Kältemittel (1u0/2u0) und Drucktransmitter (1uP/2uP). Dies dient zum Schutz des Verdichters und anderer Komponenten.
- Wenn diese Hauptparameter eingestellt sind, ist der EXD-HP1/2 fertig zum Start. Alle anderen Parameter lassen sich bei Bedarf auch im laufenden Betrieb einstellen.

Anzeige/Tastatur (LEDs und Tastenfunktionen)



Parametereinstellung:

- Parameter werden mit der Gerätetastatur eingestellt. Konfigurationsparameter sind passwortgeschützt. Das werkseitig eingestellte Passwort ist "12".
- PRG** Taste länger als 5 Sek. gedrückt halten, eine blinkende "0" erscheint
- SEL** drücken - Passwort wird bestätigt
- ▲** oder **▼** Taste drücken bis Passwort (Standardwert 12) angezeigt wird
- SEL** drücken - der aktuell eingestellte Wert wird angezeigt
- ▲** oder **▼** Taste drücken - der Wert wird vergrößert oder verkleinert
- SEL** drücken - der eingestellte Wert wird vorläufig behalten
- Zur Änderung weiterer Parameter wird dieser Ablauf wiederholt: "**▲** oder **▼** Taste drücken - nächste Parametererkennung auswählen..."

Parameter speichern und Konfigurationsmodus beenden:

- PRG** Taste drücken.

Parameter nicht speichern und Konfigurationsmodus beenden:

- mindestens 60s lang keine Taste drücken (Zeitsperre)

Alle Parameter auf Werkseinstellung zurücksetzen:

- Digitaleingang öffnen (DI1/DI2).
- ▲** und **▼** gleichzeitig mindestens 5 Sekunden drücken bis eine blinkende "0" erscheint.
- ▲** oder **▼** drücken bis Passwort (Standardwert 12) angezeigt wird.
- Falls das Passwort geändert wurde neues Passwort auswählen.
- SEL** Taste drücken - Passwort wird bestätigt
- Alle Parameter werden auf die Werkseinstellung zurückgesetzt.

Hinweis: Standardmäßig wird immer die Überhitzung angezeigt. Bei Flüssigkeiteinspritzung wechselt die Anzeige auf die Heißgasttemperatur.

- Schnelle Datenanzeige:

SEL und **▼** gleichzeitig 3 Sekunden drücken um Regelkreis 1 anzuzeigen
SEL und **▲** gleichzeitig 3 Sekunden drücken um Regelkreis 2 anzuzeigen

Zur Datenanzeige: **SEL** Taste 1 Sekunde drücken bis die Indexnummer gemäß Tabelle unten erscheint. **SEL** Taste loslassen, variable Daten werden angezeigt. Wird diese Prozedur wiederholt, erscheinen nacheinander die Werte in der Tabelle: gemessene Überhitzung (K) → gemessener Saugdruck (bar) → Ventilöffnung (%) → gemessene Sauggasttemperatur (°C) → gerechnete Sättigungstemperatur (°C) → gemessene Heißgasttemperatur (°C) (nur bei Economiser-Regelung) → wieder gemessene Überhitzung etc.

Datenanzeige	Regelkr. 1 (EXD-HP1/2)	Regelkr. 2 (EXD-HP2)
Default Superheat K	1 0	2 0
Saugdruck bar	1 1	2 1
Ventilposition %	1 2	2 2
Temp. Sauggas C.	1 3	2 3
Sättigungstemp. °C	1 4	2 4
Verdichtungstemp. °C	1 5	-

Hinweis 1: Heißgastemp. (°C) wird nur bei Economiser-Regelung angezeigt.

Hinweis 2: Nach 30 Minuten, wechselt die Anzeige wieder auf den Index 0.

Alarmanzeige zurückstellen / löschen (außer Hardwarefehler):

- **PRG** und **SEL** gleichzeitig mindestens 5 Sekunden drücken. Nach dem Löschen wird 2 sec lang "CL" angezeigt.

Handbetrieb:

- **PRG** und **▼** für 5 Sekunden drücken wechselt in den Handbetrieb.

Folgende Parameter erscheinen nacheinander mit der **▼** Taste

Code	Parameter Beschreibung und Auswahl	Min	Max	Werkeinst.	Einst.
IHo	Handbetrieb Regelkreis 1	0	1	0	
	0 = aus; 1 = ein				
IHP	Ventilöffnungsgrad (%)	0	100	0	
2Ho	Handbetrieb Regelkreis 2	0	1	0	
	0 = aus; 1 = ein				
2HP	Ventilöffnungsgrad (%)	0	100	0	

Hinweis: Während des Handbetriebes sind Funktionsalarme, wie "Zu niedrige Überhitzung" unterdrückt. Deshalb muss die Anlage in diesem Falle sorgfältig mit anderen Mitteln überwacht werden. Der Handbetrieb ist nur für Test und Servicezwecke vorgesehen. Danach sind für den Automatik Betrieb die Parameter IHo und 2Ho auf "0" zu setzen so dass der Regler entsprechend den Sollwerteinstellungen arbeiten kann.

Parametertabelle (im Regler hinterlegte Reihenfolge mit **▼ Taste):**

Code	Parameter Beschreibung und Auswahl	Min	Max	Werk
H5	Passwort	1	1999	12
Adr	Modbus Adresse	1	127	1
br	Modbus Baudrate	0	1	1
PAr	Modbus Parität	0	1	0
-C2	Regelkreis 2 von EXD-HP2 aktivieren 0 = eingeschaltet; 1 = ausgeschaltet	0	1	0
-uC	Maßeinheitensystem umstellen 0 = °C, K, bar; 1 = F, psig	0	1	0
HP-	Anzeigemode 0 = Keine Anezeige 1 = Regelkreis 1 2 = Regelkreis 2 (nur EXD-HP2)	0	2	1

Parameter Regelkreis 1

1uE	Funktion 0 = Überhitzungsregelung; 1 = Economiser-Regelung (nur für R410A/R407C/R32)	0	1	1
1u4	Regeloptionen Überhitzungsregelung 0 = Standardregelung Wärmeaustausch 1 = langsame Regelung 2 = feste PID 3 = Schnelle Regelung Plattenwärmemtauscher 4 = Standardregelung Plattenwärmemtauscher	0	4	0
1u0	Kältemittel Kreislauf 1 0 = R22 1 = R134a 2 = R410A 3 = R32 4 = R407C 5 = R290* 6 = R448A 7 = R449A 8 = R452A 9 = R454A* 10 = R454B* 11 = R454C* 12 = R513A 13 = R452B* 14 = R1234ze* 15 = R1234yf* *) EXN nicht erlaubt	0	15	2
	*) EXN nicht erlaubt			
1uP	Drucktransmitter 0 = PT5N-07... 1 = PT5N-18... 2 = PT5N-30... 3 = PT5N-10P-FLR	0	3	2
1uu	Ventilöffnungsgrad bei Start (%)	10	100	20
1u9	Dauer der Ventilöffnung bei Start (sec)	1	30	5


Code	Parameter Beschreibung und Auswahl	Min	Max	Werk
1uL	Alarm bei kleiner Überhitzung 0 = aus (für überfluteten Verdampfer) 1 = ein mit automatischer Rückstellung 2 = ein mit manueller Rückstellung	0	2	1
1u5	Überhitzung Sollwert (K) wenn 1uL = 1 / 2 (Rückstell. autom./ manuell) wenn 1uL = 0 (Rückstellung aus)	3 0,5	30 30	6 6
1u2	MOP Funktion 0 = aus 1 = ein	0	1	1
1u3	MOP Sollwert (°C) Sättigungstemperatur Die Werkseinstellung ist abhängig vom Kältemittel (2u0). Min./Max. Werte sind abhängig vom gewählten Kältemittel			Siehe MOP Tabelle
1P9	Niederdruckalarm Regelkreis 1 0 = aus 1 = ein autom. Rückstellung 2 = ein - manuelle Rückstellung	0 1	2	0
1PA	Niederdruckalarm Sollwert Regelkreis1	-0,8	17,7	0
1Pb	Niederdruckalarm Verzug Regelkreis 1	5	199	5
1Pd	Niederdruckalarm Rückst. Regelkreis 1	0,5	18	0,5
1P4	Frostschutz Alarmfunktion 0 = aus 1 = ein - autom. Rückstellung 2 = ein - manuelle Rückstellung	0 1	2	0
1P2	Frostschutzalarm Sollwert Regelkr. 1	-20	5	0
1P5	Alarmverzug Frostschutz, sec..	5	199	30
1P-	Überhitzung Regelkreis 1 (Kp Faktor) PID fest Display 1/10K	0,1	10	1,0
1i-	Überhitzung Regelkreis 1 (Ti Faktor) PID fest	1	350	100
1d-	Überhitzung Regelkreis 1 (Td Faktor) PID fest Display 1/10K	0,1	30	3,0
1EC	Eingang für Heißgastemperaturmessung 0 = ECP-P30 1 = über Modbus Eingang	0 1	1	0
1PE	Economizer Regelkreis 1 (Kp Faktor) PID fest Display 1/10K	0,1	10	2,0
1iE	Economizer Regelkreis1 (Ti Faktor) PID fest	1	350	100
1dE	Economizer Regelkreis 1 (Td Faktor) PID fest Display 1/10K	0,1	30	1,0
1uH	Alarm bei Überhitzung Regelkreis 1 0 = aus 1 = ein autom. Rückstellung	0 1	1	0
1uA	Grenzwert für Überhitzung (K) Regelkreis 1	16	40	30
1ud	Alarmverzug für Überhitzung (Min) 1	1	15	3
1E2	Positive Korrektur für Heißgas-temperaturmessung.	0	10	0
Parameter Regelkreis 2 (nur EXD-HP2)				
Code	Parameter Beschreibung und Auswahl	Min	Max	Werk
2u4	Funktion Regelkreis 2 0 = Standardregelung Wärmeaustausch 1 = langsame Regelung 2 = feste PID 3 = Schnelle Regelung Plattenwärmemtauscher 4 = Standardregelung Plattenwärmemtauscher	0	4	0
2	Kältemittel 0 = R22 1 = R134a 2 = R410A 3 = R32 4 = R407C 5 = R290* 6 = R448A 7 = R449A 8 = R452A 9 = R454A* 10 = R454B* 11 = R454C* 12 = R513A 13 = R452B* 14 = R1234ze* 15 = R1234yf* *) EXN nicht erlaubt	0 1 2 3 4 5 6 7 8 9 10 11 12 13 14 15	15 40 40 45 45 45 45 45 45 45 45 45 45 45 45 45	2 30 30 30 30 30 30 30 30 30 30 30 30 30 30 30
2uP	Drucktransmittertyp Regelkreis 2: 0 = PT5N-07... 1 = PT5N-18... 2 = PT5N-30... 3 = PT5N-10P-FLR	0 1 2 3	3 18 30 10P-FLR	1
2uu	Ventilöffnungsgrad (%) bei Start 2	10	100	20
2u9	Dauer Ventilöffnung bei Start (sek.) 2	1	30	5
2uL	Alarmsfunktion bei kleiner Überhitzung 0 = aus (für überfluteten Verdampfer) 1 = ein autom. Rückst. 2 = ein Handrückstellung	0 1	2	1
2u5	Überhitzung Sollwert (K) wenn 2uL = 1 / 2 (Rückstell.autom. / manuell) wenn 2uL = 0 (Rückstellung aus)	3 0,5	30 30	6 6

Code	Parameter Beschreibung und Auswahl	Min	Max	Werk
2u2	MOP Betrieb Regelkreis 2 0 = aus 1 = ein	0	1	1
2u3	MOP Sollwert (°C) Sättigungstemperatur Die Werkseinstellung ist abhängig vom Kältemittel (2u0). Min./Max. Werte sind abhängig vom gewählten Kältemittel			Siehe MOP Tabelle
2P9	Niederdruckalarm Regelkreis 2 0 = aus 1 = ein autom. Rückstellung 2 = ein Handrückstellung	0	2	0
2PA	Grenzwert für Niederdruckalarm (bar) Regelkreis 2	-0.8	17.7	0
2Pb	Niederdruckalarm Verzug (sec) Regelkreis 2	5	199	5
2Pd	Rückstellung Niederdruckalarm (bar) Regelkreis 2	0.5	18	0.5
2P4	Frostschatzalarm Regelkreis 2 0 = aus 1 = ein autom. Rückstellung 2 = ein Handrückstellung	0	2	0
2P2	Grenzwert Frostschatzalarm (°C) 2	-20	5	0
2P5	Alarmverzug Frostschatz, (sec.)	5	199	30
2P-	Überhitzung mit festem PID Kp Faktor Display 1/10K	0.1	10	1.0
2i-	Überhitzung mit festem PID Ti Faktor	1	350	100
2d-	Überhitzung mit festem PID Td Faktor Display 1/10K	0.1	30	3.0
2uH	Alarm bei Überhitzung Regelkreis 2 0 = aus 1 = ein autom. Rückstellung	0	1	0
2uA	Grenzwert für Überhitzung Regelkreis 2	16	40	30
2ud	Alarmverzug (Min) für Überhitzung Regelkreis 2	1	15	3

MOP Tabelle (°C)

Kältemittel	Min.	Max.	Werk	Kältemittel	Min.	Max.	Werk
R22	-40	+50	+15	R452A	-45	+66	+15
R134a	-40	+66	+15	R454A	-57	+66	+10
R410A	-40	+45	+15	R454B	-40	+45	+18
R32	-40	+30	+15	R454C	-66	+48	+17
R407C	-40	+48/	+15	R513A	-57	+66	+13
R290	-40	+50	+15	R452B	-45	+66	+25
R448A	-57	+66	+12	R1234ze	-57	+66	+24
R449A	-57	+66	+12	R1234yf	-52	+66	+15

Ventilöffnung beim Start (Parameter 1uu/2uu und 1u9/2u9)



Funktion des Kopierschlüssels

Für Serienfertigung können Konfigurationsparameter mit dem Kopierschlüssel auf weitere, identische Regler übertragen werden.

Konfigurationsparameter auf den Kopierschlüssel laden

- Der (Referenz-)Regler muss eingeschaltet sein. Kopierschlüssel einstecken und Taste betätigen. Auf der Anzeige erscheint die Meldung "uPL", danach 5 Sekunden lang "End".
- Hinweis: Falls die Fehlermeldung "Err" angezeigt wird, Prozedur wiederholen.

Konfigurationsparameter vom Kopierschlüssel auf andere Regler übertragen

- Am neuen Regler Versorgungsspannung ausschalten
- Kopierschlüssel (mit den Daten des Referenzreglers) einstecken, dann Versorgungsspannung einschalten.
- Die gespeicherten Daten werden automatisch in den Speicher des neuen Reglers übertragen. Auf der Anzeige erscheint die Meldung "doL", danach 5 Sekunden lang "End".
- Nach Erlöschen der "End" Meldung startet der neue Regler. Kopierschlüssel entfernen.
- Hinweis: Falls die Fehlermeldung "Err" angezeigt wird, Prozedur wiederholen.



Parameter Regelkreis 1 & 2 und Druckgastemperatur Überwachung

Code	Parameter Beschreibung und Auswahl	Min	Max	Werk
Et	Ventiltyp 0 = EXM / EXL 1 = EXN Hinweis: EXD-HP2 kann zwei ähnliche Ventile entweder EXM/EXL oder EXN steuern.	0	1	0
1E3	Sollwert Druckgastemperatur •Startsollwert	70	140	85
1E4	Temperatur-Regelbereich	2	25	20
1E5	Max. zulässige Druckgastemperatur	100	150	120

Error/Alarm handling

Alarm code	Description	Related parameter	Alarm relay	Valve	What to do?	Requires manual reset after resolving alarm
1E0/2E0	Drucktransmitterstörung	-	ausgelöst	geschlossen	Verdrahtung prüfen und 4 ... 20 mA Signal messen	nein
1E1/2E0	Temperatursensor 1/2	-	ausgelöst	geschlossen	Verdrahtung prüfen und Sensorwiderstand messen	nein
1Ed	Heißgas-Temperaturfühler 3	-	ausgelöst	regelt	Verdrahtung prüfen und Sensorwiderstand messen	nein
1T-2T-	EXM/EXL oder EXN Verdrahtungsfehler	-	ausgelöst	-	Verdrahtung prüfen und Wicklungswiderstand messen	nein
1Ad	Heißgastemperatur über Grenzwert		ausgelöst	regelt	Ventilöffnung prüfen / Flashgas in der Flüssigkeitsleitung prüfen / Heißgastemperaturfühler prüfen.	nein
1AF/2AF	Frostschutz	1P4/2P4: 1	ausgelöst	geschlossen	System überprüfen / Ursache des Niederdrucks ermitteln, z.B. Verdampferlast zu klein.	nein
1AF/2AF blinking		1P4/2P4: 2	ausgelöst	geschlossen		ja
1AL/2AL	Kleine Überhitzung (<0,5K)	1uL/2uL: 1	ausgelöst	geschlossen	Verdrahtung und Ventilfunktion überprüfen	nein
1AL/2AL blinking		1uL/2uL: 2	ausgelöst	geschlossen		ja
1AH/2AH	Große Überhitzung	1uH/2uH: 1	ausgelöst	regelt	System überprüfen	nein
1AP/2AP	Niederdruck	1P9/2P9: 1	ausgelöst	regelt	System überprüfen / Ursache des Niederdrucks ermitteln, z.B. Kältemittelverlust.	nein
1AP/2AP blinking		1P9/2P9: 2	ausgelöst	regelt		ja
Err	Fehler bei Kopierfunktion	-	-	-	Kopierprozedur wiederholen	nein

Hinweis: Bei mehreren Störungen wird nur der Alarm mit der höchsten Priorität angezeigt. Erst nach dessen Beseitigung erscheint der nächste Alarm usw. bis alle Alarne beseitigt sind. Erst dann werden die Daten wieder angezeigt.

Free Manuals Download Website

<http://myh66.com>

<http://usermanuals.us>

<http://www.somanuals.com>

<http://www.4manuals.cc>

<http://www.manual-lib.com>

<http://www.404manual.com>

<http://www.luxmanual.com>

<http://aubethermostatmanual.com>

Golf course search by state

<http://golfingnear.com>

Email search by domain

<http://emailbydomain.com>

Auto manuals search

<http://auto.somanuals.com>

TV manuals search

<http://tv.somanuals.com>