

# *Oster* FUSION

*User Manual*

**BLENDERS**

*Manual de Instrucciones*

**LICUADORAS**

MODEL/MODELO BRLY07 **OSTER® FUSION**  
The Ultimate Chopping and Blending Solution



*Recipes Included in Instruction Manual.*  
*Recetas Incluidas en el Manual de Instrucciones.*

# IMPORTANT SAFEGUARDS

When using your blender, you should always follow basic safety precautions, including the following:

- Read all instructions before use.
- To protect against electrical hazards, do not immerse the cord, plug or motor base in water or other liquids.
- Always use the product on a clean, flat, hard, dry surface. There should be no material such as a tablecloth or plastic between the unit and surface.
- Avoid contact with moving parts.
- Keep hands and utensils out of jar while blending to reduce the risk of:
  - Severe personal injury
  - Damage to the blender
- If scraping is necessary, turn the power OFF and use a rubber spatula only.
- Do not use the appliance:
  - With a damaged cord or plug
  - After the unit fails to work correctly
  - After you drop or damage the product in any wayReturn the product to your nearest Authorized Oster® Appliance Service Center for a safety check, adjustment or repair.
- The multi-functional blade is sharp. Handle it carefully.
- To reduce the risk of injury:
  - Do not leave the multi-functional blade sitting out or exposed
  - Always completely assemble the blade to the jar before putting on the base
- Always put the lid on the jar before operating the blender.
- When blending hot liquids beware of steam. Remove the jar lid food chute from the lid to allow steam to escape.
- Do not use outdoors.
- Do not allow the cord to touch hot surfaces or hang over the edge of a table or counter.
- Unplug the blender when it is not in use, before taking off or putting on parts, and before cleaning.
- Never leave the appliance unattended while it is running.
- You risk personal injury, fire or electric shock if you use attachments, jars or parts other than those recommended by Jarden.
- Supervise children closely when they use or are nearby appliances.
- Do not blend boiling liquids in the blender.
- The use of attachments, including canning or ordinary jar and processing assembly parts is not recommended by Jarden, and may cause risk or injury to persons.

# SAVE THESE INSTRUCTIONS

## **This product is for household use only.**

- The maximum rating marked on the product is based on the attachment that draws the greatest load. Other attachments may draw less power.

## **Power Cord Instructions:**

Please follow the instructions below to ensure the safe use of the power cord.

- This appliance is equipped with a polarized plug. This type of plug has one blade that is wider than the other. This plug will fit in a polarized outlet only one way. This is a safety feature intended to help reduce the risk of electrical shock. If you are unable to insert the plug into the outlet, contact a qualified electrician to replace the obsolete outlet. Do not attempt to defeat the safety purpose of the polarized plug by modifying the plug in any way.
- Try to position the blender near the power source to reduce the hazards associated with power cords (stuck as becoming entangled or tripping over a long power cord).
- Do not pull, twist or otherwise abuse the power cord.
- Do not wrap the power cord around the main body of the blender during or after use.
- Do not use an extension cord with this product.



**This symbol has been placed in specific areas of the User Guide portion of this book. Its purpose is to help you easily identify instructions that require your special attention.**

# Table of Contents

Welcome .....	5
Learning About Your Product.....	6
Using Your Product .....	7
Assembly (Glass Jar Models) .....	7
Using the Pre-Programmed Settings.....	7
Frozen Drinks and Shakes button.....	7
Food Chop button.....	7
Using the Manual Controls .....	8
Using the Max/Ice Crush button .....	8
Using the Medium/Blend button .....	8
Using the Low/Stir button.....	8
Using the Max Pulse button.....	9
Using the Low Pulse button .....	9
Using the Stop button.....	9
Using the On/Off button.....	9
Caring for Your Product.....	9
After Use .....	9
Cleaning (Glass Jar Models).....	9
Storing.....	9
Servicing.....	9
Blending Tips .....	10
Liquids .....	10
Using the jar lid food chute.....	10
Hot foods .....	10
Ingredients Quantities.....	10
Frequently Asked Questions .....	10
Recipes .....	11
Frozen Drinks .....	11
Smoothies & Shakes .....	12
Salsa .....	14
Soups and Foods .....	16
One-Year Limited Warranty.....	19
How to Obtain Warranty Service .....	19

# Welcome

Congratulations on your purchase of an Oster® Blender. If you have any comments, questions or inquiries about this revolutionary product, please call 1-800-334-0759. Your product includes the following technology and features:

- A **user-friendly touchpad design** gives you the option of Pre-Programmed Settings or Manual Controls. Try a frozen drink, smoothie, salsa or soup from the recipe section in the instructions.
- A **multi-functional blade** optimizes Pre-Programmed food and drink preparation.
- A **powerful reversible motor** keeps the ingredients near the blade by spinning at very low speeds and gradually speeding up to the Pre-Programmed level, ensuring optimum results from smooth to chunky.
- **Manual Controls** give you the flexibility to operate the blender for personal recipes.
- A **jar lid food chute** lets you add ingredients without removing the jar lid.

# Learning About Your Product

## Glass Jar Models

1. **Jar Lid Food Chute** – Allows you to add ingredients during use.  
Also, allows you to open to allow steam to escape when blending hot foods.
2. **Jar lid** – Seals the blender jar.
3. **Jar** – Made from heavy-duty glass.  
Has a maximum capacity of 6 cups.
4. **Sealing Ring** – Seals the jar to the multi-functional blade for leak-proof operation.
5. **Multi-Functional Blade** – Creates a forward and reverse action when the Pre-Programmed settings are in use.
6. **Threaded Jar Bottom**
7. **Sturdy Stylish Base** – Holds the jar securely. Contains a powerful, reversible, variable speed motor. It uses Pre-Programmed logic that takes the guesswork out of creating foods and drinks.
8. **Control Panel**
  - a. **Pre-Programmed Settings** – Use to select “Frozen Drinks & Shakes” Button or “Food Chop” Button. Blender automatically shuts off when cycle is finished.
  - b. **Manual Controls** – “Max/Ice Crush” button – Use for max speed or ice crushing
  - c. **Manual Controls** – “Medium/Blend” button – Use for medium speed
  - d. **Manual Controls** – “Low/Stir” button – Use for low speed
  - e. **Max Pulse Button** – Press and hold to Pulse, release the button to stop
  - f. **Low Pulse Button** – Press and hold to Pulse, release the button to stop
  - g. **Power Button (On/Off button)** – Turns the product On and Off
  - h. **Stop Button** – Use to Stop the product

# Using Your Product

Before you use the product for the first time, separate the lid, jar lid food chute and blade from the jar. Wash in warm, soapy water, or top rack in the dishwasher. Rinse and dry well.





## Assembly (Glass Jar Models)

1. Install the sealing ring over the multi-functional blade.  
⚠ Blade is sharp. Handle with care.
2. Turn the jar upside down so the small opening is at the top.
3. Turn the multi-functional blade with sealing ring upside down and place into the bottom of the jar.
4. Position the open end of the threaded jar bottom over the jar and sealing ring. Turn clockwise to tighten.  
Be sure the threaded jar bottom is locked securely to the jar before using.
5. Slide the jar onto the base.
6. Plug the power cord into a standard household 120/127-volt, 60 hz. AC outlet. You are now ready to start.

## Using the Pre-Programmed Settings

1. Press the ON/OFF power button to turn the product on.  
The power light will blink, meaning the product is active and ready to use.
2. Choose a recipe from the recipe section of this manual or use one of your own.
3. Put the ingredients into the jar.
4. Secure the lid and jar lid food chute.
5. Press one of the two Pre-Programmed Setting buttons appropriate for your recipe.  
“Frozen Drinks & Shakes” Button  
“Food Chop” Button
6. To change your selection, press Stop followed by another Pre-Programmed Setting button (“Frozen Drinks & Shakes” or “Food Chop”)
7. Once the program is finished the product automatically stops. Please note: You may press the “Stop” button to cancel the program at any time. The blinking red light indicates that the blender is ready.
8. Press the ON/OFF power button to turn the product off.



This product is pre-programmed to turn off automatically if not used for a period of several minutes. All lights will turn off when the unit automatically powers down.

## Using the Manual Controls


The **Manual Controls** include:

- Max/Ice Crush (High speed)
- Medium/Blend (Medium speed)
- Low/Stir (Low speed)
- Max Pulse
- Low Pulse

Use these buttons for personal recipes or to continue mixing after a Pre-Programmed Setting is finished.


- 
- 
- 

1. Press the ON/OFF power button to turn the product on. The power light will blink, meaning the product is active and ready to use.
2. Choose a recipe from the recipe section of this manual or use one of your own.
3. Put the ingredients into the jar.
4. Secure the lid and the jar filler cap




## Using the Max/Ice Crush button

1. Press the “Max/Ice Crush” button to run the product at a high speed.
2. Press the “Stop” button to cancel the operation at any time.
3. Press the ON/OFF power button to turn the product off.




## Using the Medium Blend button

1. Press the “Medium/Blend” button to run the product at a medium speed.
2. Press the “Stop” button to cancel the program at any time.
3. Press the ON/OFF power button to turn the product off.



## Using the Low/Stir button

1. Press the “Low/Stir” button to run the product at a low speed.
2. Press the “Stop” button to cancel the program at any time.
3. Press the ON/OFF power button to turn the product off.





## Using the Max Pulse

1. Press and hold the “Max Pulse” button.
2. Release the pulse button to stop.
3. Press the ON/OFF power button to turn the product off.

Use lower pulse settings for food and higher pulse settings for drinks.

## Using the Low Pulse


1. Press and hold the “Low Pulse” button.
2. Release the pulse button to stop.
3. Press the ON/OFF power button to turn the product off.

Use lower pulse settings for food and higher pulse settings for drinks.

## Caring for Your Product


### After Use

1. Lift the jar straight up from the base, remove the lid and empty the jar.
2. If necessary, use a rubber spatula to scrape foods away from the sides of the jar.




### Cleaning (Glass Jar Models)

Release the multi-functional blade from the bottom of the jar by turning the jar bottom cover counterclockwise. The jar lid, jar lid food chute and blade are dishwasher safe. Use the top rack of the dishwasher for the jar lid, jar lid food chute and multi-functional blade. Place sealing ring into bottom basket of dishwasher.



You can also wash the parts in warm, soapy water. Rinse well and dry. Wipe the base with a soft, damp cloth to clean. Never submerge the low profile base in a liquid.



Check the parts as you put them back together.

### Storing

Reassemble the blender for storage. Leave the lid open a gap so no odors are retained.



**WARNING: Never put the jar, or any other parts, in a microwave oven. Never store foods or drinks in the jar.**

### Servicing

If repairs are needed, send your appliance only to an authorized Oster® Appliance Service Center. Use only replacement parts from Jarden. See How to Obtain Warranty Service on page 19.

## Blending Tips

### Liquids

Put liquids into the jar first, unless the recipe says otherwise.



### Using the jar lid food chute

Do not remove the lid while in use. Food may splatter if you do. Instead, open the jar lid food chute to add smaller ingredients.

### Working with Hot Foods or Liquids



**WARNING:** When you work with **HOT FOODS**, remove the jar lid food chute to vent steam. Tilt the lid away from you partially covering the opening. Keep hands and other exposed skin away from the lid opening to prevent possible burns.



When you work with **HOT LIQUIDS**, remove the jar lid food chute and start at a low speed, and then gradually increase to a faster speed. Do not add liquid over the 4 cup (1L) level. Always keep hands away from steam.

### Ingredients Quantities

Use only the amount of food suggested in the recipes. If you want greater amounts, prepare in batches. Using larger amounts may overload and strain the motor. You might also get different results from those described.

## Frequently Asked Questions

### Why doesn't the blender/food processor turn on?

- Make sure the base is plugged in an active power receptacle.
- Verify blinking red light is active after pushing on/off button.

### How can I prevent liquids from leaking out?

Check to see that the sealing ring is correctly assembled in between the multi-functional blade and the jar.

# Recipes

These recipes have been optimized with the Pre-Programmed Settings. When experimenting with your own recipes you may choose to stop the Pre-Programmed Setting at any time by hitting the Stop button or you may run the cycle more than once if a smoother result is desired.

## Frozen Drinks:

### Frozen Margarita

Makes 4 servings

4 oz. gold tequila

2 oz. orange and cognac liqueur

2 Tbsp. fresh lime juice

¼ cup sugar

3 cups ice

Garnish: Extra lime juice and salt for coating glass rims

1. In jar, place ingredients in order given above.
2. Cover jar with lid. Press “On/Off” button, then press “Frozen Drinks & Shakes” button.
3. Dip rim of stemmed glasses in lime juice then in salt; pour drink into glasses.

Creative Cook’s Note: If desired, granulated sugar can be used in place of salt.

Note: For a smoother finish, use the high pulse button 3 to 4 times after the frozen drink cycle is complete.

### Strawberry Daiquiri

Makes 4 servings

1 can (6 oz.) frozen limeade concentrate

5 oz. rum

1 cup whole strawberries with stems removed

1 Tbsp. sugar

3 ½ cups ice

Garnish: Small whole strawberries and lime slices

1. In jar, place ingredients in order given above.
2. Cover jar with lid. Press “On / Off” button, then press “Frozen Drinks & Shakes” button.
3. Pour into stemmed glasses.
4. Garnish, if desired, with strawberry and lime slice.

Creative Cook’s Note: For variety, substitute fresh raspberries, blackberries or cubed mango, in equal amounts for the strawberries.

Note: For a smoother finish, use the high pulse button 3 to 4 times after the frozen drink cycle is complete.

## Piña Colada

Makes 4 servings

1 cup pineapple juice

6 oz. golden rum

2/3 cup cream of coconut

1 tsp. lemon juice

4 cups ice

Garnish: Pineapple slices, maraschino cherries

1. In jar, place ingredients in order given above.
2. Cover jar with lid. Press “On / Off” button, then press “Frozen Drinks & Shakes” button.
3. Pour into tall glasses.
4. Garnish, if desired, with pineapple slice and cherry.

**Note:** For a smoother finish, use the high pulse button 3 to 4 times after the frozen drink cycle is complete.

## Smoothies and Shakes:

### Strawberry Shake

Makes 2 servings

1 cup fresh, ripe strawberries with stems removed (8 to 10 medium berries)

1 cup milk

2 cups strawberry ice cream

1. In jar, place ingredients in order given above. Put berries in first!
2. Cover jar with lid. Press “On / Off” button, then press “Frozen Drinks & Shakes” button.
3. Pour into tall glasses.

### Choco-Peanut Butter Shake

Makes 2 Servings

1 cup milk

2 cups chocolate ice cream

¼ cup peanut butter

¼ tsp. vanilla

1. In jar, place ingredients in order given above.
2. Cover jar with lid. Press “On / Off” button, then press “Frozen Drinks & Shakes” button.
3. Pour into tall glasses.

## **Brandy Alexander**

Makes 4 servings

3 Tbsp. milk

4 oz. crème de cacao

2 oz. brandy

2 cups vanilla ice cream

1. In jar, place ingredients in order given above.
2. Cover jar with lid. Press “On / Off” button, then press “Frozen Drinks & Shakes” button.
3. Pour into stemmed glasses.

## **Honey-Vanilla Blast**

Makes 1 serving

1 cup fat free milk

1 cup (8 oz.) fat free vanilla yogurt

3 chunks frozen banana, about 1 medium

¼ cup protein powder

2 Tbsp. honey

1. In jar, place ingredients in order given above.
2. Cover jar with lid. Press “On / Off” button, then press “Frozen Drinks & Shakes” button.
3. Pour into tall glass to serve.

## **Morning Mocha Smoothie**

Makes 1 serving

½ cup fat free milk

1 cup (8 oz.) low fat coffee yogurt

2 Tbsp. chocolate syrup

6 ice cubes

1. In jar, place ingredients in order given above.
2. Cover jar with lid. Press “On / Off” button, then press “Frozen Drinks & Shakes” button.
3. Pour into tall glass to serve.

## **Very Berry Smoothie**

Makes 1 serving

1 cup orange juice

½ cup vanilla low fat yogurt

1 cup frozen mixed berries

2 frozen banana chunks, about 1 small

2 Tbsp. honey

1. In jar, place ingredients in order given above.
2. Cover jar with lid. Press “On / Off” button, then press “Frozen Drinks & Shakes” button.
3. Pour into tall glass to serve.

### **Tropical Power Punch Smoothie**

Makes 2 servings

- 1 can (6 oz.) pineapple juice
- 1 can (8 oz.) crushed pineapple
- 1 cup mango sorbet
- ½ tsp. coconut extract
- 1 cup ice

1. In jar, place ingredients in order given above.
2. Cover jar with lid. Press “On / Off” button, then press “Frozen Drinks & Shakes” button.
3. Pour into tall glasses to serve.

### **Salsas:**

#### **Garden Fresh Salsa**

Makes 2 cups

- ½ small onion, cut into 4 pieces
- ¼ green pepper, cut into 4 pieces
- ½ cucumber, cut into quarters
- 1 large garlic clove
- 12 oz. (4-5) plum tomatoes, cut each into 8ths.
- 3 Tbsp. red wine vinegar
- 1 tsp. Worcestershire
- 1/8 tsp. hot pepper sauce
- Salt & Pepper to taste
- Tortilla chips for serving

1. In jar, place ingredients, except tortilla chips, in order given above.
2. Cover jar with lid. Press “On / Off” button, then press “Food Chop” button.
3. Pour into bowl; serve with tortilla chips.

#### **Fiery Red Salsa**

Makes 3 cups

- 2 large garlic cloves
- 1 can (15 oz.) whole tomatoes, drained
- 1 medium onion, cut into ¼ (4 pieces)
- ½ cup cilantro leaves
- 1-4 jalapeno peppers, quartered
- ½-1 tsp. sugar
- Salt to taste
- 1 Tbsp. lime juice

1 can (15 oz each) whole tomatoes, drained  
Tortilla chips for serving

1. In jar, place ingredients, except tortilla chips, in order given above. (Note: Place one can of tomatoes in after garlic cloves and second can after rest of ingredients are added. Also, place onion in middle of jar to avoid blockage.)
2. Cover jar with lid. Press “On / Off” button, then press “Food Chop” button.
3. Pour into bowl; serve with tortilla chips.

**Creative Cook’s Note:** When handling hot peppers, such as jalapeños, use rubber gloves, and keep hands away from your eyes.

## Salsa Verde

Makes 1 ½ cups

½ small onion, cut into 4 pieces

½ small green pepper, cut into 4 pieces

2 garlic cloves

¼ cup cilantro leaves

½ tsp. ground cumin

¼ tsp. green hot pepper sauce

1/8 tsp. salt

12 oz. (8-9) tomatillos, roasted, husks removed

Tortilla chips for serving

1. In jar, place ingredients, except tortilla chips, in order given above.
2. Cover jar with lid. Press “On / Off” button, then press “Food Chop” button.
3. Pour into bowl; serve with tortilla chips.

**Notes:** Worked fine on chop cycle.

12 oz. of tomatillo is about 8 or 9

## How To Roast Tomatillos

Remove the husk and rinse to wash away the stickiness that coats the skin.

Place them on a baking sheet with a rim and roast them under a hot broiler about 4 inches from the heat source. Roast the tomatillos for 3 to 4 minutes, or until they are blistered and brown. Turn them and roast in the same manner on the other side. The rimmed baking sheet will contain the juices that should be added into the recipe.

## Soups and Foods:

### Cream of Tomato Soup

Makes 4 servings

4-5 medium ripe tomatoes, cut in quarters

1 small onion cut in quarters

3-4 fresh basil leaves

2 Tbsp. Butter

½ tsp. salt

1 cup half-and-half or milk

1. Place tomatoes, onion and basil in the jar.
2. Cover jar with lid. Press “On / Off” button, then press “Food Chop” button.
3. Pour processed mixture into 3 qt. sauce pan. Add butter, salt and half-and-half.
4. Stir while gently heating to 145°F; do not let soup boil.

### Cuban Black Bean Soup

Makes 4 servings

2 cans (15-19 oz. each) black beans

½ small red onion halved

4 or 5 sprigs cilantro stems discarded

1 small onion halved

2 garlic cloves

2 Tbsp. Olive Oil

1 cup water

½ cup sofrito\*

1 Tbsp. Cilantro leaves

1 cup sour cream

1. Rinse and drain beans; set aside.
2. Place red onion and cilantro leaves in the jar. Cover jar and press “On/Off” button and then press “Food Chop” button.
3. Remove mixture from jar and set aside (no need to rinse jar for next step).
4. Place onion and garlic in jar. Cover jar and press “On/Off” button and then press “Food Chop” button.
5. In a 4 quart sauce pan cook onion and garlic in olive oil until tender.
6. In jar, place 3 cups of beans with liquid and cilantro leaves. Cover jar with lid and press “On/Off” button and then press “Medium/Blend” button and press “Stop” button when desired consistency is reached. (Change to whatever the sequence will be on the final product).
7. Stir bean mixture into soup remaining in saucepan; reheat as desired.
8. Serve, if desired, with sour cream and onion chive mixture.

\* Sofrito is a popular condiment in Latin American cooking. It can be found in the Latin American or International foods section of most supermarkets.

**Creative Cook’s Note:** If a totally blended soup is preferred, repeat step #3 with remaining beans and liquid.



## **Peachy Applesauce**

Makes 1 ¼ cups

1 large apple, pared, cored and quartered

1 large peach, pitted, peeled and quartered (If out of season, use 2 canned peach halves.)

2 Tbsp. water

1. In small saucepan, cook fruits in water 5-8 minutes or until very tender.
2. In jar, place fruits and liquid.
3. Cover jar with lid. Press “On/Off” button, then press “Low Pulse” button 3 or 4 times, then “Max Pulse” button until smooth.
4. Remove from jar; place in covered containers.
5. Chill or freeze at once.

## **Green Pea Baby Food**

Makes 1 ½ cups

1 pkg. (10 oz.) frozen baby green peas

¾ cup water

1. In small saucepan, cook peas in water 10-15 minutes or until very tender.
2. In jar, place peas and liquid.
3. Cover jar with lid. Press “On/Off” button, then press “Frozen Drinks & Shakes” button.
4. Remove from jar. Place in covered containers.
5. Chill or freeze at once.

## **Honey-Wheat Pancakes**

Makes 12 pancakes

1 1/3 cups low fat buttermilk

2 eggs

2 Tbsp. honey

1 ½ cups reduced-fat buttermilk baking mix

½ cup whole-wheat flour

¼ cup honey-crunch wheat germ

1 tsp. baking powder

Butter and syrup for serving

1. In jar, place ingredients in order given above.
2. Cover jar with lid. Press “On/Off” button, then press “Max Pulse” button 8-10 times. When done, scrape jar and stir in the batter lightly.
3. For each pancake, pour about ¼ cup batter onto preheated griddle; cook until tops begin to bubble; turn over and continue to cook until golden.
4. Serve hot with butter and syrup.

## Chocolate Cream Pie

Makes 8 servings

1/3 cup slivered almonds

20 chocolate wafer cookies

¼ cup melted butter

2 pkg. (3.4 oz. each) instant chocolate pudding and pie filling

3 ½ cups milk

½ tsp. almond extract

1 ½ cups heavy cream

1/3 cup chocolate syrup

Garnish: White chocolate curls

### Pie Crust

1. In jar, place almonds. Then break cookies into jar.
2. Cover jar with lid. Press “On/Off” button, then press “Food Chop” button.  
(Note: Press “Stop” button if it is done to your liking before cycle ends.)
3. Spray a 9” pie plate with nonstick cooking spray; add crumbs and butter; mix well then press into bottom and up side; chill.

### Pie Filling

4. Prepare pie filling with milk as package directs; using medium blender setting; stir in extract; chill
5. In blender jar, place cream and chocolate syrup; blend until soft peaks form.
6. Pour chilled pie filling into crust; spread chocolate whipped cream over filling.
7. Garnish with chocolate curls.
8. Chill several hours.

## 1 Year Limited Warranty

Sunbeam Products, Inc., doing business as Jarden Consumer Solutions, or if in Canada, Sunbeam Corporation (Canada) Limited, doing business as Jarden Consumer Solutions (collectively “Sunbeam”) warrants that for a period of one year from the date of purchase, this product will be free from defects in material and workmanship. Sunbeam, at its option, will repair or replace this product or any component of the product found to be defective during the warranty period. Replacement will be made with a new or remanufactured product or component. If the product is no longer available, replacement may be made with a similar product of equal or greater value. This is your exclusive warranty.

This warranty is valid for the original retail purchaser from the date of initial retail purchase and is not transferable. Keep the original sales receipt. Proof of purchase is required to obtain warranty performance. Sunbeam dealers, service centers, or retail stores selling Sunbeam products do not have the right to alter, modify or any way change the terms and conditions of this warranty.

This warranty does not cover normal wear of parts or damage resulting from any of the following: negligent use or misuse of the product, use on improper voltage or current, use contrary to the operating instructions, disassembly, repair or alteration by anyone other than Sunbeam or an authorized Sunbeam service center. Further, the warranty does not cover: Acts of God, such as fire, flood, hurricanes and tornadoes.

### What are the limits on Sunbeam’s Liability?

Sunbeam shall not be liable for any incidental or consequential damages caused by the breach of any express, implied or statutory warranty or condition.

Except to the extent prohibited by applicable law, any implied warranty or condition of merchantability or fitness for a particular purpose is limited in duration to the duration of the above warranty.

Sunbeam disclaims all other warranties, conditions or representations, express, implied, statutory or otherwise.

Sunbeam shall not be liable for any damages of any kind resulting from the purchase, use or misuse of, or inability to use the product including incidental, special, consequential or similar damages or loss of profits, or for any breach of contract, fundamental or otherwise, or for any claim brought against purchaser by any other party.

Some provinces, states or jurisdictions do not allow the exclusion or limitation of incidental or consequential damages or limitations on how long an implied warranty lasts, so the above limitations or exclusion may not apply to you.

This warranty gives you specific legal rights, and you may also have other rights that vary from province to province, state to state or jurisdiction to jurisdiction.

### How To Obtain Warranty Service

#### In the U.S.A.

If you have any question regarding this warranty or would like to obtain warranty service, please call 1 800-334-0759 and a convenient service center address will be provided to you.

#### In Canada

If you have any question regarding this warranty or would like to obtain warranty service, please call 1 800-667-8623 and a convenient service center address will be provided to you.

In the U.S.A., this warranty is offered by Sunbeam Products, Inc located in Boca Raton, Florida 33431. In Canada, this warranty is offered by Sunbeam Corporation (Canada) Limited, located at 5975 Falbourne Street, Mississauga, Ontario L5R 3V8.

**PLEASE DO NOT RETURN THIS PRODUCT TO ANY OF THESE ADDRESSES OR TO THE PLACE OF PURCHASE.**

MADE IN U.S.A.

Download from [Www.Somanuals.com](http://Www.Somanuals.com) All Manuals Search And Download.

# MANUAL DE INSTRUCCIONES DE LA LICUADORA CON MOTOR REVERSIBLE

## Medidas de seguridad importantes:

Siempre tenga en cuenta las precauciones de seguridad básicas al usar la licuadora, incluidas las siguientes:

- Lea todas las instrucciones antes de usarla.
- No sumerja el cable, el enchufe ni la base del motor en agua u otros líquidos, a fin de protegerse de riesgos de descargas eléctricas.
- Siempre use el producto sobre una superficie plana, dura, limpia y seca. Asegúrese de que no haya materiales como manteles o plástico entre la unidad y la superficie.
- Evite el contacto con las piezas en movimiento.
- Mantenga las manos y los utensilios lejos de la jarra al licuar para reducir el riesgo de:
  - Lesiones personales graves
  - Daños en la licuadora
- Si necesita retirar los restos mediante raspado, apague la licuadora y use únicamente una espátula de goma.
- No use el electrodoméstico en los siguientes casos:
  - Si el cable o el enchufe están dañados.
  - Si la unidad no funciona correctamente.
  - Si el producto se ha caído o dañado de alguna forma.
- Devuelva el producto al Centro de Servicio para Electrodomésticos Oster® autorizado más cercano para realizar una comprobación de seguridad, ajuste o reparación.
- La hoja multifuncional es filosa. Manipúlela con cuidado.
- Para reducir el riesgo de lesiones:
  - No deje la hoja multifuncional sobresaliendo ni expuesta.
  - Siempre coloque la hoja en la jarra antes de unirla a la base.
- Siempre coloque la tapa sobre la jarra antes de poner la licuadora en funcionamiento.
- Al licuar líquidos calientes, tenga cuidado con el vapor. Retire la apertura para alimentos en la tapa de la jarra para permitir el escape de vapor.
- No use el electrodoméstico al aire libre.
- No permita que el cable toque superficies calientes ni cuelgue sobre el borde de una mesa o mostrador.
- Desenchufe la licuadora cuando no esté en uso, antes de retirar o colocar piezas y antes de realizar la limpieza.
- Nunca deje el electrodoméstico sin atención mientras esté en funcionamiento.
- Si usa accesorios, jarras o piezas diferentes de las recomendadas por Jarden, posiblemente se produzcan lesiones personales, incendio o descargas eléctricas.
- Supervise a los niños atentamente cuando usen o estén cerca de electrodomésticos.
- No licue líquidos hirviendo en la licuadora.
- El uso de accesorios, como los enlatados o jarras comunes, y las piezas de procesamiento no recomendadas por Oster® pueden provocar riesgos o lesiones personales.

## CONSERVE ESTAS INSTRUCCIONES

## **Este producto es para uso doméstico únicamente.**

- La calificación máxima comercializada del producto está basada en el accesorio que genera la carga más alta. Los otros accesorios pueden generar menos potencia.

## **Instrucciones sobre el cable de alimentación:**

Siga las instrucciones a continuación para garantizar el uso seguro del cable de alimentación.

- Este electrodoméstico posee un enchufe de dos espigas. Este es un dispositivo de seguridad diseñado para reducir el riesgo de una descarga eléctrica. Si no puede introducir el enchufe en el tomacorriente, comuníquese con un electricista calificado para que cambie el tomacorriente obsoleto. No intente anular la función de seguridad del enchufe de dos espigas, efectuando modificaciones al enchufe.
- Intente colocar la licuadora cerca de la fuente de alimentación para reducir los riesgos asociados a los cables de alimentación (atrapado porque se enreda o se tropieza con un cable de alimentación largo).
- No tire, tuerza ni abuse del cable de alimentación de ninguna forma.
- No coloque el cable de alimentación alrededor del cuerpo principal de la licuadora durante o después de usarla.
- No use un cable alargador con este producto.



**Este símbolo se ha utilizado en áreas específicas de la parte titulada Guía del usuario de este libro. Tiene como fin ayudarlo a identificar fácilmente las instrucciones que requieren atención especial.**

# Índice:

Bienvenido .....	23
Conozca su producto .....	24
Uso del producto.....	25
Armado (modelos con jarra de vidrio).....	25
Uso de la configuración Pre-Programmed Settings (Pre-Programada) .....	25
Botón Frozen Drinks & Shakes (Bebidas y batidos congelados).....	25
Botón Food Chop (Picar alimentos) .....	25
Uso de la configuración Manual Controls (Control Manual) .....	26
Uso del botón Max/Ice Crush (Máx./Triturar hielo).....	26
Uso del botón Medium/Blend (Media/Licuar) .....	26
Uso del botón Low/Stir (Baja/Revolver) .....	26
Uso del botón Max Pulse (Pulso máx.) .....	27
Uso del botón Low Pulse (Pulso mín.).....	27
Uso del botón Stop (Detener) .....	27
Uso del botón On/Off (Encendido/Apagado).....	27
Cuidado del producto .....	27
Después del uso.....	27
Limpieza (modelos con jarra de vidrio) .....	27
Almacenamiento .....	27
Servicio .....	27
Consejos para licuar.....	28
Líquidos.....	28
Uso de la apertura para alimentos en la tapa de la jarra.....	28
Alimentos calientes .....	28
Cantidades de ingredientes.....	28
Preguntas frecuentes.....	28
Recetas.....	29
Bebidas congeladas .....	29
Batidos de leche y Batidos de frutas .....	30
Salsa.....	32
Sopas y comidas.....	34
Garantía limitada de un año.....	38
Cómo obtener servicio en garantía.....	38

# Bienvenido


Felicitaciones por su compra de una licuadora Oster®. Si tiene comentarios, preguntas o dudas sobre este revolucionario producto, llame al 1-800-334-0759. Su producto incluye la tecnología y las características siguientes:

- **Diseño con teclado táctil fácil** de usar que le brinda la opción de la configuración Pre-Programmed Settings settings (Programada) o Manual Controls (Controles Manuales). Pruebe una de las bebidas congeladas, batidos de frutas, salsas o sopas de la sección de recetas incluida en las instrucciones.
- **Una hoja multifuncional** que optimiza la preparación programada de alimentos y bebidas.
- **Un potente motor reversible** que mantiene los ingredientes cerca de la hoja mediante la rotación a velocidades muy bajas y la aceleración gradual al nivel programado, garantizando de esta forma resultados óptimos, desde lo más suave a lo más espeso.
- **Controles manuales** que le brindan la flexibilidad de usar la licuadora para recetas personales.
- **Una apertura para alimentos en la tapa de la jarra** que le permite agregar ingredientes sin quitar la tapa de la jarra.

# Conozca su producto

## Modelos con jarra de vidrio

1. **Abertura para alimentos en la tapa de la jarra** – Le permite agregar ingredientes durante el uso. Además, puede abrirla para permitir el escape de vapor al licuar alimentos calientes.
2. **Tapa de la jarra** – Sella la jarra de la licuadora.
3. **Jarra** – Fabricada con vidrio resistente. Posee una capacidad máxima de 6 tazas.
4. **Anillo sellador** – Sella la jarra a la hoja multifuncional para lograr un funcionamiento sin derrames.
5. **Hoja multifuncional** – Crea una acción de avance y retroceso al utilizar la configuración Pre-Programmed Settings.
6. **Disco de fondo roscado**
7. **Base sofisticada** – Sostiene la jarra firmemente. Incluye un potente motor reversible de velocidad variable. Usa una lógica programada que elimina las suposiciones en la creación de alimentos y bebidas.
8. **Panel de controles**
  - a. **Configuración Pre-Programmed Settings (Programada)** – Use para seleccionar el botón “Frozen Drinks & Shakes” (Bebidas y batidos congelados) o el botón “Food Chop” (Picar alimentos). La licuadora se detiene automáticamente al finalizar el ciclo.
  - b. **Controles manuales** – Botón “Max/Ice Crush” (Máx/Triturar hielo). Use este botón para obtener la velocidad máxima o para triturar hielo.
  - c. **Controles manuales** – Botón “Medium/Blend” (Media/Licuar) Use para conseguir velocidad media.
  - d. **Controles manuales** – Botón “Low/Stir” (Baja/Revolver) Use para obtener velocidad mínima.
  - e. **Botón Max Pulse (Pulso máx.)** – Mantenga presionado para accionar el ciclo manual, libere el botón para detenerlo.
  - f. **Botón Low Pulse (Pulso mín.)** – Mantenga presionado para accionar el ciclo manual, libere el botón para detenerlo.
  - g. **Botón de encendido (botón On/Off [Encendido/Apagado])** – Enciende y apaga el producto.
  - h. **Botón Stop (Detener)** – Detiene el producto.







## Uso del producto

Antes de usar el producto, asegure la tapa y abra la abertura para alimentos. Limpie la jarra y la tapa con agua tibia y jabón. Limpie la jarra y las lavavajillas. Enjuague y seque.

### Armado (modelos con jarra de vidrio)

1. Coloque el anillo sellador sobre la hoja multifuncional.  
⚠ La hoja es filosa. Manipule con cuidado.
2. Voltee la jarra hacia abajo de manera que la abertura de la jarra y la apertura quede arriba.
3. Gire la hoja multifuncional con el anillo sellador hacia abajo y colóquela en la parte inferior de la jarra.
4. Coloque el extremo más pequeño de la rosca de la jarra sobre la jarra y encaje el anillo sellador. Gire en el sentido de las agujas del reloj hasta que se asegure. Asegúrese de que la parte inferior rosca esté fija a la jarra antes de usar.
5. Deslice la jarra sobre la base.
6. Enchufe el cable de alimentación en un tomacorriente doméstico de CA. Ahora estará listo para usar.



pp?



### Uso de Max Pulse (Pulso máx.)

1. Mantenga presionado este botón.
2. Suéltelo para detener la unidad.
3. Presione el botón de encendido ON/OFF para apagar el producto.  
Use la configuración de pulso más baja para los alimentos y la configuración más alta para las bebidas.


### Uso de Low Pulse (Pulso mín.)

1. Mantenga presionado este botón.
2. Suéltelo para detener la unidad.
3. Presione el botón de encendido ON/OFF para apagar el producto.  
Use la configuración de pulso más baja para los alimentos y la configuración más alta para las bebidas.

## Cuidado del producto


### Después del uso

1. Levante la jarra y sepárela de la base, quite la tapa y vacíela.
2. Si es necesario, use una espátula de goma para retirar los restos de alimentos de los lados de la jarra.



### Limpieza (modelos con jarra de vidrio)

Quite la hoja multifuncional de la parte inferior de la jarra girando la cubierta de la parte inferior de la jarra en el sentido contrario a las agujas del reloj. La tapa de la jarra, la abertura para alimentos y la hoja pueden colocarse en el lavavajillas sin riesgos. Use el estante superior del lavavajillas para lavar estas piezas. Coloque el anillo sellador en la canasta inferior del lavavajillas.



También puede lavar las piezas con agua tibia y detergente. Enjuague y seque bien. Limpie la base con un paño suave y húmedo. Nunca sumerja la base de perfil bajo en líquidos.

Compruebe que las piezas no están dañadas al volver a unir las.

### Almacenamiento

Vuelva a armar la licuadora para guardarla.



**ADVERTENCIA:** Nunca coloque la jarra, o ninguna de las demás piezas, en un horno microondas. Nunca guarde alimentos o bebidas en la jarra.

### Servicio

Si la licuadora debe repararse, envíe el electrodoméstico únicamente a un Centro de Servicio para Electrodomésticos Oster® autorizado. Use únicamente piezas de repuesto de Jarden. Consulte Cómo obtener servicio en garantía en la página 38.

## Consejos para licuar

### Líquidos

Coloque los líquidos en la jarra primero, salvo que la receta indique lo contrario.

### Uso de la apertura para alimentos en la tapa de la jarra

No retire la tapa si la licuadora está en funcionamiento porque pueden producirse salpicaduras. En cambio, abra la apertura para alimentos de la tapa de la jarra a fin de agregar ingredientes más pequeños.

### Uso de la licuadora con alimentos o líquidos calientes



**ADVERTENCIA:** Al usar la licuadora con **ALIMENTOS CALIENTES**, retire la apertura para alimentos de la tapa de la jarra para dejar escapar el vapor. Incline la tapa para alejarla de usted y cubrir parcialmente la apertura. Mantenga las manos y otras partes del cuerpo expuestas lejos de la apertura de la tapa para evitar posibles quemaduras.



Al usar la licuadora con **LÍQUIDOS CALIENTES**, retire la apertura para alimentos de la tapa de la jarra y comience con una velocidad baja e incremente gradualmente a una velocidad más rápida. No agregue líquidos por encima del nivel de 4 tazas (1 litro). Siempre mantenga las manos lejos del vapor.

### Cantidades de ingredientes

Use únicamente la cantidad de alimentos sugerida en las recetas. Si desea cantidades más grandes, prepare en lotes. Usar cantidades más grandes puede sobrecargar y forzar el motor. Además, es posible que obtenga resultados diferentes a los que se describen.

## Preguntas frecuentes

### ¿Por qué no se enciende la licuadora/procesador de alimentos?

- Compruebe que la base esté enchufada a un tomacorriente activo.
- Compruebe que la luz roja parpadeante esté activa después de pulsar el botón on/off.

### ¿Cómo puedo evitar el derrame de líquidos?

Compruebe que el anillo sellador esté colocado correctamente entre la hoja multifuncional y la jarra.

# Recetas

**Aviso:** Las recetas proporcionadas han sido optimizadas para usar con los botones de la configuración Pre-Programmed Settings. Si desea desarrollar nuevas recetas, recuerde que puede detener el ciclo automático en cualquier momento presionando el botón Stop o repetir el ciclo según sea necesario para obtener los mejores resultados.

## Bebidas congeladas:

### Frozen Margarita

Rinde 4 porciones

4 onzas (120 cm<sup>3</sup>) de tequila dorado

2 onzas (60 cm<sup>3</sup>) de licor de naranja y coñac

2 cucharadas de jugo de lima recién exprimido

¼ taza de azúcar

3 tazas de hielo

Decoración: jugo de lima adicional y sal para cubrir los bordes de los vasos

1. Coloque los ingredientes en la jarra en el orden mencionado.
2. Coloque la tapa a la jarra. Presione el botón “On/Off” y, a continuación, el botón “Frozen Drinks & Shakes”.
3. Moje el borde de las copas de tallo alto introduciéndolas en jugo de lima y luego en sal. Vierta la bebida en las copas.

**Nota creativa del cocinero:** Si lo desea, puede usar azúcar granulada en lugar de sal.

**Nota:** Para obtener un líquido más uniforme, use el botón de pulso alto 3 ó 4 veces después de completar el ciclo de bebida congelada.

### Daiquiri de fresa

Rinde 4 porciones

1 lata (6 onzas [175 cm<sup>3</sup>]) de jugo de lima concentrado, congelado

5 onzas (150 cm<sup>3</sup>) de ron

1 taza de fresas enteras sin tallo

1 cucharada de azúcar

3 ½ tazas de hielo

Decoración: Fresas pequeñas enteras y rebanadas de lima

1. Coloque los ingredientes en la jarra en el orden mencionado.
2. Coloque la tapa a la jarra. Presione el botón “On/Off” y, a continuación, el botón “Frozen Drinks & Shakes”.
3. Vierta en copas de tallo alto.
4. Decore, si lo desea, con rebanadas de fresa y de lima.

**Nota creativa del cocinero:** Para aumentar la variedad, sustituya por frambuesas, moras negras o mango en cubos, frescos en todos los casos, en cantidades iguales que las fresas.

**Nota:** Para obtener un líquido más uniforme, use el botón de pulso alto 3 ó 4 veces después de completar el ciclo de bebida congelada.

## Piña colada

Rinde 4 porciones

1 taza de jugo de piña

6 onzas (175 cm<sup>3</sup>) de ron dorado

2/3 taza de crema de coco

1 cucharadita de jugo de limón

4 tazas de hielo

Decoración: rebanadas de piña, cerezas al marrasquino

1. Coloque los ingredientes en la jarra en el orden mencionado.
2. Coloque la tapa a la jarra. Presione el botón “On/Off” y, a continuación, el botón “Frozen Drinks & Shakes”.
3. Vierta en vasos altos.
4. Decore, si lo desea, con rebanadas de piña y cerezas.

**Nota:** Para obtener un líquido más uniforme, use el botón de pulso alto 3 ó 4 veces después de completar el ciclo de bebida congelada.

## Batidas de leche y Batidas de frutas

### Batido de fresa

Rinde 2 porciones

1 taza de fresas maduras y frescas sin tallo (8 a 10 frutas medianas)

1 taza de leche

2 tazas de helado de fresa

1. Coloque los ingredientes en la jarra en el orden mencionado. Coloque las frutas primero.
2. Coloque la tapa a la jarra. Presione el botón “On/Off” y, a continuación, el botón “Frozen Drinks & Shakes”.
3. Vierta en vasos altos.

### Batido de chocolate y mantequilla de maní

Rinde 2 porciones

1 taza de leche

2 tazas de helado de chocolate

¼ taza de mantequilla de maní

¼ cucharadita de esencia de vainilla

1. Coloque los ingredientes en la jarra en el orden mencionado.
2. Coloque la tapa a la jarra. Presione el botón “On/Off” y, a continuación, el botón “Frozen Drinks & Shakes”.

## **Brandy Alexander**

Rinde 4 porciones

3 cucharadas de leche

4 onzas (120 cm<sup>3</sup>) de crema de cacao

2 onzas (60 cm<sup>3</sup>) de brandy

2 tazas de helado de vainilla

1. Coloque los ingredientes en la jarra en el orden mencionado.
2. Coloque la tapa a la jarra. Presione el botón “On/Off” y, a continuación, el botón “Frozen Drinks & Shakes”.
3. Vierta en copas de tallo alto.

## **Explosión de miel y vainilla**

Rinde 1 porción

1 taza de leche descremada

1 taza (8 onzas [250 cm<sup>3</sup>]) de yogur de vainilla descremado

3 trozos de banana congelada, aproximadamente, una banana mediana

¼ taza de polvo de proteínas

2 cucharadas de miel

1. Coloque los ingredientes en la jarra en el orden mencionado.
2. Coloque la tapa a la jarra. Presione el botón “On/Off” y, a continuación, el botón “Frozen Drinks & Shakes”.
3. Vierta en un vaso alto y sirva.

## **Batido de frutas con moca para la mañana**

Rinde 1 porción

½ taza de leche descremada

1 taza (8 onzas [250 cm<sup>3</sup>]) de yogur de café descremado

2 cucharadas de jarabe de chocolate

6 cubos de hielo

1. Coloque los ingredientes en la jarra en el orden mencionado.
2. Coloque la tapa a la jarra. Presione el botón “On/Off” y, a continuación, el botón “Frozen Drinks & Shakes”.
3. Vierta en un vaso alto y sirva.

## Batido de bayas

Rinde 1 porción

1 taza de jugo de naranja

½ taza de yogur de vainilla descremado

1 taza de mezcla de bayas congelada

2 trozos de banana congelada, aproximadamente, una banana pequeña

2 cucharadas de miel

1. Coloque los ingredientes en la jarra en el orden mencionado.
2. Coloque la tapa a la jarra. Presione el botón “On/Off” y, a continuación, el botón “Frozen Drinks & Shakes”.
3. Vierta en un vaso alto y sirva.

## Batido de frutas de ponche tropical

Rinde 2 porciones

1 lata (6 onzas [175 cm<sup>3</sup>]) de jugo de piña

1 lata (8 onzas [250 cm<sup>3</sup>]) de piña triturada

1 taza de sorbete de mango

½ cucharadita de extracto de coco

1 taza de hielo

1. Coloque los ingredientes en la jarra en el orden mencionado.
2. Coloque la tapa a la jarra. Presione el botón “On/Off” y, a continuación, el botón “Frozen Drinks & Shakes”.
3. Vierta en vasos altos y sirva.

## Salsas

### Salsa fresca jardinera

Rinde 2 tazas

½ cebolla pequeña, cortada en 4 partes

¼ pimienta verde, cortado en 4 partes

½ pepino, cortado en cuartos

1 diente de ajo grande

12 onzas (4 ó 5 unidades) de tomates perita, cortados en octavos

3 cucharadas de vinagre de vino tinto

1 cucharadita de salsa Worcestershire

1/8 cucharadita de salsa de pimienta picante

Salsa y pimienta a gusto

Trozos de tortilla para servir

1. Coloque los ingredientes en la jarra, excepto los trozos de tortilla, en el orden mencionado.
2. Coloque la tapa a la jarra. Presione el botón “On/Off” y, a continuación, el botón “Food Chop”.
3. Vierta en el recipiente; sirva con los trozos de tortilla.



## Salsa roja ardiente

Rinde 3 tazas

2 dientes de ajo grandes

1 lata (15 onzas [450 cm<sup>3</sup>]) de tomates enteros, deshidratados

1 cebolla mediana, cortada en cuartos (4 partes)

½ taza de hojas de cilantro

1 a 4 pimientos jalapeños, en cuartos

½ a 1 cucharadita de azúcar

Sal a gusto

1 cucharada de jugo de lima

1 lata (15 onzas [450 cm<sup>3</sup>]) de tomates enteros, deshidratados

Trozos de tortilla para servir

1. Coloque los ingredientes en la jarra, excepto los trozos de tortilla, en el orden mencionado. (Nota: Coloque una lata de tomates después de los dientes de ajo, y la otra lata después de agregar el resto de los ingredientes. Además, debe colocar la cebolla en el medio de la jarra para evitar bloqueos).
2. Coloque la tapa a la jarra. Presione el botón “On/Off” y, a continuación, el botón “Food Chop”.
3. Vierta en el recipiente; sirva con los trozos de tortilla.

**Nota creativa del cocinero:** Al manipular pimientos picantes, como los jalapeños, use guantes de goma y no se acerque las manos a los ojos.

## Salsa verde

Rinde 1 ½ tazas

½ cebolla pequeña, cortada en 4 partes

½ pimiento verde pequeño, cortado en 4 partes

2 dientes de ajo

¼ taza de hojas de cilantro

½ cucharadita de comino molido

¼ cucharadita de salsa de pimiento verde picante

1/8 cucharadita de sal

12 onzas (8 ó 9 unidades) de tomatillos, asados, sin semillas

Trozos de tortilla para servir

1. Coloque los ingredientes en la jarra, excepto los trozos de tortilla, en el orden mencionado.
2. Coloque la tapa a la jarra. Presione el botón “On/Off” y, a continuación, el botón “Food Chop”.
3. Vierta en el recipiente; sirva con los trozos de tortilla.

NOTAS: Debe procesarse bien en el ciclo de picado.

12 onzas (340 g) de tomatillo equivalen, aproximadamente, a 8 ó 9 unidades.

## Cómo asar los tomatillos

Quite las semillas y enjuague para quitar la pegajosidad que cubre la piel. Colóquelos sobre una bandeja para hornear con borde y áselos debajo de una parrilla caliente aproximadamente a 4 pulgadas de la fuente de calor. Ase los tomatillos durante 3 a 4 minutos, o hasta que estén ampollados y tostados. Voltéelos y áselos de la misma forma del otro lado. La bandeja para hornear con borde contendrá los jugos que deben agregarse a la receta.

## Sopas y Comidas

### Sopa crema de tomate

Rinde 4 porciones

4 a 5 tomates maduros medianos, cortados en 4 partes

1 cebolla pequeña cortada en cuartos

3 a 4 hojas de albahaca frescas

2 cucharadas de mantequilla

½ cucharadita de sal

1 taza de crema “half-and-half” o leche

1. Coloque los tomates, la cebolla y la albahaca en la jarra.
2. Coloque la tapa a la jarra. Presione el botón “On/Off” y, a continuación, el botón “Food Chop”.
3. Vierta la mezcla procesada en una cacerola de 3 cuartos (3,3 litros). Agregue la mantequilla, la sal y la crema “half-and-half”.
4. Revuelva mientras calienta a 145°F (63°C); no permita que la sopa hierva.

Considero que toda esta receta debe prepararse como puré en la licuadora y luego cocinarse.

### Sopa cubana de frijoles negros

Rinde 4 porciones

2 latas (15 a 19 onzas [440 a 560 cm<sup>3</sup>] cada una) de frijoles negros

½ cebolla roja pequeña en mitades

4 ó 5 ramitas de cilantro, sin tallo

1 cebolla pequeña en mitades

2 dientes de ajo

2 cucharadas de aceite de oliva

1 taza de agua

½ taza de sofrito\*

1 cucharada de hojas de cilantro

1 taza de crema agria

1. Enjuague y seque los frijoles; resérvelos.
2. Coloque la cebolla roja y las hojas de cilantro en la jarra. Tape la jarra y presione el botón “On/Off” y, a continuación, el botón “Food Chop”.
3. Retire la mezcla de la jarra y resérvela (no necesita enjuagar la jarra para cada paso).

4. Coloque la cebolla y el ajo en la jarra. Tape la jarra y presione el botón “On/Off” y, a continuación, el botón “Food Chop”.
5. Cocine la cebolla y el ajo con aceite de oliva hasta que estén tiernos en una cacerola de 4 cuartos (4,5 l).
6. Coloque las 3 tazas de frijoles con líquido y las hojas de cilantro en la jarra. Tape la jarra y presione el botón “On/Off” y, luego, el botón “Medium/Blend”. Oprima el botón “Stop” cuando se logre la consistencia deseada. (Cambie a la secuencia que se requiera en el producto final).
7. Revuelva la mezcla de frijoles en la sopa restante en la cacerola; vuelva a calentar si es necesario.
8. Si lo desea, sirva con crema agria y mezcla de cebollines.

\*El sofrito es un condimento popular de la cocina latinoamericana. Se puede encontrar en la sección de alimentos de América Latina o Internacional de la mayoría de los supermercados.

**Nota creativa del cocinero:** Si se prefiere una sopa completamente mezclada, repita el paso N° 3 con los frijoles y el líquido restantes.

### **Compota de manzana con durazno**

Rinde 1 ¼ tazas

1 manzana grande, sin piel, con corazón y cortada en cuartos

1 durazno grande, sin carozo, pelado y en cuartos (si no es la temporada, use 2 mitades de duraznos en lata).

2 cucharadas de agua

1. Cocine las frutas en agua entre 5 y 8 minutos, o hasta que estén muy tiernas, en una cacerola pequeña.
2. Coloque las frutas y el líquido en la jarra.
3. Coloque la tapa a la jarra. Presione el botón “On/Off” y, luego, presione el botón “Low Pulse” 3 ó 4 veces. A continuación, oprima el botón “Max Pulse” hasta que esté uniforme.
4. Retire de la jarra y coloque en recipientes cubiertos.
5. Enfríe o congele de inmediato.

## Guisantes - Comida de bebé

Rinde 1 ½ tazas

1 paquete (10 onzas [300 cm<sup>3</sup>]) de guisantes bebé congelados

¾ taza de agua

1. Cocine los guisantes en agua entre 10 y 15 minutos, o hasta que estén muy tiernos, en una cacerola pequeña.
2. Coloque los guisantes y el líquido en la jarra.
3. Coloque la tapa a la jarra. Presione el botón “On/Off” y, a continuación, el botón “Frozen Drinks & Shakes”.
4. Retire de la jarra. Coloque en recipientes cubiertos.
5. Enfríe o congele de inmediato.

## Panqueques de trigo y miel

Rinde 12 panqueques

1 1/3 taza de suero de leche descremado

2 huevos

2 cucharadas de miel

1 ½ taza de mezcla para hornear de suero de leche descremado

½ taza de harina de trigo integral

¼ taza de germen de trigo crujiente con miel

1 cucharadita de polvo de hornear

Mantequilla y jarabe para servir

1. Coloque los ingredientes en la jarra en el orden mencionado.
2. Coloque la tapa a la jarra. Presione el botón “On/Off” y, a continuación, el botón “Max Pulse” entre 8 y 10 veces. Cuando haya finalizado, raspe la jarra y revuelva la mezcla suavemente.
3. Para cada panqueque, vierta aproximadamente ¼ taza de mezcla sobre la plancha precalentada. Cocine hasta que en las partes superiores comiencen a formarse burbujas, y continúe cociendo hasta que estén doradas.
4. Sirva caliente con mantequilla y jarabe.

## Tarta de crema de chocolate

Rinde 8 porciones

1/3 taza de almendras acarameladas

20 galletas de chocolate crujientes

¼ taza de mantequilla derretida

2 paquetes (3,4 onzas [100 cm3] cada uno) de chocolate instantáneo y relleno para tarta

3 ½ tazas de leche

½ cucharadita de extracto de almendras

1 ½ taza de nata líquida

1/3 taza de jarabe de chocolate

### Decoración: rizos de chocolate blanco

#### Corteza de Torta

1. Coloque las almendras en la jarra. A continuación, troce y agregue las galletas.
2. Coloque la tapa a la jarra. Presione el botón “On/Off” y, a continuación, el botón “Food Chop”. (Nota: Presione el botón “Stop” si ha llegado al punto que desea hasta de finalizar el ciclo).
3. Rocíe una tartera de 9” (23 cm) con rocío para cocción antiadherente; añada las migajas y la mantequilla; mezcle bien y, a continuación, presione sobre la parte inferior y los lados. Enfríe.

#### Relleno de la tarta

4. Prepare el relleno de la tarta con leche según las indicaciones del paquete; agregue y mezcle el extracto. Enfríe.
5. En la jarra de licuadora, coloque la crema y el jarabe de chocolate. Mezcla usando el botón “Medium Blend” hasta que se formen picos suaves.
6. Vierta el relleno de la tarta frío sobre la costra; rocíe la crema batida con chocolate sobre el relleno.
7. Decore con rizos de chocolate.
8. Deje enfriar varias horas.

## **Garantía Limitada de 1 Año**

Sunbeam Products, Inc., haciendo negocios como Jarden Consumer Solutions, o si en Canadá, Sunbeam Corporation (Canadá) Limited, haciendo negocios como Jarden Consumer Solutions (colectivamente “Sunbeam”) garantiza que este producto estará libre de defectos en material o mano de obra por un período de un año a partir de la fecha de la compra. Sunbeam, a su elección, reparará o reemplazará este producto o cualquier componente del producto que se encuentre defectuoso durante el período de garantía. El reemplazo será efectuado por un producto o componente nuevo o remanufacturado. Si el producto ya no está disponible, el reemplazo podrá ser efectuado con un producto similar de igual o mayor valor. Esta es su garantía exclusiva.

Esta garantía es válida para el comprador original al detalle desde la fecha de compra original al detalle y no es transferible. Guarde el recibo de venta original. Se requiere prueba de compra para obtener la garantía. Los concesionarios Sunbeam, centros de servicio, o almacenes de ventas al detalle de productos Sunbeam no tienen el derecho de alterar, modificar o cambiar, de manera alguna, los términos y condiciones de esta garantía.

Esta garantía no cubre el desgaste normal

pr2EMC 0.273 0 Td[(l)5(o)5(s)]





For product questions contact:  
Sunbeam Consumer Service

USA : 1.800.334.0759

Canada : 1.800.667.8623

[www.oster.com](http://www.oster.com)

©2006 Sunbeam Products, Inc., doing business as  
Jarden Consumer Solutions. All rights reserved.

In the U.S., distributed by Sunbeam, Products, Inc.,

doing business as Jarden Consumer Solutions, Boca Raton, FL 33431

In Canada, imported and distributed by Sunbeam Corporation (Canada) Limited,  
doing business as Jarden Consumer Solutions, Mississauga, Ontario L5R 3V8.

AMB-XXXXXX

Para preguntas sobre los productos llame:  
Sunbeam Consumer Service

EE.UU. : 1.800.334.0759

Canadá : 1.800.667.8623

[www.oster.com](http://www.oster.com)

©2006 Sunbeam Products, Inc., operando bajo el nombre de  
Jarden Consumer Solutions. Todos los derechos reservados.

En los EE. UU., distribuido por Sunbeam Products, Inc.,  
operando bajo el nombre de Jarden Consumer Solutions, Boca Raton, FL 33431

En Canadá, importado y distribuido por  
Sunbeam Corporation (Canada) Limited, operando bajo el nombre de  
Jarden Consumer Solutions, Mississauga (Ontario) L5R 3V8.

Printed in China

Impreso en China



## Free Manuals Download Website

<http://myh66.com>

<http://usermanuals.us>

<http://www.somanuals.com>

<http://www.4manuals.cc>

<http://www.manual-lib.com>

<http://www.404manual.com>

<http://www.luxmanual.com>

<http://aubethermostatmanual.com>

Golf course search by state

<http://golfingnear.com>

Email search by domain

<http://emailbydomain.com>

Auto manuals search

<http://auto.somanuals.com>

TV manuals search

<http://tv.somanuals.com>