



## Sony Super Advanced Intelligent Tape™ Drives

### Letter of Volatility

The chart below shows the corresponding memory types for the Sony S-AIT tape drives listed. Please note, there are no remnants of customer data retained in the drive when both (i) S-AIT tape media is removed and (ii) the power is turned off.

MODEL	MEMORY SIZE	MEMORY TYPE	VOLATILITY	USER DATA*
<b>SDZ-100</b>	2 MB	FLASH	Non-Volatile	No
	16 KB	EEPROM	Non-Volatile	No
	512 KB	SRAM	Volatile	No
	32 MB x2	SDRAM	Volatile	Yes
	16 MB x2	SDRAM	Volatile	Yes
<b>SDZ-130</b>	2 MB	FLASH	Non-Volatile	No
	16 KB	EEPROM	Non-Volatile	No
	512 KB	SRAM	Volatile	No
	32 MB x2	SDRAM	Volatile	Yes
	16 MB	SDRAM	Volatile	Yes
	1 MB	SRAM	Volatile	Yes
	8 KB	EEPROM	Non-Volatile	No

**Note:**

Flash is used for firmware code upload and contains no user data. EEPROM is used to store operational parameters and contains no user data.

\* "User Data" utilized by "Memory Type"

## Free Manuals Download Website

<http://myh66.com>

<http://usermanuals.us>

<http://www.somanuals.com>

<http://www.4manuals.cc>

<http://www.manual-lib.com>

<http://www.404manual.com>

<http://www.luxmanual.com>

<http://aubethermostatmanual.com>

Golf course search by state

<http://golfingnear.com>

Email search by domain

<http://emailbydomain.com>

Auto manuals search

<http://auto.somanuals.com>

TV manuals search

<http://tv.somanuals.com>